

**SIEMENS**

# SINAMICS

**SINAMICS S120**

Safety Integrated

Function Manual

Edition

07/2016



# SIEMENS

## SINAMICS

### S120 Safety Integrated

#### Function Manual




Preface	
Fundamental safety instructions	1
General information about SINAMICS Safety Integrated	2
Overview of Safety Integrated functions	3
Description of Safety Integrated functions	4
Control of the safety functions	5
Commissioning	6
Acceptance test	7
System features	8
Maintenance	9
Standards and regulations	10
Appendix	A

Valid from: Firmware Version 4.4 SP1

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 <b>DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.
 <b>WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.
 <b>CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.
<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

 <b>WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Preface

## SINAMICS documentation

The SINAMICS documentation is organized in the following categories:

- General documentation/catalogs
- User documentation
- Manufacturer/service documentation

## Additional information

You can find information on the following topics at the following address (<https://support.industry.siemens.com/cs/de/en/view/108993276>):

- Ordering documentation/overview of documentation
- Additional links to download documents
- Using documentation online (find and search in manuals/information)

Please send any questions about the technical documentation (e.g. suggestions for improvement, corrections) to the following e-mail address (<mailto:docu.motioncontrol@siemens.com>).

## Siemens MySupport/Documentation

At the following address (<https://support.industry.siemens.com/My/ww/en/documentation>), you can find information on how to create your own individual documentation based on Siemens' content, and adapt it for your own machine documentation.

## Training

At the following address (<http://www.siemens.com/sitrain>), you can find information about SITRAIN (Siemens training on products, systems and solutions for automation and drives).

## FAQs

You can find Frequently Asked Questions in the Service&Support pages under Product Support (<https://support.industry.siemens.com/cs/de/en/ps/faq>).

## SINAMICS

You can find information about SINAMICS at the following address (<http://www.siemens.com/sinamics>).

## Usage phases and their documents/tools (as an example)

Table 1 Usage phases and the available documents/tools

Usage phase	Document/tool
Orientation	SINAMICS S Sales Documentation
Planning/configuration	<ul style="list-style-type: none"> <li>• SIZER Engineering Tool</li> <li>• Configuration Manuals, Motors</li> </ul>
Deciding/ordering	SINAMICS S120 catalogs <ul style="list-style-type: none"> <li>• SIMOTION, SINAMICS S120 and Motors for Production Machines (Catalog PM 21)</li> <li>• SINAMICS and Motors for Single-axis Drives (Catalog D 31)</li> <li>• SINUMERIK &amp; SINAMICS Equipment for Machine Tools (Catalog NC 61)</li> <li>• SINUMERIK 840D sl Type 1B Equipment for Machine Tools (Catalog NC 62)</li> </ul>
Installation/assembly	<ul style="list-style-type: none"> <li>• SINAMICS S120 Manual for Control Units and Additional System Components</li> <li>• SINAMICS S120 Manual for Booksize Power Units</li> <li>• SINAMICS S120 Manual for Booksize Power Units C/D Type</li> <li>• SINAMICS S120 Manual for Chassis Power Units, Air-cooled</li> <li>• SINAMICS S120 Manual for Chassis Power Units, Liquid-cooled</li> <li>• SINAMICS S120 Manual for AC Drives</li> <li>• SINAMICS S120 Manual Combi</li> <li>• SINAMICS S120M Manual Distributed Drive Technology</li> <li>• SINAMICS HLA System Manual Hydraulic Drive</li> </ul>
Commissioning	<ul style="list-style-type: none"> <li>• STARTER Commissioning Tool</li> <li>• SINAMICS S120 Getting Started with STARTER</li> <li>• SINAMICS S120 Commissioning Manual with STARTER</li> <li>• SINAMICS S120 CANopen Commissioning Manual</li> <li>• SINAMICS S120 Function Manual Drive Functions</li> <li>• SINAMICS S120 Safety Integrated Function Manual</li> <li>• SINAMICS S120/S150 List Manual</li> <li>• SINAMICS HLA System Manual Hydraulic Drive</li> <li>• Startdrive commissioning tool<sup>1)</sup></li> <li>• SINAMICS S120 Getting Started with Startdrive<sup>1)</sup></li> <li>• SINAMICS S120 Commissioning Manual with Startdrive<sup>1)</sup></li> </ul>
Usage/operation	<ul style="list-style-type: none"> <li>• SINAMICS S120 Commissioning Manual with STARTER</li> <li>• SINAMICS S120/S150 List Manual</li> <li>• SINAMICS HLA System Manual Hydraulic Drive</li> <li>• SINAMICS S120 Commissioning Manual with Startdrive<sup>1)</sup></li> </ul>

Usage phase	Document/tool
Maintenance/servicing	<ul style="list-style-type: none"> <li>• SINAMICS S120 Commissioning Manual with STARTER</li> <li>• SINAMICS S120/S150 List Manual</li> <li>• SINAMICS S120 Commissioning Manual with Startdrive<sup>1)</sup></li> </ul>
References	<ul style="list-style-type: none"> <li>• SINAMICS S120/S150 List Manual</li> </ul>

<sup>1)</sup> available as of Startdrive V14 release

## Target group

This documentation is intended for machine manufacturers, commissioning engineers, and service personnel who use the SINAMICS drive system.

## Benefits

This manual provides all of the information, procedures and operator actions required for the particular usage phase.

## Standard scope

The scope of the functionality described in this document can differ from that of the drive system that is actually supplied.

- Other functions not described in this documentation might be able to be executed in the drive system. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of service.
- The documentation can also contain descriptions of functions that are not available in a particular product version of the drive system. The functionality of the supplied drive system should only be taken from the ordering documentation.
- Extensions or changes made by the machine manufacturer must be documented by the machine manufacturer.

For reasons of clarity, this documentation does not contain all of the detailed information on all of the product types, and cannot take into consideration every conceivable type of installation, operation and service/maintenance.

## Technical Support

Country-specific telephone numbers for technical support are provided in the Internet at the following address (<https://support.industry.siemens.com/sc/ww/en/sc/2090>) in the "Contact" area.

## Notation

The following notation and abbreviations are used in this documentation:

### Notation for faults and alarms (examples):

- F12345            Fault 12345
- A67890           Alarm 67890
- C23456           Safety message

### Notation for parameters (examples):

- p0918            Adjustable parameter 918
- r1024            Display parameter 1024
- p1070[1]        Adjustable parameter 1070, index 1
- p2098[1].3      Adjustable parameter 2098, index 1 bit 3
- p0099[0...3]    Adjustable parameter 99, indices 0 to 3
- r0945[2](3)     Display parameter 945, index 2 of drive object 3
- p0795.4         Adjustable parameter 795, bit 4



# Table of Contents

	<b>Preface.....</b>	<b>5</b>
<b>1</b>	<b>Fundamental safety instructions .....</b>	<b>15</b>
1.1	Fundamental safety instructions .....	15
1.1.1	General safety instructions .....	15
1.1.2	Industrial security .....	16
1.2	Fundamental safety instructions for Safety Integrated .....	17
1.3	Residual risk .....	21
<b>2</b>	<b>General information about SINAMICS Safety Integrated .....</b>	<b>23</b>
2.1	Drive products with integrated safety functions .....	23
2.2	Supported functions .....	24
2.3	Supported functions: HLA module .....	27
2.4	Examples of how the safety functions can be applied .....	30
2.5	Drive monitoring with or without encoder .....	32
<b>3</b>	<b>Overview of Safety Integrated functions .....</b>	<b>33</b>
3.1	Safety Integrated Basic Functions .....	33
3.1.1	Safe Torque Off (STO) .....	34
3.1.2	Safe Stop 1 (SS1) .....	35
3.1.3	Safe Brake Control (SBC) .....	36
3.1.3.1	Hardware required for SBC .....	37
3.2	Safety Integrated Extended Functions .....	39
3.2.1	Preconditions for the Safety Extended Functions .....	39
3.2.2	Control possibilities .....	40
3.2.3	Safe Torque Off (STO) .....	40
3.2.4	Safe Stop 1 (SS1) .....	40
3.2.5	Safe Operating Stop (SOS) .....	43
3.2.6	Safe Stop 2 (SS2) .....	45
3.2.6.1	How does SS2 function in detail? .....	45
3.2.7	Safely Limited Speed (SLS) .....	47
3.2.8	Safe Speed Monitor (SSM) .....	53
3.2.9	Safe Direction (SDI) .....	55
3.2.10	Safely-Limited Position (SLP) .....	57
3.2.11	Safe referencing .....	58
3.2.12	Transferring safe position values (SP) .....	59
3.2.13	Safe Brake Test .....	60
<b>4</b>	<b>Description of Safety Integrated functions .....</b>	<b>61</b>
4.1	Safety Integrated basic functions .....	62
4.1.1	Safe Torque Off (STO) .....	62
4.1.1.1	Safe Torque Off (STO) for SINAMICS HLA .....	66

4.1.2	Safe Stop 1 (SS1, time controlled).....	68
4.1.2.1	SS1 with OFF3.....	68
4.1.2.2	SS1 with external stop.....	69
4.1.2.3	Function diagrams and parameters .....	70
4.1.3	Safe Brake Control (SBC).....	71
4.1.3.1	SBC for Motor Modules in the chassis format .....	73
4.1.3.2	Function diagrams and parameters .....	75
4.1.4	Safety faults.....	76
4.1.5	Forced dormant error detection (test stop) .....	78
4.1.6	Function diagrams and parameters .....	79
4.2	Safety Integrated Extended Functions .....	80
4.2.1	License for Extended Functions .....	80
4.2.2	Differences between Extended Functions "with encoder" and "without encoder".....	80
4.2.3	Restrictions for Safety Integrated Functions "without encoder" .....	82
4.2.4	Safe Torque Off (STO) .....	86
4.2.5	Safe Stop 1 (SS1) .....	87
4.2.5.1	Safe Stop 1 with encoder .....	87
4.2.5.2	Safe Stop 1 without encoder .....	89
4.2.5.3	Safe Stop 1 with external stop .....	90
4.2.5.4	Function diagrams and parameters .....	91
4.2.6	Safe Brake Control (SBC).....	91
4.2.7	Safe Operating Stop (SOS).....	92
4.2.8	Safe Stop 2 (SS2) .....	94
4.2.8.1	Interaction with EPOS.....	95
4.2.8.2	SS2 with external stop (SS2E) .....	96
4.2.8.3	Overview of important parameters .....	98
4.2.9	Safely-Limited Speed (SLS).....	99
4.2.9.1	Safely Limited Speed (SLS) .....	100
4.2.9.2	Safely Limited Speed without encoder .....	103
4.2.9.3	Safely-Limited Speed without selection .....	105
4.2.9.4	Function diagrams and parameters .....	106
4.2.9.5	EPOS and safe setpoint velocity limitation .....	107
4.2.10	Safe Speed Monitor (SSM) .....	108
4.2.10.1	Safe Speed Monitor with encoder .....	109
4.2.10.2	Safe Speed Monitor without encoder .....	111
4.2.10.3	Function diagrams and parameters .....	114
4.2.11	Safe Direction (SDI) .....	115
4.2.11.1	Safe Direction with encoder .....	115
4.2.11.2	Safe Direction without encoder.....	117
4.2.11.3	Safe Direction without selection.....	119
4.2.11.4	Function diagrams and parameters .....	120
4.2.12	Safely-Limited Position (SLP).....	121
4.2.12.1	Retraction .....	124
4.2.12.2	Function diagrams and parameters .....	126
4.2.13	Safe referencing.....	127
4.2.14	Transferring safe position values (SP) .....	129
4.2.15	Safe Brake Test (SBT).....	132
4.2.15.1	Communication via SIC/SCC .....	139
4.2.15.2	Function diagrams and parameters .....	141
4.2.16	Safe Acceleration Monitor (SAM).....	142
4.2.17	Safe Brake Ramp (SBR).....	144

4.2.18	Safe actual value acquisition .....	147
4.2.18.1	Notes regarding safe actual value sensing using an encoder system .....	147
4.2.18.2	Notes regarding setting parameters for safe actual value sensing without encoder .....	154
4.2.19	Safe gearbox stage switchover .....	157
4.2.20	Forced dormant error detection (test stop).....	160
<b>5</b>	<b>Control of the safety functions .....</b>	<b>167</b>
5.1	Control possibilities.....	167
5.2	Control signals by way of terminals on the Control Unit and Motor / Power Module .....	168
5.2.1	Simultaneity and tolerance time of the two monitoring channels .....	171
5.2.2	Bit pattern test.....	173
5.3	Activation via PROFIsafe .....	174
5.3.1	Enabling of the control via PROFIsafe.....	175
5.3.2	Selecting a PROFIsafe telegram.....	176
5.3.3	Telegram format .....	177
5.3.4	Process data .....	179
5.3.4.1	S_STW1 and S_ZSW1 (Basic Functions) .....	179
5.3.4.2	S_STW2 and S_ZSW2 (Basic Functions) .....	181
5.3.4.3	S_STW1 and S_ZSW1 (Extended Functions) .....	183
5.3.4.4	S_STW2 and S_ZSW2 (Extended Functions) .....	185
5.3.4.5	Additional process data.....	188
5.3.5	Function diagrams and parameters .....	189
5.4	Control via TM54F .....	190
5.4.1	Fault acknowledgment .....	191
5.4.2	Overview of the F-DIs .....	191
5.4.3	Overview of the F-DOs .....	193
5.5	Response for a communication failure via PROFIsafe or to the TM54F .....	196
5.5.1	STOP B as response to communication failure with PROFIsafe control .....	196
5.5.2	Initiating ESR for a communication failure .....	197
5.6	Control of the Extended Functions via F-DI (for CU310-2) .....	199
5.6.1	Overview of the F-DIs .....	200
5.6.2	Function of the F-DO .....	202
5.7	Motion monitoring without selection .....	205
5.8	Safety Info Channel and Safety Control Channel .....	207
5.8.1	Safety Info Channel (SIC) .....	207
5.8.2	Safety Control Channel (SCC).....	207
5.8.3	Possible telegram configuration (700, 701).....	207
5.8.4	Configuring .....	209
5.8.5	Applications .....	210
5.8.6	Send data for SIC and SCC .....	213
5.8.7	Receive data for SCC .....	216
5.8.8	Overview of important parameters .....	217
<b>6</b>	<b>Commissioning.....</b>	<b>219</b>
6.1	Safety Integrated firmware versions .....	219
6.2	Parameters, checksum, version.....	220
6.3	Handling the Safety password .....	222

6.4	DRIVE-CLiQ rules for Safety Integrated Functions.....	224
6.5	Forced dormant error detection (test stop) .....	226
6.6	Commissioning Safety Integrated functions.....	229
6.6.1	General information.....	229
6.6.2	Prerequisites for commissioning the Safety Integrated functions.....	231
6.6.3	Default settings for commissioning Safety Integrated functions without encoder .....	232
6.6.4	Setting the sampling times .....	236
6.7	Commissioning: Basic procedure .....	238
6.7.1	Basic Functions.....	238
6.7.1.1	Commissioning via direct parameter access.....	238
6.7.1.2	Commissioning with STARTER.....	240
6.7.2	Commissioning of the Extended Functions with STARTER .....	246
6.7.2.1	Extended Functions with encoder.....	247
6.7.2.2	Extended Functions without encoder .....	266
6.8	Commissioning CU310-2 using STARTER/SCOUT .....	282
6.8.1	Configuration start screen.....	283
6.8.2	F-DI/F-DO configuration.....	284
6.8.3	Control interface of the drive .....	287
6.8.4	Forced dormant error detection (test stop) of the CU310-2.....	288
6.8.4.1	Test mode 1: Evaluation of internal diagnostic signal (passive load) .....	290
6.8.4.2	Test mode 2: Read back F-DO in DI (relay circuit).....	291
6.8.4.3	Test mode 3: Read back F-DO into the DI (actuator with feedback signal) .....	292
6.8.4.4	Test stop mode parameters .....	293
6.9	Commissioning TM54F by means of STARTER/SCOUT.....	294
6.9.1	Basic sequence of commissioning .....	294
6.9.2	Configuration start screen.....	295
6.9.3	Function diagrams and parameters .....	296
6.9.4	TM54F configuration.....	297
6.9.5	F-DI/F-DO configuration.....	300
6.9.6	Control interface of the drive group.....	303
6.9.7	Forced dormant error detection (test stop) of the TM54F.....	305
6.9.7.1	Test mode 1: Evaluation of internal diagnostic signal (passive load) .....	307
6.9.7.2	Test mode 2: Read back F-DO in DI (relay circuit).....	308
6.9.7.3	Test mode 3: Read back F-DO into the DI (actuator with feedback signal) .....	309
6.9.7.4	Parameter forced dormant error detection (test stop).....	310
6.10	PROFIsafe communication .....	311
6.10.1	PROFIsafe via PROFIBUS .....	312
6.10.1.1	Configuring PROFIsafe via PROFIBUS .....	312
6.10.2	PROFIsafe via PROFINET.....	322
6.10.2.1	Assigning the IP address and the name.....	322
6.10.2.2	Configuring PROFIsafe via PROFINET.....	322
6.10.3	PROFIsafe configuration with STARTER .....	330
6.10.3.1	Selecting a PROFIsafe telegram .....	331
6.11	Commissioning a linear/rotary axis .....	333
6.12	Modular machine concept Safety Integrated.....	335
6.13	Information pertaining to series commissioning .....	336
6.14	Application examples.....	338


<b>7</b>	<b>Acceptance test.....</b>	<b>341</b>
7.1	General information about the acceptance test .....	344
7.2	Safety logbook .....	346
<b>8</b>	<b>System features.....</b>	<b>347</b>
8.1	Latest information .....	347
8.2	Certification .....	349
8.3	Probability of failure of the safety functions (PFH value) .....	350
8.4	Response times .....	351
8.4.1	Control of Basic Functions via terminals on the Control Unit and Motor Module (CU310-2 and CU320-2) .....	352
8.4.2	Control of Basic Functions via PROFIsafe (CU310-2 and CU320-2).....	353
8.4.3	Control of Basic Functions via TM54F .....	354
8.4.4	Control of Extended Functions with encoder via PROFIsafe (CU310-2 and CU320-2) .....	355
8.4.5	Control of Extended Functions with encoder via TM54F (CU310-2 and CU320-2).....	356
8.4.6	Control of Extended Functions with encoder via terminals (only CU310-2) .....	357
8.4.7	Control of Extended Functions without encoder via PROFIsafe (CU310-2 and CU320-2) .....	358
8.4.8	Control of Extended Functions without encoder via terminals (only CU310-2) .....	359
8.4.9	Control of Extended Functions without encoder via TM54F (CU310-2 and CU320-2) .....	360
<b>9</b>	<b>Maintenance.....</b>	<b>361</b>
9.1	Information pertaining to component replacements .....	361
9.2	Note regarding firmware update .....	364
9.3	Safety faults .....	365
9.3.1	Stop responses .....	365
9.3.2	Stop response priorities .....	368
9.3.3	Acknowledging safety faults .....	370
9.4	Message buffer .....	371
<b>10</b>	<b>Standards and regulations.....</b>	<b>373</b>
10.1	General information .....	373
10.1.1	Aims .....	373
10.1.2	Functional safety .....	374
10.2	Safety of machinery in Europe.....	375
10.2.1	Machinery Directive .....	375
10.2.2	Harmonized European Standards .....	376
10.2.3	Standards for implementing safety-related controllers .....	377
10.2.4	DIN EN ISO 13849-1 (replaces EN 954-1) .....	379
10.2.5	EN 62061 .....	380
10.2.6	Series of standards IEC 61508 (VDE 0803).....	381
10.2.7	Risk analysis/assessment .....	382
10.2.8	Risk reduction .....	384
10.2.9	Residual risk .....	384
10.2.10	EC declaration of conformity .....	384


10.3	Machine safety in the USA .....	385
10.3.1	Minimum requirements of the OSHA .....	385
10.3.2	NRTL listing .....	385
10.3.3	NFPA 79 .....	386
10.3.4	ANSI B11 .....	386
10.4	Machine safety in Japan .....	387
10.5	Equipment regulations .....	388
10.6	Other safety-related issues .....	389
10.6.1	Information sheets issued by the Employer's Liability Insurance Association .....	389
10.6.2	Additional references .....	389
<b>A</b>	<b>Appendix .....</b>	<b>391</b>
A.1	List of abbreviations .....	391
A.2	Documentation overview .....	401
A.3	Acceptance tests (recommendations) .....	403
A.3.1	Contents and depth of the acceptance test .....	403
A.3.1.1	Content of the complete acceptance test .....	403
A.3.1.2	Content of the partial acceptance test .....	405
A.3.1.3	Test scope for specific measures .....	407
A.3.1.4	Relevant checksums for the acceptance .....	408
A.3.2	Acceptance reports .....	409
A.3.2.1	Plant description - Documentation part 1 .....	409
A.3.2.2	Description of safety functions - Documentation Part 2 .....	411
A.3.3	Acceptance tests .....	420
A.3.3.1	Acceptance tests – Basic Functions .....	422
A.3.3.2	Acceptance tests for Extended Functions (with encoder) .....	426
A.3.3.3	Acceptance tests for Extended Functions (without encoder) .....	481
A.3.3.4	Acceptance test for the transfer of F-DIs via PROFIsafe .....	504
A.3.4	Completion of certificate .....	505
A.4	Stop variants .....	507
	<b>Index .....</b>	<b>509</b>

# Fundamental safety instructions

## 1.1 Fundamental safety instructions

### 1.1.1 General safety instructions

 <b>WARNING</b>
<b>Danger to life if the safety instructions and residual risks are not observed</b> If the safety instructions and residual risks in the associated hardware documentation are not observed, accidents involving severe injuries or death can occur. <ul style="list-style-type: none"><li>• Observe the safety instructions given in the hardware documentation.</li><li>• Consider the residual risks for the risk evaluation.</li></ul>

 <b>WARNING</b>
<b>Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization</b> As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death. <ul style="list-style-type: none"><li>• Protect the parameterization (parameter assignments) against unauthorized access.</li><li>• Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).</li></ul>

## 1.1.2 Industrial security

### Note

#### Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (<http://www.siemens.com/industrialsecurity>).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (<http://support.automation.siemens.com>).

### WARNING

#### Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.  
You will find relevant information and newsletters at this address (<http://support.automation.siemens.com>).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.  
You will find further information at this address (<http://www.siemens.com/industrialsecurity>).
- Make sure that you include all installed products into the holistic industrial security concept.

### WARNING

#### Danger to life due to software manipulation when using exchangeable storage media

Storing files onto exchangeable storage media amounts to an increased risk of infection, e.g. with viruses and malware. As a result of incorrect parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect files stored on exchangeable storage media from malicious software by taking suitable protection measures, e.g. virus scanners.



## 1.2 Fundamental safety instructions for Safety Integrated

### Note

#### Malfunctions as a result of withdrawing and inserting components

Malfunctions can occur when components are withdrawn or inserted that are used for Safety Integrated. However, this does not mean that the fail-safe state is exited. For example, PROFIsafe communication is not reestablished after this event.

- Withdrawing and inserting components used for Safety Integrated (power units, Sensor Modules, TM54F) during operation **and** in the deactivated state is **not** permissible. Activating the components always requires a POWER ON (see section "Modular machine concept Safety Integrated (Page 335)").

### Additional safety instructions and residual risks

Additional safety information and residual risks not specified in this section are included in the relevant sections of this Function Manual.

#### DANGER

##### Risk minimization through Safety Integrated

Safety Integrated can be used to minimize the level of risk associated with machines and plants.

Machines and plants can only be operated safely in conjunction with Safety Integrated, however, when the machine manufacturer:

- Precisely knows and observes this technical user documentation - including the documented limitations, safety information and residual risks.
- Carefully constructs and configures the machine/plant. A careful and thorough acceptance test must then be performed by qualified personnel and the results documented.
- Implements and validates all the measures required in accordance with the machine/plant risk analysis by means of the programmed and configured Safety Integrated functions or by other means.

The use of Safety Integrated does not replace the machine/plant risk assessment carried out by the machine manufacturer as required by the EC machinery directive.

In addition to using Safety Integrated functions, further risk reduction measures must be implemented.

#### NOTICE

##### Danger to life as a result of inactive Safety Integrated functions after powering up

The Safety Integrated functions are only activated after the system has completely powered up. System startup is a critical operating state with increased risk. When accidents occur, this can result in death or severe injury.

- Make sure that the machine is safe during the system start-up.

 **WARNING**

**Regulations from EN 60204-1**

The Emergency Stop function must bring the machine to a standstill according to stop category 0 or 1 (STO or SS1).

The machine must not restart automatically after EMERGENCY STOP.

When individual safety functions (Extended Functions) are deactivated, an automatic restart is permitted under certain circumstances depending on the risk analysis (except when Emergency Stop is reset). An automatic start is permitted when a protective door is closed, for example.

 **WARNING**

**System power-up and drive activation after changing or replacing hardware and/or software**

After hardware and/or software components have been modified or replaced, it is only permissible for the system to run up and the drives to be activated with the protective devices closed. Personnel shall not be present within the danger zone.

It may be necessary to carry out a partial or complete acceptance test or a simplified functional test after having made certain changes or replacements.

Before personnel may re-enter the hazardous area, the drives should be tested to ensure that they exhibit stable control behavior by briefly moving them in both the plus and minus directions (+/-).

**Please note the following during switch-on:**

The Safety Integrated functions are only available and can only be selected after the system has completely powered up.

 **WARNING**

**Danger to life when the drive coasts down for an STO or STOP A**

The category 0 stop function in accordance with EN 60204-1 (STO or STOP A to Safety Integrated) means that the drives are not decelerated but instead coast to standstill (the time required to coast to standstill depends on the kinetic energy).

- Carefully take this response into account when designing the protective door interlocking logic.
- For safety without encoder, you must apply other measures to ensure that the protective door remains locked until the drive has come to a standstill.

 **WARNING****Danger to life as a result of a malfunction due to an acceptance test that has not been carried out after changes to parameters have been made**

Safety Integrated functions cannot detect parameter changes made by the machine builder (OEM). Incorrect parameter changes for SI functions can result in accidents leading to death or severe injury.

- After making a change to a parameter, always carry out an acceptance test and document the values in an acceptance report.
- Only use the system or machine after the acceptance test has been successfully completed.

 **WARNING****Danger to life as a result of different responses of the Safety Integrated functions when replacing a Motor Module or a motor**

Motor Modules or the motor must be replaced with a device of the same type, as the parameter settings will otherwise lead to an incorrect response of the Safety Integrated functions. Functionality that has been modified can result in accidents leading to death or severe injury.

- Always replace a component by an identical component of precisely the same type.
- Readjust the drive involved when replacing an encoder.
- Carefully test the functionality after replacement.

 **WARNING****Danger to life as a result of parameterized safety functions, which are only available to a restricted extent, when an internal or external fault occurs**

If an internal or external fault occurs, none or only some of the parameterized safety functions are available during the STOP F response triggered by the fault.

- Carefully take this into account when parameterizing a delay time between STOP F and STOP B. This is especially true for vertical axes.

 **WARNING****Parameterizing the encoder system**

Encoder faults are detected using different hardware and software monitoring functions.

- It is not permissible to disable these monitoring functions (i.e. the encoder monitoring in the Sensor Module) and they must be parameterized carefully. Depending on the fault type and the responding monitoring function, stop function category 0 or 1 in accordance with EN 60204-1 (fault response functions STOP A or STOP B to Safety Integrated) is selected (see table "Overview of stop responses" in Section "Safety Integrated Extended Functions", in the section "Safety faults").

---

**Note**

**EDS switchover for safe motion monitoring**

An encoder which is used for safety functions must not be switched over when a drive data set (DDS) is switched over.

The safety functions check the safety-relevant encoder data for changes when data sets are switched over. If a change is detected, fault F01670 is displayed with a fault value of 10, which results in a non-acknowledgeable STOP A.

- The safety-relevant encoder data in the various data sets must therefore be identical.
- 

 **WARNING**

**Converter operation despite active messages**

With activated safety functions, there are a number of system messages that still permit the drive to be traversed. In these cases, you must ensure that the causes of the messages are corrected immediately. These messages include, among others, the following:

- A01774 SI Motion CU: Test stop required  
A01697 SI Motion: Motion monitoring test required  
Perform the required test stop.
- A13000 Insufficient license.  
Purchase the license required for the operation of the Extended Functions.
- A01669 (F, N) SI Motion: Unsuitable combination of motor and power unit.  
The motor / power unit combination can result in decreased robustness (incorrect detection of errors) in the system when operating with SI Motion.

## 1.3 Residual risk

The fault analysis enables machine manufacturers to determine the residual risk at their machine with regard to the drive unit. The following residual risks are known:

### WARNING

#### **Residual risk through possible hardware faults: PFH value**

Due to the intrinsic potential of hardware faults, electrical systems are subject to additional residual risk, which can be expressed by means of the PFH value.

- Take into account these residual risks when designing your machine and where necessary apply suitable countermeasures.

### WARNING

#### **Danger to life due to uncontrolled acceleration of the drive**

Faults in the absolute track (C-D track), cyclic interchange of the drive phases (V-W-U instead of U-V-W) and reversal of the control direction may cause acceleration of the drive. Category 1 and 2 stop functions according to EN 60204-1 (fault response functions Stop B to D according to Safety Integrated) that are provided are however not effective due to the fault.

- Category 0 stop function according to EN 60204-1 (fault response function Stop A according to Safety Integrated) is not activated until the transition or delay time set in the parameter has expired. These faults are detected when SAM is selected (fault reaction functions STOP B/C) and stop function category 0 according to EN 60204-1 (fault reaction function STOP A according to Safety Integrated) is triggered as early as possible regardless of this delay. Electrical faults (defective components or similar) may also lead to the response stated above.

### WARNING

#### **Danger to life due to short, limited movements of the motor.**

Simultaneous breakdown of 2 power transistors in the power unit can cause a short, limited movement. This can cause accidents resulting in serious injuries or death.

- If there is a hazard due to unwanted movement in your application, take measures to counter it, for example, by using a brake with safe monitoring. Further information can be found in Section "Safe Brake Control (SBC) (Page 71)".

### WARNING

#### **Danger to life due to higher speeds of short duration when the limit value is exceeded**

Violation of limits may briefly lead to a speed higher than the speed setpoint, or the axis may pass the defined position to a certain extent, depending on the dynamic response of the drive and on parameter settings.

- Take into account this situation when designing your machine and where necessary apply suitable countermeasures.

 **WARNING**

**Residual risk for a single-encoder system**

Within a single-encoder system:

- a) A single electrical fault in the encoder
- b) A break of the encoder shaft (or loose encoder shaft coupling), or a loose encoder housing will cause the encoder signals to remain static (that is, they no longer follow a movement while still returning a correct level), and prevent fault detection while the drive is in stop state (for example, drive in SOS state).

Generally, the drive is held by the active closed-loop control. Especially for drives with suspended load, from a closed-loop control perspective, it is conceivable that drives such as these move without this being detected.

The risk of an electrical fault in the encoder as described under a) is only present for few encoder types employing a specific principal of operation.

- All of the faults described above must be included in the risk analysis of the machine manufacturer. Additional safety measures have to be taken for drives with suspended/vertical or pulling loads - e.g. in order to exclude faults under a):
  - Use of an encoder with analog signal generation
  - Use of a two-encoder system
- In order to exclude the fault described in b), for example:
  - Perform an FMEA regarding encoder shaft breakage (or slip of the encoder shaft coupling) as well as loose encoder housings and use a fault exclusion process according to IEC 61800-5-2, or
  - Implementation of a two-encoder system (the encoders must not be mounted on the same shaft).

# General information about SINAMICS Safety Integrated

# 2

## 2.1 Drive products with integrated safety functions

	Applications With fixed speed		Applications with variable speed						High Performance and Motion Control applications		
	SINAMICS ET 200S starter	SINAMICS ET 200pro starter	SINAMICS ET 200pro FC-2	SINAMICS G120C	SINAMICS G120	SINAMICS G120D	SINAMICS G130	SINAMICS G150	SINAMICS S110	SINAMICS S120	SINAMICS S150
Integrated safety functions according to IEC 61800-5-2											
STO Safe Torque Off	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SS1 Safe Stop 1	-	-	-	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SBC Safe Brake Control	-	-	-	-	Yes <sup>2)</sup>	-	Yes <sup>3)</sup>	Yes <sup>3)</sup>	Yes <sup>4)</sup>	Yes <sup>3)4)6)</sup>	Yes <sup>3)</sup>
SOS Safe Operating Stop	-	-	-	-	-	-	Yes	Yes	Yes	Yes	Yes
SS2 Safe Stop 2	-	-	-	-	-	-	Yes	Yes	Yes	Yes	Yes
SLS Safely-Limited Speed	-	-	-	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SSM Safe Speed Monitor	-	-	-	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SDI Safe Direction	-	-	-	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SLP Safely-Limited Position	-	-	-	-	-	-	Yes	Yes	-	Yes	Yes
Integrated safe diagnostic function											
SBT Safe Brake Test	-	-	-	-	-	-	Yes	Yes	-	Yes <sup>8)</sup>	Yes
Fail-safe interfaces											
PROFIBUS/PROFINET with PROFIsafe profile	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Fail-safe inputs	Yes, with external Components			Yes	Yes	Yes	Yes	Yes	Yes <sup>5)</sup>	Yes <sup>5)</sup>	Yes <sup>5)</sup>
Fail-safe outputs	-	-	-	-	Yes <sup>8)</sup>	Yes	Yes <sup>5)</sup>	Yes <sup>5)</sup>	Yes	Yes <sup>5)</sup>	Yes <sup>5)</sup>
Certifications											
EN ISO 13849-1	Cat. 4/ PL e	Cat. 4/ PL e	Cat. 3/ PL d	Cat. 3/ PL d	Cat. 3/ PL d <sup>7)</sup>	Cat. 3/ PL d	Cat. 3/ PL d	Cat. 3/ PL d	Yes	Cat. 3/ PL d	Yes
IEC 61508	SIL 3	SIL 3	SIL 2	SIL 2	SIL 2 <sup>7)</sup>	SIL 2	SIL 2	SIL 2	SIL 2	SIL 2	SIL 2
NFPA 79	Yes	Yes	-	-	-	-	Yes	Yes	Yes	Yes	-
NRTL-gelistet	Yes	Yes	-	-	-	-	-	-	-	Yes <sup>1)</sup>	-

<sup>1)</sup> Only for SINAMICS S120 Booksize

<sup>5)</sup> CU320-2, G130, G150: With use of the TM54F

<sup>2)</sup> For CU250S-2 with Safe Brake Relay only

CU310-2: Onboard interfaces or TM54F

<sup>3)</sup> With Chassis and Cabinet Modules with Safe Brake Adapter

<sup>4)</sup> CU305, CU310-2/SIMOTION D410-2, CUA31/CUA32: With Safe Brake Relay

<sup>6)</sup> Not available with SINAMICS HLA

<sup>7)</sup> STO via terminals of Power Module PM240-2: Cat. 4/PL e, SIL 3

<sup>8)</sup> Only for Control Unit CU250S-2

STO via the Control Unit terminals and all other safety functions: Cat. 3/PL d, SIL 2

Content of the present manual

## 2.2 Supported functions

All of the Safety Integrated functions available under SINAMICS S120 are listed in this section. SINAMICS makes a distinction between Safety Integrated Basic Functions and Safety Integrated Extended Functions.

The safety functions listed here conform to:

- Safety Integrity Level (SIL) 2 according to IEC 61508
- Category 3 according to DIN EN ISO 13849-1
- Performance level (PL) d according to DIN EN ISO 13849-1

The safety functions correspond to the functions according to DIN EN 61800-5-2 (under the assumption that they are defined there).

### Safety Integrated Basic Functions

These functions are part of the standard scope of the drive and can be used without requiring an additional license. These functions are always available. These functions do not require an encoder and/or do not place any special requirements on the encoder used.

- Safe Torque Off (STO)

Safe Torque Off is a safety function to avoid unexpected startup in accordance with EN 60204-1. STO prevents the supply of power to the motor, which can produce a torque. This is equivalent to stop category 0.

- Safe Stop 1 (SS1, time-controlled)

Safe Stop 1 is based on the "Safe Torque Off" function. This means that a Category 1 stop according to EN 60204-1 can be implemented.

- Safe Brake Control (SBC)

Safe Brake Control is used to safely control a holding brake.<sup>1) 2)</sup>

<sup>1)</sup> Note regarding Power/Motor Modules in the chassis format: For the chassis format, SBC is only supported by Power/Motor Modules with article number ...3 or higher. A Safe Brake Adapter is also needed for this format.

<sup>2)</sup> Note regarding Power/Motor Modules in the blocksize format: Blocksize Power Modules also require a Safe Brake Relay for this function.

### Safety Integrated Extended Functions

These functions require an additional safety license. Extended Functions with encoder require an encoder with safety capability (see Section "Notes regarding safe actual value sensing using an encoder system (Page 147)").

- Safe Torque Off (STO)

Safe Torque Off is a safety function to avoid unexpected starting in accordance with EN 60204-1.

- Safe Stop 1 (SS1, time and acceleration controlled)

Safe Stop 1 is based on the "Safe Torque Off" function. This means that a Category 1 stop in accordance with EN 60204-1 can be implemented.



- **Safe Brake Control (SBC)**  
Safe Brake Control is used to safely control a holding brake.<sup>1) 2)</sup>
- **Safe Operating Stop (SOS)**  
Safe Operating Stop is used to protect against unintentional movement. The drive is in closed-loop control mode and is not disconnected from the power supply.
- **Safe Stop 2 (SS2)**  
Safe Stop 2 is used to safely brake the motor with a subsequent transition into the "Safe Operating Stop" state (SOS). This means that a Category 2 stop in accordance with EN 60204-1 can be implemented.
- **Safely Limited Speed (SLS)**  
Safely Limited Speed monitors that the drive does not exceed a preset speed/velocity limit.
- **Safe Speed Monitor (SSM)**  
Safe Speed Monitor is used for safely identifying when a speed limit is undershot in both directions of motion, e.g. to identify zero speed. A fail-safe output signal is available for further processing.
- **Safe Direction (SDI)**  
Safe Direction is used to safely monitor the direction of motion.
- **Safely Limited Position (SLP)**  
Safely Limited Position ensures that a freely definable traversing range is not left.
- **Transferring safe position values (SP)**  
The "Transfer safe position values (SP)" function enables you to transfer a safe position to the higher-level control via PROFIsafe.
- **Safe gearbox stage switchover**  
The "Safe gearbox stage switchover" function facilitates reliable switching between different gearbox stages. The switchover is only possible via PROFIsafe.
- **Safe Brake Test (SBT)**  
The **diagnostic function** "Safe Brake Test" function (SBT) checks the required holding torque of a brake (operating or holding brake).

<sup>1)</sup> Note regarding Power/Motor Modules in the chassis format: For the chassis format, SBC is only supported by Power/Motor Modules with article number ...3 or higher. A Safe Brake Adapter is also needed for this design.

<sup>2)</sup> Note regarding Power/Motor Modules in the blocksize format: Blocksize Power Modules also require a Safe Brake Relay for this function.

---

## Note

### Parallel use of Safety Integrated Functions

All Safety Integrated Functions can be used simultaneously.

Exception: If SOS and SLS are activated simultaneously, SOS has higher priority and overrides the SLS reaction.

---



## 2.3 Supported functions: HLA module

### SINAMICS HLA and Safety Integrated

SINAMICS HLA supports the following Safety Integrated functions:

- Basic Functions

These functions are part of the standard scope of the drive and can be used without requiring an additional license. These functions are always available. These functions do not require an encoder and/or do not place any special requirements on the encoder used.

- Safe Torque Off (STO)

Safe Torque Off is a safety function to avoid unexpected startup in accordance with EN 60204-1. STO prevents the supply of power to the valve, which can produce a force. It is equivalent to stop category 0.

- Safe Stop 1 (SS1, time-controlled)

Safe Stop 1 is based on the "Safe Torque Off" function. This means that a Category 1 stop in accordance with EN 60204-1 can be implemented.

- Extended Functions

---

#### Note

#### Only Safety Integrated with encoder is possible

SINAMICS HLA only supports Safety Integrated Extended Functions with encoder.

---

These functions require an additional safety license. Extended Functions with encoder require an encoder with safety capability.

---

#### Note

#### Encoder types for SINAMICS HLA

The following encoder types are permissible for SINAMICS HLA:

- Single-encoder systems
    - DRIVE-CLiQ encoder with safety capability
    - sin/cos encoder connected via SME20/25, SME120/125 or SMC20 (1Vss, pure analog signal processing)
  - 2-encoder systems
    - Encoders with DRIVE-CLiQ connection
    - sin/cos encoder connected via SME20/25, SME120/125 or SMC20 (1Vss, pure analog signal processing)
    - HTL/TTL encoder connected via SMC30 (not in connection with SINUMERIK)
    - TTL encoder connected via the onboard interface of the HLA module (not in connection with SINUMERIK)
- 

- Safe Torque Off (STO)

Safe Torque Off is a safety function that prevents the drive from restarting unexpectedly according to EN- 60204-1.

2.3 Supported functions: HLA module

- Safe Stop 1 (SS1, time and acceleration controlled)  
Safe Stop 1 is based on the "Safe Torque Off" function. This means that a Category 1 stop in accordance with EN 60204-1 can be implemented.
- Safe Operating Stop (SOS)  
Safe Operating Stop provides protection against unwanted movements. The drive is in closed-loop control mode and is not disconnected from the power supply.
- Safe Stop 2 (SS2)  
Safe Stop 2 is used to safely brake the valve with a subsequent transition into the "Safe Operating Stop" state (SOS). This means that a Category 2 stop in accordance with EN 60204-1 can be implemented.
- Safely Limited Speed (SLS)  
Safely Limited Speed ensures that the drive does not exceed a preset speed limit.
- Safe Speed Monitor (SSM)  
Safe Speed Monitor is used for safely identifying when a speed limit is undershot in both directions of motion, e.g. to identify zero speed. A fail-safe output signal is available for further processing.
- Safe Direction (SDI)  
Safe Direction is used to safely monitor the direction of motion.
- Safely Limited Position (SLP)  
Safely Limited Position ensures that a freely definable traversing range is not left.
- Transferring safe position values (SP)  
The "Transfer safe position values (SP)" function enables you to transfer a safe position to a higher-level control via PROFIsafe.

---

**Note**

**Only "linear" axis type permitted**

For SINAMICS HLA, only the "linear" axis type is permitted.

---

## Commissioning in STARTER

The Safety Integrated functions of SINAMICS HLA can be commissioned in STARTER as follows:

	Expert list	STARTER screen forms
Basic Functions	Yes	No
Extended Functions	Yes	Yes

---

### Note

#### Comparison, description of electric ↔ hydraulic drives

In the Safety Integrated Function Manual, Safety Integrated functions are described from the perspective of an electric drive. However, these descriptions essentially also apply in the same way for hydraulic systems. You will find parameters and messages for the drive object HLA in the SINAMICS S120/S150 List Manual.

---

## 2.4 Examples of how the safety functions can be applied

Safety function	Application examples	Possible solution
STO	It is only permissible to open a protective door if the motor torque has been switched off.	<ul style="list-style-type: none"> <li>Select STO in the converter via a terminal or via PROFIsafe.</li> <li>The pulses are suppressed and the motor coasts to a standstill.</li> </ul>
	A central Emergency Stop button ensures that several drives cannot unintentionally start.	Evaluating the Emergency Stop button in a central controller, selecting STO in the converter via PROFIsafe.
SS1	The drive must brake as quickly as possible after the Emergency Stop button has been pressed. It is not permissible that the stationary motor undesirably accelerates.	Select SS1 in the converter using a fail-safe input or via PROFIsafe .
SBC	Safe control of a motor holding brake must be guaranteed to guarantee the motor is at a standstill.	SBC is (if configured) initiated together with STO. The Motor Module / Safe Brake Relay / Safe Brake Adapter then carries out the action and safely controls the outputs for the brake.
SOS	The standstill position of the motor must be monitored and ensured.	Select SOS, e.g. through SS2, in order to monitor the standstill position of the motor after braking.
SS2	The drive must brake as quickly as possible after the stop button has been pressed. The standstill position of the motor must be monitored and ensured.	Select SS2 in the converter using a fail-safe input or via PROFIsafe.
SLS	The machine operator must be able to enter the machine after the protective door has been opened and slowly move a horizontal conveyor with an acknowledgment button in the danger zone.	Selecting SLS in the converter. The converter limits and monitors the velocity of the horizontal conveyor.
	A spindle drive, depending on the selection of the cutting tool, must not exceed a specific maximum speed.	Selecting SLS and the corresponding SLS level in the converter via PROFIsafe.
SSM	A centrifuge may only be filled below a velocity defined by the user.	<p>If the Extended Functions are enabled, SSM is always <sup>1)</sup>. The function does not have to be selected.</p> <p>The converter safely monitors the centrifuge speed and enables the process to advance to the next step using the "SSM status" bit.</p> <p><sup>1)</sup> Exception: Motion monitoring without selection (Page 205)</p>
SDI	A protective door must only be opened if a drive moves in the safe direction (away from the operator).	Selecting SDI in the converter; enable the protective doors via status bit (PROFIsafe) of the converter.
	When replacing the pressure cylinders of the plates, the drive must only move in the safe direction of rotation.	Selecting SDI in the converter. Disabling the hazardous direction of rotation.
	Once the protection against jamming has been triggered, a roller shutter gate must only be able to start moving in one direction.	
	At an operational limit switch, the trolley of a crane must only start in the opposite direction.	

<b>Safety function</b>	<b>Application examples</b>	<b>Possible solution</b>
SLP	The drive may not exit the specified position ranges.	Selection of SLP in the converter; inhibits the range that is not permitted.
SP	<p>It is necessary to transmit a "safe position," for example, in the following use cases.</p> <ul style="list-style-type: none"> <li>• Safe cam sequencer</li> <li>• Calculation of the safe velocity</li> <li>• Safety concepts across axes <ul style="list-style-type: none"> <li>– Multi-dimensional protection areas</li> </ul> </li> <li>• Zone concepts <ul style="list-style-type: none"> <li>– Safe response depending on the position of the axes</li> <li>– Different reaction to sensors</li> </ul> </li> </ul>	The selection of SP in the converter enables you to transfer a safe position (i.e. absolute or relative position) to the higher-level controller via PROFIsafe.
SBT	The effect of a brake is reduced through wear.	The diagnostic function "Safe Brake Test SBT" detects whether a brake is achieving the required braking effect.
Safe gearbox stage switchover	For a machine equipped with selector gearbox it must be ensured that the switchover is actually performed.	The "Safe gearbox stage switchover" function ensures safe switchover between the gearbox stages.

## 2.5 Drive monitoring with or without encoder

If motors without a (safety-capable) encoder are being used, not all Safety Integrated functions can be used.

### Note

#### Definition: "Without encoder"

When "without encoder" is used in this manual, then this always means that either no encoder or no safety-capable encoder is being used.

In operation without encoder the actual speed values are calculated from the measured electrical actual values. Therefore, speed monitoring is also possible during operation without encoder.

Table 2- 1 Overview of Safety Integrated functions

	Functions	Abbr.	With encoder	Without encoder	Brief description
Basic Functions	Safe Torque Off	STO	Yes	Yes	Safe torque off
	Safe Stop 1	SS1	Yes	Yes	Safe stopping process according to stop category 1
	Safe Brake Control	SBC	Yes	Yes	Safe brake control
Extended Functions	Safe Torque Off	STO	Yes	Yes <sup>1)</sup>	Safe torque off
	Safe Stop 1	SS1	Yes	Yes <sup>1)</sup>	Safe stop according to stop category 1
	Safe Brake Control	SBC	Yes	Yes <sup>1)</sup>	Safe brake control
	Safe Operating Stop	SOS	Yes	No	Safe monitoring of the standstill position
	Safe Stop 2	SS2	Yes	No	Safe stop according to stop category 2
	Safely Limited Speed	SLS	Yes	Yes <sup>1)</sup>	Safe monitoring of the maximum speed
	Safe Speed Monitor	SSM	Yes	Yes <sup>1)</sup>	Safe monitoring of the minimum speed
	Safe Direction	SDI	Yes	Yes <sup>1)</sup>	Safe monitoring of the direction of motion
	Safely Limited Position	SLP	Yes	No	Safely limited position
	Safe referencing	SR	Yes	No	Safe referencing
	Transferring safe position values	SP	Yes	Yes <sup>1)</sup>	Transferring safe position values
	Safe Brake Test	SBT	Yes	No	Safe test of the required holding torque of a brake
	Safe Acceleration Monitor	SAM	Yes	Yes <sup>1)</sup>	Safe monitoring of drive acceleration
	Safe Brake Ramp	SBR	Yes	Yes <sup>1)</sup>	Safe braking ramp
	Safe gearbox stage switch-over	–	Yes	No	–

<sup>1)</sup> The use of this safety function without encoder is permitted only for induction motors or synchronous motors of the SIEMOSYN series.

The configuration of the Safety Integrated functions and the selection of monitoring with or without encoder is realized in the safety screens of the STARTER or SCOUT tools.



# Overview of Safety Integrated functions

## 3.1 Safety Integrated Basic Functions

---

**Note****Basic functions do not require an encoder**

The Safety Integrated Basic Functions are functions for safely stopping the drive. You do not require an encoder.

---

---

**Note****Application of the Basic Functions**

The Basic Functions are available without any restrictions in all control modes, with and without an encoder, for synchronous, induction, and reluctance motors.

---

---

**Note****Control via TM54F**

If you want to control the Safety Integrated Basic Functions via TM54F, set p9601.6 = 1.

---

This chapter should provide first users with a quick overview of the principle mode of operation of safety functions.


The entry into the description of the safety functions is based on the definition according to standard EN 61800-5-2 and some simple examples for using the function.

The description of the functions is simplified, as far as possible to clearly shown essential properties and setting options.

More information about the functions can be found in the following sections, e.g.: "Safety Integrated basic functions (Page 62)".

### 3.1.1 Safe Torque Off (STO)

Definition according to EN 61800-5-2:  
 "The STO function prevents energy from being supplied to the motor, which can generate a torque."




#### Examples of how the function can be used

Example	Possible solution
It is only permissible to open a protective door if the motor torque has been switched off.	<ul style="list-style-type: none"> <li>Select STO in the converter.</li> <li>The pulses are suppressed and the motor coasts to a standstill.</li> </ul>

#### How does STO function in detail?

The converter recognizes the selection of STO via a fail-safe input or via the safe communication PROFIsafe.  
 The converter then safely switches off the torque of the connected motor.




#### Details and parameterization

For further details and information on how to parameterize this function, refer to Chapter "Safe Torque Off (STO) (Page 62)".

### 3.1.2 Safe Stop 1 (SS1)

Definition according to EN 61800-5-2:  
 "The function SS1 brakes the motor and trips the function STO after a delay time."




#### Example of how the function can be used

Example	Possible solution
After an Emergency Stop button has been pressed, the drive must be braked as quickly as possible and brought into the STO state.	<ul style="list-style-type: none"> <li>• Wire the Emergency Stop button with a fail-safe input.</li> <li>• Select SS1 via the fail-safe input.</li> </ul>
A central Emergency Stop button ensures that several drives are braked as quickly as possible and brought into the STO state.	<ul style="list-style-type: none"> <li>• Evaluating an emergency stop pushbutton in a central control.</li> <li>• Select SS1 via PROFIsafe.</li> </ul>

#### How does SS1 function in detail?

##### Overview

The drive decelerates once "Safe Stop 1" has been selected, and goes into the "Safe Torque Off" state once the delay time has expired.



#### Select SS1

As soon as the converter identifies that SS1 has been selected via a terminal or via the PROFIsafe safe communication, the following happens:


- If, when selecting SS1, the motor is already switched off, then until the SS1 delay time expires, there is no response. STO becomes active after the time expires.
- If the motor is switched on when SS1 is selected, the inverter brakes the motor with the OFF3 ramp-down time. After the delay time, STO is triggered automatically.

**Details and parameterization**

For further details and information on how to parameterize this function, see Section "Safe Stop 1 (SS1, time controlled) (Page 68)".

**3.1.3 Safe Brake Control (SBC)**

Definition according to EN 61800-5-2:  
 "The SBC function supplies a safe output signal to control a holding brake."



Safe Brake Control (SBC)

**Example of how the function can be used**


Example	Possible solution
The safe control of a motor holding brake must be guaranteed in order to guarantee the motor is at a standstill.	SBC is (if configured) initiated together with STO. The Motor Module / Safe Brake Relay / Safe Brake Adapter then carries out the action and safely controls the outputs for the brake.

**How does SBC function in detail?**

The converter recognizes the selection of STO via a fail-safe input or via the safe communication PROFIsafe.

The converter then safely switches off the torque of the connected motor.

SBC is (if configured) initiated together with STO. The Motor Module / Safe Brake Relay / Safe Brake Adapter then carries out the action and safely controls the outputs for the brake.



**Details and parameterization**

For further details and information on how to parameterize this function, see Section "Safe Brake Control (SBC) (Page 71)".

### 3.1.3.1 Hardware required for SBC

#### Hardware required for SBC

- Safe Brake Relay

The command for releasing or applying the brake is transferred to the Motor Module / Power Module via DRIVE-CLiQ. The Motor Module / Safe Brake Relay then carries out the action and appropriately activates the outputs for the brake.




Image 3-1 Interconnecting the Safe Brake Relay using Blocksize as an example

The brake cannot be directly connected to the Motor Module in the chassis format. The connection terminals are only designed for 24 VDC with 150 mA; the Safe Brake Adapter is required for higher currents and voltages.

#### Note

##### Additionally required hardware for other formats

A Safe Brake Relay is also required for the "Safe Brake Control" in the blocksize format. With the chassis format (article numbers ending ...3 or higher), a Safe Brake Adapter is required. The Safe Brake Adapter is available for a 230 V AC brake control voltage.

3.1 Safety Integrated Basic Functions




Image 3-2 Interconnecting the Safe Brake Adapter

## 3.2 Safety Integrated Extended Functions

This chapter should provide first users with a quick overview of the principle mode of operation of safety functions.

The entry into the description of the safety functions is based on the definition according to standard EN 61800-5-2 and some simple examples for using the function.

The description of the functions is simplified, as far as possible to clearly shown essential properties and setting options.

More information about the functions can be found in the following sections, e.g.: "Safety Integrated Extended Functions (Page 80)".

### 3.2.1 Preconditions for the Safety Extended Functions

- For operation of the Safety Integrated Extended Functions, **one** license is required for **each** axis.
- An activated current controller in the drive
- Overview of hardware components that support the Extended Functions:
  - Control Unit CU320-2
  - Control Unit CU310-2
  - Motor Modules Booksize Compact
  - Motor Modules Booksize with an article number ending: -...3 or higher
  - Motor Modules Chassis with an article number ending: -...3 or higher
  - Motor Modules Cabinet with an article number ending: -...2 or higher
  - Power Modules Blocksize
  - Control Unit Adapter CUA31 as of article number: 6SL3040-0PA00-0AA1
  - Control Unit Adapter CUA32 as of article number: 6SL3040-0PA01-0AA0
  - For the safety functions with encoder:

Motors with sin/cos encoder and encoder evaluation with DRIVE-CLiQ interface or via Sensor Module SMC20, SME20/25/120/125

The list of approved encoders can be found on the Internet at:

<http://support.automation.siemens.com>

Enter the number **33512621** there as search term or contact your local Siemens office.

### 3.2.2 Control possibilities

The following options are available for controlling Safety Integrated Extended Functions:

- PROFIsafe
- TM54F
- Onboard F-DI (CU310-2)
- Permanent selection (Safety Integrated functions without selection)


### 3.2.3 Safe Torque Off (STO)

For the control options and the functionality for "Safe Torque Off" (STO), see Section "Safe Torque Off (STO) (Page 62)".

### 3.2.4 Safe Stop 1 (SS1)

Definition according to EN 61800-5-2:

"The function SS1 brakes the motor, monitors the magnitude of the motor deceleration within specified limits, and after a delay time or violation of a speed threshold, initiates the STO function."



#### Example of how the function can be used


Example	Possible solution
After an Emergency Stop button has been pressed, the drive must be braked as quickly as possible and brought into the STO state.	<ul style="list-style-type: none"> <li>• Wire the Emergency Stop button with a fail-safe input.</li> <li>• Select SS1 via the fail-safe input.</li> <li>• SS1 brakes the drive and then brings it into the STO state.</li> </ul>
A central Emergency Stop button ensures that several drives are braked as quickly as possible and brought into the STO state.	<ul style="list-style-type: none"> <li>• Evaluating an emergency stop pushbutton in a central control.</li> <li>• Select SS1 via PROFIsafe.</li> <li>• SS1 brakes the drives and then brings them into the STO state.</li> </ul>



## How does SS1 function in detail?

### Overview

Using the SS1 function, the converter brakes the motor and monitors the absolute speed. If the motor speed is low enough or the delay time has expired, the converter safely switches off the motor torque using STO.



## Select SS1


As soon as the converter identifies that SS1 has been selected via a fail-safe input or via PROFIsafe safe communication, the following happens:

- If the motor has already been switched off when selecting SS1 then the converter safely switches off the motor torque (STO).
- If the motor is switched on when SS1 is selected, the converter brakes the motor with the AUS3 ramp-down time.

### Monitoring modes

For the Extended Functions **with** or **without** encoder, you can choose between 2 different monitoring modes of the function SS1:

- Safe Brake Ramp (SBR)
- Safe Acceleration Monitor (SAM)



**Note**

**SS1 with external stop (SS1E)**


If you use SS1E, neither of the two monitoring functions (SBR, SAM) is active. The drive must be shut down in SS1E within the delay time, for example, by a user program of a CPU. STO becomes active after the delay time expires.

**Details and parameterization**

For further details and information on how to parameterize this function, see Section "Safe Stop 1 (SS1) (Page 87)".

### 3.2.5 Safe Operating Stop (SOS)

Definition according to EN 61800-5-2:  
"This SOS function is used for safe monitoring of the standstill position of a drive."



#### Example of how the function can be used

Example	Possible solution
A protective door must only be opened if a motor is in the safe standstill state.	<ul style="list-style-type: none"> <li>• Select SOS</li> <li>• A higher-level controller brakes the axis (e.g. position-controlled) down to standstill within the configured time between the selection of SOS and when it becomes active.</li> <li>• Standstill is then safely monitored via the SOS function.</li> </ul>

The protected machine areas can be entered without having to shut down the machine as long as SOS is active.

After SOS has been selected it becomes active after the parameterizable delay time has expired. The drive must be braked to standstill within this delay time (e.g. by the controller).

Drive stopping is monitored using an SOS tolerance window. At the instant this function becomes active, the current actual position is stored as the comparison position until SOS is deselected again. Any delay time is cleared after SOS is deselected and the drive can be immediately moved.

The drive is stopped with SS1 when the standstill tolerance window is violated.

#### Note

##### Contrary to SS1 and SS2, SOS does not automatically brake the drive

The control still enters the setpoint.

This means that in the user program of the control system, the system must respond to the "SOS selected" bit so that the control system brings the drive to a standstill within the delay time.





Image 3-3 Standstill tolerance

### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safe Operating Stop (SOS) (Page 92)".

### 3.2.6 Safe Stop 2 (SS2)

Definition according to EN 61800-5-2:  
"The function SS2 brakes the motor, monitors the magnitude of the motor deceleration, and after a delay time, initiates the SOS function."



#### Example of how the function can be used


Example	Solution
A protective door must only be opened if a motor is in the safe standstill state.	<ul style="list-style-type: none"> <li>Select SS2 in the converter via a terminal or via PROFIsafe .</li> <li>After braking, the converter goes into the SOS state. Only then may the protective door be released.</li> </ul>

#### 3.2.6.1 How does SS2 function in detail?

##### Overview

The safety function SS2 monitors the load speed and initiates the SOS function if the SS2 delay time has expired.

With SS2, braking is monitored on the OFF3 ramp. A faulty acceleration is detected and the drive then shuts down with STO.



If you are operating the motor with closed-loop torque control, the converter switches to the closed-loop speed control mode when SS2 is selected.

**Detailed description**

The fail-safe logic (e.g. F-CPU) selects the SS2 safety function via a fail-safe input or via the PROFIsafe safe communication.

- If, when selecting SS2, the motor is already at a standstill, after a delay time, the converter activates the Safe Operating Stop function (SOS).
- If the drive is not at standstill when SS2 is selected, it is braked along the OFF3 ramp. Braking is monitored with one of the following functions, depending on the setting in p9506:
  - "Safe Acceleration Monitor (SAM)"
    - A faulty acceleration is therefore detected.
  - "Safe Brake Ramp (SBR)"
    - In this way, a violation of the braking ramp is detected.

After a delay time, the converter activates the Safe Operating Stop function (SOS). This function monitors the safe standstill of the drive.

**Braking behavior**




Image 3-4 Braking behavior and diagnostics of the safety function SS2 (example of SS2 with SAM)

**Note**

**SS2 with external stop (SS2E)**

If you use SS2E, neither of the two monitoring functions (SBR, SAM) is active. The drive must be shut down in SS2E within the delay time, for example, by a user program of a CPU. SOS becomes active after the delay time expires.


**Details and parameterization**

For further details and information on how to parameterize this function, see Section "Safe Stop 2 (SS2) (Page 94)".

**3.2.7 Safely Limited Speed (SLS)**

Definition according to EN 61800-5-2:

"The SLS function prevents the motor from exceeding the specified speed limit."



**Examples of how the function can be used**

Example	Possible solution
The machine operator must be able to enter the machine after the protective door has been opened and slowly move a horizontal conveyor with an acknowledgment button in the danger zone.	<ul style="list-style-type: none"> <li>• Select SLS in the converter via a fail-safe input or PROFIsafe .</li> <li>• The converter limits and monitors the velocity of the horizontal conveyor.</li> </ul>
A spindle drive, depending on the selection of the cutting tool, must not exceed a specific maximum velocity.	<ul style="list-style-type: none"> <li>• Select SLS and the corresponding SLSlevel in the converter via PROFIsafe.</li> </ul>


## How does SLS function in detail?

### Overview

1. The inverter recognizes the selection of SLS via a fail-safe input or via the PROFIsafe safe communication.
2. SLS allows a motor to reduce its possibly inadmissibly high speed within a defined time.
3. SLS monitors the absolute value of the actual velocity.

The SLS setpoint limit can be transferred to the higher-level motion controller (e.g. SIMOTION), where the velocity setpoint can be limited.

In addition, you can configure the setpoint limit provided by SLS as maximum speed in the ramp-function generator. In this case, SLS limits the speed setpoint.



### Note

#### SLS without selection

As an alternative to controlling via terminals and/or PROFIsafe, there is also the option to parameterize the SLS function without selection. In this case, the SLS function is permanently active after POWER ON. You can find details about this in Section "Safely-Limited Speed without selection (Page 105)".

#### Selecting SLS when the motor is switched on

As soon as the converter detects the selection of SLS via a fail-safe input or via PROFIsafe safe communication, the following happens:

- To avoid a limit value being violated, the setpoint limit can be transferred to the higher-level motion controller (e.g. SIMOTION). The higher-level motion controller can then limit the velocity setpoint.
- If the speed setpoint limitation is interconnected to the ramp-function generator, the converter limits the speed to a value below the SLS monitoring.
- For SLS without encoder, you can select whether the converter monitors motor braking using the function SBR (Safe Brake Ramp) or not. For SLS with encoder, the SBR function cannot be selected.




With braking ramp monitoring <sup>1)</sup> (only without encoder)	Without braking ramp monitoring (with or without encoder)
<ul style="list-style-type: none"> <li>• After the adjustable "delay time for the braking ramp", using the SBR (Safe Brake Ramp) function, the converter monitors whether the velocity decreases.</li> <li>• The converter switches from SBR to SLS as soon as one of the following two conditions is fulfilled:                         <ul style="list-style-type: none"> <li>– The SBR monitoring ramp has reached the value of the SLS monitoring. This case is shown in the diagram above.</li> <li>– After the actual velocity has reached the value of the SLS monitoring threshold, the system again waits for the "delay time for braking ramp" until SLS becomes active.</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• The converter monitors the load velocity after the "delay time for SLS switchover" has expired.</li> </ul>
<p>Advantages:</p> <ul style="list-style-type: none"> <li>• Already when braking, the converter detects as to whether the load velocity decreases too slowly.</li> <li>• The feedback signal "SLS active" generally comes earlier than without acceleration monitoring.</li> </ul>	<p>Advantage:</p> <ul style="list-style-type: none"> <li>• Commissioning is simplified, because instead of the subfunction SBR or SAM of the alternative brake ramp monitoring, you only have to set the delay time.</li> </ul>

<sup>1)</sup> The automatic reduction of the speed only takes effect when the ramp-function generator is interconnected to the speed setpoint limitation.

### Selecting SLS at low velocities

If the motor velocity when selecting SLS is less than the SLSlimit, then the drive responds as follows:




### Deselecting SLS

If the higher-level controller deselects SLS, then the converter deactivates limiting and monitoring.

### Switching over the monitoring limits

When SLS is active, you can switchover between 4 different speed levels. An exception is "SLS without selection": In this case, there is only one limit.


### Switching to a lower speed level



<sup>1)</sup> The automatic reduction of the speed only takes effect when the ramp-function generator is interconnected to the speed setpoint limitation.

### Switching to a higher speed level

If you switch over from a lower to a higher speed level, the converter immediately monitors the actual velocity against the higher velocity.




### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safely-Limited Speed (SLS) (Page 99)".

### 3.2.8 Safe Speed Monitor (SSM)

Definition according to EN 61800-5-2:  
 "The SSM function supplies a safe output signal to indicate whether the motor speed is below a specified limit value."



**Note**

**SSM is a pure signaling function**

Unlike other Safety Integrated functions, exceeding the SSM limit value does not result in a drive-autonomous stop response.

#### Example of how the function can be used

Example	Possible solution
A centrifuge may only be filled below a velocity defined by the user.	<ul style="list-style-type: none"> <li>SSM is activated by configuring the Safety Integrated Extended Functions.</li> <li>The converter safely monitors the centrifuge speed and enables the process to advance to the next step using the "Status SSM" status bit.</li> </ul>

#### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safe Speed Monitor (SSM) (Page 108)".

### How does SSM function in detail?

#### Requirements

The safety function SSM cannot be selected or deselected using external control signals. SSM is active when you have set a monitoring velocity  $> 0$  for SSM.

#### Evaluating the speed

The converter compares the load speed with the speed limit and signals if the limit value is undershot to the high-level control.

#### Parameterizable hysteresis

The parameterizable hysteresis ensures that the SSM output signal does not jump between the values "0" and "1" in the limit range.





Image 3-5 Time response of the safety function SSM (Safe Speed Monitor)

### 3.2.9 Safe Direction (SDI)

Definition according to EN 61800-5-2:  
"The SDI function prevents the motor shaft moving in the wrong direction."



#### Examples of how the function can be used

Example	Possible solution
A protective door must only be opened if a drive moves in the safe direction (away from the operator).	<ul style="list-style-type: none"> <li>Select SDI in the converter using a fail-safe input or PROFIsafe .</li> <li>Enable the locking mechanism of the protective doors via the PROFIsafe status bit of the converter.</li> </ul>
When replacing the pressure cylinders of the plates, the drive must only move in the safe direction of rotation.	<ul style="list-style-type: none"> <li>Select SDI in the converter using a fail-safe input or PROFIsafe .</li> <li>In the converter, inhibit the direction of rotation that is not permitted.</li> </ul>
Once the protection against jamming has been triggered, a roller shutter gate must only be able to start moving in one direction.	
At an operational limit switch, the trolley of a crane must only be able to start in the opposite direction.	


#### How does SDI function in detail?

SDI monitors the actual direction of rotation.

The SDI setpoint limit can be transmitted to the higher-level motion controller (e.g. SIMOTION) to enable limitation of the velocity setpoint there.

In addition, you can configure the setpoint limit provided by SDI as maximum speed in the ramp-function generator. In this case, SDI limits the speed setpoint to the permissible direction.

You can select to block either the positive or the negative direction of rotation via 2 fail-safe signals (F-DIs or PROFIsafe).



### Selecting and deselecting SDI

As soon as the converter identifies that SDI has been selected via a fail-safe input or via PROFIsafe safe communication, the following happens:

- You can also set a delay time, within which you can ensure that the converter moves in the enabled (safe) direction.
- You can also set a tolerance, within which the converter tolerates movement in the direction that has not been enabled (unsafe). You can avoid the triggering of faults during braking (overshoot) as well as in controlled standstill.
- After the delay time has expired, the converter monitors the direction of rotation of the motor.
- If the converter now moves in the blocked direction by more than the configured tolerance, a message will be output and the defined stop response will be initiated.




Image 3-6 Time response of the safety function SDI (Safe Direction)

#### Note

##### SDI without selection

As an alternative to controlling via terminals and/or PROFIsafe, there is also the option of parameterizing SDI without selection. In this case, SDI will be permanently active after POWER ON. You will find details of this in Chapter "Safe Direction without selection (Page 119)."


### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safe Direction (SDI) (Page 115)".



### 3.2.10 Safely-Limited Position (SLP)

Definition according to EN 61800-5-2:  
"The SLP function prevents the motor shaft from exceeding the specified position limit(s)."



The Safely Limited Position function (SLP) is used to safely monitor the limits of two traversing and/or positioning ranges, which are toggled between using a safe signal.

#### Examples of how the function can be used

Example	Possible solution
The drive must not exit the specified position ranges.	<ul style="list-style-type: none"> <li>• Selection of SLP in the converter; inhibiting the range that is not permitted.</li> <li>• After the enabled range has been exited, a parameterizable stop response is initiated.</li> </ul>

#### Features

- Selection via terminals or PROFIsafe
- 2 position ranges, each defined by a limit switch pair
- Safe switchover between the two position ranges
- Adjustable stop response
- To run the motor out of the prohibited range, you must perform a special sequence (see Chapter "Retraction (Page 124)").

#### Requirements

- The function is only available with a suitable encoder.
- The drive has to be safely referenced (see Chapter "Safe referencing (Page 58)").

#### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safely-Limited Position (SLP) (Page 121)".

### 3.2.11 Safe referencing

The "safe referencing" function allows a safe absolute position to be defined. This safe position is used for the following functions:

- Safely-Limited Position (SLP) (Page 57)
- Transferring safe position values (SP) (Page 59)

#### General description

In most cases, an external control performs referencing to an absolute position. The converter only performs this task in special cases (for example, EPOS).

- Referencing using an external control

Requirement: No movement of the drive

The reference position determined by the control is entered into parameter p9572 and is declared to be valid using p9573 = 89.

- Referencing by EPOS

The SINAMICS EPOS function transfers, when referencing, the determined position directly to Safety Integrated. This can also take place during motion.

- User agreement

The user agreement must be set (p9726 = p9740 = AC hex) within 2 seconds after referencing.

Safety Integrated only evaluates the reference position if this is required by a function that has been enabled (e.g. SLP). Using diagnostics bit r9723.17, Safety Integrated indicates whether the drive has been referenced. Safety Integrated indicates the position of the drive in diagnostic parameters r9708 and r9713. Bit r9722.23 is set when the axis is safely referenced.

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2821 SI Extended Functions - Safe referencing


#### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safe referencing (Page 127)".

### 3.2.12 Transferring safe position values (SP)

The "Safe Position (SP)" function enables you to transfer safe position values to the higher-level fail-safe controller (F-CPU) via PROFIsafe (telegram 901 or 902).

From the position change over time, the F-CPU can also calculate the current velocity. In telegram 902, the values are transferred in 32-bit format, in telegram 901, in 16-bit format.



After parameter assignment, release and POWER ON, the function is automatically selected and the values transferred. Please observe the following:

- For use as the safe absolute position, the "Absolute position" must also be enabled and then safely referenced.
- In order that the transferred position can be used, the actual position value must be valid.

Using the time stamp that is also transferred, you can also calculate the velocity from the position values. If you only want to calculate the velocity, it is sufficient to enable the "Transfer of safe position values" without the "Absolute position."

#### Details and parameterization

For further details and information on how to parameterize this function, see Section "Transferring safe position values (SP) (Page 129)".

### 3.2.13 Safe Brake Test

The diagnostic function "Safe Brake Test" function (SBT) checks the required holding torque of a brake (operating or holding brake). You can test linear and rotary brakes. The drive purposely generates a force/torque against the applied brake. If the brake is operating correctly, the axis motion remains within a parameterized tolerance. If, however, a larger axis motion is detected, it must be assumed that the braking force/torque has deteriorated and maintenance is required.

The "Safe Brake Test" function allows a safe test of up to two brakes:

- 1 motor holding brake and 1 external brake
- 2 external brakes
- 1 motor holding brake
- 1 external brake

The Safe Brake Test (SBT) diagnostic function meets the requirements for Category 2 according to EN ISO 13849-1.

#### Details and parameterization

For further details and information on how to parameterize this function, see Section "Safe Brake Test (SBT) (Page 132)".

# Description of Safety Integrated functions

## Two-channel parameterization

Parameterization of the Safety Integrated functions must be performed in two channels; i.e. there is one parameter each for the 1st and 2nd channel. These two parameters must be identically parameterized.

For safety reasons, when using the STARTER commissioning tool (or SCOUT), you can only set the safety-related parameters of the first channel offline.

To set the safety-related parameters of the second channel, proceed as follows:

- Activate the "Copy parameters after download" checkbox and then establish an online connection to the drive unit. Perform the download and then adapt the checksums. Execute the "Copy RAM to ROM" command and then a POWER ON.
- Or establish an online connection to the drive unit first and then duplicate the parameters by clicking the "Copy parameters" button on the start screen of the configuration.

Because, in STARTER, you can set the safety-related parameters of the 2nd channel by copying, only the parameters of the 1st channel are stated in this manual. You will find the relevant parameters of the 2nd channel in the parameter description, e.g. in SINAMICS S120/S150 List Manual.

On faults and alarms, only the error number of the 1st channel is stated.

## 4.1 Safety Integrated basic functions

---

### Note

#### Basic functions do not require an encoder

The Safety Integrated Basic Functions are functions for safely stopping the drive. You do not require an encoder.

---

### Note

#### Application of the Basic Functions

The Basic Functions are available without any restrictions in all control modes, with and without an encoder, for synchronous, induction, and reluctance motors.

---

### Note

#### Control via TM54F

If you want to control the Safety Integrated Basic Functions via TM54F, set p9601.6 = 1.

---

### Note

#### PFH values

The PFH values of the individual SINAMICS S120 safety components can be found at:

<http://support.automation.siemens.com/WWW/view/de/76254308>

---

### 4.1.1 Safe Torque Off (STO)

In conjunction with a machine function or in the event of a fault, the "Safe Torque Off" (STO) function is used to safely disconnect the torque-generating energy supply to the motor.

A restart is prevented by the two-channel pulse suppression. The switching on inhibited prevents an automatic restart after deselection of STO.

The two-channel pulse suppression function integrated in the Motor Modules / Power Modules is the basis for this function.

#### Functional features of "Safe Torque Off"

- The function is completely integrated in the drive. It can be selected via terminals, TM54F or PROFIsafe from an external source.
- The function is drive-specific, i.e. it is available for each drive and must be individually commissioned.
- The function must be enabled via parameter.

- When the "Safe Torque Off" function is selected, the following applies:
  - The motor cannot be started accidentally.
  - The pulse suppression safely disconnects the torque-generating energy supply to the motor.
  - The power unit and motor are not electrically isolated.
- The selection/deselection of the STO function also acknowledges the safety faults when the Basic Functions are used. The standard acknowledgment mechanism must also be performed.
- Extended acknowledgement:
 

The selection/deselection of STO can also acknowledge the safety messages of the extended safety functions. This requires that the extended message acknowledgement is configured (p9507.0 = 1).

If in addition to the "Extended Functions", the "Basic Functions via terminals" are also enabled, in addition to selection/deselection of STO via PROFIsafe or TM54F, acknowledgement is also possible by selection/deselection of STO via terminals.
- The status of the "Safe Torque Off" function is displayed using parameters (r9772, r9872, r9773 and r9774).

 <b>WARNING</b>
---

<b>Danger to life as a result of undesirable motor movement</b>
---

After the energy feed has been disconnected (STO active) the motor can undesirably move (e.g. the motor can coast down), therefore presenting risk to persons.
--

- |  |
|--|
| <ul style="list-style-type: none"> <li>• Take suitable measures to prevent undesirable movement, e.g. by using a brake with safety-relevant monitoring. For additional information, see Section "Safe Brake Control (SBC) (Page 71)".</li> </ul> |
|--|

 <b>WARNING</b>
--

<b>Danger to life as a result of undesirable motor movement</b>
---

Undesirable motor motion can occur if 2 power transistor simultaneously become defective (breakdown of the depletion layer). This can result in accidents leading to death or severe injury.
--

- |  |
|--|
| <ul style="list-style-type: none"> <li>• Take suitable measures to prevent undesirable movement, e.g. by using a brake with safety-relevant monitoring. For additional information, see Section "Safe Brake Control (SBC) (Page 71)".</li> </ul> |
|--|

1) The maximum movement can involve:

- Synchronous rotary motors: Max. movement =  $180^\circ$  / no. of pole pairs
- Synchronous linear motors: Max. movement = pole width

## Enabling the "Safe Torque Off" function

The "Safe Torque Off" function is enabled via parameter p9601:

- STO for the Safety Integrated Basic Functions:
  - p9601 = 1 hex (Basic Functions via onboard terminals)
  - p9601 = 8 hex (Basic Functions via PROFIsafe)
  - p9601 = 9 hex (Basic Functions via PROFIsafe and onboard terminals)
  - p9601 = 40 hex (basic functions via TM54F)
  - p9601 = 41 hex (basic functions via TM54F and onboard terminals)
- STO in the Safety Integrated Extended Functions (EF):
  - p9601 = 4 hex (EF via TM54F)
  - p9601 = 5 hex (EF via TM54F and basic functions via onboard terminals)
  - p9601 = C hex (EF via PROFIsafe)
  - p9601 = D hex (EF via PROFIsafe via onboard terminals)
  - p9601 = 25 hex (EF without selection and basic functions via onboard terminals)

### Selecting/deselecting "Safe Torque Off"

The following is executed when "Safe Torque Off" is selected:

- Each monitoring channel triggers safe pulse suppression via its switch-off signal path.
- A motor holding brake is closed (if connected and configured).

Deselecting "Safe Torque Off" represents an internal safety acknowledgment. The following is executed if the cause of the fault has been removed:

- Each monitoring channel cancels safe pulse suppression via its switch-off signal path.
- The Safety requirement "Close motor holding brake" is canceled.
- Any pending STOP F or STOP A commands are canceled (see r9772).
- The messages in the fault memory must also be reset using the general acknowledgment mechanism.

---

### Note

#### No message for selection/deselection within the tolerance time (p9650)

If "Safe Torque Off" is selected and deselected through one channel within the tolerance time p9650, the pulses are suppressed without a message being output.

However, if you want a message to be displayed, then you must reconfigure N01620 as an alarm or fault using p2118 and p2119.

---



### Restart after the "Safe Torque Off" function has been selected

1. Deselect the function.
2. Set drive enables.
3. Cancel the "switching on inhibited" and switch the drive back on.
  - 1/0 edge at input signal "ON/OFF1" (cancel "switching on inhibited")
  - 0/1 edge at input signal "ON/OFF1" (switch on drive)

### Status for "Safe Torque Off"

The status of the function STO is displayed via r9772, r9872, r9773, and r9774. Alternatively, you can display the status of the function via the configurable message N01620 (configuration via p2118 and p2119).

### Response time for the "Safe Torque Off" function

For the response times when the function is selected/deselected via input terminals, see the table in Section "Response times (Page 351)".

### Internal armature short-circuit with the "Safe Torque Off" function

The function "internal armature short-circuit" can be configured together with the "STO" function.

The "STO" safety function has the higher priority when simultaneously selected. If the "STO" function is initiated, then an activated "internal armature short-circuit" is disabled.

### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2810 SI Basic Functions - STO (Safe Torque Off), SS1 (Safe Stop 1)
- 2811 SI Basic Functions - STO (Safe Torque Off), safe pulse suppression

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9601 SI enable functions integrated in the drive (Control Unit)
- r9720 CO/BO: SI Motion drive-integrated control signals
- r9722 CO/BO: SI Motion drive-integrated status signals
- r9772 CO/BO: SI Status (Control Unit)
- r9773 CO/BO: SI Status (Control Unit + Motor Module)
- r9774 CO/BO: SI Status (group STO)

### 4.1.1.1 Safe Torque Off (STO) for SINAMICS HLA

For the HLA module, safe torque off (STO) corresponds to shutting off a safety-relevant shutoff valve.

#### Special features of STO for HLA

- The shutoff valve controls the infeed to the hydraulic circuit. The shutoff valve is controlled via an F-DO of SINAMICS HLA.
- For Safety Integrated functions, it is absolutely necessary that a shutoff valve is connected with the associated feedback signals.
- You configure the feedback signal contacts of the shutoff valve using parameter p9626.
- You can take into account the response times of the feedback signals using parameter p9625.
- The shutoff valve is safely closed by selecting STO. If the shutoff valve signals a safe state via the feedback signal(s), the "STO active/Power removed" state is displayed, and is output at the configured safety-relevant output (PROFIsafe feedback signal telegram, F-DO on TM54F).




Image 4-1 Interconnecting the shutoff valve (for an axis)

- F-DO is dynamized each time that STO is selected/deselected: "Diag DO+" and "Diag DO-" are checked when switching F-DO+ and F-DO-.

- This makes it unnecessary to select forced dormant error detection (test stop) explicitly.
- If an error occurs in forced dormant error detection (test stop), the converter will issue the fault F01632 or F30632.

### **Function diagrams (see SINAMICS S120/S150 List Manual)**

- 2810 SI Basic Functions - STO (Safe Torque Off), SS1 (Safe Stop 1)
- 2811 SI Basic Functions - STO (Safe Torque Off), safe pulse suppression

### **Overview of important parameters (see SINAMICS S 120/S150 List Manual)**

- p9625[0...1] SI HLA shutoff valve wait time (CU)
- p9626 SI HLA shutoff valve feedback contacts configuration (CU)
- r9773 CO/BO: SI Status (Control Unit + Hydraulic Module)
- r9774 CO/BO: SI Status (group STO)
- r9780 SI monitoring cycle (Control Unit)

## 4.1.2 Safe Stop 1 (SS1, time controlled)

### 4.1.2.1 SS1 with OFF3

The "Safe Stop 1" (SS1) function allows the drive to be stopped in accordance with EN 60204-1, Stop Category 1. The drive decelerates with the OFF3 ramp (p1135) once "Safe Stop 1" is selected and switches to "Safe Torque Off" once the delay time set in p9652 has elapsed.

---

#### Note

##### Selection via terminals

The selection of the "Safe Stop 1" (time-controlled) function via terminals is parameterized by setting a delay  $> 0$  in p9652. In this case, the STO function can no longer be selected directly via terminals, i.e. either STO or SS1 can be selected via terminals.

If the "Safe Stop 1" (time-controlled) function has been selected by parameterizing a delay time in p9652, STO can no longer be selected directly via terminals.

---

## Functional features of Safe Stop 1

SS1 is enabled by p9652 (delay time)  $\neq 0$ .

- Setting parameter p9652 has the following effect:
  - p9652 = 0  
SS1 is not enabled. Only STO can be selected via TM54F, the onboard terminals and/or PROFIsafe.
  - p9652  $> 0$   
SS1 is enabled. Only SS1 can be selected via the onboard terminals; with PROFIsafe, a selection of SS1 and STO is possible.
- When SS1 is selected, the drive is braked along the OFF3 ramp (p1135) and STO/SBC is automatically initiated after the delay time has expired (p9652).

After the function has been selected, the delay timer runs down - even if the function is deselected during this time. In this case, after the delay time has expired, the STO/SBC function is selected and then again deselected immediately.

---

#### Note

##### Setting the delay time

So that the drive is able to travel down the OFF3 ramp completely and any motor holding brake present can be applied, before the pulses have been safely deleted, the delay time should be set as follows:

- Motor holding brake parameterized: Delay time  $p9652 \geq p1135 + p1228 + p1217$
  - Motor holding brake not parameterized: Delay time  $p9652 \geq p1135 + p1228$
  - The setting of parameter p1135 must be oriented towards the actual braking capability of the drive.
- 

- The timer (p9652) after whose expiration STO is activated, is implemented with two channels, although deceleration along the OFF3 ramp is only one channel.

## Requirement

- The Basic Functions are enabled via terminals and/or PROFIsafe:
  - p9601 = 1, 8 or 9 (hex)
- Enabling Basic Functions via TM54F
  - p9601.6 = 1
- In order that the drive can brake down to a standstill even when selected through one channel, the time in p9652 must be shorter than the sum of the parameters for the data cross-check (p9650 and p9658). Otherwise the drive will coast down after the time p9650 + p9658 has elapsed.


## Status of Safe Stop 1

The status of the "Safe Stop 1" (SS1) function is displayed using the parameters r9772, r9872, r9773 and r9774.

As an alternative, the status of the function can be displayed using the configurable message N01621 (configured using p2118 and p2119).

### 4.1.2.2 SS1 with external stop

In drive line-ups (e.g. drives that are mechanically connected via the material), the drive-independent braking on the respective OFF3 ramp can cause problems. If the SS1E function is used, the safe delay time (p9562) is started when the function is selected, but no OFF3 is triggered. The higher-level controller still enters the setpoint. The controller receives the information that SS1E has been selected via the Safety Info Channel.

 <b>WARNING</b>
<p><b>Danger to life due to unsupervised axis motion</b></p> <p>During the unsupervised delay time, for "Safe Stop 1 (time-controlled) with external stop", unsupervised axis motion is possible.</p> <ul style="list-style-type: none"> <li>• If there is a hazard due to unwanted movement in your application, take measures to counter it, for example, by using a brake with safe monitoring. For more information, see Chapter "Safe Brake Control (SBC) (Page 71)".</li> </ul>

### Differences between "SS1 with OFF3" and "SS1 with external stop"

"SS1 with OFF3" and "SS1 with external stop" have the following differences:

- In order to activate "Safe Stop 1 with external stop", **additionally** set p9653 to 1.
- When SS1E is selected, the drive is **not** braked along the OFF3 ramp, but after the delay time has expired (p9652), only STO/SBC is automatically initiated.

### 4.1.2.3 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2810 SI Basic Functions - STO (Safe Torque Off), SS1 (Safe Stop 1)
- 2811 SI Basic Functions - STO (Safe Torque Off), safe pulse cancellation

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p1135[0...n] OFF3 ramp-down time
- p1217 Motor holding brake closing time
- p1228 Pulse suppression delay time
- p9601 SI enable functions integrated in the drive (Control Unit)
- p9652 SI Safe Stop 1 delay time (Control Unit)
- r9772.0...23 CO/BO: SI Status (Control Unit)
- r9773.0...31 CO/BO: SI Status (Control Unit + Motor Module)
- r9774.0...31 CO/BO: SI Status (group STO)

#### Only for "Safe Stop 1 (time-controlled) with external stop"

- p9653 SI Safe Stop 1 drive-based braking response

### 4.1.3 Safe Brake Control (SBC)

The "Safe Brake Control" function (SBC) is used to safely control holding brakes that function according to the closed-circuit principle (e.g. motor holding brake).

The opening and closing of the brake is controlled by the Motor Module / Power Module. Terminals are available for this on the device in booksize format. A Safe Brake Relay is also required for the "Safe Brake Control" in the blocksize format. A Safe Brake Adapter is required in the chassis format (starting with article numbers ending with ...3). When the Power Module is configured automatically, the Safe Brake Relay is detected and the motor holding brake type is defaulted (p1278 = 0).

Brake activation via the brake connection on the Motor Module / Safe Brake Relay (SBR) / Safe Brake Adapter (SBA) involves a safe, two-channel method.

---

#### Note

##### No SBC for SINAMICS HLA

SINAMICS HLA does not support Safe Brake Control.

---

#### Note

##### Controlling the brake via a relay for "Safe Brake Control":

If you use the "Safe Brake Control (SBC)" function, the use of relays/contactors can cause faults in the brake control when brakes are switched. For this reason, this type of control is not generally enabled.

---

 <b>WARNING</b>
--

#### Danger to life as a result of undesirable motor motion due to defective brake

"Safe Brake Control" does not detect mechanical defects of the brake.

A cable break or a short-circuit in the brake winding is only detected when the state changes, i.e. when the brake either opens and/or closes. In SINAMICS S120M, a cable break is only identified when opening the brake.

For devices in chassis format with connected Safe Brake Adapter, the connecting cable between the Safe Brake Adapter and the motor brake is not monitored for cable break or short-circuit.

The aforementioned defects may trigger unwanted motor motion, which may result in physical injury or death.

- In particular, ensure the brake is not powered from an external source. Information on this topic can be found in EN 61800-5-2:2007, Appendix D.
- During commissioning, test the brake using the Safety Integrated Extended Function "Safe Brake Test (SBT)" (for further information, see Section "Safe Brake Test (SBT) (Page 132)").

### Functional features of "Safe Brake Control"

- SBC is executed when "Safe Torque Off" (STO) is selected.
- In contrast to conventional brake control, SBC is executed via two channels.
- SBC is executed regardless of the brake control or mode set in p1215. However, SBC does not make sense for 1215 = 0 or 3.
- The function must be enabled using parameters.
- When the state changes, electrical faults, such as a short circuit in the brake winding or wire breakage can be detected.

### Enabling the "Safe Brake Control" function

The "Safe Brake Control" function is enabled via parameter p9602.

The SBC function can be used only together with STO. The selection of SBC alone is not possible.

### Two-channel brake control

#### Note

#### Connecting the brake

The brake cannot be directly connected to the Motor Module in chassis format: A Safe Brake Adapter is also required.

The brake is controlled from the Control Unit. Two signal paths are available for applying the brake.




Image 4-2 Two-channel brake control, blocksize (example)

For the "Safe Brake Control" function, the Motor/Power Module assumes a monitoring function to ensure that when the Control Unit fails or malfunctions, the brake current is interrupted therefore closing the brake.



The brake diagnosis can only reliably detect a malfunction in either of the switches (TB+, TB-) when the status changes, i.e. when the brake is released or applied.

If the Motor Module or Control Unit detects a fault, the brake current is switched off. The brake then closes and a safe state is reached.

#### **4.1.3.1 SBC for Motor Modules in the chassis format**

To be able to set higher power in the brakes of devices of this format, an additional Safe Brake Adapter (SBA) module is needed. For more information about connecting and wiring the Safe Brake Adapter, refer to the "SINAMICS G130/G150/S120 Chassis/S120 Cabinet Modules/S150 Safety Integrated" Function Manual.

Using parameter p9621, you can define via which digital input the relay (NO contacts) feedback signal of the Safe Brake Adapter is routed to the Control Unit.

To evaluate the feedback signal contacts, you must maintain the wait times caused by the SBA. Parameter p9622 is pre-assigned with the SBA-relay wait times:

- p9622[0]  $\triangleq$  wait time, switching on
- p9622[1]  $\triangleq$  wait time, switching off

Further functionality and the activation of the brake, i.e. reaching the safe status, are in this case the same as the above described procedure for booksize devices.

### **Safe Brake Control with power units in a parallel connection**

---

#### **Note**

#### **SBC for parallel connection of power units**

Safe Brake Control with power units in a parallel connection is available if r9771.14 = 1.

---

If you wish to use SBC with SBA for chassis format power units connected in parallel, then it is only permissible that you connect precisely one SBA to a power unit in the parallel connection. The Safe Brake Adapter and therefore the brake are controlled via this power unit.

4.1 Safety Integrated basic functions

There are two options for registering this power unit with the system:

- Automatic brake identification when commissioning the system for the first time
  - Requirements:
    - No Safety Integrated functions enabled
    - p1215 = 0 (no motor holding brake available)
  - During the first commissioning, SINAMICS checks at which power unit an SBA is connected. If precisely one SBA is found, the number of the power unit is entered into parameter p7015.  
  
If several SBAs are found at the parallel-connected power units, message "F07935 drive: Motor holding brake configuration error" is output.
  - For devices in the chassis format, if the SBA feedback signal (SBA\_DIAG) is read in via an input of the power unit, then in addition, this digital input is automatically entered into parameter p9621.
- Manually defining the power unit
  - Enter the component number of the power unit, to which the SBA is connected, into parameter p7015. If no SBA is connected to the power unit, faults are detected when controlling the motor holding brake and fault F01630 is output.
  - In parameter p9621 (p9621 = BICO interconnection to r9872.3), enter the digital input of the power unit to which the SBA is connected and via which the SBA feedback signal (SBA\_DIAG) is read in.

---

**Note**

**Disconnecting the brake cable for service purposes**

As long as the brake is permanently released and not actuated, it is possible to briefly disconnect the brake cable, e.g. for service purposes, and not receive fault messages. In the case of a fault, message F07935 is only output when the brake is controlled.

---

### 4.1.3.2 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2814 SI Basic Functions - SBC (Safe Brake Control), SBA (Safe Brake Adapter)

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p0799 CU inputs/outputs, sampling time
- p1215 Motor holding brake configuration
- p7015 Par\_circuit holding brake power unit data set
- p9602 SI enable safe brake control (Control Unit)
- p9621 BI: SI Safe Brake Adapter signal source (Control Unit)
- p9622[0...1] SI SBA relay wait times (Control Unit)
- r9771.14 SI common functions (Control Unit): SBC supported for parallel connection
- r9780 SI monitoring cycle (Control Unit)

4.1 Safety Integrated basic functions


4.1.4 Safety faults

The fault messages of the Safety Integrated Basic Functions are saved in the standard message buffer and can be read out from there. By contrast, the fault messages of the Safety Integrated Extended Functions are stored in a separate Safety message buffer (see Chapter "Message buffer (Page 371)").

When faults associated with Safety Integrated Basic Functions occur, the following stop responses can be initiated:

Table 4- 1 Stop responses for Safety Integrated Basic Functions

Stop response	Triggered ...	Action	Effect
STOP A cannot be acknowledged	For all Safety faults with pulse suppression that cannot be acknowledged.	Trigger safe pulse suppression via the switch-off signal path for the relevant monitoring channel. During operation with SBC: Apply motor holding brake.	The motor coasts to a standstill or is braked by the holding brake.
STOP A	For all acknowledgeable Safety faults As a follow-up reaction of STOP F		
<p>STOP A corresponds to Stop Category 0 in accordance with EN 60204-1.</p> <p>With STOP A, the motor is switched directly to zero torque via the "Safe Torque Off (STO)" function. A motor at standstill cannot be started again accidentally.</p> <p>A moving motor coasts to standstill. This can be prevented by using external braking mechanisms, e.g. holding or operating brake.</p> <p>When STOP A is present, "Safe Torque Off" (STO) is active.</p>			
STOP F	If an error occurs in the data cross-check.	Transition to STOP A.	Follow-up response STOP A with adjustable delay (factory setting without delay) if one of the safety functions is selected
<p>STOP F is permanently assigned to the data cross-check (DCC). In this way, errors are detected in the monitoring channels.</p> <p>After STOP F, STOP A is triggered.</p> <p>When STOP A is present, "Safe Torque Off" (STO) is active.</p>			

 <b>WARNING</b>
<p><b>Danger to life due to an uncontrolled movement of the axis</b></p> <p>With a vertical axis or a pulling load, there is a danger of uncontrolled movement of the axis when STOP A/F if triggered.</p> <p>This can cause serious injury or death to persons in the danger zone.</p> <ul style="list-style-type: none"> <li>• If there is a hazard due to unwanted movement in your application, take measures to counter it, for example, by using a brake with safe monitoring. For additional information, see Section "Safe Brake Control (SBC) (Page 71)".</li> </ul>

## Acknowledging the Safety faults

There are several ways to acknowledge Safety faults:

- Acknowledgment through deselection of STO or SS1:
  - Remove the cause of the fault.
  - Deselect "Safe Torque Off" (STO) or "Safe Stop 1" (SS1).
  - Acknowledge the fault.

If the Safety commissioning mode is excited when the Safety functions are switched off (p0010 ≠ 95 when p9601 = 0), all Safety faults can be acknowledged.

Once safety commissioning mode has been selected again (p0010 = 95), all the faults that were previously present reappear.

- The higher-level controller sets the signal "Internal Event ACK" via the PROFIsafe telegram (STW bit 7). A falling edge in this signal resets the status "Internal Event" and so acknowledges the fault.
- Acknowledgment by switching the drive unit off/on

Safety faults can also be acknowledged (as with all other faults) by switching the drive unit off and then on again (POWER ON). If this action has not eliminated the fault cause, the fault is displayed again immediately after power-up.

## Description of faults and alarms

---

### Note

### References

The faults and alarms for SINAMICS Safety Integrated functions are described in the following document:

References: SINAMICS S120/S150 List Manual

---

### 4.1.5 Forced dormant error detection (test stop)

#### Forced dormant error detection or test of the switch-off signal paths (test stop) for Safety Integrated Basic Functions

The forced dormant error detection function (test stop) at the switch-off signal paths is used to detect software/hardware faults at both monitoring channels in time and is automated by means of activation/deactivation of the "Safe Torque Off" (STO) or "Safe Stop 1" (SS1) function.

To fulfill the requirements of ISO 13849-1 regarding timely error detection, the two switch-off signal paths must be tested at least once within a defined time to ensure that they are functioning properly. This functionality must be implemented by means of forced dormant error detection (test stop), triggered either in manual mode or by the automated process.

A timer ensures that forced dormant error detection (test stop) is carried out in a timely fashion.

- p9659 SI forced dormant error detection, timer.

A forced dormant error detection (test stop) must be performed on the switch-off signal paths at least once during the time set in this parameter.

Once this time has elapsed, an alarm is output and remains active until forced dormant error detection (test stop) is carried out.

The timer returns to the set value each time the STO/SS1 function is deactivated.

When the appropriate safety devices are implemented (e.g. protective doors), it can be assumed that running machinery will not pose any risk to personnel. As a consequence, the user is only made aware of the forced checking procedure (test stop) that is required using an alarm, and is requested to perform the forced checking procedure (test stop) at the next possible opportunity. This alarm does not affect machine operation.

The user must set the time interval for carrying out forced dormant error detection (test stop) to between 0.00 and 9000,00 hours depending on the application (factory setting: 8.00 hours).

Examples of when forced dormant error detection (test stop) must be performed:

- When the drives are at a standstill after the system has been switched on (POWER ON).
- When the protective door is opened.
- At defined intervals (e.g. every 8 hours).
- In automatic mode (time and event dependent).
- The maximum time interval is one year (8760 hours).

Forced dormant error detection (test stop) can be automatically executed at POWER ON.

- If the forced dormant error detection (test stop) as well as the test of the F-DO for the CU310-2 are to be executed automatically, then set p9507.6 = 1. When testing the FD-O of the CU310-2, you must parameterize p10042 and activate the test in p10046.
- If the forced dormant error detection (test stop) of the F-DI and F-DO of the TM54F is to be executed automatically, then set p10048 = 1.

- If you have parameterized the forced dormant error detection (test stop) for POWER ON, you can still initiate a forced dormant error detection (test stop) at any time through the application.
- If the automatically initiated function cannot be correctly completed as a result of a problem (e.g. communication failure), then after the problem has been resolved, the function is automatically restarted.
- After the forced dormant error detection (test stop) has been successfully executed, the converter goes into the "Ready" state.
- Timer p9659 is automatically reset as a result of the forced dormant error detection (test stop).
- The automatic forced dormant error detection (test stop) for POWER ON does not influence the Safety Integrated functions.

---

### Note

#### Resetting the timer of the basic functions

- If the Extended Functions and the associated forced dormant error detection (test stop) are used at the same time, the timer of the Basic Functions is also reset.  
Discrepancy is not checked at the terminals used to select the Basic Functions as long as STO is set by the Extended Functions. This means that the forced dormant error detection (test stop) of the basic functions must be performed by the Extended Functions without simultaneous selection of STO or SS1. It is otherwise not possible to verify the correct control through the terminals.
  - The timer is also reset if you first select "Change settings" and then "Activate settings" in the start screen of the configuration in STARTER.
- 

## 4.1.6 Function diagrams and parameters

### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2800 SI Basic Functions - Parameter manager
- 2802 SI Basic Functions - Monitoring functions and faults/alarms
- 2890 SI TM54F - Overview
- 2891 SI TM54F - Parameter manager
- 2900 SI TM54F - Basic Functions control interface (p9601.2/3 = 0, p9601.6 = 1)
- 2901 SI TM54F - Basic Functions Safe State selection
- 2902 SI TM54F - Basic Functions assignment (F-DO 0 ... F-DO 3)

## 4.2 Safety Integrated Extended Functions

---

### Note

#### PFH values

The PFH values of the individual SINAMICS S120 safety components can be found at:

<http://support.automation.siemens.com/WWW/view/de/76254308>

---

### 4.2.1 License for Extended Functions

- For operation of the Safety Integrated Extended Functions, **one** license is required for **each** axis. You enter the associated license key with the "License Key" button in STARTER. Then activate the license key using **Activate**.

As an alternative, you can enter the license key into parameter p9920 in the ASCII code. The license key is activated using parameter p9921 = 1.

- For information on how to generate the license key for the product "SINAMICS Safety Integrated Extended Functions", read the section "Licensing" in the SINAMICS S120 Function Manual. An insufficient license is indicated via the following alarm and LED:
  - A13000 --> License not sufficient
  - LED RDY --> Flashes green/red at 0.5 Hz
- When purchasing your drive, you can already decide to use Safety Integrated functions, and you will then be provided with the required license(s) on the memory card supplied. In this case, you do not have to explicitly activate the licenses.

### 4.2.2 Differences between Extended Functions "with encoder" and "without encoder"

If motors without a (safety-capable) encoder are being used, not all Safety Integrated functions can be used. You will find general information on this distinction in Chapter "Drive monitoring with or without encoder (Page 32)."

### Activation

For activation of the Safety Integrated Extended Functions "with encoder" and "without encoder", set the parameters p9306 and p9506 (factory setting = 0). You can also make this setting by selecting "with encoder" or "without encoder" on the Safety Integrated STARTER screen. You will find this STARTER screen in every drive under "Functions > Safety Integrated."

- Operation with encoder  
p9506 = 0 or p9506 = 2
- Operation without encoder  
p9506 = 1 or p9506 = 3



## Monitoring with an encoder

The Safety Integrated Functions with encoder are configured with p9506 = 0 (factory setting) or p9506 = 2 in the expert list or by selecting "with encoder" in the Safety screen.

- **If p9506 = 0:**

Braking is monitored with the "Safe Acceleration Monitor" function.

- **If p9506 = 2:**

Here, also for SS1, the monitoring function "Safe Brake Ramp" is active.

More detailed information on actual value acquisition with encoder can be found in Section "Notes regarding safe actual value sensing using an encoder system (Page 147)".

## Monitoring without an encoder

The Safety Integrated functions without encoder are configured in the expert list using p9506 = 1 or p9506 = 3 or by selecting "without encoder" in the Safety screen form.

- **For p9506 = 1, the following applies:**

Here, also for SS1, the monitoring function "Safe Brake Ramp" is active.

- **For p9506 = 3, the following applies:**

Braking is monitored with the "Safe Acceleration Monitor" function. The behavior corresponds to "monitoring with encoder".

### Taking into account the slip of an induction motor

For Safety Integrated without encoder (depending on the drive load), as a result of slip (deviations between electrical and mechanical speed), deviations can occur between the safely determined electrical speed and the mechanical speed at the motor shaft.

---

#### Note

Sudden changes in the current and voltage curve (e.g. sudden change in the setpoint setting and load) and very small absolute values with a high proportion of noise generally result in faults of the safe encoderless actual value acquisition and must be avoided.

---

More detailed information on actual value acquisition without encoder can be found in Section "Notes regarding setting parameters for safe actual value sensing without encoder (Page 154)".

---

#### Note

##### Scope of functions

There are fewer Safety Integrated Extended Functions available "without encoder" than "with encoder" (see Section "Drive monitoring with or without encoder (Page 32)").

---

#### Note

##### Safety Integrated functions "without encoder" for group drives

The Safety Integrated functions "without encoder" are also permitted for group drives (several motors connected to one power unit).

---

## "Parking" state for Safety Integrated Extended Functions with encoder

---

### Note

#### Extended Functions with encoder and "parking"

When a drive object, for which Safety Integrated Extended Functions with encoder are enabled, is switched to "Park" mode, the Safety Integrated software responds by selecting STO without generating a separate message. This internal STO selection is displayed in parameter r9772.19.

---

## 4.2.3 Restrictions for Safety Integrated Functions "without encoder"

### Basic Functions

The Basic Functions are available without any restrictions in all control modes, with and without an encoder, for synchronous, induction, and reluctance motors.

A safety-related encoder is not required for Basic Functions.

The Safety Integrated functions "without encoder" are also permitted for group drives (several motors connected to one power unit).

### Extended Functions

Extended Functions SS1, SLS, SDI and SSM "without encoder" do not require safety-related speed actual value sensing. If an encoder is used for the drive control, this has no influence on the sensorless safety functions. They can be used with induction motors in all control modes, as well as with SIEMOSYN synchronous motors with U/f control.

The Safety Integrated functions "without encoder" are also permitted for group drives (several motors connected to one power unit).

---

### Note

#### The slip of an induction motor must be taken into account

For Safety Integrated without encoder (depending on the drive load), as a result of slip for induction motors (deviations between electrical and mechanical speed), deviations can occur between the safely determined electrical speed and the mechanical speed at the motor shaft.

---

When using Extended Functions, observe the following restrictions.

### Inadmissible operating modes for Safety Integrated Functions "without encoder"

- No operation with SINAMICS Hydraulic Drive (HLA)
  - Current controller clock cycles 31.25  $\mu$ s and 62.5  $\mu$ s (for Double Motor Modules with two configured safety drives) are not permissible.
  - For the independent setting of current controller clock cycle and pulse frequency in conjunction with Safety Integrated "without encoder", the following system clock cycles are not permitted:
    - Double Motor Module: <125  $\mu$ s
    - All other components: <62.5  $\mu$ s
    - p9589 must be set = 3300 to allow the current controller clock cycle and pulse frequency to be independently set.
  - For chassis format devices, the following also applies:
    - For chassis format devices, operation without encoder is only permissible for induction motors, however **not** for synchronous motors.
    - No operation involving parallel connections
    - Optimized pulse patterns cannot be selected for SIMOTICS FD
    - Only using parameter p1810 = factory setting, this includes:
      - No wobbling
      - No fine setting of the pulse frequency
  - No "shaft generator" functionality
  - Induction motors up to 1000 kW
- On very large machines, it may also be necessary to adjust the parameter p9585.

### Critical operating modes for Safety Integrated Functions "without encoder"

When the safety functions are deactivated, the following technology functions are not negatively influenced.

When using the following operating modes with the Safety Integrated functions activated without encoder, this can result in errors in the encoderless safe actual value sensing (see messages C01711, C30711 with fault values 1040 ff.).

Safe, encoderless actual value sensing is based on the measurement of current and voltage variables, which can influence the following functions. **This does not result in unsafe states.** However, this fault can be expected to have a negative impact on availability.

---

#### Note

##### Irregular operating states

Note that in irregular operating states (e.g. "stalled motor"), the converter can fail with safety faults. However, under no circumstances is an unsafe state reached.

---

- Current limiting of the power unit

When the current limitation of the power unit responds, a fault of the encoderless safe actual value acquisition and a consequent stop response can be expected.

---

**Note**

When engineering the drive and when the parameterizing the current and torque limits, it must be ensured that the power unit current limiting does not respond.

---

- Operation with pulling loads

It is not permissible that the converter is forced into regenerative operation as a result of external forces.

---

**Note**

If a coupled drive comprises an electric drive that motors and one that regenerates (e.g. a test stand), and the speeds of both drives are safely monitored, safety functions without encoder can be used. This is because in the case of a fault, the motoring drive recognizes when a limit value is violated. If, in this example, the motoring drive is an internal combustion engine, which is not safely monitored, then it is not permissible to use safety functions without encoder for the braking drive.

Winders with a motoring and a braking drive can be assessed in the same way (both drives are monitored).

---

- Motor data identification

When using the measuring functions (stationary and rotating measurement) to determine the motor data, then it can be assumed that the encoderless safe actual value sensing will have an error.

---

**Note**

The motor data identification should always be performed before commissioning the Safety Integrated Functions.

---

- Data set switchover

The motor and drive data switchover can always be used for safety functions without encoder. It is not possible to switch over between induction and synchronous motors (this is interlocked). For several motor data sets it must be ensured that all motors have the same number of pole pairs. If the number of pole pairs in r0313 is not the same value that was taken into account when configuring the safe actual value sensing (gearbox), then the calculated, safe actual speed no longer corresponds to the mechanical speed of the shaft.

**When SLS is activated, the shaft can rotate faster than the configured limits.**

- Alternating acceleration/deceleration

For alternating acceleration and deceleration, it must be ensured that the following conditions are maintained.

- Within 1 s, only one acceleration and one braking ramp are permitted.

Therefore, for a cycle  $0 \rightarrow +n_{\text{set}} \rightarrow -n_{\text{set}} \rightarrow 0$  – one period of at least 2 s is required.

- This also applies to positioning operation; it may be necessary that the position control settings and traversing profiles must be adapted so that no overshoots occur in the speed characteristic (e.g. reduce the dynamic response, use flatter braking ramps).

- Flying restart

A flying restart should not be performed in operation with the Safety Integrated Functions active.

---

#### Note

If you must use this function, then before the flying restart, you can deactivate the Safety Integrated Functions, and then reactivate them again after the flying restart has been completed.

**In this case, the user must check as to whether it is permissible that the safety functions are deactivated during the flying restart.**

**It is only permissible to activate and deactivate Safety Integrated Functions using fail-safe signals.**

---

- DC brake

When using this function, DC current is impressed to brake the drive: This can result in a fault of the encoderless safe actual value acquisition and a consequent stop response.

---

#### Note

If you must use this function, then before braking, you can deactivate the Safety Integrated Functions, and then reactivate them again after braking has been completed.

**In this case, the user must check as to whether it is permissible that the safety functions are deactivated during braking.**

**It is only permissible to activate and deactivate Safety Integrated Functions using fail-safe signals.**

---

## Recommendations for stable operation with active Extended Functions without encoder

The following preconditions must be fulfilled to avoid fault messages from the safe actual value sensing without encoder:

- The motor and the power unit are adequately dimensioned for this application.
- Motor and power unit should fulfill the following condition: The ratio between the rated power unit current (r0207[0]) and rated motor current (p0305) should be less than 5.
- Before commissioning the safety functions, we recommend that the motor data are identified at standstill and a rotating measurement is carried out.
- For the basic commissioning, i.e. before the safety commissioning, the closed-loop control should be optimally set. The following effects should be avoided:
  - speed overshoots
  - current peaks and/or discontinuous/unsteady current actual value over time
  - voltage peaks and/or discontinuous/unsteady voltage actual value over time
  - the lowest possible amount of noise in the current and voltage

### Safety Integrated Extended Functions without encoder for Control Unit Adapter CUA31 and CUA32

In the case of the control unit adapters CUA31 and CUA32, the Safety Integrated Extended Functions without encoder with SINAMICS firmware version 4.5 (or higher) are available as follows:

Control Unit Adapter	Article number	Safety Integrated without encoder SINAMICS firmware version 4.5 (or higher)	
		Not available for	Available for
CUA31	6SL3040-0PA01-0AA1	Version (function states) A, B and C	Version D or newer
CUA32	6SL3040-0PA01-0AA0	Version (function states) A and B	Version C or newer

#### 4.2.4 Safe Torque Off (STO)

For the control options and the functionality for "Safe Torque Off" (STO), see Section "Safe Torque Off (STO) (Page 62)".

## 4.2.5 Safe Stop 1 (SS1)

### 4.2.5.1 Safe Stop 1 with encoder

For function SS1 of the Extended Safety Functions, braking monitoring is included.

- **If p9506 = 0:**

Braking is monitored with the "Safe Acceleration Monitor" function (see Chapter "Safe Acceleration Monitor (SAM) (Page 142)").

In this case, we also talk about "SS1 (time and acceleration controlled)".

- **If p9506 = 2:**

Here, also for SS1, the monitoring function "Safe Brake Ramp" is active (see Chapter "Safe Brake Ramp (SBR) (Page 144)").

In this case, we also talk about "SS1 (speed controlled)".

The "Safe Stop 1" (SS1) function allows the drive to be stopped according to EN 60204-1, Stop Category 1. The drive brakes with the OFF3 ramp (p1135) once "Safe Stop 1" is selected and switches to "Safe Torque Off" (STO) once the delay time has elapsed (p9556) or when the shutdown speed is fallen below (p9560).

### Functional features of Safe Stop 1 with encoder

- The delay time starts after the function has been selected. If SS1 is deselected within this time, after the delay time has elapsed or after the velocity has fallen below the shutdown speed, the STO function is selected and deselected again immediately; i.e. the SS1 function is ended completely normally. It cannot be interrupted.
- Selection and monitoring of the acceleration (SAM) or the monitoring function "Safe Brake Ramp" are implemented in two channels, but braking along the OFF3 ramp is only implemented in one channel.

---

#### Note

##### Interrupting the ramp function with OFF2 by the higher-level controller

Activating SS1 can mean that the higher-level controller (PLC, motion controller), which specifies the speed setpoint, interrupts the ramp function (e.g. with OFF2). The device behaves in this way as a result of a fault reaction triggered by OFF3 activation. This fault reaction must be avoided by assigning appropriate parameters or configurations.

---

#### Note

##### No OFF2 with SS1 and EPOS

If you use SS1 together with EPOS, the fault reaction to F07490 (EPOS: enable withdrawn while traversing) OFF2 is not permitted. The response to this error message (OFF1, OFF2 or OFF3) can be configured via p2100/p2101.

---

## Commissioning

The delay time (SS1 time) is set by entering parameter p9556. The wait time until safe pulse suppression (STO) can be shortened by specifying a shutdown speed in p9560.

To enable the drive to brake to standstill after selection, the time in p9556 must be selected to be large enough for the drive to be able to brake along the OFF3 ramp (p1135) from any speed of the work process to below the shutdown speed (p9560).

---

### Note

#### Setting the delay time

To enable the drive to travel the entire OFF3 ramp and close any existing motor holding brake, you must set the delay time as follows:

- Motor holding brake parameterized: Delay time  $\geq$  p1135 + p1228 + p1217
  - Motor holding brake not parameterized: Delay time  $\geq$  p1135 + p1228
- 

The shutdown speed defined in p9560 must be set in such a way that coasting down (due to the subsequent STO function) does not represent any risk for man and machine.

## Responses: System error

1. STOP F with subsequent STOP B, followed by STOP A
2. Safety message C01711

## Status for "Safe Stop 1"

The status of the "Safe Stop 1" function is displayed using the following parameters:

- r9722.1 CO/BO: SI Motion drive-integrated status signals, SS1 active
- r9722.0 CO/BO: SI Motion drive-integrated status signals, STO or safe pulse suppression active



### 4.2.5.2 Safe Stop 1 without encoder

Two encoderless Safe Stop 1 (SS1) monitoring functions can be set with parameter p9506:

- p9506 = 3: Safe monitoring of acceleration (SAM) / delay time

The function is identical to "Safe Stop 1" with encoder, which was described in the previous section.

In this case, we also talk about "SS1 (time and acceleration controlled)".

- p9506 = 1: Safe brake ramp monitoring (SBR)

In this case, there is no SS1 delay time active. The transition from SS1 to STO depends entirely on the speed falling below the shutdown speed (p9560). You will find more information on the function "Safe Brake Ramp (SBR)" in Chapter "Safe Brake Ramp (SBR) (Page 144)." In this case, we also talk about "SS1 (speed controlled)".




Image 4-3 Sequence for "Safe Stop 1" without encoder with SBR monitoring (p9506 = 1)

### Functional feature of Safe Stop 1 without encoder

- Selection and monitoring of the brake ramp (SBR) or the acceleration (SAM) are implemented in two channels, however braking at the OFF3 ramp is only through one channel.

### 4.2.5.3 Safe Stop 1 with external stop

#### General description

<b>NOTICE</b>
<b>Danger to life due to any axis movement</b> During the delay time (p9652), for "Safe Stop 1 (time-controlled) with external stop," any axis movements are possible. <ul style="list-style-type: none"><li>• If there is a hazard due to unwanted motion in your application, take measures to counter it, for example, by using a brake with safe monitoring. Further information can be found in Section "Safe Brake Control (Page 91)".</li></ul>

With external stop, "Safe Stop 1" basically works exactly as described in the previous Chapters "Safe Stop 1 with encoder (time and acceleration controlled)" and "Safe Stop 1 without encoder (speed controlled)." Note, however, the following differences:

#### Differences between "Safe Stop 1 with OFF3" and "SS1 with external stop"

- In order to activate "Safe Stop 1 with external stop", **additionally** set p9507.3 = 1.
- When SS1 with external stop is selected, the drive is **not** braked along the OFF3 ramp: You are responsible in applying suitable measures to brake the drive. After the delay time has expired (p9556), only STO/SBC are automatically initiated. After the function has been selected, the delay timer runs down - even if the function is deselected during this time. In this case, after the delay time has expired, the STO/SBC function is selected and then again deselected immediately.
- The brake ramp (SBR) and the acceleration (SAM) are not monitored and there is no standstill detection.
- With this configuration, STO becomes active after the SS1 timer p9556 has expired; this also applies if SBR has been configured.
- Further information can be found in Section Stop responses (Page 365).

#### 4.2.5.4 Function diagrams and parameters

##### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2819 SI Extended Functions - SS1, SS2, SOS, internal STOP B, C, D, F

##### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p1135[0...n] OFF3 ramp-down time
- p9501 SI Motion enable safety functions (Control Unit)
- p9506 SI Motion function specification (Control Unit)
- p9560 SI Motion STO shutdown speed (Control Unit)
- r9722.0...31 CO/BO: SI Motion drive-integrated status signals

##### Only for SS1 (Extended Functions) with external stop

- p9507 SI Motion function configuration (Control Unit)

#### 4.2.6 Safe Brake Control (SBC)

For the control options and the functionality for "Safe Brake Control" (STO), see Section "Safe Brake Control (SBC) (Page 71)".

---

**Note****No SBC for SINAMICS HLA**

SINAMICS HLA does not support Safe Brake Control.

---

### 4.2.7 Safe Operating Stop (SOS)

This function serves for fail-safe monitoring of the standstill position of a drive.

 **WARNING**

**Danger to life: Drive can be forced out of the SOS position by mechanical forces**

Mechanical forces greater than the maximum drive torque may force a drive currently operated in the position control mode out of the Safe Operating Stop (SOS) and trigger stop function category 1 according to EN 60204-1 (fault response function STOP B).

- If there is a hazard due to unwanted movement in your application, take measures to counter it, for example, by using a brake with safe monitoring. For further information, see Chapter "Safe Brake Control (SBC) (Page 71)."

**Note**

**SOS only with encoder**

In particular, the motor is energized while the SOS function is performing position control.

- Ensure that the motor cannot be touched while it is in the SOS state.

Drive stopping is monitored using an SOS tolerance window (p9530).

**Note**

**Size of the tolerance window**

The size of the tolerance window should be slightly above the standard standstill monitoring limit, otherwise the standard monitoring functions will no longer be effective.

Parameter r9731 displays the safe position accuracy (load side) that can be achieved as a maximum, based on the acquisition of the actual value for the safe motion monitoring functions.

STOP B is the stop response after the standstill tolerance window has been violated.

The SOS function comes into effect in the following cases:

- After SOS is selected and the delay time in p9551 has elapsed  
The drive must be braked to standstill within this delay time (e.g. by the controller).
- As a consequence of SS2
- As a consequence of STOP C (corresponds to selection of SS2)
- As a consequence of STOP D (corresponds to selection of SOS)
- As a consequence of STOP E (corresponds to selecting SOS with additional activation of the standard "Extended stop and retract (ESR)" function)

## Responses

- **Standstill tolerance violated in p9530**
  - STOP B with subsequent STOP A
  - Safety message C01707
- **System error**
  - STOP F
  - Safety message C01711

## Function diagrams (see SINAMICS S120/S150 List Manual)

- 2819                      SI Extended Functions - SS1, SS2, SOS, internal STOP B, C, D, F

## Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9501                      SI Motion enable safety functions (Control Unit)
- p9530                      SI Motion standstill tolerance (Control Unit)
- p9551                      SI Motion SLS(SG) switchover/SOS(SBH) delay time (CU)
- r9722.0...31              CO/BO: SI Motion drive-integrated status signals
- r9731                      SI Motion safe positioning accuracy

## 4.2.8 Safe Stop 2 (SS2)

---

### Note

The "Safe Stop 2" (SS2) safety function can only be used with an encoder.

---

The safety function "Safe Stop 2" (SS2) is used to brake the motor of the OFF3 deceleration ramp (p1135) safely with transition after the delay time (p9552) has expired in to the SOS state (see Chapter "Safe Operating Stop (SOS) (Page 92)"). The delay time set must allow the drive to brake to a standstill from every speed of the operating process within this time. The standstill tolerance (p9530) may not be violated after this time.

After braking, the drives remain in speed control mode with the speed setpoint  $n = 0$ . The full torque is available.

The default setpoint (e.g. from the setpoint channel, or from a higher-level controller) remains inhibited as long as SS2 is selected.

During braking, one of the following functions is active:

- **If p9506 = 0:**

Braking is monitored with the "Safe Acceleration Monitor" function (see Chapter "Safe Acceleration Monitor (SAM) (Page 142)").

- **If p9506 = 2:**

Here, also for SS1, the monitoring function "Safe Brake Ramp" is active (see Chapter "Safe Brake Ramp (SBR) (Page 144)").

The selection and monitoring of the acceleration (SAM) are realized through two channels – however, braking along the OFF3 ramp, only through one channel.

### Interruption of the ramp function with OFF2

Activating SS2 can mean that the higher-level controller (PLC, motion controller) which specifies the speed setpoint, interrupts the ramp function (e.g. with OFF2). The device behaves in this way as a result of a fault reaction triggered by OFF3 activation. This fault reaction must be avoided by assigning appropriate parameters or configurations.

## Responses

- **Speed limit violated (SAM):**

- STOP A
- Safety message C01706

- **Standstill tolerance violated in p9530 (SOS):**

- STOP B with subsequent STOP A
- Safety message C01707

- **System fault:**

- STOP F with subsequent STOP A
- Safety message C01711

## Function diagrams (see SINAMICS S120/S150 List Manual)

- 2814 SI Basic Functions - SBC (Safe Brake Control), SBA (Safe Brake Adapter)

## Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p1135[0...n] OFF3 ramp-down time
- p9501 SI Motion enable safety functions (Control Unit)
- p9530 SI Motion standstill tolerance (Control Unit)
- p9548 SI Motion SAM actual speed tolerance (Control Unit)
- p9552 SI Motion transition time STOP C to SOS (SBH) (Control Unit)<sup>1)</sup>
- r9722.0...31 CO/BO: SI Motion drive-integrated status signals

<sup>1)</sup>STOP C corresponds to SS2.

### 4.2.8.1 Interaction with EPOS

Since the function SS2 – with its setpoint-independent braking – is not suitable for use with EPOS, the Safe Operating Stop (SOS) function can be used with delay.

On selection of SOS, the EPOS function "intermediate stop" (p2640 = 0) ensures that EPOS is able to stop the drive in its tracks and then keep it under control in this state before the SOS becomes active. The maximum necessary braking time (from p2573 and p2645) must then be entered in the delay time for SLS/SOS (p9551) with a safety margin: This ensures that the drive is at a standstill before SOS is active.

To do this, proceed as follows:

1. Connect the EPOS function "intermediate stop" (p2640) with the control signal "Deselect SOS" (r9720.3).
2. Enter the maximum necessary EPOS braking time (depending on the values set in p2573 and p2645) with a safety margin (approx. +5%) in the SOS delay time (p9551).


Since the STOP C stop response – with its setpoint-independent braking – is not suitable for use with EPOS, the Safe Operating Stop (SOS) function can be used with delay.

On selection of SOS, the EPOS function "intermediate stop" (p2640 = 0) ensures that EPOS is able to stop the drive in its tracks and then keep it under control in this state before the SOS becomes active. The maximum required braking time (from p2573 and p2645) must then be entered in the "Transition time STOP D to SOS" (p9553) with a small safety margin: This ensures that the drive is at a standstill before SOS is active.

To do this, proceed as follows:

1. Parameterize "STOP D" as stop response.
2. Connect the EPOS function "intermediate stop" (p2640) with the control signal "Deselect SOS" (r9720.3).
3. Enter the maximum required EPOS braking time (depending on the values set in p2573 and p2645) with a safety margin (approx. +5%) in the "Transition time STOP D to SOS" (p9553).

## 4.2.8.2 SS2 with external stop (SS2E)

 <b>WARNING</b>
<p><b>Danger to life through unexpected axis movement</b></p> <p>When function "Safe Stop 2 with external stop" (SS2E) is active, during the delay time (p9553) the speed follows the setpoint issued from the higher-level control system. As a consequence, unexpected axis motion is possible, which can lead to severe injury and death.</p> <ul style="list-style-type: none"> <li>• During delay time (p9553), avoid that persons enter the hazardous area of the machine or system, e.g. by keeping protective equipment closed.</li> </ul>




Image 4-4 Selecting function SS2E

With external stop, "Safe Stop 2" functions in principle exactly the same way as described in the previous sections. Note, however, the following differences:

#### Differences between "Safe Stop 2 with OFF3" and "SS2 with external stop (SS2E)"

- When SS2 is selected with external stop, the drive does not automatically brake the motor, but instead, follows the specified speed setpoint.
- During delay time p9553, the brake ramp (SBR) and the acceleration (SAM) are not monitored and there is no standstill detection.
- SOS becomes active after the delay time p9553 expires.

When function SS2E is active, the higher-level control must issue the speed setpoint so that at the latest after delay time p9553 expires, the motor has come to a complete standstill.

- In order to activate "Safe Stop 2 with external stop", set p9501.18 = 1.
- PROFIsafe STW2.28 selects function SS2E. PROFIsafe STW2.28 is included in telegrams 30, 901 and 902.
- PROFIsafe ZSW2.28 indicates whether function SS2E is active. PROFIsafe ZSW2.28 is included in telegrams 30, 901 and 902. The associated diagnostics parameter is r9722.28.

In the "Safety Info Channel", status word S\_ZSW3B.11 indicates whether function SS2E is active. The associated diagnostics parameter is r10234.11.

Diagnostic parameters p9722.28 and p10234.11 are also set during an internal STOP D.



For additional information, see Section "Safety faults (Page 365)".

### Deselecting function SS2E while SS2E is active




Image 4-5 Deselecting function SS2E while SS2E is active

After the function has been selected, the delay time starts to expire - even if the function is deselected during this time. In this case, after the delay time has expired, the SOS function is briefly active. Afterwards, the drive may accelerate the motor back to the speed setpoint.

### Interruption of the active SS2E function by functions SS1 and SS2




Image 4-6 Interruption of function SS2E by functions SS1 (shown at the left) and SS2 (shown at the right)

When selecting SS1, the drive brakes the motor along the OFF3 ramp and monitors the speed using the SAM function. Function STO becomes active when the motor is at a standstill.

When selecting SS2, the drive also brakes the motor along the OFF3 ramp and monitors the speed using the SAM function. Function SOS becomes active after time p9552.

### 4.2.8.3 Overview of important parameters

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p2573 EPOS maximum delay
- p2594 CI: EPOS maximum speed, externally limited
- p2640 BI: EPOS intermediate stop (0 signal)
- p2645 CI: EPOS direct setpoint input/MDI, deceleration override
- p9551 SI Motion SLS(SG) switchover/SOS(SBH) delay time (CU)
- p9552 SI motion transition time STOP C to SOS (SBH) (Control Unit)
- p9553 SI motion transition time STOP D to SOS (SBH) (Control Unit)
- r9720.0...27 CO/BO: SI Motion drive-integrated control signals
- r9733[0...2] CO: SI Motion speed setpoint limit active

## 4.2.9 Safely-Limited Speed (SLS)

The Safely Limited Speed (SLS) function is used to protect a drive against unintentionally high speeds in both directions of rotation. This is achieved by monitoring the current drive speed up to a speed limit.

Safely Limited Speed prevents a parameterized speed limit from being exceeded. Limits must be specified based on results of the risk analysis. Up to four different SLS speed limits can be parameterized using parameter p9531[0..3]; it is possible to switch between them even if the SLS is activated.

An override can also be added to SLS limit value 1. In operation, this override can be varied using a PROFIsafe telegram.

---

### Note

#### Deviation of the displayed speed limit

The SLS speed limit displayed in r9714[2] can deviate slightly from the specified SLS speed limit. The reason for this is the internal resolution (r9732) of the speed values.

---

### Note

#### Response in the event of a communication error

If p9580  $\neq$  0 and SLS is active, in the event of communication failure, the parameterized ESR reaction is only realized if, as SLS response, a STOP with delayed pulse cancellation when the bus fails has been parameterized (p9563[0...3]  $\geq$  10).

---

### Note

#### Setpoint speed limit and SLS

- It makes sense to configure the set velocity limit if SLS is also parameterized. This is done in a higher-level controller that evaluates the safety information channel, for example, or by wiring r9733[0/1] to the speed limits of the ramp-function generator (p1051/p1052).
  - It does not make sense to use the positive and negative setpoint limiting for SLS in conjunction with standard telegram 105 and others: With this combination, the velocity setpoint of the standard telegram is only effective after the setpoint limiting.
-

### 4.2.9.1 Safely Limited Speed (SLS)

#### Features


- When SLS is selected, the monitoring only takes effect after the configured delay time has expired (p9551). Within this time, the actual speed must be below the (selected) limit. The delay time is not effective when SLS is deselected.
  - After switching to a lower limit value (p9531), the actual speed of the drive must have dropped below the new limit within the delay time (p9551). The existing limit remains active during the delay time. The lower limit value becomes active after the delay time expires. This also applies to a reduction of the limit value via PROFIsafe.
  - If the actual speed of the drive is higher than the new Safely Limited Speed limit after the delay time has elapsed, a message is generated with the parameterized stop response.
  - The stop response (STOP A, STOP B, STOP C, STOP D or STOP E) is parameterized with p9563.
  - During changeover to a higher limit value, the delay time is not active and the high limit value becomes immediately active. This also applies to increasing the limit value via PROFIsafe.
  - 4 parameterizable limit values p9531[0...3]
  - The first limit value can be entered via the PROFIsafe telegrams 901 and 902 (for p9501.24 = 1)
  - In parameter p9533 enter the weighting factor to determine the setpoint limit from the selected actual speed limit in percent. The active limit value is evaluated using this factor, and is provided as setpoint limit in r9733.
    - $r9733[0] = p9531[x] \times p9533$  (converted from the load to the motor side)
    - $r9733[1] = - p9531[x] \times p9533$  (converted from the load to the motor side)[x] = selected SLS stage
- Conversion factor from the motor to the load side:
- Motor type = rotary and axis type = linear:  $p9522/(p9521 \times p9520)$
  - Otherwise:  $p9522/p9521$
- Limit value
    - $r9733[0] = p9531[x] \times p9533$ ; x = selected SLS limit value
    - $r9733[1] = - p9531[x] \times p9533$ ; x = selected SLS limit valuer9733 is used, for example, for transferring values to a higher-level controller, which can then, for example, adjust traversing speeds to the SLS levels or at the setpoint channel (p1051). r9733 is a part of the Safety Info Channel (SIC).
  - The currently monitored limit value is displayed in parameter r9714[2].

## Changeover of SLS limit values

The changeover is executed binary-coded via 2 F-DIs or 2 PROFIsafe control bits. The speed selection status can be checked using parameters r9720.9/r9720.10. Parameters r9722.9 and r9722.10 indicate the actual speed limit, bit r9722.4 must carry a "1" signal.

Table 4- 2 Changeover of speed limits:

F-DI for bit 1 (r9720.10)	F-DI for bit 0 (r9720.9)	Speed limit	SLS level
0	0	p9531[0]	1
0	1	p9531[1]	2
1	0	p9531[2]	3
1	1	p9531[3]	4

 <b>WARNING</b>
<b>Danger to life due to high speed with defective control of the safely-limited speed limits via F-DI</b>
For all control options except PROFIsafe, limit SLS1 is activated after 2 unacknowledged discrepancy errors. This means that, for the 2 F-DIs for selecting the speed levels, the value 0 is the "safe state" (failsafe value).
<ul style="list-style-type: none"> <li>Therefore parametrize the SLS limits in ascending order, i.e. with limit SLS1 as the lowest speed and limit SLS4 as the highest speed.</li> </ul>

## Responses

### Speed limit value exceeded:

- Configured subsequent stop STOP A/B/C/D/E via p9563
- Safety message C01714

### System fault:

- STOP F
- Safety messages C01711

### Transferring the first limit value via PROFIsafe

SINAMICS offers the option of influencing the first SLS limit value via PROFIsafe:

- The transfer of the first SLS limit value via PROFIsafe is active if the speed level 1 in the PROFIsafe telegram is selected and the bit "Enable transfer SLS (SG) limit via PROFIsafe" (p9501.24) is set.
- S\_SLS\_LIMIT\_A has the value range 1 ... 32767; the following applies:
  - 32767  $\triangleq$  100 % of the 1st SLS level
  - The actually monitored limit value is calculated as follows:  
$$\text{SLS limit value} = (\text{S\_SLS\_LIMIT\_A}/32767) \times \text{p9531}[0]$$
- Also in this case, speed levels 2, 3 and 4 can be parameterized and selected.
- In operation, the selected delay time cannot be changed. If you require various delay times in your application, then you must realize this using a time-delayed transfer of the SLS limit value using your control system (F-CPU).
- If an incorrect SLS limit value is transferred, then the converter responds with the stop response of speed level 1 parameterized in p9563 and the safety message C01711(1041).

## 4.2.9.2 Safely Limited Speed without encoder

### Functions

2 different encoderless Safely Limited Speed monitoring functions can be set with parameter p9506:

- p9506 = 3: Safe monitoring of acceleration (SAM) / delay time  
The function is identical to "Safely Limited Speed with encoder" which was described in the previous section.
- p9506 = 1: Safe brake ramp monitoring (SBR)

---

#### Note

#### Defaults

- For commissioning, also pay attention to the description in Chapter "Default settings for commissioning Safety Integrated functions without encoder (Page 232)."
  - Information about setting the SBR monitoring function can be found in Chapter "Safe Brake Ramp (SBR) (Page 144)".
- 

### Monitoring the brake ramp

- If the speed setpoint limitation (r9733) was connected to the setpoint channel (p1051/p1052) and then SLS was selected – or if you change over to a lower SLS level – the motor is decelerated from the actual speed to below the value defined with r9733 along the OFF3 ramp. In this case, the drive may no longer follow the setpoint of the higher-level motion controller.
- Parameter p9582 is used to set the delay time for the braking ramp monitoring.
- Monitoring of the brake ramp is activated once the delay time in p9582 has elapsed. If the actual speed of the drive violates the brake ramp (SBR) during braking, safety message C01706 is output and the drive is stopped with STOP A.
- The newly selected SLS limit value is also taken over as the new limit speed, if either
  - The SBR ramp has reached the new SLS limit value, or
  - The actual speed of the drive was below the new SLS limit value for at least the time set in p9582.
- The "Safely Limited Speed without encoder" function then monitors whether the actual speed remains below the newly selected SLS limit value.
- The parameterized stop response (p9563[x]) is triggered if the SLS limit value is exceeded.

### Configuring the limits

- The speed limits for Safely Limited Speed without encoder are configured in exactly the same way as described for Safely Limited Speed with encoder.
- Only STOP A and STOP B may be configured as stop responses for "Safely Limited Speed" (SLS) without encoder.

### Restart after OFF2/STO

If the drive has been switched off via STO, the following steps need to be carried out before a restart can be performed:

1st case	<ul style="list-style-type: none"> <li>State after switching on</li> </ul>	
		<ul style="list-style-type: none"> <li>SLS selected</li> </ul>
		<ul style="list-style-type: none"> <li>STO selected</li> </ul>
		<ul style="list-style-type: none"> <li>Pulse suppression active</li> </ul>
	<ul style="list-style-type: none"> <li>Deselect STO</li> </ul>	
<ul style="list-style-type: none"> <li>The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.</li> </ul>		
2nd case	<ul style="list-style-type: none"> <li>Situation</li> </ul>	
		<ul style="list-style-type: none"> <li>Traversing to standstill with SLS selected</li> </ul>
		<ul style="list-style-type: none"> <li>OFF1 is initiated, pulse cancellation becomes active (internal selection STO)</li> </ul>
	<ul style="list-style-type: none"> <li>Select STO</li> </ul>	
	<ul style="list-style-type: none"> <li>Deselect STO</li> </ul> <p>STO activated internally via pulse suppression: This activation must be undone by selection/deselection.</p>	
<ul style="list-style-type: none"> <li>The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.</li> </ul>		
3rd case	<ul style="list-style-type: none"> <li>Situation</li> </ul>	
		<ul style="list-style-type: none"> <li>Traversing to standstill with SLS selected</li> </ul>
		<ul style="list-style-type: none"> <li>OFF1 is initiated, pulse cancellation becomes active (internal selection STO)</li> </ul>
	<ul style="list-style-type: none"> <li>Deselect SLS</li> </ul> <p>STO activated internally via pulse suppression: This activation must be undone by selecting/deselecting SLS.</p>	
	<ul style="list-style-type: none"> <li>Select SLS</li> </ul> <p>The drive enable must be issued with a positive edge at OFF1 within 5 seconds, otherwise STO is reactivated.</p>	
4th case	<ul style="list-style-type: none"> <li>Situation</li> </ul>	
		<ul style="list-style-type: none"> <li>All Safety Integrated functions are deselected.</li> </ul>
	<ul style="list-style-type: none"> <li>After this the drive enable must be given by a positive edge at OFF1.</li> </ul>	
	<ul style="list-style-type: none"> <li>In this case, the motor is not started safely.</li> </ul>	



### 4.2.9.3 Safely-Limited Speed without selection

#### Differences between Safely Limited Speed with and without selection

- As an alternative to controlling via terminals and/or PROFIsafe, there is also the option to parameterize the SLS function without selection (see Motion monitoring without selection (Page 205)).
- The function "SLS without selection" is selected with  $p9512.4 = 1$ .
- For "SLS without selection", only one SLS limit value can be parameterized ( $p9531[0]$ ).
- The stop response is parameterized with  $p9563[0]$ .
- For Safely Limited Speed without selection there is no delay time. The function is always active (with encoder), or it becomes active when switching on (without encoder).

#### Switching the motor on and off (without encoder)

The time response and diagnostic options are as follows in this SLS version:




Image 4-7 Time response of SLS without selection (example: Switching the motor on and off (without encoder))

"SLS without selection" behaves as follows when switching off and switching on again:

- After switch-off, the motor behaves in accordance with the removed signal (OFF1, OFF2 or OFF3).
- The "safe pulse cancellation" becomes active after the standstill limit is undershot. If a brake has been parameterized, it is also closed.
- After the ON command, the converter cancels the "safe pulse cancellation" state and the start procedure is initiated.
- If the minimum current has not been reached after 5 s, the converter returns into the "safe pulse suppression" state and initiates alarm C01711.

#### 4.2.9.4 Function diagrams and parameters

##### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2820 SI Extended Functions - SLS (Safely-Limited Speed)

##### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501.0 SI Motion enable safety functions (Control Unit)
- p9512 Select SI Motion safety functions without selection (CU)
- p9531[0...3] SI Motion SLS (SG) limits (Control Unit)
- p9551 SI Motion SLS(SG) switchover/SOS(SBH) delay time (CU)
- p9563[0...3] SI Motion SLS (SG)-specific stop response (Control Unit)
- p9580 SI Motion STO delay bus failure (Control Unit)
- p9581 SI Motion braking ramp reference value (Control Unit)
- p9582 SI Motion braking ramp delay time (Control Unit)
- p9583 SI Motion braking ramp monitoring time (Control Unit)
- p9601 SI enable functions integrated in the drive (Control Unit)
- r9707[0...2] CO: SI Motion diagnostics actual position value GX\_XIST1
- r9714[0...2] CO: SI motion diagnostics velocity
- r9720.0...27 CO/BO: SI Motion drive-integrated control signals
- r9721.0...15 CO/BO: SI Motion status signals (Control Unit)
- r9722.0...31 CO/BO: SI Motion drive-integrated status signals (Control Unit)

#### 4.2.9.5 EPOS and safe setpoint velocity limitation

If safe speed monitoring (SLS) or the safe direction motion monitoring (SDI) is also to be used at the same time as the EPOS positioning function, EPOS must be informed about the activated monitoring limits. Otherwise these speed monitoring limits can be violated by the EPOS setpoint input. By monitoring the limit value, if violated, the drive is stopped therefore exiting the intended motion sequence. In this case, the relevant safety faults are output first, and then the sequential faults created by EPOS.

Using parameter r9733, the safety functions offer EPOS setpoint limiting values, which when taken into account, prevent the safety limit value being violated.

In order to prevent a safety limit violation by the EPOS setpoint specification, you must transfer the setpoint limit value (r9733) as follows to the maximum speed setpoint of EPOS (p2594):

- r9733[0] = p2594[1]
- r9733[1] = p2594[2]

In this regard you must set the delay time for SLS/SOS (p9551), so that the relevant safety monitoring function only becomes active after the maximum required time for the speed to be reduced below the limit. This required braking time is determined by the current speed, the jerk limit in p2574 and the maximum delay in p2573.

#### Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p2573 EPOS maximum delay
- p2574 EPOS jerk limitation
- p2593 CI: EPOS LU/revolution LU/mm
- p2594[0...2] CI: EPOS maximum speed, externally limited
- p9551 SI Motion SLS(SG) switchover/SOS(SBH) delay time (CU)
- r9733[0...2] CO: SI Motion speed setpoint limit active

### 4.2.10 Safe Speed Monitor (SSM)

The "Safe Speed Monitor" (SSM) function provides a reliable method for detecting when a speed limit has been fallen below (p9546) in both directions of rotation, e.g. for zero speed detection. A fail-safe output signal is available for further processing.

The function is activated automatically as soon as the Safety Integrated Extended Functions are enabled with parameter  $p9501.0 = 1$  and  $p9546 > 0$ . The SSM function is deactivated with setting  $p9546 = 0$ .

---

#### Note

##### Relationship between SSM and SAM

If 0 is entered for p9568 (SAM shutdown threshold), the speed limit of the SSM function (p9546) is simultaneously the lower limit for the Safe Acceleration Monitor function (SAM).

In this case, the effects of safe acceleration monitoring are therefore restricted if a relatively high SSM velocity limit is set when using the SS1 and SS2 stop functions.

---

#### Note

##### Danger due to unwanted behavior of the STOP F on SSM

A STOP F is indicated by safety message C01711. STOP F only results in the follow-up response STOP B / STOP A if one of the Safety functions is active. If only the SSM function is active, a STOP F cross-checking error does not result in a STOP B / STOP A follow-up response.

- SSM is only valid as an active monitoring function if "Hysteresis and filtering" is parameterized ( $p9501.16 = 1$ ).
- 

#### Note

##### Parameterization of hysteresis and actual value synchronization

You must carefully observe the following rules when parameterizing hysteresis and actual value synchronization:

- If "SSM hysteresis" has been enabled ( $p9501.16 = 1$ ), you must set parameters p9546 and p9547 according to this rule:  
$$p9547 \leq 0.75 \times p9546$$
  - If "Actual value synchronization" has been enabled ( $p9501.3 = 1$ ), you must also observe this rule:  
$$p9549 \leq p9547$$
- 

## Features

- Safe monitoring of the speed limit specified in p9546
- Parameterizable hysteresis via p9547
- Variable PT1 filter via p9545
- Safe output signal
- No stop response

### 4.2.10.1 Safe Speed Monitor with encoder

#### Functional features of "Safe Speed Monitor" with encoder

The parameter p9546 "SI Motion SSM (SGA n < n\_x) speed limit n\_x" is used to set the speed limit. The abbreviation "SGA n < n\_x" indicates the safety function required for determining an output signal when a parameterizable velocity limit has been undershot.

If the speed limit for the SSM feedback signal (n < n\_x) is fallen below, the signal "Safe Speed Monitor feedback signal active" (SGA n < n\_x) is set. When the set threshold value has been undershot, the "Safe Acceleration Monitor" (SAM) function is also deactivated (see p9568). If p9568 = 0, then p9546 (SSM feedback signal) is also used as a minimum threshold for the SAM monitoring.

A hysteresis can be configured for the SSM function via p9547. In this way, a more stable signal characteristic of SSM can be achieved at speeds close to the monitoring threshold (p9546).

When hysteresis is configured, then the velocity (or speed) determined by the two channels may not differ by more than the difference between p9546 and p9547. Otherwise it would be theoretically possible that one channel returns a HIGH signal and the other a LOW signal for SSM.

The following diagram shows the characteristic of the safe output signal SSM when the hysteresis is active:




Image 4-8 Safe output signal for SSM with hysteresis

The output signal for SSM is smoothed by setting a filter time with a PT1 filter (p9545).

*4.2 Safety Integrated Extended Functions*

During safe motion monitoring, the "hysteresis and filtering" functions can be activated or deactivated together using the enable bit p9501.16. In the default setting, the functions are deactivated (p9501.16 = 0).

---

**Note**

**Exception: SSM as an active monitoring function**

If the "hysteresis and filtering" function is enabled, the SSM function is evaluated as an active monitoring function and, after a STOP F, also results in a follow-up response STOP B / STOP A.

---

**Note**

**Time-delayed SSM feedback**

When "hysteresis and filtering" is activated with output signal SSM, a time-delayed SSM feedback signal occurs for the axes. This is a characteristic of the filter.

---

### 4.2.10.2 Safe Speed Monitor without encoder

Set p9506 = 1 or p9506 = 3 (factory setting = 0) to activate Safety Integrated functions without encoder. You can also make this setting by selecting "Without encoder" on the Safety screen in STARTER.

Without an encoder, the "Safe Speed Monitor" essentially functions exactly the same as described in the previous section under "Safe Speed Monitor with encoder".

---

#### Note

#### Defaults

For commissioning, also pay attention to the description in Chapter "Default settings for commissioning Safety Integrated functions without encoder (Page 232)."

---

#### Note

#### Setting of the OFF1 or OFF3 ramp-down time

If the OFF1 or OFF3 ramp-down time is too short or the difference between the SSM limit speed and the shutdown speed is too small, the "speed below limit value" signal may not change to 1, because no actual speed value could be determined below the SSM limit before pulse suppression occurred. In this case, the OFF1 or OFF3 ramp-down time or the margin between SSM speed limit and shutdown speed should be increased.

---

### Differences between Safe Speed Monitor with and without encoder

- For Safe Speed Monitor without encoder, after pulse suppression the drive is unable to determine the current speed. 2 responses can be selected for this operating state with parameters p9509.0:
  - p9509.0 = 1  
The status signal (SSM feedback signal) shows "0" (factory setting).
  - p9509.0 = 0  
The status signal (SSM feedback signal) is frozen. "Safe Torque Off" (STO) is selected internally.
- Due to the less precise speed recognition, "Safe Speed Monitor without encoder" requires a larger hysteresis (p9547) and, where applicable, a filter time (p9545) compared with the function with encoder.

Sequence diagram

The following diagram shows the signal characteristic for the case  $p9509.0 = 0$ .




Image 4-9 Safe Speed Monitor without encoder ( $p9509.0 = 0$ )

The speed remains below the limits of  $p9546$  throughout the entire monitoring period. Therefore, the SSM feedback signal remains  $r9722.15 = 1$ . After the command for pulse suppression, the motor speed drops. The internal STO is set when the speed drops below the zero speed detection level.

In this case, the SSM feedback signal remains HIGH; it is frozen. The drive cannot accelerate again, due to the internal STO selection.

To restart the motor safely, the STO must be selected manually and deselected once more. After the STO has been deselected, a 5 second time window is opened. If the pulse enable takes place within this time window, the motor starts. If the pulse enable does not take place within this 5 second time window, the internal STO becomes active once more.

If  $p9509.0 = 1$ , the SSM monitoring is ended after the pulse suppression. The feedback signal  $p9722.15$  drops to 0. The SSM monitoring is only reactivated after a new pulse enable. In this case, STO must not be selected and deselected to start the drive.



**Restart after pulse cancellation for p9509.0 = 0**

If the drive pulses have been suppressed using OFF1/OFF2/STO, the following steps must be carried out for a restart:

1st Case	• State after switching on	
		• SSM active
		• STO selected
		• Pulse suppression active
	• Deselect STO	
• The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.		
2nd Case	• Situation	
		• SSM active
		• Motor turning
		• OFF1 triggered, pulses are suppressed
	• Select STO	
	• Deselect STO STO activated internally via pulse suppression: This activation must be undone by selecting/deselecting STO.	
• The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.		

### 4.2.10.3 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2823 SI Extended Functions - SSM (Safe Speed Monitor)
- 2840 SI Extended Functions - SI Motion drive-integrated control signals/status signals
- 2905 SI TM54F - Extended Functions control interface (p9601.2 = 1 & p9601.3 = 0)
- 2907 SI TM54F - Extended Functions assignment (F-DO 0 ... F-DO 3)

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501 SI Motion enable safety functions (Control Unit)
- p9506 SI Motion function specification (Control Unit)
- p9509 SI Motion behavior during pulse suppression (Control Unit)
- p9545 SI Motion SSM (SGA n < nx) filter time (Control Unit)
- p9546 SI Motion SSM (SGA n < nx) speed limit (CU)
- p9547 SI Motion SSM (SGA n < nx) speed hysteresis n\_x (CU)
- r9722.0...31 CO/BO: SI Motion drive-integrated status signals (Control Unit)

## 4.2.11 Safe Direction (SDI)

---

### Note

#### Response to bus failure

If  $p9580 \neq 0$  and SDI is active, in the event of communication failure, the parameterized ESR reaction is only realized if, as SDI response, a STOP with delayed pulse cancellation when the bus fails has been parameterized ( $p9566[0...3] \geq 10$ ).

---

### 4.2.11.1 Safe Direction with encoder

The Safe Direction function (SDI) allows reliable monitoring of the direction of motion of the drive. If this function is activated, the drive can only move in the enabled direction.

#### Principle of operation

After SDI has been selected via terminals or PROFIsafe, the delay time  $p9565$  is started. During this time, you have the option of ensuring that the drive is moving in the enabled direction. After this, the Safe Direction function is active and the direction of motion is monitored.

If the drive now moves more than the configured tolerance ( $p9564$ ) in the blocked direction, message C01716 is output and the stop response defined in  $p9566$  is initiated. To acknowledge the messages you must first deselect SDI, remove the fault cause and then safely acknowledge the messages. Only then can you reselect SDI.

#### Features

- Parameters  $r9720.12$  and  $r9720.13$  display whether the SDI function is selected.
- Parameters  $r9722.12$  and  $r9722.13$  display whether the SDI function is active.
- Parameter  $p9564$  are used to set the tolerance within which a movement in a non-enabled (non-safe) direction is tolerated.
- Parameter  $p9566$  define the stop response in the case of a fault.
- For control via TM54F, parameters  $p10030$  and  $p10031$  are used to define the terminals for SDI.
- Parameters  $p10042$  to  $p10045$  are used to define whether the SDI status in the F-DO status display of the TM54F is taken into account.
- If "SDI positive" is selected, the following value is set automatically:
  - $r9733[1] = 0$  (setpoint limitation negative)
- If "SDI "negative" is selected, the following value is set automatically:
  - $r9733[0] = 0$  (setpoint limitation positive)
- The absolute setpoint speed limit is available in  $r9733[2]$ .

### Enabling the Safe Direction function

The "Safe Direction" function is enabled with  $p9501.17 = 1$ .




Image 4-10 Functional principle SDI with encoder

### 4.2.11.2 Safe Direction without encoder

Set p9506 = 1 or p9506 = 3 (factory setting = 0) to activate Safety Integrated functions without encoder. You can also make this setting by selecting "Without encoder" on the STARTER safety screen.

---

#### Note

#### Defaults

For commissioning, also pay attention to the description in Chapter "Default settings for commissioning Safety Integrated functions without encoder (Page 232)."

---

### Differences between SDI with encoder and SDI without encoder

- For Safe Direction without encoder, after pulse suppression the drive is unable to determine the current speed. For this operating state, the behavior is defined using parameter p9509.8:
  - p9509.8 = 1  
The status signal displays "inactive".
  - p9509.8 = 0  
The status signal displays "active", and the drive takes on the state STO.
- Due to the less precise position recognition, "Safe Direction without encoder" requires a larger tolerance (p9564) compared with the function with encoder.

---

#### Note

#### No detection of a change in direction by means of p1820 or p1821

If the direction of rotation is reversed via p1820 or p1821, then safe monitoring is still possible: However, in this case, the setpoint limitation r9733 is calculated with the wrong direction of rotation. A reversal of the rotational direction with p1820 or p1821 therefore does not make sense.

---

### Restart after pulse cancellation for p9509.8 = 0

If the drive has been switched off via OFF1/OFF2/STO etc., the following steps need to be carried out before a restart can be performed:

1. Case	• State after switching on	
		• SDI selected
		• STO selected
		• Pulse suppression active
	• Deselect STO	
• The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.		

2. Case	• Situation	
		• Traversing to standstill with SDI selected
		• Initiate OFF1
		• Pulses are canceled; internal selection STO becomes active
	• Select STO	
• Deselect STO		
STO activated internally via pulse suppression: This activation must be undone by selecting/deselecting STO.		
• The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.		
3. Case	• Situation	
		• Traversing to standstill with SDI selected
		• Initiate OFF1
		• Pulses are canceled; internal selection STO becomes active
	• Deselect SDI	
STO activated internally via pulse suppression: This activation must be undone by deselecting SDI.		
• Select SDI		
The drive enable must be issued within 5 seconds via a positive edge at OFF1, otherwise STO is reactivated.		
4. Case	• Situation	
		• All Safety Integrated functions are deselected.
	• After this the drive enable must be given by a positive edge at OFF1.	
	• In this case, the motor is not started safely.	

When acknowledging SDI with STOP C, you must maintain the following sequence:

1. Correct the incorrect setpoint input.
2. Deselect SDI.

While the safety STOP is active, this ensures that the motor cannot travel in the direction that has not been enabled while the SDI function is deselected.

3. Select SDI again.

The SDI limits are then set again.

4. Cancel the safety STOP as a result of "safe acknowledgment".

### 4.2.11.3 Safe Direction without selection

#### Differences between Safe Direction with and without selection

- As an alternative to controlling via terminals and/or PROFIsafe, there is also the option of parameterizing SDI without selection. In this case, SDI will be permanently active after POWER ON (with encoder) or will be active after switch-on (without encoder).
- The "SDI without selection" function is activated as follows:
  - p9512.12 = 1 (SDI positive (CU) statically selected)
  - p9512.13 = 1 (SDI negative (CU) statically selected)
- The stop response is parameterized with p9566[0].

#### Switching the motor on and off (without encoder)

The time response and diagnostic options are as follows in this SDI version:




Image 4-11 Time response of SDI without selection (example: Switching the motor on and off (without encoder))

"SDI without selection" behaves as follows when switching off and switching on again:

- After switch-off, the motor behaves in accordance with the canceled signal (OFF1, OFF2 or OFF3).
- STO ( $\Delta$  safe pulse cancellation) becomes active after the standstill limit is undershot.
- After the ON command, the converter cancels the "safe pulse suppression" state and the start procedure is initiated.
- If the minimum current has not been reached after 5 seconds, the converter returns to the "safe pulse suppression" state and initiates the safety message C01711(1041).

#### 4.2.11.4 Function diagrams and parameters

##### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2824 SI Extended Functions - SDI (Safe Direction)
- 2840 SI Extended Functions - SI Motion drive-integrated control signals/status signals
- 2905 SI TM54F - Extended Functions control interface (p9601.2 = 1 & p9601.3 = 0)
- 2906 SI TM54F - Extended Functions Safe State selection
- 2907 SI TM54F - Extended Functions assignment (F-DO 0 ... F-DO 3)

##### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p1820[0...n] Reverse the output phase sequence
- p1821[0...n] Direction of rotation
- p9501.17 SI Motion enable safety functions (Control Unit): Enable SDI
- p9506 SI Motion function specification (Control Unit)
- p9509 SI Motion behavior during pulse suppression (Control Unit)
- p9564 SI Motion SDI tolerance (Control Unit)
- p9565 SI Motion SDI delay time (Control Unit)
- p9566 SI Motion SDI stop response (Control Unit)
- p9580 SI Motion STO delay bus failure (Control Unit)
- r9720.0...27 CO/BO: SI Motion drive-integrated control signals
- r9722.0...31 CO/BO: SI Motion drive-integrated status signals (Control Unit)
- r9733[0...2] CO: SI Motion speed setpoint limit active
- p10017 SI Motion digital inputs debounce time (CPU 1)
- p10030[0...3] SI TM54F SDI positive input terminal (CPU 1)
- p10031[0...3] SI TM54F SDI negative input terminal (CPU 1)
- p10039[0...3] SI TM54F Safe State signal selection (CPU 1)
- p10042[0...5] SI TM54F F-DO signal sources (CPU 1)
- p10043[0...5] SI TM54F F-DO 1 signal sources
- p10044[0...5] SI TM54F F-DO 2 signal sources
- p10045[0...5] SI TM54F F-DO 3 signal sources



## 4.2.12 Safely-Limited Position (SLP)

The Safely-Limited Position function (SLP) is used to safely monitor the limits of two traversing or positioning ranges which can be switched over by a safe signal.

### Requirements

For the Safely-Limited Position function, the following requirements must be met:

- The use of one or two suitable encoders for the extended safety functions with encoder (see also Section "Notes regarding safe actual value sensing using an encoder system (Page 147)").
- Determining the absolute position of the drive by referencing during commissioning and after all actions after which a safe absolute reference can no longer be guaranteed (POWER ON, parking)

A description of safe referencing is provided in Section "Safe referencing (Page 127)".

### Principle of operation

As soon as SLP is active, maintaining the limits of the active positioning range is safely monitored. With a safety signal you can switch between 2 position ranges. Each position range is limited by its previously defined limit switch pair. When passing the position of one of the two limit switches, a parameterizable stop response (STOP A, STOP B, STOP C, STOP D or STOP E) is initiated and the messages C01715 are output.

To acknowledge this fault, you can either switch over to a range whose limits have not been violated, or you can deselect the SLP function. After acknowledgment, the drive can then be traversed again in the permissible range.

Traversing in the permissible range can be realized in a safety-related fashion using the "Retract" function (available for TM54F) (see Chapter "Retraction (Page 124)").

### Features

- Selection via safe terminals (TM54F or onboard F-DI) or PROFIsafe
- Definition of the position range using 2 limit switch pairs (p9534 and p9535)
- Safe switchover between 2 different position ranges (not available for PROFIsafe telegram 30)
- Adjustable stop response (p9562)

### Enabling the Safely-Limited Position function

- The "Safety-Limited Position" function is enabled with p9501.1 = 1.
- After the enable, POWER ON at the converter.

---

**Note**

**No actual value synchronization for SLP**

It is not permissible to simultaneously enable the SLP function and the actual value synchronization ( $p9501.3 = 1$ ). In this case, the drive outputs fault F01688.

---

## Control and status signals from the SLP

Selecting SLP and switching over between the position ranges is realized via an F-DI or a PROFIsafe control bit. SLP selection can be checked using parameter  $r9720.6$ . The selected position range can be checked using parameter  $r9720.19$ . Status bit  $r9722.6$  is set if SLP is active. The active position range is displayed by  $r9722.19$ . Maintaining the upper or lower active SLP limit can be checked using  $r9722.30$  and  $r9722.31$ .

---

**Note**

**Jumps in the display**

There is no hysteresis available for  $r9722.30$  and  $r9722.31$ . Small fluctuations in the area around the range limit can result in the display jumping back and forth.

---

## Controlling the Safely-Limited Position function

You have 2 options to select/deselect the Safely-Limited Position function and to switch over the range limits:

- PROFIsafe
  - SLP is selected/deselected using control words  $S\_STW1.6$  or  $S\_STW2.6$ .
  - Switchover between the two limit switch pairs using control word  $S\_STW2.19$ .
  - $S\_ZSW2.23$  indicates whether the actual position is "safe"; for instance, the bit is only set after the axis was "safely referenced".
  - Whether SLP is active is indicated in bit 6 of the status words  $S\_ZSW1.6$  or  $S\_ZSW2.6$ . The bit is not set until SLP is selected and the axis is in the "safely referenced" state.
  - Which SLP limit switch pair is active is indicated in status word  $S\_ZSW2.19$ . This indication is only valid if SLP is itself active.
  - $S\_ZSW2.30$  and  $S\_ZSW2.31$  indicate whether the upper or lower limit of the active position range is maintained.

**Note****Extended Functions via PROFIsafe**

The status signal "SLP active" (S\_ZSW1.6 or S\_ZSW2.6) is not the same as the diagnostic signal "SLP active" (r9722.6), but is the AND logic operation of "SLP active" (r9722.6) and "safely referenced" (r9722.23).

The other SLP status signals S\_ZSW2.19 "SLP active position range", S\_ZSW2.30 "upper SLP limit maintained" and S\_ZSW2.31 "lower SLP limit maintained" match the corresponding bits in r9722.

---

**Note****Restrictions for PROFIsafe telegram 30**

The use of PROFIsafe telegram 30 (with the 16-bit words S\_STW1 and S\_ZSW1) has the following restrictions:

- Only position range 1 is available.
  - A switchover to position range 2 is not possible.
  - The status feedback signals "safely referenced", "active position range", "upper SLP limit maintained" and "lower SLP limit maintained" are not available.
- 

- F-DI

The function can be selected via the F-DI of the TM54F or via onboard F-DI (CU310-2):

- Parameter p10032 is used to predefine the terminal for the safely limited position selection.
  - The terminals to select the SLP position range are defined using parameters p10033.
  - The status signal "SLP active" can be used directly as signal source, or linked via the safe state signal (p10039) with an F-DO (p10042).
- 

**Note****Extended Functions via TM54F or onboard terminals**

The safe status signal "SLP active" is not the same as the diagnostic signal "SLP active" (r9722.6), but is the AND logic operation of "SLP active" (r9722.6) and "safely referenced" (r9722.23).

On the other hand, the status signal "Active SLP area" corresponds to the signal "SLP active position range" (r9722.19 ).

---

**Note****Response to bus failure**

If p9580  $\neq$  0 and SLP is active, in the event of communication failure the parameterized ESR reaction is only realized if, as an SLP response, a STOP with delayed pulse suppression when the bus fails has been parameterized (p9562[0...1]  $\geq$  10).

---

### 4.2.12.1 Retraction

After a limit of the active traversing range has been exceeded, the drive must be brought back to the permissible range. A safety acknowledgment would, in this case, only retrigger the safety messages; the drive would be prevented from moving. If a switchover to the other traversing range doesn't come into question, then the only thing that remains is to deselect SLP. However, this would have the disadvantage that it is not monitored as to whether the drive is moving in the direction of the permissible traversing range.

Therefore, it is recommended that a retract function is implemented as follows:

#### Safety commissioning

1. Completely parameterize SLP.
2. Completely parameterize SDI.
3. Perform an acceptance test for both functions.

The next steps differ depending on the control type.

#### Control via PROFIsafe

- Implement a user program in your F-CPU with the following steps to implement a retract function:
  - Select SDI positive in the case that the lower SLP limit is violated, or SDI negative if the upper SLP limit is violated
  - Wait until the selected SDI is active, then deselect SLP
  - Safe acknowledgment of the limit violation
  - Movement of the drive with suitable setpoint inputs into the range that has been enabled
  - Select SLP
  - Wait until SLP is active, then deselect SDI
- Proceed as follows for an SLP limit violation:
  - Activate this program for retraction, for example, using an F-DI of the F-CPU

---

#### Note

##### FAQ retraction

You will find a description of how retraction can be implemented via a fail-safe control and PROFIsafe communication in the Internet at:

<http://support.automation.siemens.com/WWW/view/de/65128501>

---

### Control via F-DI (TM54F or onboard terminals)

1. Using parameters p10009, parameterize an F-DI, with which you can select/deselect the internal retract logic function.
2. Parameterize two F-DIs for the selection/deselection of the SDI positive and SDI negative functions in an independent acceptance test.
3. Proceed as follows for an SLP limit violation:
  - Switch the signal at the F-DI "retract" from 0 to 1 (the signal edge is evaluated). The retract function is active at all drives that are safely referenced and where presently a limit value has been violated. When the retract function is active, SLP is inactive and depending on which limit which has been violated, either SDI positive or SDI negative is selected.
  - Safe acknowledgment of the limit violation
  - Move the drive into the range that has been enabled using the appropriate setpoint inputs.
  - Switch the signal at the F-DI "retract" from 1 to 0 (the signal edge is evaluated): As a consequence, SDI is again deselected and SLP is active again.




Image 4-12 Time behavior of SLP and retraction

### 4.2.12.2 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2822 SI Extended Functions - SLP (Safely Limited Position)
- 2840 SI Extended Functions - SI Motion drive-integrated control signals/status signals
- 2893 SI TM54F - Fail-safe digital inputs (F-DI 0 ... F-DI 4)
- 2894 SI TM54F - Fail-safe digital inputs (F-DI 5 ... F-DI 9)
- 2895 SI TM54F - Fail-safe digital outputs (F-DO 0 ... 3), digital inputs (DI 20 ... 23)
- 2905 SI TM54F - Extended Functions control interface (p9601.2 = 1 & p9601.3 = 0)
- 2906 SI TM54F - Extended Functions Safe State selection
- 2907 SI TM54F - Extended Functions assignment (F-DO 0 ... F-DO 3)
- 2870 SI Extended Functions - CU310-2 (F-DI 0 ... F-DI 2)
- 2873 SI Extended Functions - CU310-2 fail-safe digital output (F-DO 0)
- 2875 SI Extended Functions - CU310-2 control interface
- 2876 SI Extended Functions - CU310-2 Safe State selection
- 2877 SI Extended Functions - CU310-2 assignment (F-DO 0)

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501 SI Motion enable safety functions (Control Unit)
- p9534[0...1] SI Motion SLP (SE) upper limit values (Control Unit)
- p9535[0...1] SI Motion SLP (SE) lower limit values (Control Unit)
- p9544 SI Motion actual value comparison tolerance (referencing) (CU)
- p9562[0...1] SI Motion SLP (SE) stop response (Control Unit)
- p10009 SI Motion SLP retraction F-DI (CPU 1)
- p10032[0...3] SI TM54F SLP input terminal (CPU 1)
- p10033[0...3] SI TM54F SLP position range input terminal (CPU 1)
- p10039[0...3] SI TM54F Safe State signal selection (CPU 1)
- p10109 SI Motion SLP retraction F-DI (CPU 2)
- p10132 SI Motion SLP input terminal (CPU 2)
- p10133 SI Motion SLP position range input terminal (CPU 2)
- p10139 SI Motion Safe State signal selection (CPU 2)

### 4.2.13 Safe referencing

The "safe referencing" function allows a safe absolute position to be defined. This safe position is used for the following functions:

- Safely-Limited Position (SLP) (Page 121)
- Transferring safe position values (SP) (Page 129)

#### General description

In most cases, an external control performs referencing to an absolute position. The converter only performs this task in special cases (for example, EPOS).

- Referencing using an external control

Requirement: No movement of the drive

The reference position determined by the control is entered into parameter p9572 and is declared to be valid using p9573 = 89.

- Referencing by EPOS

The SINAMICS EPOS function transfers, when referencing, the determined position directly to Safety Integrated. This can also take place during motion.

- User agreement

The user agreement must be set (p9726 = p9740 = AC hex) within 2 seconds after referencing.

Safety Integrated only evaluates the reference position if this is required by a function that has been enabled (e.g. SLP). Using diagnostics bit r9723.17, Safety Integrated indicates whether the drive has been referenced. Safety Integrated indicates the position of the drive in diagnostic parameters r9708 and r9713. Bit r9722.23 is set when the axis is safely referenced.

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2821 SI Extended Functions - Safe referencing

#### Value range r9708

The diagnostics information in parameter r9708 is displayed with the following properties:

Table 4- 3 Value range and resolution (32 bits)

	Linear axis	Rotary axis
Position values	±737280000	±737280000
Unit	1 µm	0.001 °
Comment	Monitoring ±737.280 m with an accuracy of 1 µm	± 2048 revolutions

What is shown in parameter r9713 is identical to the values of r9708; however, in SINAMICS-internal calculation units.

## Referencing types

SINAMICS distinguishes between 2 types of referencing:

- Initial referencing

For initial safe referencing, or in the event of a fault during a subsequent referencing, the following steps are necessary:

- The reference position determined by the controller is entered in parameter p9572 and is declared to be valid with p9573 = 89. This step is not required for closed-loop position control with EPOS.
- Referencing has been correctly implemented (r9723.17 = 1)
- Confirm the actual position value: Within 2 s, set parameters p9726 = p9740 = AChex  
If both parameters are not set within the 2 seconds, the converter outputs the messages C01711 (value: 1002).

After this "user agreement", the drive is "safely referenced" (r9722.23 = 1)

### No automatic user agreement permitted

Please note that the operator must be capable of assigning the determined position to the real position of the axis before setting the user agreement. This can be performed, for example, by a visual inspection of the axis position. Under no circumstances must these parameters ever be set fully automatically by a control system without agreement by the user. This would only be permitted if the reference position can be safely sensed by means of a safe sensor.

- Subsequent referencing

Subsequent referencing involves referencing with a safety-relevant history (i.e. with an internally buffered user agreement) after a POWER ON or after deselecting "parking axis".

- The position determined by the controller is entered in parameter p9572 and is declared to be valid with p9573 = 89. This step is not required for closed-loop position control with EPOS and use of an absolute encoder.
- After the drive has been referenced, Safety Integrated automatically performs a plausibility check.
- If the deviation between the actual absolute position and the previous standstill position saved from Safety Integrated in the NVRAM is within the tolerance p9544, then the drive goes into the state "safely referenced" (r9722.23 = 1).

## Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9572 SI Motion reference position (Control Unit)
- p9573 Accept SI Motion reference position (Control Unit)
- r9708[0...5] SI Motion diagnostics safe position
- r9713[0...5] CO: SI Motion diagnostics actual position value load side
- r9722.0...31 CO/BO: SI Motion drive integrated status signals (Control Unit)
- r9723.0...17 CO/BO: SI Motion diagnostics signals integrated in the drive
- p9726 SI motion, user agreement, select/deselect
- p9740 SI motion, user agreement, select/deselect MM



#### 4.2.14 Transferring safe position values (SP)

The function "Transfer safe position values (SP)" enables you to transfer a safe position (i.e. absolute or relative position) to the higher-level controller via PROFIsafe. From the position values, the control can calculate, for example, the actual velocity.

##### Enabling the "Transfer safe position values" function

The following steps are required to enable the "Transfer safe position values" function:

- Enable the Safety Integrated Extended Functions
  - p9601 = 12 = C hex ( $\hat{=}$  Extended Functions via PROFIsafe) or
  - p9601 = 13 = D hex ( $\hat{=}$  Extended Functions via PROFIsafe and Basic Functions via onboard terminals)
- Enable "Transfer the safe absolute position with the possibility of calculating the velocity by the controller"
  - Select one of the PROFIsafe telegrams 901 or 902 (p60022, p9611, p9811)
  - p9501.2 = 1 ( $\hat{=}$  enable absolute position)
  - p9501.25 = 1 ( $\hat{=}$  enable transfer of safe position via PROFIsafe)

---

##### Note

##### No actual value synchronization when SP is enabled

If the transfer safe position value function is used, it is not permissible to enable actual value synchronization (p9501.3 = 1): In this case, the drive outputs fault F01688.

---

- Enable the "Transfer safe relative position" only to calculate the speed by the controller
  - Select one of the PROFIsafe telegrams 901 or 902
  - p9501.25 = 1
- After the enable, POWER ON the converter.

##### Principle of operation

After parameter assignment, release and POWER ON, the function is automatically selected and the values transferred. Please observe the following:

- Transfer of safe absolute position values
  - If the transfer of the safe relative position has been enabled through p9501.25 = 1 and p9501.2 = 0, the validity of the safe relative position is displayed by the set bit S\_ZSW2.22.
  - If the transfer of the safe absolute position has been enabled using p9501.25 = 1 and p9501.2 = 1, S\_ZSW2.22 is only set when the drive has also been safely referenced.
- Transfer of safe relative position values (e.g. for calculating the velocity)
  - Only S\_ZSW2.22 (r9722.22, actual position value valid) must be set to calculate the speed.

### Setting the modulo value for rotary axes

- p9505 is used to define the modulo range of a safety rotary axis (p9502 = 1) when the transfer of a safe absolute position (p9501.2 = 1 and p9501.25 = 1) is enabled.  
Parameterizing the modulo value can result in a jump in the position actual value if the range that can be represented overflows. p9505 must therefore only be parameterized in steps of  $2^n \times 360^\circ$  (n = 1, 2, 3, ...). In all other cases, the converter issues alarm A01794. This alarm can be hidden in the case that the possible jump in the position actual value can be tolerated in the particular application – or this does not present a problem.
- The modulo function is deactivated if p9505 = 0. This parameter has no relevance for a safety linear axis (p9502 = 0) or when the transfer of a safe relative position (p9501.2 = 0 and p9501.25 = 1) is enabled.
- If SLP is also enabled (p9501.1 = 1), the modulo function must be deactivated (p9505 = 0).

### Transfer formats and value range

- 32-bit  
The values are transferred in telegram 902 as 32-bit values with the following value ranges:

Table 4- 4 Value range and resolution (32 bits)

	Linear axis	Rotary axis
Position values	$\pm 737280000$	$\pm 737280000$
Unit	1 $\mu\text{m}$	0.001 $^\circ$
Comment	Monitoring $\pm 737.280$ m with an accuracy of 1 $\mu\text{m}$	$\triangleq$ 2048 revolutions

- 16-bit  
To transfer the position values in telegram 901 in the 16-bit format, you must scale the values using p9574. In this case, you must select the scaling factor so that the value of the actual position value does not exceed the 16-bit format. If the actual position value exceeds the range that can be displayed with 16 bits ( $\pm 32767$ ), a STOP F is initiated and message C01711 is output with fault value 7001. Depending on the scaling factor, this means that ranges with different sizes can be monitored with varying accuracy. Example:
  - Scaling factor: 1000
  - Unit: 1  $\mu\text{m}$  (linear axis)
  - Position value:  $\pm 32767$  mm

It may therefore be precisely monitored in a range of  $\pm 32.767$  m to an accuracy of 1 mm.

#### Note

##### Scaling to 16 bits

The scaling is performed by dividing the mean value of r9708[0] and r9708[1] with this scaling factor.

Example: For a position of -29.999 mm signaled in r9708[0] and r9708[1] and a scaling factor of p9574 = 1000, a numerical value of -29 is signaled to the controller.

## Value range r9708

The diagnostics information in parameter r9708 is displayed with the following properties:

Table 4- 5 Value range and resolution (32 bits)

	Linear axis	Rotary axis
Position values	$\pm 737280000$	$\pm 737280000$
Unit	1 $\mu\text{m}$	0.001 °
Comment	Monitoring $\pm 737.280$ m with an accuracy of 1 $\mu\text{m}$	$\pm 2048$ revolutions

What is shown in parameter r9713 is identical to the values of r9708; however, in SINAMICS-internal calculation units.

## Speed calculation

The control must calculate the speed from the position change:

- $\text{Pos diff} = \text{Pos new} - \text{Pos old}$
- $\text{Cycle diff} = \text{cycle counter new} - \text{cycle counter old}$
- $\text{Timediff} = \text{Cyclediff} \times \text{Safetycycle}$   
(If  $\text{Cyclediff} = 0$ , the speed that was last calculated must be used.)
- $v = \text{Pos diff} / \text{time diff}$
- Format v

## Acceptance test

An acceptance test is not required for the "Transfer safe position values" function, but the function that was implemented with the aid of SP must be accepted in the higher-level controller.

## Function diagrams (see SINAMICS S120/S150 List Manual)

- 2840 Extended Functions - SI Motion drive-integrated control signals/status signals
- 2905 SI TM54F - Extended Functions control interface (p9601.2 = 1 & p9601.3 = 0)
- 2906 SI TM54F - Extended Functions Safe State selection
- 2907 SI TM54F - Extended Functions assignment (F-DO 0 ... F-DO 3)

## Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501 SI Motion enable safety functions (Control Unit)
- p9505 SI Motion SP modulo value (Control Unit)
- p9542 SI Motion actual value comparison tolerance (crosswise) (Control Unit)
- p9601 SI enable functions integrated in the drive (Control Unit)
- r9708[0...5] SI Motion diagnostics safe position
- r9713[0...5] CO: SI Motion diagnostics actual position value load side

## 4.2.15 Safe Brake Test (SBT)

---

### Note

#### SBT only with encoder

The "Safe Brake Test" (SBT) safety function can only be used with an encoder.

---

The diagnostic function "Safe Brake Test" function (SBT) checks the holding torque of a brake (operating or holding brake). The drive purposely generates a configurable torque against the applied brake. If the brake is operating correctly, the axis motion remains within a parameterized tolerance. However, if larger axis motion is identified from the encoder actual values, the brake is not in a position to provide the specified holding torque. The brake must now be serviced or replaced.

## Features

The Safe Brake Test function has the following properties:

- The parameters of the SBT function are protected by the safety password, and can only be changed in the safety commissioning mode.
- Using this function, brakes can be tested that are directly connected to SINAMICS S120 (integrated brake control), but also externally controlled brakes (e.g. via a PLC).
- A maximum of 2 brakes can be tested:
  - A motor holding brake, controlled by the integrated brake control of the SINAMICS, and in addition, an externally controlled brake.
  - Two externally controlled brakes
  - A motor holding brake, controlled by the integrated brake control of the SINAMICS.
  - One externally controlled brake
- The following options are available to control the SBT function:
  - BICO interconnection; here, digital signals (e.g. DIs) are used to operate the SBT function.
  - Safety Control Channel (SCC) via PROFIBUS or PROFINET  
Using SCC, the SBT function can be directly controlled from a higher-level control system. You can find additional information about SCC and SIC data in Chapter "Safety Info Channel and Safety Control Channel (Page 207)".
  - The brake test can be automatically executed when the forced checking procedure (test stop) is selected. No additional signals are required for the control. However, the test possibilities are restricted.
- The Safe Brake Test (SBT) diagnostic function meets the requirements for Category 2 according to EN ISO 13849-1.

You will find an application example of the calculation at this address (<https://support.industry.siemens.com/cs/ww/en/view/69870640>).

## Requirements

The following preconditions must be satisfied when using the "Safe Brake Test" function:

- The Safety Integrated Extended Functions must be enabled; also available for the Safety Integrated Extended Functions without selection.
- Safe Brake Control must be enabled when testing a brake controlled by SINAMICS (motor holding brake).
- Safety Integrated Extended Functions with encoder have been enabled.

You can find information about possible encoder concepts in Chapter "Notes regarding safe actual value sensing using an encoder system (Page 147)".

- Speed control with encoder (p1300 = 21).

SBT is not possible with encoderless speed control (e.g. vector V/f control) and torque control. In this case, alarm A01784 is output.

## Enabling the SBT function

To enable the Safe Brake Test function, proceed as follows:

- Enable the Safe Brake Control (SBC) function when using an internal motor holding brake: p9602 = 1.
- Select the SBT selection type with parameter p10203:
  - = 0  
Selection of SBT via SCC
  - = 1  
Selection of SBT via BICO
  - = 2  
Selection of SBT on forced dormant error detection (test stop)
- Check the motor type; the following must apply: p10204 = r0108.12

## Parameterizing the test sequences

For testing brake 1 [index 0] or 2 [index 1], initially, those values must be entered, which apply to both test sequences:

- Brake type (p10202[0,1])
  - = 0 (≙ block)  
This must be set if one of the brakes is either not available or is not to be tested.
  - = 1 (≙ test motor holding brake)  
Here, in addition p1215 must be set to = 1
  - = 2 (≙ set external brake)
- You define the holding torque of brakes using p10209.

- Test torque ramp time p10208[0,1]

Within this time, before starting the test sequence, the test torque is ramped up – and at the end of the sequence, is ramped down again.

---

**Note**

When testing an external brake, whose mechanical design exhibits backlash (e.g. if there is a gearbox located between the motor and external brake), it can make sense to extend the ramp time (p10208) when ramping up and ramping down the test torque.

---

- The interconnection of the parameters for the telegram extension, relevant for SCC/SIC, can be performed automatically by setting p60122 = 701. However, the telegram extension must have been previously created. More detailed information on this can be found in Chapter "Safety Info Channel and Safety Control Channel (Page 207)".
- The following parameters must also be set if you control the brake test using BICO signals (p10203 = 1):

p10230.0	Signal for selecting the brake test
p10230.1	Signal for starting the test sequence
p10230.2	Signal for selecting the brake to be tested (= 0: Brake 1; = 1: Brake 2)
p10230.3	Signal for selecting the sign of the test torque (= 0: positive; = 1: negative)
p10230.4	Signal to select the test sequence (= 0: sequence 1; = 1: sequence 2)
p10230.5	Feedback signal for the state of the external brake (= 0: external brake open; = 1: external brake closed)

You can parameterize 2 test sequences for each brake. Each test sequence is characterized by the following setting values:

- Brake test sequence 1

p10210[0,1]	Test torque to be generated in % of the brake holding torque
p10211[0,1]	Test duration in ms
p10212[0,1]	Positional deviation to be tolerated in mm/degrees during the test

- Brake test sequence 2

p10220[0,1]	Test torque to be generated in % of the brake holding torque
p10221[0,1]	Test duration in ms
p10222[0,1]	Positional deviation to be tolerated in mm/degrees during the test

- Perform a POWER ON after commissioning

**NOTICE****Damage to the motor holding brake as a result of an incorrect setting**

Brake wear increases if the motor holding brake is incorrectly set. This can damage the brake.

- Correctly adjust the opening and closing times of the motor holding brake.
- If an external brake is used, it is only permissible that this is closed when requested by signal r10234.6 = 1 ("close"). The feedback signal is realized using p10230.5 = 1 ("external brake closed").
- If an internal brake is used, then the switching times are set in parameters p1216 ("motor holding brake opening time") and p1217 ("motor holding brake closing time"). Further information can be found in the SINAMICS S120 Function Manual Drive Functions.

---

**Note****SBT and EPOS**

If EPOS is activated, you must activate "follow-up mode" (r2683.0) before you perform the brake test so that the position monitoring does not react during the brake test.

---

**Note****SBT and DSC**

If SBT is used with SIMOTION, parameter r10234 (S\_ZSW3B) must be evaluated and Safety Control Channel control word 3B (S\_STW3B) activated. In SIMOTION, r10234.1 specifies that no position monitoring may be active during the brake test (the same applies of course for traversing).

---

**Note****SBT and HLA**

The "Safe Brake Test" (SBT) function is not available for SINAMICS HLA.

---

## Starting SBT

### 1. Selection

You have the following options for the selection of the Safe Brake Test:

- Selection via BICO using a 0/1 signal edge at DI for p10230[0]
- Selected via fieldbus (SCC):  
Select the brake test sequence with a 0/1 edge in S\_STW3B bit 0
- Selected using forced dormant error detection (test stop) of the Extended Functions:  
Selection by signal at the intended DI  
After the 0/1 edge at the DI for p9705 or in S\_STW1B bit 8, then initially SBT is automatically executed. Forced dormant error detection (test stop) is then performed.

---

#### Note

When selected via DI (BICO) and selected via fieldbus (SCC, S\_STW3B bit 0), then the sequence of the subsequently described steps 2 to 5 must be carefully observed.

---

#### Note

##### Only brake 1 when selecting via forced dormant error detection (test stop)

When selecting using forced dormant error detection (test stop), only the internal motor holding brake parameterized as brake 1 is tested with test sequence 1 in the direction parameterized in p10218.

It is not possible to use the brake test together with the "Automatic test stop when powering up" function.

---

The pulses must be enabled when SBT is selected. The actual speed value must not exceed 1% of the maximum speed (p1082) when SBT is selected and over the complete time that SBT is active.

The brake(s) must be open.

### 2. Wait for feedback signal, r10231[0] = 1

### 3. Select brake and test sequence

Make the following decisions before starting the brake test sequence:

- The brake to be tested using DI for p10230[2] or S\_STW3B bit 2
- Positive or negative direction of the test torque using DI for p10230[3] or S\_STW3B bit 3
- Brake test sequence 1 or 2 using DI for p10230[4] or S\_STW3B bit 4.

### 4. Start brake test

Start the brake test sequence using a 0/1 edge at the DI for p10230[1] or in S\_STW3B bit 1.

### 5. Exit brake test

- Withdraw "Start brake test" using a 1/0 signal edge at DI for p10230[1] or in S\_STW3B bit 1.
- Withdraw "Select brake test" using a 1/0 signal edge at DI for p10230[0] or in S\_STW3B bit 0.



## Sequence

SBT has the following basic sequence:




Image 4-13 SBT: Time sequence

- After the user selects the brake test (0/1 edge in r10231.0), the static hanging load is determined. For this reason, all brakes must be open and the pulses enabled when the brake test is selected.
  - When testing a motor holding brake, which is directly controlled from SINAMICS, the brake is automatically opened when the pulses are enabled and p1215=1.
  - When testing an external brake, via p10234.6 or for SIC/SCC, via S\_ZSW3B.6, a value of 0 indicates that the external brake must be opened. This must occur within 11 seconds, otherwise the test is canceled and a fault is output.
- The brake, the test sequence and the test direction are then selected by the user.
- Only when the brake test is active after the user has started the brake test/brake test sequence (0/1 edge in r10231.1) is the holding brake closed, or there is a prompt to close the external brake. The request to close the brake is again indicated with p10234.6 = 1 or S\_ZSW3B.6 = 1. Also in this case, only a maximum of 11 seconds must elapse, otherwise a fault is issued.
- The test torque (test torque  $\pm$  load torque for a vertical axis) is specified during the SBT. When  $n = 0$  is entered, the controller builds up an appropriate test torque against the closed brake. The test torque is built up along a ramp. The ramp is defined by the time of p10208.

*4.2 Safety Integrated Extended Functions*

- At the end of the test sequence, the brake is opened or there is a prompt to open the brake.
- After deselection of the test sequence (test sequence is switched off), another test sequence can be started, e.g. with a different brake in a different direction, assuming that the brake test is still selected.
- When the test sequence is active, the brake that is not being tested must remain open.
- After deselection of the SBT, the original speed setpoint takes effect again.

**Cancel**

A 1/0 edge of signal r10231.1 "Start brake test", interrupts the brake test. The converter issues alarm A01782 after the brake test has been interrupted. The brake test can then be deselected using a 1/0 signal edge of signal r10231.0.


**Acknowledging alarms**

The alarms relevant for the brake test can only be safely acknowledged (fail-safe acknowledge, e.g. using TM54F), and under certain circumstances only acknowledged, when the brake test is deselected. For "motion monitoring without selection," a POWER ON is required – or STO/SS1 must be selected/deselected (if extended message acknowledgment is configured).

### 4.2.15.1 Communication via SIC/SCC


#### Test of a motor holding brake

The following figure shows the communication via SIC and SCC during the test of a motor holding brake:



### Test of an external brake

The following figure shows the communication via SIC and SCC during the test of an external brake:



### 4.2.15.2 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2836 SI Extended Functions - SBT (Safe Brake Test)
- 2837 SI Extended Functions – Selection of active control word

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p1215 Motor holding brake configuration
- p1216 Motor holding brake opening time
- p1217 Motor holding brake closing time
- p9501 SI Motion enable safety functions (Control Unit)
- p9601 SI enable functions integrated in the drive (Control Unit)
- p9602 SI enable safe brake control (Control Unit)
- p10201 SI Motion SBT enable
- p10202[0...1] SI Motion SBT brake selection
- p10203 SI Motion SBT control selection
- p10204 SI Motion SBT motor type
- p10208[0...1] SI Motion SBT test torque ramp time
- p10209[0...1] SI Motion SBT brake holding torque
- p10210[0...1] SI Motion SBT test torque factor sequence 1
- p10211[0...1] SI Motion SBT test duration sequence 1
- p10212[0...1] SI Motion SBT position tolerance sequence 1
- p10218 SI Motion SBT test torque sign
- p10220[0...1] SI Motion SBT test torque factor sequence 2
- p10221[0...1] SI Motion SBT test duration sequence 2
- p10222[0...1] SI Motion SBT position tolerance sequence 2
- p10230[0...5] BI: SI Motion SBT control word
- r10231 SI Motion SBT control word diagnostics
- r10234.0...15 CO/BO: SI Safety Info Channel status word S\_ZSW3B
- p10235 CI: SI Safety Control Channel control word S\_STW3B
- r10240 SI Motion SBT test torque diagnostics
- r10241 SI Motion SBT load torque diagnostics
- p60122 IF1 PROFIdrive SIC/SCC telegram selection

### 4.2.16 Safe Acceleration Monitor (SAM)

The "Safe Acceleration Monitor" (SAM) function is used to safety monitor braking along the OFF3 ramp. The function is active for SS1, SS2 or STOP B and STOP C.

#### Features

As long as the speed is less, the converter continuously adds the adjustable tolerance p9548 to the actual speed so that the monitoring tracks the speed. If the speed is temporarily higher, the monitoring remains at the last value. The converter reduces the monitoring threshold until the "Shutdown speed" has been reached.

SAM recognizes if the drive accelerates beyond the tolerance defined in p9548 during the ramp-down phase, and generates a STOP A. The monitoring function is activated for SS1 (or STOP B) and SS2 (or STOP C) and is deactivated after the speed drops below the value set in p9568.

---

#### Note

##### Relationship between SSM and SAM

If 0 is entered for p9568, the speed limit of the SSM function (p9546) is also used as minimum limit value for the SAM function (safe acceleration monitoring). The SAM is deactivated if the speed is below this limit.

In this case, the effects of safe acceleration monitoring are therefore significantly restricted if a relatively high SSM velocity limit is set when using the SS1 and SS2 stop functions.

---

#### Note

##### No direct selection of SAM

SAM is part of the Safety Integrated Extended Functions SS1 and SS2 or STOP B and STOP C. SAM cannot be individually selected.

---

Calculating the SAM tolerance of the actual speed

- The following applies when parameterizing the SAM tolerance:
  - The maximum speed increase after SS1 or SS2 is triggered results from the effective acceleration (a) and the duration of the acceleration phase.
  - The duration of the acceleration phase is equivalent to one monitoring cycle (MC p9500) (delay from detecting an SS1 / SS2 until  $n_{set} = 0$ )

- Calculating the SAM tolerance:

Actual speed for SAM = acceleration × acceleration duration

The following setup rule is derived thereof:

- For linear axes:  
SAM tolerance [mm/min] = a [m/s<sup>2</sup>] × MC [s] × 1000 [mm/m] × 60 [s/min]
- For rotary axes:  
SAM tolerance [rpm] = a [rev/s<sup>2</sup>] × MC [s] × 60 [s/min]

- Recommendation  
The SAM tolerance value entered should be approx. 20% higher than the calculated value.
- You set the tolerance such that the "overshoot" is tolerated that necessarily occurs when standstill is reached after braking along the OFF3 ramp. However, it cannot be calculated as to just how high this is.

---

### Note

#### First monitoring cycle

For SAM, in the first "SI Motion monitoring cycle" (p9500) a higher SAM tolerance is taken into account in order to compensate for possible settling operations without resulting in an incorrect initiation. The increase factor is calculated as follows:

SI Motion monitoring cycle (p9500) / SI Motion actual value acquisition cycle (p9511)

Example:

SI Motion monitoring cycle (p9500) = 12 ms

SI Motion actual value acquisition cycle (p9511) = 1 ms

SAM tolerance (p9548) = 300 rpm

Actual speed = 250

Rotary axis

In the first cycle after activation of the monitoring, the SAM limit value is therefore:

Actual speed + SAM tolerance × (12 ms/1 ms) =

250 rpm + 300 rpm × 12 =

approx. 3850 rpm

---

## Responses

- **Speed limit violated (SAM):**
  - STOP A
  - Safety message C01706
- **System fault:**
  - STOP F with subsequent STOP A
  - Safety message C01711

## Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9546 SI Motion SSM (SGA n < nx) speed limit (CU)
- p9548 SI Motion SAM actual speed tolerance (Control Unit)
- p9568 SI Motion SAM speed limit (Control Unit)

### 4.2.17 Safe Brake Ramp (SBR)

The Safe Brake Ramp (SBR) function provides a safe method for monitoring the brake ramp. The Safe Brake Ramp function is used to monitor braking with the functions "SS1 with/without encoder," "SLS without encoder," SS2 and STOP B / STOP C (for Safety with encoder). For SLS, the setpoint limiting of the Safety Integrated Functions (r9733) must be connected to the ramp-function generator (p1051/p1052).

#### Features

The motor is decelerated with the OFF3 ramp as soon as SS1, SS2, or SLS is triggered. Monitoring of the brake ramp is activated once the delay time in p9582 has elapsed. Monitoring ensures that the motor does not exceed the set brake ramp (SBR) when braking. The safe monitoring of the brake ramp is deactivated

- For SS1:
  - As soon as the speed drops below the shutdown speed (p9560).
  - Or:
  - As soon as the delay time (p9556) has elapsed.
- For SS2:
  - As soon as the SS2 delay time (p9552) has elapsed.
- For SLS:
  - As soon as the set brake ramp has reached the new SLS level
  - Or:
  - As soon as the actual speed drops below the newly selected SLS level and has remained there for the time parameterized in p9582.

Additional specific functions (e.g. STO, new SLS speed limit, etc.) are activated at this point, depending on the Safety Integrated function used.






Image 4-14 Safe Brake Ramp without encoder (for SLS)

### Parameterization of the brake ramp

p9581 (SI Motion braking ramp reference value) and p9583 (SI Motion brake ramp monitoring time) are used to set the gradient of the brake ramp. Parameter p9581 determine the reference speed and parameter p9583 define the ramp-down time. Parameter p9582 is used to set the time which passes after the triggering of SS1, selection of SLS or SLS level changeover and the start of brake ramp monitoring.

---

#### Note

##### SBR and OFF3 curve

The SBR curve should be aligned to the OFF3 curve. In addition, you should check that under every load condition, the drive can follow this OFF3 ramp.

---

#### Note

##### Limitation of the SBR delay time

The SBR delay time (p9582) is limited to a minimum value of 2 SI motion monitoring clock cycles ( $2 \times p9500$ ), i.e. even if a value less than  $2 \times p9500$  is parameterized for the delay time (p9582), then SBR is only effective 2 clock cycles after an active SS1.

If a value greater than  $2 \times p9500$  is parameterized for the delay time (p9582), SBR becomes active after active SS1 after the time p9582. Ensure that you round off the SBR delay time to an integer multiple of the safety cycle (p9500).

---

### Responses to brake ramp violations (SBR)

- Safety message C01706 (SI Motion: SAM/SBR limit exceeded)
- Drive stopped with STOP A
- For an encoder fault in a 1-encoder system, the "Safe acceleration monitoring" function is not active. A stop response, Category 0 or 1 (EN 60204-1) can be set using parameter p9516.4.

### Features

- Part of the "SS1 with/without encoder", "SS2 with encoder", "SLS without encoder" and "STOP B/STOP C (for safety with encoder)" functions.
- Parameterizable safe brake ramp

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9516 SI Motion encoder configuration safety functions (Control Unit)
- p9560 SI Motion STO shutdown speed (Control Unit)
- p9581 SI Motion braking ramp reference value (Control Unit)
- p9582 SI Motion braking ramp delay time (Control Unit)
- p9583 SI Motion braking ramp monitoring time (Control Unit)

## 4.2.18 Safe actual value acquisition

### 4.2.18.1 Notes regarding safe actual value sensing using an encoder system

#### Supported encoder systems

The following encoder systems can in principle be used for safety-relevant speed/position acquisition:

- Single-encoder systems
- or
- 2-encoder systems

---

#### Note

##### Rules for connecting an encoder

Note when connecting an encoder the valid rules: See SINAMICS S120 Drive Functions Function Manual.

---

#### Single-encoder system

In a single-encoder system, only the motor encoder is used to safely acquire the drive actual values. This motor encoder must be appropriately suitable (see encoder types). The actual values are generated in a safety-relevant fashion either directly in the encoder or in the Sensor Module and are transferred to the Control Unit via DRIVE-CLiQ.

For motors without a DRIVE-CLiQ interface, the connection is made using additional Sensor Modules.

Even if the drive is operating in the closed-loop torque controlled mode, motion monitoring functions may be selected as long as it is guaranteed that the encoder signals can be evaluated.

---

#### Note

##### No "Safe acceleration monitoring" for encoder faults in a 1-encoder system

For an encoder fault in a 1-encoder system, the "Safe acceleration monitoring" function (p9506 = 3) is not active.

A stop response, Category 0 or 1 (EN 60204-1), can be set using parameter p9516.4.

---

### Special feature in the case of linear motors

The motor encoder (linear scale) of linear motors also acts as load measuring system. Only one measuring system is required for this reason. The system is connected by means of a Sensor Module or directly via DRIVE-CLiQ.




Image 4-15 Example of a single-encoder system

### 2-encoder system

The fail-safe actual values for a drive are provided by two separate encoders. The actual values are transferred to the Control Unit via DRIVE-CLiQ.

For motors without a DRIVE-CLiQ interface, the connection is made using additional Sensor Modules (see encoder types).




Image 4-16 Example of a 2-encoder system on a linear axis via a ball screw




Image 4-17 Example of a 2-encoder system on a rotary axis

When parameterizing a 2-encoder system with Safety Integrated, you must align parameters p9315 to p9329 with parameters r0401 to r0474.

---

**Note**

**Assignment of the encoder parameters**

Parameters p95xx are assigned to the 1st encoder; parameters p93xx to the 2nd encoder.

---

**Note**

**Transfer of the values from the encoder commissioning**

To accept the values from the parameters filled during the encoder commissioning to the safety parameterization, set parameter p9700 = 46 (2E hex). This copy function is only possible if you are connected online with the drive unit.

---

Table 4- 6 Encoder parameters and corresponding safety parameters for 2-encoder systems

Safety parameters	Designation	Encoder parameters
p9315/p9515 SI Motion coarse position value configuration		
p9315.0/p9515.0	Up-counter	r0474[x].0
p9315.1/p9515.1	Encoder CRC, least significant byte first	r0474[x].1
p9315.2/p9515.2	Redundant coarse position value, most significant bit left-justified	r0474[x].2
p9315.16/p9515.16	DRIVE-CLiQ encoder	p0404[x].10
p9316/p9516 SI Motion encoder configuration, safety functions		
p9316.0/p9516.0	Motor encoder, rotary/linear	p0404[x].0
p9316.1/p9516.1	Actual position value, sign change	p0410[x]
p9317/p9517	SI Motion linear scale grid division	p0407
p9318/p9518	SI Motion encoder pulses per revolution	p0408
p9319/p9519	SI Motion fine resolution G1_XIST1	p0418
p9320/p9520	SI Motion leadscrew pitch	STARTER encoder parameterizing screen form
p9321/p9521	SI Motion gearbox encoder	STARTER encoder parameterizing screen form
p9322/p9522	SI Motion gearbox encoder	STARTER encoder parameterizing screen form
p9323/p9523	SI Motion redundant coarse position value valid bits	r0470
p9324/p9524	SI Motion redundant coarse position value fine resolution bits	r0471
p9325/p9525	SI Motion redundant coarse position value relevant bits	r0472
p9326/p9526	SI Motion encoder assignment	STARTER encoder parameterizing screen form
p9328/p9528	SI Motion Sensor Module node identifier	
p9329/p9529	SI Motion Gx_XIST1 coarse position safety most significant bit	For DRIVE-CLiQ encoders: p0415 = r0470 – r0471 For SMx modules: p0415 = 14

### Encoder types for single and 2-encoder systems

Incremental encoders or absolute encoders can be used for safe acquisition of the position values on a drive.

The absolute position values can be transferred via the serial EnDat interface or an SSI interface to the controller. However, these are not evaluated by the safety functions.

In systems with encoders with SINAMICS Safety Integrated (single and 2-encoder systems), the following encoders are permitted for safe actual value acquisition:

- Encoders with sin/cos 1 Vpp signals
  - Single and 2-encoder systems
  - Connected to the SINAMICS SME20/25, SME120/125 and SMC20 Sensor Modules
  - The encoders must contain purely analog signal processing and creation. This is necessary to be able to prevent the A/B track signals with valid levels from becoming static ("freezing").
- HTL/TTL encoders
  - Can only be used for 2-encoder systems. In this case, one encoder must be an HTL/TTL encoder. The other encoder can be a sin/cos encoder or an HTL/TTL encoder.
  - Connected to an SMC30 Sensor Module Cabinet or to the onboard interface of the C U310-2, SINAMICS HLA or SINAMICS S120 Combi.
  - An HTL/TTL encoder connected to the onboard interface of CU310-2, SINAMICS HLA or SINAMICS S120 Combi must not be operated as first encoder.
  - Note the lowest possible velocity resolution (r9732[1]) for an HTL/TTL encoder system.

---

**Note****Encoders with integrated DRIVE-CLiQ interface**

These encoders must be certified at least according to IEC 61800-5-2 (SIL2) or ISO 13849-1 (Performance Level d / Category 3).

---

A fault mode effect analysis (FMEA) for securing the encoder on the motor shaft or on the linear drive must be performed. The result must be that the risk of the encoder mounting loosening is defined as a fault that can be ruled out (see DIN EN 61800-5-2, 2008, Table D.16). The encoder would no longer correctly map the motion if its mounting were to become loose.

It should be noted that the machine manufacturer has sole responsibility for the fulfillment of the above-described requirements. Information on the internal realization of the encoder must come from the encoder manufacturer. The FMEA must be created by the machine manufacturer.

Siemens motors with and without DRIVE-CLiQ connection, which can be used for Safety Integrated functions, are listed under:

<http://support.automation.siemens.com/WW/view/en/33512621>

For these motors, the encoder mounting on the motor shaft can be considered to be safety relevant, and faults associated with an encoder becoming loose ruled out.

**Note**

**Basic absolute encoders with EnDat interface and additional sin/cos tracks**

Basic absolute encoders (e.g. EQI) that offer an EnDat interface with additional sin/cos tracks, but operate according to an inductive measuring principle internally, are not permitted for SINAMICS Safety Integrated.


**Note**

**Encoder types for SINAMICS HLA**

The following encoder types are permissible for SINAMICS HLA:

- Single-encoder systems
  - Safety-capable DRIVE-CLiQ encoder
  - sin/cos encoder connected via SME20/25, SME120/125 or SMC20 (1Vpp, pure analog signal processing)
- 2-encoder systems
  - Encoders with DRIVE-CLiQ connection
  - sin/cos encoder connected via SME20/25, SME120/125 or SMC20 (1Vpp, pure analog signal processing)
  - HTL/TTL encoder connected via SMC30 (not in conjunction with SINUMERIK)
  - TTL encoder connected via the onboard interface of the HLA module (not in conjunction with SINUMERIK)

**Actual value synchronization**



1) This deviation cannot be larger than the position difference that can arise at maximum slip (p9549) during a cross-check cycle (r9724).

Image 4-18 Example diagram of actual value synchronization

The mean value of the actual values of both channels is calculated cyclically after actual value synchronization (p9501.3 = 1) has been activated, for example, for systems or machines with slip. The maximum slip defined in p9549 is monitored in the cross-check cycle



(r9724). The maximum slip defined in p9549 is monitored once per cross-check cycle (r9724).

If "actual value synchronization" is not enabled, the value parameterized in p9542 is used as tolerance value for the crosswise comparison.

## Safe motion monitoring

The properties of the actual value acquisition determine not only the encoders used, but also the values for safe motion monitoring that can be achieved in the best case.

- Safe maximum speed (r9730)

The maximum speed (load side) that is permissible due to the acquisition of actual values for safe motion monitoring functions is indicated in r9730. This parameter shows the load velocity up to which the safety-relevant encoder actual values (redundant coarse encoder position) can still be correctly sensed as a result of the particular encoder parameterization.

The actual value acquisition clock (p9511) determines the frequency at which the actual values are acquired. The longer the clock cycle, the higher the "safe maximum velocity." On the other hand, a longer actual value acquisition clock cycle places a greater load on the Control Unit. You must consider this circumstance when setting the optimum for your application.

For SINAMICS S120M, only the values 2 and 0 ms are allowed for the actual value acquisition cycle clock (p9511). In both cases, the frequency converter calculates with an actual value acquisition cycle clock of 2 ms regardless of the PROFIBUS DP/PN cycle clock.

- Safe positioning accuracy (r9731)

This positioning accuracy can be achieved in the best case by acquiring the actual values. If a 2-encoder system is used, the accuracy of the poorer encoder is indicated based on the number of encoder pulses.

## Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9501.3 SI Motion enable safety-related functions Enable actual value synchronization
- p9502 SI Motion axis type (Control Unit)
- p9511 SI Motion actual value acquisition clock (Control Unit)
- p9515 SI Motion encoder coarse position value configuration (Control Unit)
- p9516 SI Motion encoder configuration safety functions (Control Unit)
- p9517 SI Motion linear encoder grid division (Control Unit)
- p9518 SI Motion encoder pulses per revolution (Control Unit)
- p9519 SI Motion fine resolution G1\_XIST1 (Control Unit)
- p9520 SI Motion leadscrew pitch (Control Unit)
- p9521[0...7] SI Motion gearbox encoder (motor)/load denominator (Control Unit)
- p9522[0...7] SI Motion gearbox encoder (motor)/load numerator (Control Unit)

4.2 Safety Integrated Extended Functions

- p9523 SI Motion redundant coarse position value valid bits (Control Unit)
- p9524 SI Motion redundant coarse position value fine resolution bits (CU)
- p9525 SI Motion redundant coarse position value relevant bits (CU)
- p9526 SI Motion encoder assignment second channel
- p9542 SI Motion actual value comparison tolerance (crosswise) (Control Unit)
- p9549 SI Motion slip velocity tolerance (Control Unit)
- p9700 SI Motion copy function
- r9713[0...5] CO: SI Motion diagnostics actual position value load side
- r9714[0...2] CO: SI Motion diagnostics velocity
- r9724 SI Motion, cross-check cycle
- r9730 SI Motion safe maximum speed
- r9731 SI Motion safe positioning accuracy
- r9732[0...1] SI Motion velocity resolution

4.2.18.2 Notes regarding setting parameters for safe actual value sensing without encoder

Several parameters are available in order to guarantee safe motion monitoring for Safety Extended Functions without encoder depending on the situation in a specific application. You define these parameters in the following STARTER dialog box:




Image 4-19 Configuration, actual value acquisition without encoder

In most cases, you can work with the default values.

- If, during the start phase, the actual value acquisition is still not operating correctly, the converter outputs messages; however these still do not represent any safety problems. In order to avoid this, increase this value of parameter **Delay time of the evaluation encoderless** (p9586). In this way, you determine the "Evaluation delay time without encoder" (p9586):
  - To determine the minimum delay time of p9586, record the starting behavior of the drive system (with motor and the intended load). The STARTER trace function allows the value for p9586 to be determined.
  - In order to avoid fault responses, deselect the "SDI without encoder" and "SLS without encoder" functions.
  - Activate the trace function using the "OFF2 → inactive" trigger, and the following as the signals to be recorded: At least one motor current phase and OFF2. After the ON command, record this motor phase current until  $I_{rated}$  is reached. Enter the time required to reach  $I_{min}$  (+ 10% reserve) in p9586.
  - Perform application-specific startup characteristics for the drive. Deduct from the trace recording the time after which the peak current of the asynchronous motor or the pulse pattern of the rotor position identification finishes, and the current of p9588 which exceeds the "Minimum current actual value acquisition without encoder".
  - Enter the measured time + approx. 10 % into p9586.
  - Activate the "SDI without encoder" and "SLS without encoder" functions. Restart the machine, and keep the trace function activated.

Now it is no longer permissible that messages are output.

  - Alternatively, you can change the value of p9586 in small steps and then monitor the system response. You have found a suitable value if unnecessary messages/signals no longer occur.
- Using parameter **Fault tolerance actual value acquisition encoderless** (p9585), you can set the tolerance of the plausibility monitoring of current and voltage angle.
  - For synchronous motors, p9585 = 4 must be parameterized.
  - Reducing this value can have a negative impact on the actual value acquisition and the plausibility check.
  - Increasing the value results in a longer evaluation delay.
  - For devices in the chassis format, Safety Integrated without encoder can be used with induction motors up to a maximum of 1000 kW: For very large motors, it may be necessary to increase the value in parameter p9585. For chassis format devices, parameter p9585 is preassigned a value of "2".
  - For the factory setting (= -1), for synchronous motors, the calculation automatically uses the value 4, for induction motors, the value 0.
  - The diagnostics parameter r9786[0...2] shows you the values of the plausibility angle, voltage angle and current angle currently measured by the converter. These values allow you to optimize what you enter into p9585.

- Set the value of **voltage tolerance acceleration** (p9589) as follows:
    - Record the following parameters with the trace function in the STARTER in the current controller cycle:
      - r9784[0]: Target acceleration value
      - r9784[1]: Actual acceleration value
      - r9714[0]: load side actual velocity value on the Control Unit
      - r0063: Actual speed value
    - Accelerate the motor , if possible until it reaches the rated speed.
    - Check whether r9714[0] and r0063 match in the range 0 ... rated speed.
    - Set p9589 such that r9784[1] touches r9784[0] a maximum of twice per second in the range 0 ... rated speed.  
If the value if the message C01711 with fault value 1043 occurs, you have to increase p9589.
    - Check once again whether r9714[0] and r0063 match in the range 0 ... rated speed.
- If you change one of the following parameters, you have to check and set the encoderless actual value acquisition once again:
- PROFIdrive isochronous mode asynchronous participation:  
p2049 = 1
  - Current controller sampling time for servo control:  
p0115[0] = 187.5  $\mu$ s, 150  $\mu$ s, 100  $\mu$ s, 93.75  $\mu$ s, 75  $\mu$ s, 50,0  $\mu$ s or 37.5  $\mu$ s
  - Current controller sampling time for vector control:  
p0115[0] = 375  $\mu$ s, 312.5  $\mu$ s, 218.75  $\mu$ s, 200  $\mu$ s, 187.5  $\mu$ s, 175  $\mu$ s, 156.25  $\mu$ s, 150  $\mu$ s or 137.5  $\mu$ s

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9585 SI Motion actual value acquisition without encoder fault tolerance (CU)
- p9586 SI Motion actual value acquisition without encoder delay time (CU)
- p9587 SI Motion actual value acquisition without encoder filter time (CU)
- p9588 SI Motion actual value acquisition without encoder minimum current (CU)
- p9589 SI Motion actual value acquisition without encoder acceleration limit (CU)
- p9700 SI Motion copy function
- r9732[0...1] SI Motion velocity resolution

## 4.2.19 Safe gearbox stage switchover

"Safe gearbox switchover" allows you to switch between 8 gearbox ratios in operation. Switchover between gearbox ratios is only possible via PROFIBUS (p9601.3 = 1).

### Parameterization

Before you can use "Safe gearbox switchover", you must parameterize the following values:

- Gear ratios

You can set up to 8 different gearbox ratios using parameter p9521 (denominator) and p9522 (numerator).

- Direction reversal

Using parameter p9539, you can set as to whether a direction of rotation reversal is involved for the particular gearbox.

- Position tolerance

As a result of the motion that can possibly occur when switching over the gearbox, it may be necessary to increase the tolerance threshold for the duration of the switchover operation. Using parameter p9539, you set how the tolerance is calculated when switching over the gearbox:

- Without actual value synchronization:  $p9542 \times p9543$
- With actual value synchronization:  $p9549 \times p9543$

### Selection

Proceed as follows to enable the "Safe gearbox switchover" function:

1. Set p9501.26 = 1
  - If control via PROFIsafe is not parameterized, then the converter outputs fault F01681 with the appropriate fault value.
  - If you activate the "Safe gearbox switchover" function on a converter, which does not support the function, then the converter outputs fault F01682 with fault value 39.
2. Switch off the drive unit and then on again (POWER ON).

### Gearbox switchover without increased position tolerance

In order to switch over the gearbox stage, where no increased tolerance is required for the crosswise comparison of the actual positions, proceed as follows:

1. Set the new gearbox stage using bits 0 to 2 in byte 3 of S\_STW2.
2. The actual values are then synchronized once automatically. This synchronization is used to compensate any possible difference that occurs between the position actual values of the two monitoring channels as a result of the switchover operation.

The new gearbox stage is then active.




Image 4-20 Gearbox switchover from stage "0" to "1" without increased position tolerance

### Gearbox switchover with increased position tolerance

In order to switch over the gearbox stage, where increased tolerance is required for the crosswise comparison of the actual positions, proceed as follows:

---

#### Note

##### Maximum duration of the increased position tolerance

It is not permissible that the increased position tolerance is set for longer than 2 min. If this time is exceeded, then the converter outputs message C01711 with fault value 1015 (≙ STOP F).

---

1. Set the increased position tolerance using bit 3 (= 1) in byte 3 of S\_STW2.
2. Set the new gearbox stage using bits 0 to 2 in byte 3 of S\_STW2.

3. Set the position tolerance back to the normal value using bit 3 (= 0) in byte 3 of S\_STW2.
4. The actual values are then synchronized once automatically. This synchronization is used to compensate any possible difference that occurs between the position actual values of the two monitoring channels as a result of the switchover operation.

The new gearbox stage is then active.




Image 4-21 Gearbox switchover with increased position tolerance

## Diagnostics

The selected gearbox stage is displayed for diagnostic purposes in parameter r9720, bits 24 to 26.

The selected gearbox stage is displayed for diagnostic purposes in parameter r9720, bit 27.

## "Safe gearbox switchover" and referencing

The gearbox stage switchover means that the reference position and the user agreement are lost. This means that after a gearbox switchover, initial referencing is required, to return to the "safely referenced" state (see Chapter "Safe referencing (Page 127)").

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501.26 SI Motion enable safety functions (Control Unit): Enable reliable gearbox switchover
- p9521[0...7] SI Motion gearbox encoder (motor)/load denominator (Control Unit)
- p9522[0...7] SI Motion gearbox encoder (motor)/load numerator (Control Unit)
- p9539[0...7] SI Motion gearbox direction of rotation reversal (Control Unit)
- p9542 SI Motion actual value comparison tolerance (crosswise) (Control Unit)
- p9543 SI Motion gearbox switching position tolerance factor (CU)
- p9549 SI Motion slip velocity tolerance (Control Unit)
- r9720.0...27 CO/BO: SI Motion drive-integrated control signals

## 4.2.20 Forced dormant error detection (test stop)

### Forced dormant error detection (test stop) and function test

The functions and switch-off signal paths must be tested at least once within a defined period to establish whether they are working properly in order to meet the requirements of EN ISO 13849-1 and IEC 61508 in terms of timely error detection.

The maximum permissible interval for forced dormant error detection (test stop) for Basic and Extended Functions is 8760 hours; i.e. forced dormant error detection (test stop) must be performed at least once per year.

This functionality must be implemented by initiating forced dormant error detection (test stop) cyclically either manually or as part of an automated process.

The test stop cycle is monitored. On expiration of the parameterized timer (also after POWER ON / warm restart), the alarm A01697: "SI Motion: Test of motion monitoring required" is generated and a status bit is set which can be transferred to an output or to a PZD bit via BICO. This alarm does not affect machine operation.



## Executing a forced checking procedure (test stop)

Forced dormant error detection (test stop) can be executed at the following points in time:

1. Forced dormant error detection (test stop) can be initiated application-specifically and can therefore be executed at a time that suits application requirements.

This functionality is implemented by means of a single-channel parameter p9705, which can be wired via BICO either to an input terminal on the drive unit (Control Unit) - or to a bit of any arbitrary PZD.

In addition, it is possible to select the test stop via the Safety Control Channel (see Chapter "Safety Info Channel and Safety Control Channel (Page 207)").

- p9559 SI Motion Forced checking procedure timer (Control Unit)
- p9705 BI: SI Motion Test stop signal source
- r9723.0 CO/BO: SI Motion diagnostics signals integrated in the drive

If the test stop is executed as described, the action does not require a POWER ON. The acknowledgment is set by canceling the test stop request.

2. Forced dormant error detection (test stop) can be automatically executed at POWER ON.

- To perform an automatic test stop of the Safety Integrated Extended functions as well as an automatic test of the F-DO for the CU310-2, set p9507.6 = 1.

When testing the F-DO of the CU310-2, you must parameterize p10042 and activate the test in p10046.

---

### Note

#### Automatic forced dormant error detection (test stop) and SBT

Automatic forced dormant error detection (test stop) of the Safety Integrated Extended functions is possible together with the "Brake test for test stop selection" function (p10203 = 2)

- To perform automatic forced dormant error detection (test stop) of the F-DI and F-DO of the TM54F, set p10048 = 1.
- Even if you have parameterized forced dormant error detection (test stop) for POWER ON, you can still initiate a test stop at any time through the application.
- If the automatically initiated function cannot be correctly completed as a result of a problem (e.g. communication failure), the function will be automatically restarted after the problem has been resolved.
- After forced dormant error detection (test stop) has been performed successfully, the converter goes into the "Ready" state.
- Timer p9559 is reset as a result of automatic forced dormant error detection (test stop).
- Automatic forced dormant error detection (test stop) for POWER ON does not influence the Safety Integrated functions.

In all cases, the scope of forced dormant error detection (test stop) function is identical.

## Safety devices

When the appropriate safety devices are implemented (e.g. protective doors), it can be assumed that running machinery will not pose any risk to personnel. The user is therefore only informed that forced dormant error detection (test stop) is due by an alarm, which requests the user to perform forced dormant error detection (test stop) at the next possible opportunity.

Examples of when forced dormant error detection (test stop) must be performed:

- When the drives are at a standstill after the system has been switched on (POWER ON).
- Before the protective door is opened.
- At defined intervals (e.g. every eight hours).
- In automatic mode (time and event dependent).

---

### Note

#### Requirements

STO is triggered when a test stop is carried out for the Safety functions. It is not permissible that STO is selected before selecting the test stop.

When blocksize Power Modules are used, the test stop must be triggered under controlled standstill conditions (speed setpoint setting 0, current is flowing through the motor).

---

## Forced dormant error detection (test stop) F-DI/F-DO of TM54F

An automatic test stop function is available for forced dormant error detection (test stop) to test the F-DI/F-DO.

To ensure that the test stop function of the TM54F can be used, the F-DIs that are used must be interconnected according to the following wiring example. The digital inputs of F-DI 0 to F-DI 4 must be connected to the "L1+" power supply. The digital inputs of F-DI 5 to F-DI 9 must be connected to the "L2+" power supply.




Image 4-22 Connection example for TM54F

The F-DIs must be registered for the test stop by means of p10041.

---

**Note**

**F-DI not operational during the test**

The F-DI states are frozen for the duration of the test!

- Ensure that the states of the F-DIs are not evaluated during the test.
- 

The corresponding F-DOs must be registered for the test stop by means of p10046.

---

**Note**

**F-DOs during the period of the test stop**

F-DOs which are not registered for evaluation by means of p10046 are set to "0" for the duration of the test stop ("fail-safe values").

Maximum test stop period:  $T_{\text{Test stop}} = T_{\text{FDIs}} + T_{\text{FDOs}}$

- Testing F-DIs:  $T_{\text{FDIs}} = 3 \times r10015 + 3 \times X \text{ ms}$   
( $X = 20 \text{ ms}$  or  $r10015$  or  $p10017$  - the greatest time value of the 3 values determines the waiting time X)
- Test of the F-DOs:  $T_{\text{FDOs}} = 8 \times r10015 + 6 \times Y \text{ ms}$   
( $Y = p10001$  or  $r10015$  or  $p10017$  - the longest time of the 3 values determines the wait time Y)

The safety functions of the TM54F are executed in the sampling time displayed in r10015. This sampling time corresponds to the lowest value of the communication sampling time entered in p10000[0..5].

---

**Note**

**Manual dynamization required for specific F-DIs or F-DOs**

It may not be possible to use this test stop function for certain F-DIs or F-DOs because of the devices that are connected.

- Ensure dynamic operation of the affected F-DIs/F-DOs by other means, e.g. switch operation or triggering certain machine functions.
- 
- The test stop should be executed at a suitable time. This is the reason that it must be initiated by the application or carried out at POWER ON. This functionality is implemented using parameter p10007, which can be wired via BICO either to an input terminal on the drive unit (CU), or to a bit of any arbitrary PZD.

- Forced dormant error detection (test stop) can be automatically executed at POWER ON.
  - If an automatic test stop of F-DI and F-DO of the TM54F is to be executed, then set p10048 = 1.
  - Even if you have parameterized the test stop for POWER ON, you can still initiate a test stop at any time through the application.
  - If the automatically initiated function cannot be correctly completed as a result of a problem (e.g. communication failure), then after the problem has been resolved, the function is automatically restarted.
  - After forced dormant error detection (test stop) has been successfully executed, the TM54F goes into the "Ready" state.
  - Timer p9559 is reset as a result of automatic forced dormant error detection (test stop).
  - The automatic test stop for POWER ON does not influence the Safety Integrated functions.

The test stop cycle is monitored. On expiration of the parameterized timer (also after POWER ON / warm restart), the alarm A35014: "TM54F: Test stop required" is output.

- p10001 SI wait time for test stop at F-DO 0 ... 3
- p10003 SI Motion forced dormant error detection timer
- p10007 BI: SI Motion forced dormant error detection F-DO signal source
- p10041 SI TM54F F-DI enable for test
- p10046 SI Motion F-DO feedback signal input activation

Forced dormant error detection (test stop) does not require a POWER ON, but it can be automatically performed at POWER ON: The acknowledgment is set by canceling the test stop request.

---

### Note

#### Forced dormant error detection (test stop) of the CU310-2

The description applies analogously to forced dormant error detection (test stop) of the F-DO on the CU310-2. You will find more instructions for carrying out test stops in Section "Forced dormant error detection (test stop) of the CU310-2 (Page 288)".

---

### Note

#### Manual checking of F-DIs and/or F-DOs

If there are F-DIs and/or F-DOs that you do not wish to have checked automatically, or that cannot be checked automatically (e.g. F-DIs of the CU310-2), the correct function of the connected sensor/actuator and its response should be checked at suitable intervals by actuating it.

---

Additional instructions for performing the test stops are provided in Chapters:

- Forced dormant error detection (test stop) of the CU310-2 (Page 288)
- Forced dormant error detection (test stop) of the TM54F (Page 305)



# Control of the safety functions

## 5.1 Control possibilities

The following options for controlling Safety Integrated functions are available:

Table 5- 1 Controlling the Safety Integrated functions

	Terminals (on the Control Unit and Motor/Power Module)	PROFIsafe based on PROFIBUS or PROFINET	TM54F	Control without selection	Onboard F-DI/F-DO (CU310-2)
Basic Functions	Yes	Yes	Yes	No	Yes <sup>1)</sup>
Extended Functions	No	Yes	Yes	SLS, SDI	Yes

<sup>1)</sup> Only the F-DI 0 can be used for the control. The F-DO is not available.

---

### Note

#### PROFIsafe or TM54F

Using a Control Unit, control is possible either via PROFIsafe or TM54F. Mixed operation is not permissible.

---

The safety-oriented input and output terminals (F-DI and F-DO) act as an interface between the SINAMICS S120 Safety Integrated functionality and the process.

A dual-channel signal applied to an F-DI (Fail-safe Digital Input, safety-oriented digital input = safe input terminal pair) controls the active monitoring of the activation/deactivation of safety functions.

An F-DO (Fail-safe Digital Output, safety-oriented digital output = safe output terminal pair) delivers a dual-channel signal representing feedback from the safety functions.

### Dual-channel processing of I/O signals

A dual-channel structure is implemented for data input/output and for processing safety-oriented I/O signals. All requests and feedback signals for safety-oriented functions should be entered or tapped using both channels.

## 5.2 Control signals by way of terminals on the Control Unit and Motor / Power Module

### Features

- Only for the Basic Functions
- Two-channel structure via two digital inputs (e.g. Control Unit / power unit)
- A debounce function can be applied to the terminals of the Control Unit and the Motor Module to prevent incorrect trips due to signal disturbances or test signals. The filter times are set using parameter p9651.
- Different terminal blocks depending on the format
- Automatic ANDing of up to eight digital inputs (p9620[0...7]) on the Control Unit for chassis format power units connected in parallel
- The F-DI 0 is available on the CU310-2

### Overview of the safety function terminals for SINAMICS S120

The different power unit formats of SINAMICS S120 have different terminal designations for the inputs of the safety functions. These are shown in the following table.

Table 5-2 Inputs for safety functions

Module	1st switch-off signal path (p9620[0])	2nd switch-off signal path (EP terminals)
Control Unit CU320-2	X122.1...6/X132.1...6 DI 0...7/16/17/20/21	
Single Motor Module Booksize/Booksize Compact	(see CU320-2)	X21.3 and X21.4 (on the Motor Module)
Single Motor Module/ Power Module Chassis	(see CU320-2)	X41.1 and X41.2
Double Motor Module Booksize/Booksize Compact	(see CU320-2)	X21.3 and X21.4 (motor connection X1) X22.3 and X22.4 (motor connection X2) (on the Motor Module)
Power Module Blocksize with CUA31/CUA32	(see CU320-2)	X210.3 and X210.4 (on the CUA31/CUA32)
Control Unit CU310-2	X120.3 X121.1...4	X120.4 and X120.5
Power Module Chassis with CU310-2	(see CU310-2)	X41.1 and X41.2

For further information about the terminals, see the Equipment Manuals.

#### Note

##### Function of the EP terminals

The EP terminals are only evaluated if the Safety Integrated Basic Functions are released via onboard terminals.



## Description of the two-channel structure

The functions are separately selected/deselected for each drive using two terminals.

- Switch-off signal path, Control Unit (CU310-2/CU320-2)

The desired input terminal is selected via BICO interconnection (BI: p9620[0]).

- Switch-off signal path, Motor Module / Power Module (with CUA3x or CU310-2)

The input terminal is the "EP" terminal ("Enable Pulses").

Both terminals must be energized within the tolerance time p9650, otherwise a fault will be output.




Image 5-1 Example: Terminals for "Safe Torque Off": Example of Motor Modules Booksize and CU320-2

## Grouping drives (not for CU310-2)

To ensure that the function works for more than one drive at the same time, the terminals for the corresponding drives must be grouped together as follows:

1. Switch-off signal path

Connect the p9620 parameters of all drives that belong to a group with a single DI (r0722.x) of the CU320-2.

2. Switch-off signal path (Motor Module / Power Module with CUA3x)

Wire the terminals for the individual Motor Modules / Power Modules, belonging to the group, with CUA31/CUA32.

**Note**

**Parameterization of the grouping**

The grouping must be configured (DI on Control Unit) and wired (EP terminals) identically in both monitoring channels.

**Note**

**Response of STO for grouping**

If a fault in a drive results in a "Safe Torque Off" (STO), this does not automatically mean that the other drives in the same group also switch to "Safe Torque Off" (STO).

The assignment is checked during the test for the switch-off signal paths. The operator selects "Safe Torque Off" for each group. The check is drive-specific.

**Example: Terminal groups**

It must be possible to select/deselect "Safe Torque Off" separately for group 1 (drives 1 and 2) and group 2 (drives 3 and 4). For this purpose, the same grouping for "Safe Torque Off" must be realized both for the Control Unit and the Motor Modules.




Image 5-2 Example: Grouping terminals with Motor Modules Booksize and CU320-2

**Information on the parallel connection of chassis type Motor Modules**

When chassis type Motor Modules are connected in parallel, a safe AND element is created on the parallel drive object. The number of indexes in p9620 corresponds to the number of parallel chassis components in p0120.

### 5.2.1 Simultaneity and tolerance time of the two monitoring channels

The monitoring functions must be selected/deselected simultaneously in both monitoring channels via the input terminals and only have an effect on the associated drive.

- 1 signal: Deselecting the function
- 0 signal: Selecting the function

The time delay that is unavoidable due to mechanical switching processes, for example, can be adapted via parameters. The tolerance time, within which selection/deselection of the two monitoring channels must occur if they are to be considered "simultaneous," is set in the following parameters:

- p9650 (Basic Functions)
- p10002 (Extended Functions)

---

#### Note

##### Parameterization of the tolerance time

In order to avoid that faults are incorrectly initiated, at these inputs the tolerance time must always be set shorter than the shortest time between two switching events (ON/OFF, OFF/ON).

---

- If the monitoring functions are not selected/deselected within the tolerance time, this is detected by the cross-check, and the following fault (STOP F) is output.
  - F01611 (Basic Functions)
  - C01770 (Extended Functions)

For STO: In this case, the pulses have already been canceled as a result of the selection of "Safe Torque Off" on one channel.

---

#### Note

##### Timing between the switching operations in the Basic Functions

Message F01611 with fault value 1000 is output if switching operations occur too frequently. The cause depends on the type of control:

- The signals are continually changing at the F-DI.
- STO is being permanently initiated via PROFIsafe (also as subsequent response).

Within the time  $5 \times p9650$ , there must be at least two switching operations at the terminals or via PROFIsafe with a minimum time between them of p9650.

---

- If the "Safe Stop 1" of the Basic Functions is not selected within the tolerance time in two channels, this is detected by the cross-check, and fault F01611 (STOP F) is output. After the set "SI Safe Stop 1 delay time" (p9652), the pulses are suppressed.

---

**Note**

To enable the drive to brake to standstill even when selected through one channel, the time in p9652 must be shorter than the sum of the parameters for the data cross-check (p9650 and p9658). Otherwise, the drive will coast down after the time p9650 + p9658 has elapsed.

---

Further notes for setting the discrepancy time are contained in the "SINAMICS S120/S150 List Manual" for the following message:

- F01611 (Basic Functions)
- C01770 (Extended Functions)

**Overview of important parameters (see SINAMICS S120/S150 List Manual)**

- p9650 SI SGE switchover discrepancy time (Control Unit)
- p9652 SI Safe Stop 1 delay time (Control Unit)
- p9658 SI transition time STOP F to STOP A (Control Unit)
- p10002 SI Motion F-DI switchover discrepancy time (CPU 1)

## 5.2.2 Bit pattern test

### Bit pattern test of fail-safe outputs

The converter normally responds immediately to signal changes in its fail-safe inputs. This is not desired in the following case: Several control modules test their fail-safe outputs using bit pattern tests (on/off tests), in order to identify faults due to either short-circuit or cross-circuit faults. When you interconnect a fail-safe input of the converter with a fail-safe output of a control module, the converter responds to these test signals.




Image 5-3 Converter response to a bit pattern test

#### Note

##### Debounce time for unwanted triggering of Safety Integrated functions

If the test pulses cause an unwanted triggering of the Safety Integrated functions, these test pulses can be suppressed using the F-DI input filter (p9651 for Basic Functions or p10017 for Extended Functions). To do this, a value must be entered in p9651 or p10017 that is greater than the duration of a test pulse.

### Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9651 SI STO/SBC/SS1 debounce time (Control Unit)
- p10017 SI Motion digital inputs debounce time (processor 1)

## 5.3 Activation via PROFIsafe

As an alternative to controlling Safety Integrated Functions via terminals, TM54F or on-board terminals on the CU310-2, they can also be controlled via PROFIsafe. For communication via PROFIBUS and PROFINET, the following PROFIsafe telegrams can be used: 30, 31, 901, and 902

Control via PROFIsafe is available for both Safety Integrated Basic Functions and Safety Integrated Extended Functions.

---

### Note

#### Timing between the switching operations

Message F01611 with fault value 1000 is output if switching operations occur too frequently. The cause depends on the type of control:

- The signals are continually changing at the F-DI.
- STO is being permanently initiated via PROFIsafe (also as subsequent response).

Within the time  $5 \times p9650$ , there must be at least two switching operations at the terminals or via PROFIsafe with a minimum time between them of  $p9650$ .

---

### 5.3.1 Enabling of the control via PROFIsafe

For PROFIsafe communication, SINAMICS devices require a PROFIBUS or a PROFINET interface. Every drive with configured PROFIsafe in the drive unit represents a PROFIsafe slave (F slave or F device) with a fail-safe communication to the F host via PROFIBUS or PROFINET and is assigned its own PROFIsafe telegram.

In this case, a PROFIsafe channel, known as a safety slot, is created using the STARTER commissioning tool and transferred to HW Config (alternatively, this safety slot can be created by the SIMATIC Manager Step 7 using HW Config). The Safety Integrated functions can then be additionally controlled via the PROFIsafe telegrams 30, 31, 901 and 902. The structure of the associated control and status words is described below (see Section "Telegram format (Page 177)"). The selected PROFIsafe telegrams for Safety Integrated are placed in front of the standard telegram for communication (e.g. telegram 2).

#### Enabling PROFIsafe

The Safety Integrated Functions are enabled via PROFIsafe using parameters p9601:

- Basic Functions: p9601 = 8 hex or 9 hex
- Extended Functions: p9601 = C hex or D hex

---

#### Note

##### License requirement for Safety Integrated functions via PROFIsafe

No license is required to use Basic Functions. This also applies for control via PROFIsafe. However, for Extended Functions, you require an appropriate license that will be charged for.

---

All parameters involved in PROFIsafe communication are password protected against undesirable changes and secured using a checksum. The telegram configuration is performed in the hardware configuration in the F-host (see Sections "PROFIsafe via PROFIBUS (Page 312)" and "PROFIsafe via PROFINET (Page 322)").

#### Safety Integrated Basic Functions via PROFIsafe and via terminals

Control of the Basic Functions via terminals on the Control Unit and on the Motor/Power Module (parameters p9601.0 = 1) may be enabled in parallel. In order to be able to select SS1, an SS1 delay time p9652 > 0 must be configured. With PROFIsafe, both SS1 and STO can be selected. Only SS1 is available for control via terminal.

STO takes priority over SS1, i.e. STO becomes active if SS1 and STO are simultaneously selected.

### 5.3.2 Selecting a PROFIsafe telegram

Proceed as follows to define the PROFIsafe telegram:

1. In parameter p60022 select the required telegram.
2. In parameter p9611, select the same telegram number.

---

#### Note

##### Compatibility mode

If you set p9611 = 998 for p60022 = 0 (for instance, if you have upgraded the safety project to firmware V4.5), then the PROFIsafe telegram 30 is also set as for p60022 = 30 and p9611 = 30.

---

The STARTER commissioning tool supports you when setting these parameters:

1. In STARTER, select "<Drive device> > Communication > Telegram configuration".
2. Click the "Adapt telegram configuration" button and select the telegram there.
3. Then select "<Drive device> > <Drive> > Functions > Safety Integrated".
4. Click the "Configuration" button.



- In the "Configuration" dialog box, click the "PROFIsafe configuration" button.

In the "PROFIsafe configuration" dialog, the telegrams currently set in parameters p60022 and p9611 are displayed.




Image 5-4 Selecting a PROFIsafe telegram

- To transfer the telegram from p60022 to p9611, click the "Accept PROFIsafe telegram" button.

### 5.3.3 Telegram format

The PROFIsafe telegram received at the Control Unit is displayed in r9768, and the PROFIsafe telegram to be sent, in parameter r9769.

#### Structure of telegram 30

Telegram 30 transfers safety control word 1 (S\_STW1) and safety status word 1 (S\_ZSW1) as user data. It is structured as follows:

	Output data	Input data
PZD1	S_STW1	S_ZSW1

### Structure of telegram 31

Telegram 31 transfers safety control word 2 (S\_STW2) and safety status word 2 (S\_ZSW2) as user data. It is structured as follows:

	Output data	Input data
PZD1	S_STW2	S_ZSW2
PZD2		

### Structure of telegram 901

Telegram 901 transfers the S\_STW2, the variable SLS limit (S\_SLS\_LIMIT\_A), the S\_ZSW2, the active SLS value of level 1 (S\_SLS\_LIMIT\_A\_ACTIVE), a counter value (S\_CYCLE\_COUNT) and the safe position value in 16-bit format (S\_XIST16) as user data. It is structured as follows:

	Output data	Input data
PZD1	S_STW2	S_ZSW2
PZD2		
PZD3	S_SLS_LIMIT_A	S_SLS_LIMIT_A_ACTIVE
PZD4	–	S_CYCLE_COUNT
PZD5	–	S_XIST16

### Structure of telegram 902

Telegram 902 transfers the S\_STW2, the variable SLS limit (S\_SLS\_LIMIT\_A), the S\_ZSW2, the active SLS value of level 1 (S\_SLS\_LIMIT\_A\_ACTIVE), a counter value (S\_CYCLE\_COUNT) and the safe position value in 32-bit format (S\_XIST32) as user data. It is structured as follows:

	Output data	Input data
PZD1	S_STW2	S_ZSW2
PZD2		
PZD3	S_SLS_LIMIT_A	S_SLS_LIMIT_A_ACTIVE
PZD4	–	S_CYCLE_COUNT
PZD5	–	S_XIST32
PZD6		

Telegram 902 can only be used, if the higher-level controller (F-host) can process 32-bit values.

#### Note

##### Telegram 902 for SIEMENS products

STEP 7 Safety in the TIA Portal can process this value. However, Distributed Safety in older STEP 7 version cannot do this.

## 5.3.4 Process data

### 5.3.4.1 S\_STW1 and S\_ZSW1 (Basic Functions)

#### Safety control word 1 (S\_STW1)

S\_STW1, output signals  
see function chart [2806].

Table 5- 3 Description of safety-control word1 (S\_STW1)

Byte	Bit	Meaning	Remarks	
0	0	STO	1	Deselect STO
			0	Select STO
	1	SS1	1	Deselect SS1
			0	Select SS1
	2	SS2	0	– <sup>1)</sup>
	3	SOS	0	– <sup>1)</sup>
	4	SLS	0	– <sup>1)</sup>
	5	Reserved	–	–
	6	SLP	0	– <sup>1)</sup>
7	Internal Event ACK	1/0	Acknowledgment	
		0	No acknowledgment	
1	0	Reserved	–	–
	1	Select SLS bit 0	0	– <sup>1)</sup>
	2	Select SLS bit 1	0	– <sup>1)</sup>
	3	Reserved	–	–
	4	SDI positive	0	– <sup>1)</sup>
	5	SDI negative	0	– <sup>1)</sup>
	6, 7	Reserved	–	–

<sup>1)</sup> Signals not relevant for Basic Functions: Should be set to "0".

**Safety status word 1 (S\_ZSW1)**

S\_ZSW1, input signals  
see function diagram [2806].

Table 5- 4 Description of safety status word 1 (S\_ZSW1)

Byte	Bit	Meaning	Remarks	
0	0	STO active	1	STO active
			0	STO not active
	1	SS1 active	1	SS1 active
			0	SS1 not active
	2	SS2 active	0	– <sup>1)</sup>
	3	SOS active	0	– <sup>1)</sup>
	4	SLS active	0	– <sup>1)</sup>
	5	Reserved	–	–
	6	SLP active	0	– <sup>1)</sup>
7	Internal Event	1	Internal event	
		0	No internal event	
1	0	Reserved	–	–
	1	Active SLS level bit 0	0	– <sup>1)</sup>
	2	Active SLS level bit 1	0	– <sup>1)</sup>
	3	SOS selected	0	– <sup>1)</sup>
	4	SDI positive active	0	– <sup>1)</sup>
	5	SDI negative active	0	– <sup>1)</sup>
	6	Reserved	–	–
	7	SSM (speed below limit value)	0	– <sup>1)</sup>

<sup>1)</sup> Signals not relevant for Basic Functions: Must not be evaluated.

### 5.3.4.2 S\_STW2 and S\_ZSW2 (Basic Functions)

#### Safety control word 2 (S\_STW2)

S\_STW2, output signals  
see function diagram [2806].

Table 5- 5 Description of safety-control word 2 (S\_STW2)

Byte	Bit	Meaning	Remarks	
0	0	STO	1	Deselect STO
			0	Select STO
	1	SS1	1	Deselect SS1
			0	Select SS1
	2	SS2	0	- <sup>1)</sup>
	3	SOS	0	- <sup>1)</sup>
	4	SLS	0	- <sup>1)</sup>
	5	Reserved	-	-
	6	SLP	0	- <sup>1)</sup>
7	Internal Event ACK	1/0	Acknowledgment	
		0	No acknowledgment	
1	0	Reserved	-	-
	1	Select SLS bit 0	0	- <sup>1)</sup>
	2	Select SLS bit 1	0	- <sup>1)</sup>
	3	Reserved	-	-
	4	SDI positive	0	- <sup>1)</sup>
	5	SDI negative	0	- <sup>1)</sup>
	6, 7	Reserved	-	-
2	0 ... 2	Reserved	-	-
	3	Select SLP position range	0	- <sup>1)</sup>
	4 ... 7	Reserved	-	-
3	0 ... 3	Reserved	-	-
	4	SS2E	0	- <sup>1)</sup>
	5, 6, 7	Reserved	-	-

<sup>1)</sup> Signals not relevant to Basic Functions should be set to "0".

**Safety status word 2 (S\_ZSW2)**

S\_ZSW2, input signals  
see function diagram [2806].

Table 5-6 Description of safety status word 2 (S\_ZSW2)

Byte	Bit	Meaning	Remarks	
0	0	STO active	1	STO active
			0	STO not active
	1	SS1 active	1	SS1 active
			0	SS1 not active
	2	SS2 active	0	– <sup>1)</sup>
	3	SOS active	0	– <sup>1)</sup>
	4	SLS active	0	– <sup>1)</sup>
	5	Reserved	–	–
	6	SLP active	0	– <sup>1)</sup>
7	Internal Event	1	Internal event	
		0	No internal event	
1	0	Reserved	–	–
	1	Active SLS level, bit 0	0	– <sup>1)</sup>
	2	Active SLS level, bit 1	0	– <sup>1)</sup>
	3	Reserved	–	–
	4	SDI positive active	0	– <sup>1)</sup>
	5	SDI negative active	0	– <sup>1)</sup>
	6, 7	Reserved	–	–
2	0 ... 2	Reserved	–	–
	3	SLP active position range	0	– <sup>1)</sup>
	4, 5	Reserved	–	–
	6	Safe position valid	0	– <sup>1)</sup>
	7	Safely referenced	0	– <sup>1)</sup>
3	0 ... 2	F-DI 0 ... 2 <sup>2)</sup>	0	– <sup>1)</sup>
	3	Reserved	–	–
	4	SS2E active	0	– <sup>1)</sup>
	5	SOS selected	0	– <sup>1)</sup>
	6	SLP upper limit maintained	0	– <sup>1)</sup>
	7	SLP lower limit maintained	0	– <sup>1)</sup>

<sup>1)</sup> Signals not relevant for Basic Functions: Must not be evaluated.

<sup>2)</sup> Only valid for CU310-2.

### 5.3.4.3 S\_STW1 and S\_ZSW1 (Extended Functions)

#### Safety control word 1 (S\_STW1)

S\_STW1, output signals  
see function chart [2842].

Table 5- 7 Description of safety-control word1 (S\_STW1)

Byte	Bit	Meaning	Remarks	
0	0	STO	1	Deselect STO
			0	Select STO
	1	SS1	1	Deselect SS1
			0	Select SS1
	2	SS2	1	Deselect SS2
			0	Select SS2
	3	SOS	1	Deselect SOS
			0	Select SOS
	4	SLS	1	Deselect SLS
			0	Select SLS
	5	Reserved	–	–
	6	SLP	1	Deselect SLP
			0	Select SLP
	7	Internal Event ACK	1/0	Acknowledgment
0			No acknowledgment	
1	0	Reserved	–	–
	1	Select SLS bit 0	–	Selection of the speed limit for SLS (2 bits)
	2	Select SLS bit 1	–	
	3	Reserved	–	–
	4	SDI positive	1	Deselect SDI positive
			0	Select SDI positive
	5	SDI negative	1	Deselect SDI negative
			0	Select SDI negative
6, 7	Reserved	–	–	

**Safety status word 1 (S\_ZSW1)**

S\_ZSW1, input signals  
see function diagram [2842].

Table 5- 8 Description of safety status word 1 (S\_ZSW1)

Byte	Bit	Meaning	Remarks	
0	0	STO active	1	STO active
			0	STO not active
	1	SS1 active	1	SS1 active
			0	SS1 not active
	2	SS2 active	1	SS2 active
			0	SS2 not active
	3	SOS active	1	SOS active
			0	SOS not active
	4	SLS active	1	SLS active
			0	SLS not active
	5	Reserved	–	–
	6	SLP active	1	SLP active
			0	SLP not active
			–	The status signal "SLP active" is not the same as the diagnostic signal "SLP active" (r9722.6), but is the AND logic operation of "SLP active" (r9722.6) and "safely referenced" (r9722.23).
7	Internal Event	1	Internal event	
		0	No internal event	
1	0	Reserved	–	–
	1	Active SLS level bit 0	–	Display of the velocity limit for SLS (2 bits)
	2	Active SLS level bit 1	–	
	3	SOS selected	1	SOS selected
			0	SOS deselected
	4	SDI positive active	1	SDI positive active
			0	SDI positive not active
	5	SDI negative active	1	SDI negative active
			0	SDI negative not active
6	Reserved	–	–	
7	SSM (speed)	1	SSM (speed below limit value)	
		0	SSM (speed higher than/equal to limit)	



### 5.3.4.4 S\_STW2 and S\_ZSW2 (Extended Functions)

#### Safety control word 2 (S\_STW2)

S\_STW2, output signals  
see function diagram [2843].

Table 5-9 Description of safety-control word 2 (S\_STW2)

Byte	Bit	Meaning	Remarks	
0	0	STO	1	Deselect STO
			0	Select STO
	1	SS1	1	Deselect SS1
			0	Select SS1
	2	SS2	1	Deselect SS2
			0	Select SS2
	3	SOS	1	Deselect SOS
			0	Select SOS
	4	SLS	1	Deselect SLS
			0	Select SLS
5	Reserved	–	–	
6	SLP	1	Deselect SLP	
		0	Select SLP	
7	Internal Event ACK	1/0	Acknowledgment	
		0	No acknowledgment	
1	0	Reserved	–	–
	1	Select SLS bit 0	–	Selection of the speed limit for SLS (2 bits)
	2	Select SLS bit 1	–	
	3	Reserved	–	–
	4	SDI positive	1	Deselect SDI positive
			0	Select SDI positive
	5	SDI negative	1	Deselect SDI negative
0			Select SDI negative	
6, 7	Reserved	–	–	
2	0 ... 2	Reserved	–	–
	3	Select SLP position range	1	Select SLP area 2 (SLP2)
			0	Select SLP area 1 (SLP1)
4 ... 7	Reserved	–	–	
3	0	Select gearbox stage, bit 0	–	Select gearbox stage (3 bits)
	1	Select gearbox stage, bit 1	–	
	2	Select gearbox stage, bit 2	–	
	3	Gearbox stage switchover		
	4	SS2E	1	Deselect SS2E
			0	Select SS2E
5 ... 7	Reserved	–	–	

**Safety status word 2 (S\_ZSW2)**

S\_ZSW2, input signals  
see function diagram [2843].

Table 5- 10 Description of safety status word 2 (S\_ZSW2)

Byte	Bit	Meaning	Remarks	
0	0	STO active	1	STO active
			0	STO not active
	1	SS1 active	1	SS1 active
			0	SS1 not active
	2	SS2 active	1	SS2 active
			0	SS2 not active
	3	SOS active	1	SOS active
			0	SOS not active
	4	SLS active	1	SLS active
			0	SLS not active
	5	Reserved	–	–
	6	SLP active	1	SLP active
			0	SLP not active
			–	The status signal "SLP active" is not the same as the diagnostic signal "SLP active" (r9722.6), but is the AND logic operation of "SLP active" (r9722.6) and "safely referenced" (r9722.23).
7	Internal Event	1	Internal event	
		0	No internal event	
1	0	Reserved	–	–
	1	Active SLS level bit 0	–	Display of the velocity limit for SLS (2 bits)
	2	Active SLS level bit 1	–	
	3	Reserved	–	–
	4	SDI positive active	1	SDI positive active
			0	SDI positive not active
	5	SDI negative active	1	SDI negative active
			0	SDI negative not active
	6	Reserved	–	–
7	SSM (speed)	1	SSM (speed below limit value)	
		0	SSM (speed higher than/equal to limit)	

Byte	Bit	Meaning	Comments	
2	0 ... 2	Reserved	–	–
	3	SLP active position range	1	SLP area 2 (SLP2) active
			0	SLP area 1 (SLP1) active
			–	The status signal "SLP active position range" always corresponds to the diagnostic signal "SLP active position range" (r9722.19).
	4, 5	Reserved	–	–
	6	Safe position valid	1	Safe position valid
			0	Safe position invalid
	7	Safely referenced	1	Safe position is applicable as "safely referenced"
0			Safe position is not applicable as "safely referenced"	
3	0	F-DI 0 <sup>1)</sup>	1	F-DI 0 inactive
			0	F-DI 0 active
	1	F-DI 1 <sup>1)</sup>	1	F-DI 1 inactive
			0	F-DI 1 active
	2	F-DI 2 <sup>1)</sup>	1	F-DI 2 inactive
			0	F-DI 2 active
	3	Reserved	–	–
	4	SS2E active	1	SS2E active
			0	SS2E not active
	5	SOS selected	1	SOS selected
			0	SOS deselected
	6	SLP upper limit maintained	1	SLP: Upper limit maintained
			0	SLP: Upper limit not maintained
			–	The status signal "upper SLP limit maintained" always corresponds to the diagnostic signal "upper SLP limit maintained" (r9722.30).
	7	SLP lower limit maintained	1	SLP: Lower limit maintained
			0	SLP: Lower limit not maintained
–			The status signal "lower SLP limit maintained" always corresponds to the diagnostic signal "lower SLP limit maintained" (r9722.31).	

<sup>1)</sup> Only valid for CU310-2.

### 5.3.4.5 Additional process data

#### S\_SLS\_LIMIT\_A

- PZD3 in telegrams 901 and 902, output signals
- SLS limit value input
- Value range 1 ... 32767; 32767  $\triangleq$  100% of the 1st SLS level

#### S\_SLS\_LIMIT\_A\_ACTIVE

- PZD3 in telegrams 901 and 902, input signals
- Active SLS limit value
- Value range 1 ... 32767; 32767  $\triangleq$  100%
- Must only be evaluated if SLS 1 active and p9501.24 = 1.

#### S\_CYCLE\_COUNT

- PZD4 in telegrams 901 and 902, input signals
- Counter for the safety cycle
- Value range -32768 ... +32767
- May only be evaluated if the transfer of safe position values is active (p9501.25 = 1) and the position value is valid (r9722.22 = r9722.23 = 1).

#### S\_XIST16

- PZD5 in telegram 901, input signals
- Current actual position value (16 bits)
- Value range  $\pm$ 32767
- Scaling using p9574

---

#### Note

##### Scaling

It is not permissible that the position value transferred in S\_XIST16 exceeds the value range that can be represented. This is the reason that the safe position value of the drive (r9713[0]) can be allocated a scaling factor. The position value is divided by this factor before transfer. As a consequence, a wider value range can be transferred with a reduced accuracy.

Example: For a position of -29.999 mm signaled in r9708[0] and r9708[1] and a scaling factor of p9x74 = 1000, a numerical value of -29 is signaled to the controller.

---

- May only be evaluated if the transfer of safe position values is active (p9501.25 = 1) and the position value is valid (r9722.22 = r9722.23 = 1).

## S\_XIST32

- PZD5 and PZD6 in telegram 902, input signals
- Current actual position value (32 bits)
- Value range  $\pm 737280000$
- Unit: 1  $\mu\text{m}$  (linear axis), 0.001  $^\circ$  (rotary axis)
- May only be evaluated if the transfer of safe position values is active (p9501.25 = 1) and the position value is valid (r9722.22 = r9722.23 = 1).

### 5.3.5 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2840 SI Extended Functions - SI Motion drive-integrated control signals/status signals
- 2858 SI Extended Functions - control via PROFIsafe (p9601.2=p9601.3 = 1)

#### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9562[0...3] SI Motion SLP (SE) stop response (Control Unit)
- p9563[0...3] SI Motion SLS (SG)-specific stop response (Control Unit)
- p9566 SI Motion SDI stop response (Control Unit)
- p9580 SI Motion stop response delay bus failure (Control Unit)
- p9601 SI enable functions integrated in the drive (Control Unit)
- p9610 SI PROFIsafe address (Control Unit)
- p9611 SI PROFIsafe telegram selection (Control Unit)
- p9612 SI PROFIsafe failure response (Control Unit)
- p60022 Selecting a PROFIsafe telegram

## 5.4 Control via TM54F

The TM54F is a terminal expansion module for snapping onto a DIN EN 60715 mounting rail: The TM54F features fail-safe digital inputs and outputs for controlling and signaling the states of the Safety Integrated Extended Functions.

### Note

#### DRIVE-CLiQ line of the TM54F

- A TM54F must be connected directly to a Control Unit via DRIVE-CLiQ.
- Each Control Unit can be assigned only one TM54F which is connected via DRIVE-CLiQ.
- Additional DRIVE-CLiQ nodes can be operated at the TM54F, such as Sensor Modules and Terminal Modules (excluding an additional TM54F). It is not permissible that Motor Modules and Line Modules are connected to a TM54F.
- In the case of a CU310-2 Control Unit, it is not possible to connect the TM54F to the DRIVE-CLiQ line of a Power Module. The TM54F can only be connected to the sole DRIVE-CLiQ X100 socket of the Control Unit.

Table 5- 11 Overview of the TM54F interfaces

Type	Number
Fail-safe digital outputs (F-DO)	4
Fail-safe digital inputs (F-DI)	10
Sensor <sup>1)</sup> power supplies, dynamic response supported <sup>2)</sup>	2
Sensor <sup>1)</sup> power supply, no dynamic response	1
Digital inputs for checking the F-DO with activated forced checking procedure (test stop)	4

<sup>1)</sup> Sensors: Fail-safe devices for command operations and sensing (e.g. Emergency Stop pushbuttons, safety door locks, position switches, and light arrays / light curtains).

<sup>2)</sup> Dynamic response: The sensor power supply is switched on and off by the TM54F when the forced dormant error detection (test stop) is active for the sensors, cable routing, and the evaluation electronics.

The TM54F provides four fail-safe digital outputs and ten fail-safe digital inputs. A fail-safe digital output consists of a 24 VDC switching output, an output switching to ground and a digital input for reading back the switching state. A fail-safe digital input is made up of 2 digital inputs.

### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2890 SI TM54F - overview

### 5.4.1 Fault acknowledgment

You have the following options of acknowledging TM54F faults after troubleshooting:

- POWER ON
- Falling edge of the signal "Internal Event ACK" with subsequent acknowledgment on the Control Unit ("fail-safe acknowledgment").

### 5.4.2 Overview of the F-DIs

#### Description

Fail-safe digital inputs (F-DI) consist of 2 digital inputs. For the 2nd digital input, in addition cathode (M) of the optocoupler is fed out in order to allow the connection of an output of an F control system with switched ground (for this purpose, the anode must be connected to 24 V DC).

Parameter p10040 is used to determine whether an F-DI is operated as NC/NC or NC/NO contact. The status of each DI can be read at parameter r10051. The bits of both drive objects are logically AND'ed and return the status of the relevant F-DI.

Test signals from F-DOs and interference pulses can be filtered out using the input filter (p10017), so that they do not cause any faults.

#### Explanation of terms:

**NC contact / NC contact:** To select the safety function, a "zero level" must be present at both inputs.

**NC contact / NO contact:** To select the safety function, a "zero level" must be present at input 1 and a "1 level" at input 2.

The signal states at the two associated digital inputs (F-DI) must assume the same status configured in p10040 within the monitoring time set in p10002.

To enable forced dormant error detection (test stop), connect the digital inputs of F-DI 0 ... 4 of the TM54F to the dynamic voltage supply L1+ and the digital inputs to F-DI 5 ... 9 to L2+. (For further information on forced dormant error detection (test stop), see the relevant function description in Chapter "Forced dormant error detection (test stop) (Page 160)").

Table 5- 12 Overview of the fail-safe inputs in the SINAMICS S120/S150 List Manual:

Module	Function diagram	Inputs
TM54F	2893	F-DI 0 ... 4
	2894	F-DI 5 ... 9

## F-DI features

- Fail-safe configuration with 2 digital inputs per F-DI
- Input filter to block test signals with an adjustable suppression time (p10017), see Chapter "Bit pattern test (Page 173)".
- Configurable connection of NC/NC or NC/NO contacts by means of p10040
- Status parameter r10051
- Adjustable time window for monitoring discrepancy at both digital inputs by means of parameter p10002 for all F-DIs

---

### Note

#### Discrepancy time

To avoid incorrect triggering of fault messages, at these inputs the discrepancy time must always be set less than the shortest time between 2 switching events (ON/OFF, OFF/ON).

- Second digital input with additional tap of the optocoupler cathode for connecting a ground-switching output of a fail-safe controller.
- The signal states of the two digital inputs of the F-DIs are frozen at logical 0 (safety function selected) when different signal states are present within a failsafe F-DI until a safe acknowledgment has been carried out by means of an F-DI via parameter p10006 (SI acknowledgment internal event input terminal).
- The monitoring time (p10002) for the discrepancy of the two digital inputs of an F-DI may have to be increased so that switching operations do not trigger an undesired response, thereby necessitating a safe acknowledgment. Therefore, the signal states at the two associated digital inputs (F-DI) must have the same state within this monitoring time, otherwise the following fault will be output F35151 "TM54F: Discrepancy error". This requires safe acknowledgment.

 <b>WARNING</b>
--

<b>Danger to life due to incorrect switching states caused by quiescent currents in the switched-off state</b>
--

In contrast to mechanical switching contacts (e.g. Emergency Stop switches), quiescent currents can still flow through semiconductor switches even when they are switched off. This can lead to false switching states if digital inputs are not connected correctly.
---

- |   |
|---|
| <ul style="list-style-type: none"><li>• Pay attention to the conditions for digital inputs/outputs specified in the relevant manufacturer documentation.</li><li>• Use only outputs that have a maximum quiescent current of 0.5 mA when "OFF" (in accordance with IEC 61131 part 2, Chapter 5.2 (2008)).</li></ul> |
|---|

More information on this topic is available on the Internet at: Parameterizing and configuring safety hardware (<http://support.automation.siemens.com/WW/view/de/39700013>)



**Function diagrams (see SINAMICS S120/S150 List Manual)**

- 2893 SI TM54F - Fail-safe digital inputs (F-DI 0 ... F-DI 4)
- 2894 SI TM54F - Fail-safe digital inputs (F-DI 5 ... F-DI 9)

**Overview of important parameters (see SINAMICS S120/S150 List Manual)**

- p10002 SI TM54F F-DI switchover discrepancy time
- p10017 SI TM54F digital inputs debounce time
- p10040 SI TM54F F-DI input mode
- r10051.0...9 CO/BO: SI TM54F digital inputs, status

**5.4.3 Overview of the F-DOs**

Fail-safe digital outputs (F-DO) consist of 2 digital outputs and 1 digital input that checks the switching state for forced dormant error detection (test stop). The 1st digital output switches 24 V DC, and the 2nd switches the ground of the power supply of X514 (TM54F).

The status of each F-DO can be read at parameter r10052. The status of the associated DI can be read at parameter r10053 (only available for TM54F\_SL (TM54F Slave Module)).

The actuator connected to the F-DO can also be tested under specific conditions as part of forced dormant error detection (test stop). See Section "Forced dormant error detection (test stop) of the TM54F (Page 305)".

Table 5- 13 Overview of the fail-safe outputs in the SINAMICS S120/S150 List Manual:

Module	Function diagram	Outputs	Associated checking inputs
TM54F	2895	F-DO 0 ... 3	DI 20 ... 23

**F-DO signal sources**

A drive group contains several drives with similar characteristics. The groups are parameterized at the p10010 and p10011 parameters.

The following signals are available for interconnecting (p10042, ..., p10045) each one of the four drive groups with the F-DO:

- STO active
- SS1 active
- SS2 active
- SOS active
- SLS active
- SSM feedback active
- Safe State

- SOS selected
- Internal event
- Active SLS level bit 0
- Active SLS level bit 1
- SDI positive active
- SDI negative active
- SLP active
- Active SLP area

The following (safe state) signals can be requested via p10039[0...3] for each drive group (index 0 corresponds with drive group 1 etc.):

- STO active (power removed/pulses suppressed)
- SS1 active
- SS2 active
- SOS active
- SLS active
- SDI positive active
- SDI negative active
- SLP active




Image 5-5 Safe state selection (example Extended Functions)

The same signals (high-active) of each drive or drive group are logically linked by means of AND operation. The different signals selected via p10039 are logically OR'ed. Result of these logic operations is the "Safe State" for each drive group. You will find details in the SINAMICS S120/S150 List Manual in function diagrams 2901 (Basic Functions) and 2906 (Extended Functions).

Each F-DO supports the interconnection of up to 6 signals by way of indexing (p10042[0...5] to p10045[0...5]) and their output as logical AND operation.

**Function diagrams (see SINAMICS S120/S150 List Manual)**

- 2893 SI TM54F - Fail-safe digital inputs (F-DI 0 ... F-DI 4)
- 2894 SI TM54F - Fail-safe digital inputs (F-DI 5 ... F-DI 9)
- 2895 SI TM54F - Fail-safe digital outputs (F-DO 0 ... 3), digital inputs (DI 20 ... 23)
- 2900 SI TM54F - Basic Functions control interface (p9601.2/3 = 0, p9601.6 = 1)
- 2901 SI TM54F - Basic Functions Safe State selection
- 2902 SI TM54F - Basic Functions assignment (F-DO 0 ... F-DO 3)
- 2905 SI TM54F - Extended Functions control interface (p9601.2 = 1 & p9601.3 = 0)
- 2906 SI TM54F - Extended Functions Safe State selection
- 2907 SI TM54F - Extended Functions assignment (F-DO 0 ... F-DO 3)

**Overview of important parameters (see SINAMICS S120/S150 List Manual)**

- p10039[0...3] SI TM54F Safe State signal selection
- p10042[0...5] SI TM54F F-DO 0 signal sources
- p10043[0...5] SI TM54F F-DO 1 signal sources
- p10044[0...5] SI TM54F F-DO 2 signal sources
- p10045[0...5] SI TM54F F-DO 3 signal sources
- r10051.0...9 CO/BO: SI TM54F digital inputs, status
- r10052.0...3 CO/BO: SI TM54F digital outputs, status
- r10053.0...3 CO/BO: SI TM54F digital inputs 20 ... 23, status

## 5.5 Response for a communication failure via PROFIsafe or to the TM54F

### Factory setting for the response to communication failure

In the following cases, the drive responds with a STOP A.

- PROFIsafe communication to the higher-level control has failed.
- DRIVE-CLiQ communication to the TM54F has failed.

### 5.5.1 STOP B as response to communication failure with PROFIsafe control

If, for a communication failure, the axis coasting down can result in subsequent damage, as response to the communication failure, instead of a STOP A, you can select that the axis is stopped along a ramp.

#### Precondition

You have enabled Safety Integrated Extended Functions or Basic Functions.

#### Communication failure

In this context, communication failure can mean the following:

- Interruption or disturbance in PROFIsafe communication
- The higher-level controller (F-CPU) is in the STOP state

#### Drive response

Parameter p9612 defines the drive stop response when PROFIsafe communication fails:

- p9612 = 0: STOP A
- p9612 = 1: STOP B

---

#### Note

For the selected STOP B stop response, in order to ensure that the OFF3 ramp is actually maintained, when just using the Safety Basic Functions, the following must be carefully observed:

- The STOP F to STOP A (p9658, p9858) transition time must be set to greater than or equal to the SS1 delay time (p9652, p9852).
  - If a higher-level control system responds to the drive fault by withdrawing the controller enable signals, for faults F01611 and F30611, the message type must be changed to alarm (p2118, p2119).
-

## 5.5.2 Initiating ESR for a communication failure

If, braking the axis along the braking ramp for a communication failure can result in subsequent damage, the braking operation can be delayed by a maximum of 800 ms. During this delay time, the converter can suitably stop the axis using the "Extended stop and retract (ESR)" function.

If communication to the higher-level motion control is still available (e.g. when the TM54F fails or the SIMATIC F-CPU fails for separate motion control), then the control system can control the retraction during this delay time. This assumes that retraction has been configured on the control side, see S\_ZSW1B, bit 14 (r9734.14) "ESR retraction requested".

### Requirement

The following preconditions apply to the drive response subsequently described:

- You have enabled Safety Integrated Extended Functions.
- The function module "Extended stop and retract" is activated and enabled.

### Communication failure

In this context, communication failure can mean the following:

- Interruption or disturbance in PROFIsafe communication
- The higher-level controller (SIMATIC F-CPU) is in the STOP state
- Interruption or disturbance in the DRIVE-CLiQ communication for control via TM54F

### Drive response

For a communication failure, the converter responds corresponding to the settings of the ESR function module.

For communication failure, a maximum delay time of (p9580) 800 ms can be set. The converter activates the "Safe Torque Off" function after this time expires.

Depending on the particular setting, stop responses or safety functions can prevent the ESR response. You must set the safety functions as follows in order that you do not influence the ESR response:

Safety function	Precondition for the ESR response after communication failure	Setting
SLP	As SLP response, a STOP is parameterized with delayed pulse cancellation when the bus fails	p9562[0...1] ≥ 10
SLS	As SLS response, a STOP is parameterized with delayed pulse cancellation when the bus fails	p9563[0...3] ≥ 10
SDI	As SDI response, a STOP is parameterized with delayed pulse cancellation when the bus fails	p9566[0...3] ≥ 10
---	Adequate STOP F to STOP B transition time if additional faults occur when the communication fails	p9555 ≥ p9580
---	Adequate STOP F to STOP A transition time if additional faults occur when the communication fails	p9658 ≥ p9580
---	Check whether the effective setpoint speed limiting (CO: r9733) is set to zero when STOP F is active.	p9507.1



## 5.6 Control of the Extended Functions via F-DI (for CU310-2)

The following terminals are provided on the CU310-2:

Table 5- 14 Interface overview of the CU310-2

Type	Number
Fail-safe digital outputs (F-DO)	1
Fail-safe digital inputs (F-DI)	3
Sensor <sup>1)</sup> power supply, no dynamic response	1
Digital input for checking the F-DO during forced dormant error detection (test stop)	1

<sup>1)</sup> Sensors: Fail-safe devices for command operations and sensing (e.g. Emergency Stop pushbuttons, safety door locks, position switches, and light arrays / light curtains).

The CU310-2 has 1 fail-safe digital output and 3 fail-safe digital inputs. A fail-safe digital output consists of a 24 VDC switching output, an output switching to ground and a digital input for reading back the switching state. A fail-safe digital input is made up of 2 digital inputs.

---

### Note

#### Fault acknowledgment

You have the following options of acknowledging CU310-2 faults after removing the fault:

- POWER ON
  - Falling edge of the signal "Internal Event ACK" with subsequent acknowledgment on the Control Unit ("fail-safe acknowledgment").
- 

The signal states of the two digital inputs of the F-DI are frozen at logical 0 (safety function selected) when different signal states are present within a fail-safe F-DI, until a safe acknowledgment has been performed through an F-DI via parameter p10006 (SI acknowledgment internal event input terminal) or the extended message acknowledgment has been performed.

The monitoring time (p10002) for the discrepancy of the two digital inputs of an F-DI may have to be increased so that switching operations do not trigger an undesired response, thereby necessitating a safe acknowledgment. The signal states at the two related digital inputs (F-DI) will need to have the same state within this monitoring time or fault C01770/C30770 will be triggered, "discrepancy error" (CU310-2). This requires safe acknowledgment.

---

### Note

#### Discrepancy time

The discrepancy time must be set so that it is always less than the smallest expected switching interval of the signal at this F-DI.

---

## 5.6.1 Overview of the F-DIs

### Description

Fail-safe digital inputs (F-DI) consist of 2 digital inputs. For the 2nd digital input, in addition cathode (M) of the optocoupler is fed out in order to allow the connection of an output of an F control system with switched ground (for this purpose, the anode must be connected to 24 V DC).

Parameter p10040 is used to determine whether an F-DI is operated as NC/NC or NC/NO contact. The status of each DI can be read at parameter r10051. The same bits of both drive objects are logically linked by AND operation and return the status of the relevant F-DI.

Test signals from F-DOs and interference pulses can be filtered out using the input filter (p10017), so that they do not cause any faults.

#### Explanation of terms:

**NC contact / NC contact:** To select the safety function, a "zero level" must be present at both inputs.

**NC contact / NO contact:** To select the safety function, a "zero level" must be present at input 1 and a "1 level" at input 2.

The signal states at the two associated digital inputs (F-DI) must assume the same status configured in p10040 within the monitoring time set in p10002.

The digital inputs of the CU310-2 cannot be dynamized by a test stop.

Table 5- 15 Overview of the fail-safe inputs in the SINAMICS S120/S150 List Manual:

Module	Function diagram	Inputs
CU310-2	2870	F-DI 0 ... 2

### F-DI features

- Fail-safe configuration with 2 digital inputs per F-DI
- Input filter to block test signals with an adjustable suppression time (p10017), see Chapter "Bit pattern test (Page 173)".
- Configurable connection of NC/NC or NC/NO contacts by means of parameter p10040
- Status parameter r10051
- Adjustable time window for monitoring discrepancy at both digital inputs by means of parameter p10002 for all F-DIs

---

#### Note

##### Discrepancy time

To avoid incorrect triggering of fault messages, at these inputs the discrepancy time must always be set less than the shortest time between 2 switching events (ON/OFF, OFF/ON).

---



- 2nd digital input with additional tap of the optocoupler cathode for connecting an output of a fail-safe control grounded through a switch.

 **WARNING**
**Danger to life due to incorrect switching states caused by quiescent currents in the switched-off state**

In contrast to mechanical switching contacts (e.g. Emergency Stop switches), quiescent currents can still flow through semiconductor switches even when they are switched off. This can lead to false switching states if digital inputs are not connected correctly.

- Pay attention to the conditions for digital inputs/outputs specified in the relevant manufacturer documentation.
- Use only outputs that have a maximum quiescent current of 0.5 mA when "OFF" (in accordance with IEC 61131 part 2, Chapter 5.2 (2008)).

More information on this topic is available on the Internet at:

Parameterizing and configuring safety hardware

<http://support.automation.siemens.com/WW/view/de/39700013>

### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2870                    SI Extended Functions - CU310-2 (F-DI 0 ... F-DI 2)

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p10002                SI Motion F-DI switchover discrepancy time (CPU 1)
- p10017                SI Motion digital inputs debounce time (CPU 1)
- p10040                SI Motion, F-DI input mode (CPU 1)
- r10051.0...2        CO/BO: SI Motion digital inputs status (CPU 1)

## 5.6.2 Function of the F-DO

### Description

The fail-safe digital output (F-DO) comprises 2 digital outputs plus one digital input that checks the switching state for forced dormant error detection (test stop). The 1st digital output switches 24 V DC, and the 2nd switches M of the X130 (CU310-2) voltage supply.

The status of each F-DO can be read at parameter r10052. The status of the associated DI22 can be read using parameter r0722.22.

The actuator connected to the F-DO can also be tested under specific conditions as part of forced dormant error detection (test stop). See Section "Forced dormant error detection (test stop) of the CU310-2 (Page 288)".

Table 5- 16 Overview of the fail-safe outputs in the SINAMICS S120/S150 List Manual:

Module	Function diagram	Outputs	Associated checking inputs
CU310-2	2873	F-DO 0	DI 22

### Signal sources for the F-DO

For the CU310-2, the following signals are available for interconnecting (p10042, ..., p10045) on the F-DO:

- STO active
- SS1 active
- SS2 active
- SOS active
- SLS active
- SSM feedback active
- Safe State
- SOS selected
- Internal event
- Active SLS level bit 0
- Active SLS level bit 1
- SDI positive active
- SDI negative active
- SLP active
- Active SLP area

For the F-DO, up to 6 signals can be interconnected via indexes (p10042[0...5]; these are then output AND'ed.

## Safe state signal selection

For the CU310-2, the following (Safe State) signals can be requested via p10039[0...3]:

- STO active (power removed/pulses suppressed)
- SS1 active
- SS2 active
- SOS active
- SLS active
- SDI positive active
- SDI negative active
- SLP active




Image 5-6 Safe state selection

The same signals (high-active) are logically AND'ed. The different signals selected via p10039 are logically OR'ed. Result of these logic operations is the "Safe State". Details can be found in function block diagram 2876, see SINAMICS S120/S150 List Manual.

## F-DO features

- Each F-DO with fail-safe configuration consisting of 2 digital outputs plus one digital input for checking the switching state for forced dormant error detection (test stop)
- Status parameters r10051/r10052

### Note

#### Display using r0747.16

If digital outputs DO16+ and DO16- act as F-DO, parameter r0747 "CU, digital outputs status", bit 16 "DO 16 (- / X130.7, 8)" does not display the level defined by Safety Integrated. Instead, it displays the ineffective setpoint state according to BICO signal source p0746 "BI: CU signal source for terminal DO 16".

**Function diagrams (see SINAMICS S120/S150 List Manual)**

- 2870 SI Extended Functions - CU310-2 (F-DI 0 ... F-DI 2)
- 2873 SI Extended Functions - CU310-2 fail-safe digital output (F-DO 0)
- 2875 SI Extended Functions - CU310-2 control interface
- 2876 SI Extended Functions - CU310-2 Safe State selection
- 2877 SI Extended Functions - CU310-2 assignment (F-DO 0)

**Overview of important parameters (see SINAMICS S120/S150 List Manual)**

- p10039 SI Safe State signal selection (CPU 1)
- p10042[0...5] SI F-DO 0 signal sources
- r10051.0...2 CO/BO: SI Digital inputs status (processor 1)
- r10052.0 CO/BO: SI Digital output status (processor 1)

## 5.7 Motion monitoring without selection

As an alternative to controlling via terminals and/or PROFIsafe, there is also the option to parameterize several Safety functions without selection. For this mode, after parameterization and a POWER ON, these functions are permanently selected.

### Example

"SLS without selection" can be used, for example, to monitor the maximum velocity to prevent that the drive exceeds a mechanical speed limit. For this purpose, using the "without selection" function, an F-DI does not have to be used; an F-CPU is also not required.

### Features

- The function "Motion monitoring without selection" is available in the following versions:

p9601	Meaning	Scope of functions	Comment
0024 hex	Motion monitoring functions without selection integrated in the drive are enabled	<ul style="list-style-type: none"> <li>• SLS</li> <li>• SDI</li> </ul>	<ul style="list-style-type: none"> <li>• p9501.0 = 1</li> <li>• p9501.17 = 1</li> </ul>
0025 hex	Motion monitoring functions integrated in the drive without selection with STO via terminals are enabled	<ul style="list-style-type: none"> <li>• SLS</li> <li>• SDI</li> <li>• STO</li> <li>• SS1</li> <li>• SBC</li> </ul>	<ul style="list-style-type: none"> <li>• p9501.0 = 1</li> <li>• p9501.17 = 1</li> <li>• Basic Functions</li> <li>• Basic Functions</li> <li>• Basic Functions</li> </ul>

- The functions "SLS without selection" and "SDI without selection positive/negative" are selected with p9512.
- The functions without selection are available in the versions "with encoder" and "without encoder" (selection via p9506).
- The functions without selection are parameterized and enabled in the same way as the versions with control via PROFIsafe/terminals.

### Acknowledging safety faults

For acknowledging Safety faults, a distinction should be made between the following cases:

- Motion monitoring functions without selection integrated in the drive  
Acknowledging Safety faults is only possible with POWER ON.
- Motion monitoring functions without selection integrated in the drive and Basic Functions via onboard terminals

Acknowledging safety faults is possible with POWER ON or selecting/deselecting STO SS1 (see "Extended acknowledgment" in Chapter "Safe Torque Off (STO) (Page 62)").

## Differences

Differences in the behavior of the functions to the versions with control via PROFIsafe/terminals are described in the sections for commissioning the individual functions; see Chapter:

- Safely-Limited Speed (SLS) (Page 99)
- Safe Direction (SDI) (Page 115)

## Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9501.0 SI Motion enable safety functions (Control Unit)
- p9512 Select SI Motion safety functions without selection (CU)
- p9601 SI enable functions integrated in the drive (Control Unit)

## 5.8 Safety Info Channel and Safety Control Channel

### 5.8.1 Safety Info Channel (SIC)

The Safety Info Channel (SIC) enables Safety Integrated functionality status information of the drive (S\_ZSW1B, S\_ZSW2B, S\_ZSW3B, and S\_V\_LIMIT\_B) to be transmitted to the higher-level controller.

### 5.8.2 Safety Control Channel (SCC)

Using the Safety Control Channel (SCC), control information (S\_STW1B and S\_STW3B) can be sent from the higher-level control to the Safety functions of the drive.

### 5.8.3 Possible telegram configuration (700, 701)

The predefined PROFIdrive telegrams 700 and 701 are available for the transfer of the SIC and the SCC:

---

#### Note

#### No STARTER support for PROFIdrive telegrams 700 and 701

The supplementary safety telegrams 700 and 701 are not displayed in the STARTER "Telegram configuration" screen form, and are consequentially also not displayed after aligning with STEP 7 in "HW Config". In "HW Config" these supplementary telegrams are only available when configuring the SINAMICS drive using GSD. When configuring the drive using the "Object Manager" in "HW Config" you must manually extend the telegram as required.

---

## Telegram 700

The predefined PROFIdrive telegram 700 is available for the transfer of the SIC:

Table 5- 17 Structure of telegram 700

	Receive data	Send data	Parameter
PZD1	–	S_ZSW1B	r9734
PZD2	–	S_V_LIMIT_B	r9733[2]
PZD3	–		

You can find further information on communication via PROFIdrive in the Manual "SINAMICS S120 Drive Functions Function Manual", Section "Communication according to PROFIdrive".

## Telegram 701

The predefined PROFIdrive telegram 701 is available for the transfer of the SIC and the SCC:

Table 5- 18 Structure of telegram 701

	Receive data	Parameter	Send data	Parameter
PZD1	S_STW1B	p10250	S_ZSW1B	r9734
PZD2	S_STW3B	p10235	S_ZSW2B	r9743
PZD3	–	–	S_V_LIMIT_B	r9733[2]
PZD4	–	–		
PZD5	–	–	S_ZSW3B	r10234

---

### Note

#### Update of the send data

The send data S\_ZSW2B and S\_ZSW3B are only updated if the Safety Integrated Extended Functions are enabled.

---

You will find further information on communication via PROFIdrive in the Manual "SINAMICS S120 Drive Functions Function Manual," Chapter "Communication according to PROFIdrive."



### 5.8.4 Configuring

The following diagram shows the principle when configuring for telegrams 700 and 701:




Image 5-7 Telegram configuration sequence in STARTER

- Parameter p2070 is used to define at which location (after how many words) the SCC starts in receive words r2050/r2060.
- Parameter p2071 is used to define at which location (after how many words) the SIC starts in send words r2051/r2061.
- If, using p0922 = 999 and p2079 = x, a fixed telegram is to be parameterized with PZD extension, then you can appropriately adapt p2070 and p2071.
- For p0922 = p2079 = x, p2070 and p2071 are locked to prevent changes being made.
- When writing to parameter p0922 or p2079, parameters p2070 and p2071 are appropriately preassigned (with the length of the standard telegram). All BICO interconnections in r2050[...]/r2060[...] and p2051[...]/p2061[...] are deleted and reassigned to telegram x. In so doing, p60122 is also set = 999.
- When changing from a fixed telegram (p0922 = p2079 = x) to a free telegram (p0922 = 999), p2070 and p2071 remain unchanged, however they are released so that they can be changed. The value of p60122 is kept.
- If p10235 and p10250 are manually changed, fault F01786 is output without any drive response. This fault can be acknowledged by the standard message acknowledgment.

---

**Note**

**Effects in r2050[...]/r2060[...] and p2051[...]/p2061[...] when changes are made to p2070, p2071 and p60122**

- If you change p2070 and p2071, all BICO interconnections in r2050[...]/r2060[...] and p2051[...]/p2061[...] will be deleted (starting with the end of the currently set standard telegram). In so doing, p60122 is also set = 999.
  - If you change p60122 to a value ≠ 999, then (starting with the indices set in p2070 or p2071) all BICO interconnections are deleted in r2050[...]/r2060[...] and p2051[...]/p2061[...] and the new telegram set for SIC/SCC.
- 

## 5.8.5 Applications

### Applications

You can attach the telegrams 700 and 701 as an extension to your telegram. You can only select one of the two telegrams.

To do this, proceed as follows:

Application	Action by the user	Effect										
Standard telegram + SIC/SCC	<ul style="list-style-type: none"> <li>Specify standard telegram; e.g. p0922 = 106</li> </ul>	<ul style="list-style-type: none"> <li>p2079 = p0922 = 106</li> <li>r2050 and p2051 are appropriately preassigned and completely locked so that changes cannot be made.</li> <li>In p2070 and p2071, the number of transmit/receive words are occupied and cannot be changed (e.g: p2070 = 11 and p2071 = 15).</li> </ul>										
	<ul style="list-style-type: none"> <li>Select SIC/SCC; e.g. p60122 = 701</li> </ul>	<ul style="list-style-type: none"> <li>The telegram extension for SCC/SIC is directly attached to the standard telegram in r2050 and p2051.</li> </ul>										
	<table border="1"> <tr><td>p0922</td><td>106</td></tr> <tr><td>p2079</td><td>106</td></tr> <tr><td>p2070</td><td>11</td></tr> <tr><td>p2071</td><td>15</td></tr> <tr><td>p60122</td><td>701</td></tr> </table>	p0922	106	p2079	106	p2070	11	p2071	15	p60122	701	
p0922	106											
p2079	106											
p2070	11											
p2071	15											
p60122	701											
Standard telegram + free telegram configuration with BICO + SIC/SCC	<ul style="list-style-type: none"> <li>Define standard telegrams with possible telegram extension; e.g. p0922 = 999 and p2079 = 106</li> </ul>	<ul style="list-style-type: none"> <li>r2050 and p2051 are appropriately preassigned. Areas that are not preassigned, can be freely interconnected.</li> <li>p2070 = 11, p2071 = 15 are preassigned corresponding to p0922 and cannot be changed.</li> </ul>										
	<ul style="list-style-type: none"> <li>Reserve space for the telegram extension with free BICO wiring, e.g. 2 words in the receive direction and 1 word in the send direction: <ul style="list-style-type: none"> <li>p2070 = 11 + 2 = 13</li> <li>p2071 = 15 + 1 = 16</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>Words r2050[11...12] and p2051[15] are reserved for the telegram extension and can be freely interconnected.</li> </ul>										
	<ul style="list-style-type: none"> <li>Select SIC/SCC; e.g. p60122 = 701</li> </ul>	<ul style="list-style-type: none"> <li>The telegram extension for SIC/SCC is inserted from r2050[13...] and p2051[16...].</li> <li>In r2050 and p2051, the words for SIC/SCC are preassigned accordingly and locked. The other words can be freely connected.</li> </ul>										
	<table border="1"> <tr><td>p0922</td><td>999</td></tr> <tr><td>p2079</td><td>106</td></tr> <tr><td>p2070</td><td>13</td></tr> <tr><td>p2071</td><td>16</td></tr> <tr><td>p60122</td><td>701</td></tr> </table>	p0922	999	p2079	106	p2070	13	p2071	16	p60122	701	
p0922	999											
p2079	106											
p2070	13											
p2071	16											
p60122	701											

Application	Action by the user	Effect
Changing the standard telegram (without free telegram configuration)	<ul style="list-style-type: none"> <li>Specify a new telegram; e.g. p0922 = 105</li> </ul>	<ul style="list-style-type: none"> <li>r2050 and p2051 are deleted and re-assigned accordingly.</li> </ul>
	<ul style="list-style-type: none"> <li>Select SIC/SCC; e.g. p60122 = 701</li> </ul>	<ul style="list-style-type: none"> <li>The telegram extension for SCC is added after the standard telegram.</li> <li>r2050 and p2051 are preassigned corresponding to p0922 and SIC/SCC are completely locked so that they cannot be changed.</li> </ul>
Changing the standard telegram (with free telegram configuration)	<ul style="list-style-type: none"> <li>Change standard telegram (see above)</li> <li>Now continue as described in the "Standard telegram + free telegram configuration with BICO + SIC/SCC"</li> </ul>	–
Change of the SIC/SCC telegram	<ul style="list-style-type: none"> <li>Change SIC/SCC; now, e.g. p60122 = 700</li> </ul>	<ul style="list-style-type: none"> <li>Starting with the indices set in p2070 or p2071, all BICO interconnections are deleted in r2050[...] and p2051[...].</li> <li>The telegram extension for SIC is inserted into parameter p2071 according to p2051.</li> </ul>
Adding further "Free telegram configuration with BICO" words	<ul style="list-style-type: none"> <li>Change the values in p2070 or p2071.</li> </ul>	<ul style="list-style-type: none"> <li>When changing from a fixed telegram (p0922 = p2079 = x) to a free telegram (p0922 = 999), p2070 and p2071 remain unchanged, however they are released so that they can be changed. The value of p60122 is kept.</li> </ul>
	<ul style="list-style-type: none"> <li>Select SIC/SCC; e.g. p60122 = 701</li> </ul>	<ul style="list-style-type: none"> <li>SIC/SCC is reconfigured.</li> </ul>
	<ul style="list-style-type: none"> <li>Now specify the new free telegram configuration (see above).</li> </ul>	–

---

### Note

#### Parameter interdependencies

- Values for p2070 or p2071, which fall below the length of the standard telegram, will be rejected and cannot be entered.
  - Write access in p60122 is rejected if excessively high values are set in p2070 or p2071 so that attaching a SCC/SIC telegram would mean that the maximum permissible PZD lengths would be exceeded.
-

## 5.8.6 Send data for SIC and SCC

### S\_ZSW1B

SI Motion Safety Info Channel status word

Table 5- 19 Description S\_ZSW1B

Bit	Meaning	Remarks		Parameter
0	STO active	1	STO active	r9734.0
		0	STO not active	
1	SS1 active	1	SS1 active	r9734.1
		0	SS1 not active	
2	SS2 active	1	SS2 active	r9734.2
		0	SS2 not active	
3	SOS active	1	SOS active	r9734.3
		0	SOS not active	
4	SLS active	1	SLS active	r9734.4
		0	SLS not active	
5	SOS selected	1	SOS selected	r9734.5
		0	SOS deselected	
6	SLS selected	1	SLS selected	r9734.6
		0	SLS deselected	
7	Internal event	1	Internal event	r9734.7
		0	No internal event	
8	Reserved	–	–	–
9	Active SLS level bit 0	–	Display of the velocity limit for SLS (2 bits)	r9734.9
10	Active SLS level bit 1	–		r9734.10
11	Reserved	–	–	–
12	SDI positive selected	1	SDI positive selected	r9734.12
		0	SDI positive deselected	
13	SDI negative selected	1	SDI negative selected	r9734.13
		0	SDI negative deselected	
14	ESR retract requested	1	ESR retract requested	r9734.14
		0	ESR retract not requested	
15	Safety message effective	1	Safety message effective	r9734.15
		0	No Safety message effective	

**S\_ZSW2B**

Safety Info Channel status word 2

Table 5- 20 Description of S\_ZSW2B

Bit	Meaning	Remarks		Parameter
0...3	Reserved	–	–	–
4	SLP selected position range	1	SLP area 2 selected	r9743.4
		0	SLP area 1 selected	
5, 6	Reserved	–	–	–
7	SLP selected and user agreement	1	SLP selected and user agreement set	r9743.7
		0	SLP selected or user agreement not set	
8	SDI positive	1	SDI positive selected	r9743.8
		0	SDI positive deselected	
9	SDI negative	1	SDI negative selected	r9743.9
		0	SDI negative deselected	
10, 11	Reserved	–	–	–
12	Test stop active	1	Test stop active	r9743.12
		0	Test stop not active	
13	Test stop required	1	Test stop required	r0743.13
		0	Test stop not required	
14, 15	Reserved	–	–	–

**S\_ZSW3B**

Safety Info Channel status word 3

Table 5- 21 Description of S\_ZSW3B

Bit	Meaning	Remarks		Parameter
0	Brake test	1	Brake test selected	r10234.0
		0	Brake test deselected	
1	Setpoint input, drive/external <sup>1)</sup>	1	Setpoint specification for the drive	r10234.1
		0	Setpoint specification, external (controller)	
2	Active brake	1	Test brake 2 active	r10234.2
		0	Test brake 1 active	
3	Brake test active	1	Test active	r10234.3
		0	Test inactive	
4	Brake test result	1	Test successful	r10234.4
		0	Test error	
5	Brake test completed	1	Test run	r10234.5
		0	Test incomplete	
6	External brake request	1	Close brake	r10234.6
		0	Open brake	
7	Current load sign	1	Negative sign	r10234.7
		0	Positive sign	
8...10	Reserved	–	–	–
11	SS2E	1	SS2E active	r10234.11
		0	SS2E not active	
12...13	Reserved	–	–	–
14	Acceptance test SLP (SE) selected	1	Acceptance test SLP (SE) selected	r10234.14
		0	Acceptance test SLP (SE) deselected	
15	Acceptance test mode selected	1	Acceptance test mode selected	r10234.15
		0	Acceptance test mode deselected	

<sup>1)</sup> Setpoint input for the drive: The speed setpoint is entered by the function SBT.  
 External setpoint input (open-loop control): The "normal" speed setpoint is effective.

**S\_V\_LIMIT\_B**

SLS speed limit with a 32-bit resolution with sign bit.

- The SLS speed limit is available in r9733[2].
- The SLS speed limit is standardized via p2000.

$S\_V\_LIMIT\_B = 4000\ 0000\ \text{hex} \hat{=} \text{speed in p2000}$

## 5.8.7 Receive data for SCC

### S\_STW1B

Safety Control Channel control word 1

Table 5- 22 Description of S\_STW1B

Bit	Meaning	Remarks		Parameter
0...7	Reserved	–	–	–
8	Extended functions forced dormant error detection (test stop)	1	Extended functions forced dormant error detection (test stop) selected	r10251.8
		0	Extended functions forced dormant error detection (test stop) deselected	
9...15	Reserved	–	–	–

### S\_STW3B

Safety Control Channel control word 3

Table 5- 23 Description of S\_STW3B

Bit	Meaning	Remarks		Parameter
0	Select brake test	1	Brake test selected	r10231.0
		0	Brake test deselected	
1	Start brake test	1	Start brake test requested	r10231.1
		0	Start brake test not requested	
2	Brake selection	1	Test brake 2 selected	r10231.2
		0	Test brake 1 selected	
3	Select direction of rotation	1	Negative direction selected	r10231.3
		0	Positive direction selected	
4	Select test sequence	1	Test sequence 2 selected	r10231.4
		0	Test sequence 1 selected	
5	Status of external brake	1	External brake closed	r10231.5
		0	External brake open	
6...15	Reserved	–	–	–



## 5.8.8 Overview of important parameters

### Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- r9733[0...2] CO: SI Motion setpoint speed limit effective
- r9734.0...15 CO/BO: SI Safety Info Channel status word S\_ZSW1B
- r9743.4...15 CO/BO: SI Safety Info Channel status word S\_ZSW2B
- r10231 SI Motion SBT control word diagnostics
- r10234.0...15 CO/BO: SI Safety Info Channel status word S\_ZSW3B
- p10235 CI: SI Safety Control Channel control word S\_STW3B
- p10250 CI: SI Safety Control Channel control word S\_STW1B
- r10251.8...12 CO/BO: SI Safety Control Channel control word S\_STW1B diagnostics
- p60122 IF1 PROFIdrive SIC/SCC telegram selection



# Commissioning

## 6.1 Safety Integrated firmware versions

### Firmware versions for Safety Integrated

The safety firmware installed on the Control Unit and the safety firmware installed on the Motor Module each have separate version IDs. The parameters listed below can be used to read the version IDs from the relevant hardware.

- Read the overall firmware version via:
  - r0018 Control Unit firmware version
- The following firmware data can be read for the Basic Functions:
  - r9770[0...3] SI version, drive-autonomous safety functions (Control Unit)
  - r9870[0...3] SI version, drive-autonomous safety functions (Motor Module)
- The following firmware data can be read for the Extended Functions:
  - r9590[0...3] SI Motion version safety motion monitoring (Control Unit)
  - r9390[0...3] SI Motion version safety motion monitoring (Motor Module)
  - r9890[0...2] SI version (Sensor Module)

or

  - r0148[0...n] for DQI encoders
  - r10090[0...3] SI TM54F version

### Basic Functions and Extended Functions

Basic and/or Extended Functions that have been enabled are checked to determine whether the parameter for the automatic firmware update is set (p7826 = 1).

This means that at each boot, the firmware version of the DRIVE-CLiQ components involved is checked in comparison to the firmware version of the Control Unit and, if required, updated.

Otherwise, the message F01664 (SI CU: No automatic firmware update) is output.

In the acceptance test of the Safety Integrated Basic Functions, the Safety Firmware Versions (r9770, r9870) must be read out and recorded.

In the acceptance test of the Safety Integrated Extended Functions, the Safety Firmware Versions of the Motor Modules (r9590, r9390), the Sensor Modules (r9890 or r0148[0...n] for DQI encoders), and, if necessary, the Terminal Module TM54F (r10090) participating in the safety functions must be read out and recorded.

## 6.2 Parameters, checksum, version

### Properties of Safety Integrated parameters

The following applies to Safety Integrated parameters:

- The safety parameters are kept separate for each monitoring channel.
- During startup, checksum calculations (Cyclic Redundancy Check, CRC) are performed on the safety parameter data and checked. The display parameters are not contained in the CRC.
- Data storage: The parameters are stored on the non-volatile memory card.
- The safety parameterization is password-protected against accidental or unauthorized changes.
- Factory settings for safety parameters
  - The drive-specific reset of the Safety parameters to the factory setting with p3900 and p0010 = 30, is only possible if the safety functions are not enabled (p9501 = p9601 = p10010 = 0).
  - Safety parameters can be reset to the factory setting with p0970 = 5. To do so, the Safety Integrated password must be set. When Safety Integrated is enabled, this can result in error messages, which in turn require an acceptance test to be performed. Then save the parameters and carry out a POWER ON.
  - A complete reset of all parameters to the factory settings (p0976 = 1 and p0009 = 30 on the Control Unit) is possible even when the safety functions are enabled (p9501 = p9601 = p10010 ≠ 0).

---

#### Note

The Safety password is not reset to the factory setting by resetting the Safety parameters. You will find more detailed information on this password in Chapter "Handling the Safety password (Page 222)."

---

---

#### Note

##### Safety parameters that are not protected

The following safety parameters are not protected by the safety password:

- p9370 SI Motion acceptance test mode (Motor Module)
  - p9570 SI Motion acceptance test mode (Control Unit)
  - p9533 SI Motion SLS speed setpoint limitation
  - p9783 SI Motion synchronous motor current injection without encoder
- 

#### Note

The password protection is only available online.

---

## Checking the checksum

For each monitoring channel, the Safety parameters include 2 parameters for the reference and actual checksum for the Safety parameters that have undergone a checksum check.

During commissioning, the actual checksum must be transferred to the corresponding parameter for the reference checksum. This can be done for all checksums of a drive object at the same time using parameter p9701 or using the corresponding STARTER functionality.

- Basic Functions

• r9798	SI actual checksum SI parameters (Control Unit)
• p9799	SI reference checksum SI parameters (Control Unit)
• r9898	SI actual checksum SI parameters (Motor Module)
• p9899	SI reference checksum SI parameters (Motor Module)

- Extended Functions (contain also the following checksum parameters)

• r9398[0...1]	SI Motion actual checksum SI parameters (Motor Module)
• p9399[0...1]	SI Motion reference checksum SI parameters (Motor Module)
• r9728[0...2]	SI Motion actual checksum SI parameters
• p9729[0...2]	SI Motion reference checksum SI parameters

During each ramp-up procedure, the actual checksum is calculated via the Safety parameters and then compared with the reference checksum.

If the actual and reference checksums are different, fault F01650/F30650 or F01680/F30680 is output.

## Function diagrams (see SINAMICS S120/S150 List Manual)

- 2818 SI Extended Functions - Parameter managers

## 6.3 Handling the Safety password

The safety password protects the safety parameters against unintentional or unauthorized access. This safety aspect therefore prevents anyone from resetting the password to the factory setting without knowing the current password.

---

### Note

The password protection is only available online.

---

The machine manufacturer decides whether or not a password is required. The probabilities of failure (PFH) and the certification of the safety functions also apply when no password has been set.

If a password is set, in commissioning mode for Safety Integrated (p0010 = 95), you cannot change safety parameters until you have entered the valid safety password in p9761 for the drives or p10061 for the TM54F. In addition to the specified parameters, a corresponding functionality is available in STARTER!

- When Safety Integrated is commissioned for the first time, the following applies:
  - Default of p10061 = 0 (SI password entry TM54F)
  - Default of p9761 = 0 (SI password entry drive)

This means:

You do not need to enter a safety password during the first commissioning.

- In the case of a series commissioning of Safety or in the case of spare part installation, the following applies:
  - The Safety password is retained on the memory card and in the STARTER project.
  - No safety password is required in the case of spare part installation.
- Change password for the drives
  - p0010 = 95 Commissioning mode
  - p9761 = Enter the "old safety password".
  - p9762 = Enter "new password".
  - p9763 = Confirm "new password".
  - p0977 = 1; "Copy RAM to ROM"
  - The new and confirmed safety password is valid immediately.
- Change password for the TM54F
  - p0010 = 95 Commissioning mode
  - p10061 = Enter "Old TM54F Safety Password" (factory setting "0")
  - p10062 = Enter "new password"
  - p10063 = Acknowledge "new password"
  - p0977 = 1; "Copy RAM to ROM"
  - The new and acknowledged safety password is valid immediately.

- Change the password using STARTER
  - Click the "Change password" button on the start screen of the configuration.
  - In the subsequent dialog, first enter the old password.
  - Enter the new password.
  - Confirm the new password by entering it again.
  - Click "OK" to accept the setting.
- Reset the password with STARTER
  - Click the "Change password" button on the start screen of the configuration.
  - In the subsequent dialog, first enter the old password.
  - Set the new password = 0.
  - Select the "Change settings" button.
  - SINAMICS S120 responds with the message "Please change the password!"
  - Close the message.
  - In the "Change password" dialog box, then click the "Cancel" button.
  - The password has now been reset to the default "0."
- If the safety password is no longer available, you can no longer change the safety configuration. You then have the following options:
  - To commission the SINAMICS S120 completely as new:
    - Restore the factory settings of the entire drive (Control Unit with all connected drives/components).
    - Commission the drive unit and the drives afresh.
    - Commission Safety Integrated as new.
  - To load another project into the drive (without a Safety password or with a known Safety password). This is possible without a password because this operation is the same as complete new commissioning.
  - If neither option is acceptable to you, please contact "Technical Support" (see "Preface (Page 5)").

### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2818                      SI Extended Functions - Parameter managers

### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- p9761                      SI password input
- p9762                      SI password new
- p9763                      SI password acknowledgment
- p10061                     SI TM54F password entry
- p10062                     SI TM54F password new
- p10063                     SI TM54F password confirmation

## 6.4 DRIVE-CLiQ rules for Safety Integrated Functions

**Note**

**General DRIVE-CLiQ rules**

For the Safety Integrated Functions (Basic and Extended Functions) the general DRIVE-CLiQ rules apply as a basic principle. You will find these rules in Section "Rules for connection with DRIVE-CLiQ" in the following manual:

References: SINAMICS S120 Drive Functions Function Manual

This specification also lists the exceptions for Safety Integrated components depending on the firmware version.

- The following rule also applies particularly for Safety Integrated Basic Functions:
  - Maximum of four drives per DRIVE-CLiQ line for control via PROFIsafe
- The following rules also apply particularly for Safety Integrated Extended Functions:
  - Maximum of 6 servo axes for default clock cycle settings (Safety monitoring clock cycle = 12 ms; current controller cycle = 125 µs); of which a maximum of 4 servo axes in one DRIVE-CLiQ line
  - Maximum of six vector axes for the following cycle settings (Safety monitoring cycle = 12 ms; current controller cycle = 500 µs)
  - A Double Motor Module, a DMC20 or DME20 and a TM54F each correspond to 2 DRIVE-CLiQ nodes.
  - On Double Motor Modules, on the drive objects, different values for p9511 are not permitted, even if the values in p0115[0] are different.
  - No more than 4 Motor Modules with Safety Extended Functions can be operated on one DRIVE-CLiQ line (for current controller clock  $T_{Reg} = 125 \mu s$  on all axes). No further DRIVE-CLiQ components other than a Line Module and Sensor Modules may be operated on this DRIVE-CLiQ line.
 

Exception: In the case of SINAMICS S120M, no more than 6 S120M with Safety Extended Functions can be operated on one DRIVE-CLiQ line.
  - For "V/f control (vector control)", the following rules<sup>1)</sup> apply:

Table 6- 1 Maximum number of controllable drives for the particular control type.

Safety functionality	Number of V/f axes
Basic Functions	12
Basic Functions via TM54F	6
Extended Functions via PROFIsafe	11
Extended Functions via TM54F	6
Motion monitoring without selection	12 <sup>2)</sup>

1) The values specified in the table apply to Extended Functions with and without encoder and also for group drives connected in parallel.

2) All axes V/f control, 500 µs, Safety Integrated with encoder



- TM54F
  - The TM54F connection must be established via the DRIVE-CLiQ directly at a Control Unit. Only one TM54F Terminal Module can be assigned to each Control Unit.
  - Additional DRIVE-CLiQ nodes can be operated at the TM54F, such as Sensor Modules and Terminal Modules (excluding an additional TM54F). It is not permissible that Motor Modules and Line Modules are connected to a TM54F.
  - In the case of a CU310-2 Control Unit, it is not possible to connect the TM54F to the DRIVE-CLiQ line of a Power Module. The TM54F can only be connected to the sole DRIVE-CLiQ X100 socket of the Control Unit.

## 6.5 Forced dormant error detection (test stop)

To fulfill the requirements of standards DIN EN ISO 13849-1 and IEC 61508 regarding timely error detection, the converter must regularly test its safety-relevant circuits to ensure that they function correctly – this must be performed at least once every year. The converter monitors the regular testing of its safety-related circuits, which monitor the speed of the motor and which safely interrupt the torque-generating energy supply to the motor by means of safe pulse suppression.




Image 6-1 Monitoring of regular forced dormant error detection (test stop) in the converter

Table 6-2 Monitoring forced dormant error detection (test stop)

Extended Functions	Basic Functions
r9765 contains the remaining monitoring time.	r9660 contains the remaining monitoring time.
The converter signals that the monitoring time has come to an end with alarm A01697.	The converter signals that the monitoring time has come to an end with alarm A01699.

### Setting forced dormant error detection (test stop)

If you only use the "Basic Functions", you must take the following steps during commissioning:

1. Set monitoring time p9659 to a value to match your application.
2. Evaluate the warning A01699 in your higher-level control, e.g. r9773.31 with a digital output or a bit in the status word of the field bus.

The circuits of "Basic Functions" are part of the circuits of "Extended Functions". If you use the "Extended Functions", you must take the following steps during commissioning:

1. Set monitoring time p9559 to a value to match your application.
2. Set the monitoring time p9659 to the maximum value.
3. Evaluate alarm A01697 in your higher-level controller, for example by interconnecting the output of the time monitoring (r9723.0) with a digital output or a bit in the status word of the fieldbus.

## Run forced dormant error detection (test stop)

If the converter signals the warning A01699 or A01697, you must trigger forced dormant error detection (test stop) at the next opportunity.

These alarms do not affect the operation of your machine. Before forced dormant error detection (test stop), you should shut down the drive.

---

### Note

#### Internal selection of STO

Controlling forced dormant error detection (test stop) causes STO to be selected internally. In this case, drives that were previously not stopped, or that do not have a holding brake, coast down.

---

## Triggering forced dormant error detection (test stop)

- Extended Functions

- You define the signal with which the converter tests its circuits for speed monitoring. Alternatively, the test can be performed automatically every time the power supply is switched on (POWER ON).
- To ensure that forced dormant error detection (test stop) is performed without error, STO must not be active.
- If you select forced dormant error detection (test stop), the converter checks the circuits of Extended Functions and of Basic Functions.

- Basic Functions

The converter checks its circuits for interruption of the torque-generating energy feed to the motor for one of the following conditions:

- After the power supply has been connected (POWER ON).
  - Each time after selecting the function STO or SS1.
  - In the forced dormant error detection (test stop) of the Extended Functions.
- 

### Note

#### Additional information

- You will find detailed information on forced dormant error detection (test stop), in Chapter "Forced dormant error detection (test stop) (Page 160)."
  - You will find a description of forced dormant error detection (test stop) of the TM54F in Section "Forced dormant error detection (test stop) of the TM54F (Page 305)."
-

**Examples of the instant at which forced dormant error detection (test stop) is performed**

- When the drives are at a standstill after the system has been switched on
- When the protective door is opened
- At defined intervals (e.g. every eight hours)
- Automatically, each time the power supply voltage is switched on (POWER ON).
- In the automatic mode, time and event-dependent

---

**Note**

**Test stop on a CU310-2**

During a test stop on a CU310-2, the pulses must be enabled: Here, the drive should be switched on with  $N_{set} = 0$ .

---

## 6.6 Commissioning Safety Integrated functions

### 6.6.1 General information

1. To commission Safety Integrated Basic functions, you can select the following settings in the drop-down menu of the safety screen form. You can also simultaneously select the control version of the safety functions:
  - Basic Functions via onboard terminals
  - Basic Functions via PROFIsafe
  - Basic Functions via PROFIsafe and onboard terminals
  - Basic functions via TM54F
  - Basic functions via TM54F and onboard terminals
2. To commission Safety Integrated Extended functions, you can select the following settings in the drop-down menu of the safety screen form. You can also simultaneously select the control version of the safety functions – as well as a possible combination with the Basic functions:
  - Extended Functions via TM54F
  - Extended Functions via PROFIsafe
  - Extended Functions via TM54F and Basic Functions via onboard terminals
  - Extended Functions via PROFIsafe and Basic Functions via onboard terminals
  - Extended Functions via onboard terminals (only for CU310-2)
  - Extended Functions without selection
  - Extended Functions without selection and Basic Functions via onboard terminals

---

#### Note

##### Configuration in STARTER

- You can find examples for configuring the Safety Integrated functions in the chapters "Basic Functions (Page 240)" and "Extended Functions (Page 238)".
  - You can find detailed information on configuring in STARTER in the online help.
- 

### Safety slot

A safety slot must first be created in order to be able to control the Safety Integrated functions via PROFIBUS or PROFINET. The procedure for this is described in the following sections:

- "PROFIsafe via PROFIBUS (Page 312)"
- "PROFIsafe via PROFINET (Page 322)"

## Expert list

The Safety Integrated Functions can be parameterized via the expert list but the settings via the STARTER screens are more convenient and less prone to error.

---

### Note

#### Password for the factory setting

The password "0" is set by default.

---

---

### Note

#### Incompatible version in the Motor Module

If there is no compatible version in the Motor Module, the Control Unit will respond as follows on transition to Safety commissioning mode (p0010 = 95):

- The fault F01655 (SI CU: comparison of the monitoring function) is output. The fault initiates the stop response OFF2.
  - The Control Unit triggers safe pulse suppression via its own Safety switch-off signal path.
  - If parameterized (p1215, p9602), the motor holding brake is closed.
  - The fault can only be acknowledged after the Safety functions have been blocked (p9601).
- 

---

### Note

#### Duplicate the parameters for the 2nd channel

When parameterizing the safety functions using STARTER screens (online and offline), only set the values of one channel. When writing the parameters of the second channel, you must distinguish the following:

- Offline  
To set the safety-related parameters of the second channel, activate the "Copy parameters after download" check box and then establish an online connection to the drive unit. Or establish an online connection to the drive unit first and then duplicate the parameters by clicking the "Copy parameters" button on the start screen of the configuration.
  - Online  
Parameters of the second channel are written to when pressing the "Copy parameters" button.
-

**Note****Behavior when copying**

For the encoder parameters (p9515 to p9529), which are used for safe motion monitoring, the following procedure applies when copying:

- The following applies to safety-related functions that have not been enabled (p9501 = 0):  
The parameters are automatically set during startup in the same way as the corresponding encoder parameters (e.g. p0410, p0474, ...).
- The following applies to safety-related functions that have been enabled (p9501 > 0):  
The parameters are checked against their corresponding encoder parameters (e.g. p0410, p0474, ...).

Further information can be found in the parameter descriptions in the SINAMICS S120/S150 List Manual.

---

**Note****Activating changed safety parameters**

When exiting the commissioning mode (p0010 = 0), most of the changed parameters immediately become active.

However, for some parameters, a POWER ON is required. In this case, a drive message (A01693 or A30693) will inform you.

---

## 6.6.2 Prerequisites for commissioning the Safety Integrated functions

- Commissioning of the drives must be complete.
- It is not permissible that the drive, on which the safety functions are to be commissioned online, is in the "Operation" state.
- To commission the "Safe Brake Control" (SBC) function, the following also applies:  
A motor with motor holding brake must be connected to the appropriate connection of the Motor Module or to Safe Brake Relay/Safe Brake Adapter (SBR/SBA).

### 6.6.3 Default settings for commissioning Safety Integrated functions without encoder

Additional default settings are required before commissioning Safety functions without an encoder. The parameterization of the ramp-function generator is necessary, so that in encoderless operation stepped signals do not occur.

1. The ramp-function generator is automatically created if a vector drive is configured. Continue with point 3.
2. If a servo drive has been configured, activate the ramp-function generator as follows: In the configured project, call the "Drive Navigator" offline, select the "Device configuration" and click on "Configure drive". In the next window, select the "Extended setpoint channel" function module. With "Continue", proceed with the configuration and when completed, exit with "Complete". The ramp-function generator is now active and can be parameterized.
3. Open the ramp-function generator in the project window by double-clicking on "<Drive unit> > Drives > <Drive> > Setpoint channel > Ramp-function generator":




Image 6-2 Ramp-function generator



- To open the "Basic ramp-function generator" dialog box, click the button showing the ramp.




Image 6-3 Ramp-function generator ramp

- Here, enter the data to define the ramp-function generator ramp.
- Subsequently carry out a "motor data identification" to determine the motor data and to improve the torque accuracy: Start with static measurements and then take rotating measurements. You will find details in the relevant chapters on "Motor data identification" in the "Function manual SINAMICS S120 drive functions."

Activating Safety Integrated

1. Open the Safety Integrated selection window under "<Drive unit> > Drives > <Drive> > Functions > Safety Integrated" and select the required safety control type:




Image 6-4 Safety Integrated selection

2. In the drop-down list below that, select "[1] Safety without encoder and brake ramp (SBR)" or "[3] Safety without encoder with acc\_monitoring (SAM)/delay time."
3. Click on "Configuration" and set the actual value acquisition cycle (p9511) to the value of the current controller cycle (p0115[0]) (e.g. 125 µs).




Image 6-5 Safety Integrated without encoder (example)

4. Then click in the "Configuration" dialog on "Mechanical system configuration": Set the actual value tolerance (p9542) to a higher value (e.g. 1 mm or 12 °) and when configuring the gear ratio, take into account the pole pair number of the motor.

---

**Note****Interrelationship between the electrical ↔ mechanical speed**

The encoderless safe actual value sensing calculates the electric speed of the drive. The pole pair number (r0313) specifies the factor with which the electrical speed must be multiplied in order to obtain the mechanical speed at the motor shaft.

---

5. Open SS1, and set the shutdown velocity > 0 (p9560). This is only absolutely necessary if "Safety without encoder with braking ramp (SBR)" was selected.
6. Open SLS/SDI, and switch over all of the stop responses to "[0] STOP A" or "[1] STOP B" (p9563[0...3], p9566) and close the window.
7. You can now carry out the user-specific safety settings.
8. Using p9585, define the value for the "SI Motion fault tolerance actual value acquisition - sensorless" (see Notes regarding setting parameters for safe actual value sensing without encoder (Page 154).
9. Click the "Copy parameters" button.
10. Click the "Activate settings" button.
11. Switch the drive off and back on again to accept the changes.

---

**Note****Response to message C01711/C30711**

If during acceleration or deceleration, the drive outputs the message C01711/C30711 (message value 1041 to 1043), this indicates problems, for example, with values too high for acceleration/deceleration. You have the following options to remedy this:

- Reduce the ramp gradient.
  - Use the extended ramp-function generator (with rounding) to set a more gentle ramp up.
  - Reduce the precontrol.
  - Change the values of parameters p9586, p9587, p9588, p9589 and p9783 (see specifications in the List Manual).
-

## 6.6.4 Setting the sampling times

### Terminology

The software functions installed in the system are executed cyclically at different **sampling times** (p0115, p0799, p4099).

Safety functions are executed in the **monitoring cycle** (p9500) and the TM54F is executed with the **sampling time** displayed in r10015. This sampling time corresponds to the lowest value of the communication sampling time entered in p10000[0..5]. For Basic Functions, the cycle is displayed in r9780.

Communication via PROFIBUS is performed cyclically via the **communication cycle**.

During the PROFIsafe scan cycle, the PROFIsafe telegrams issued by the master are evaluated.

### Rules

- The monitoring cycle (p9500) can be set between 500 µs to 25 ms.

---

#### Note

##### Setting an identical monitoring cycle

The monitoring cycle must be the same on all drives and the TM54F.

---

However, the calculation time required for the Extended Functions in the Control Unit depends on the monitoring cycle, that is, shorter cycles extend the calculation time. The availability of a specific monitoring cycle therefore depends on calculation time resources of the Control Unit.

CPU time resources on the Control Unit are influenced primarily by the number of drives, the number of drives with enabled Extended Functions, the connected DRIVE-CLiQ components, the selected DRIVE-CLiQ topology, the use of a CBE20 and by the selected technological functions. You can determine the number of axes that can be controlled (closed loop) using the "SIZER" tool.

---

#### Note

##### Influence of deactivated drives on the required CPU time

Please note that the deactivated drives also affect the required CPU time. In the case of utilization limits being reached, it is sufficient to deactivate one drive. This drive must then be deleted.

---

- PROFIsafe (via PROFIBUS/PROFINET)
  - The monitoring cycle (p9500) must be an integer multiple of the actual value update cycle. p9511 is generally used for the cycle time for actual value acquisition. If p9511 = 0 in *isochronous operation* the isochronous PROFIBUS communication cycle is used, in *non-isochronous* operation the actual update cycle in this case is 1 ms.
  - Actual value acquisition cycle  $\geq 4 \times$  current controller cycle  
Recommendation: Actual value sensing cycle  $\geq 8 \times$  current controller cycle

**Note****Actual value sensing cycle for safety functions without encoder**

This is not applicable when using safety functions without encoder: In this case, the actual value sensing cycle must be configured to be the same as the current controller cycle.

**Note****Actual value acquisition cycle clock for SINAMICS S120M**

SINAMICS S120M only allows a fixed actual value acquisition cycle clock of 2 ms: For SINAMICS S120M, only 2 ms or 0 will be accepted for p9511 (in the latter case, 2 ms is accepted internally – regardless of the PROFIBUS DP-/PN cycle clock).

- Depending on the set sampling time of the current controller (p0115[0]), the maximum number of controllable drives will vary (see SINAMICS S120 Function Manual drive functions, Chapter "System control, sampling times, and DRIVE-CLiQ wiring").

- TM54F

The sampling time of the TM54F must be set the same as the monitoring cycle of the safety function used (p10000[0..5] = p9500 or r9780).

**Note****Relationship between the monitoring cycle and the PROFIsafe scan cycle**

The Safety functions are carried out in the monitoring cycle (r9780 for Basic Functions or p9500 for Extended Functions). PROFIsafe telegrams are evaluated in the PROFIsafe scan cycle, which corresponds to twice the monitoring cycle.

**Overview of important parameters (see SINAMICS S120/S150 List Manual)**

- p9500            SI Motion monitoring cycle (Control Unit) (only Extended Functions)
- p9511            SI Motion actual value acquisition clock (Control Unit)
- r9780            SI monitoring cycle (Control Unit)
- p10000[0..5]   SI TM54F communication clock

## 6.7 Commissioning: Basic procedure

### 6.7.1 Basic Functions

#### 6.7.1.1 Commissioning via direct parameter access

To commission the "STO", "SBC" and "SS1" functions via terminals, carry out the following steps:

Table 6-3 Commissioning the "STO", "SBC" and "SS1" functions

No.	Parameter	Description/comments
1	p0010 = 95	<p><b>Safety Integrated: Set commissioning mode.</b></p> <ul style="list-style-type: none"> <li>• The following alarms and faults are output:               <ul style="list-style-type: none"> <li>– A01698 (SI CU: Commissioning mode active)</li> </ul> </li> <li>• During first commissioning only:               <ul style="list-style-type: none"> <li>– F01650 (SI CU: Acceptance test required) with fault value = 130 (no Safety parameters exist for the Motor Module).</li> <li>– F30650 (SI MM: Acceptance test required) with fault value = 130 (no Safety parameters exist for the Motor Module).</li> </ul> </li> <li>• Acceptance test and test certificate, see step 17.</li> <li>• The pulses are safely suppressed.</li> <li>• An existing and parameterized motor holding brake has already been applied.</li> <li>• In this mode, fault F01650 or F30650 with fault value = 2003 is output after a Safety parameter is changed for the first time.</li> </ul> <p>This behavior applies for the entire duration of Safety commissioning, that means, the "STO" function cannot be selected/deselected while safety commissioning mode is active because this would constantly force safe pulse suppression.</p>
2	p9761 = "Value"	<p><b>Enter the Safety password.</b></p> <p>When Safety Integrated is commissioned for the first time, the following applies:</p> <ul style="list-style-type: none"> <li>• Safety password = 0</li> <li>• Default setting for p9761 = 0</li> </ul> <p>This means that the Safety password does not need to be set during first commissioning.</p>
3	p9601.0 = 1	<b>Enable "Safe Torque Off (STO)" function.</b>
4	p9602 = 1	<p><b>Enable "Safe Brake Control (SBC)" function.</b></p> <ul style="list-style-type: none"> <li>• SBC cannot be used alone, but only in conjunction with one of the STO and SS1 functions.</li> </ul>
5	p9652 > 0	<p><b>Enable "Safe Stop 1 (SS1)" function.</b></p> <ul style="list-style-type: none"> <li>• The "Safe Stop 1" function is not activated until at least one safety monitoring function has been enabled (i.e. p9601 ≠ 0).</li> </ul>

No.	Parameter	Description/comments
6	p9620 = "fast DI on CU" Terminal "EP"	<p><b>Set terminals for "Safe Torque Off (STO)".</b></p> <p>Wire terminal "EP" (enable pulses) on the Motor Module.</p> <ul style="list-style-type: none"> <li>• Control Unit monitoring channel: By appropriately interconnecting BI: p9620 for the individual drives, the following is possible: <ul style="list-style-type: none"> <li>– Selecting/deselecting the STO</li> <li>– Grouping the terminals for STO</li> </ul> </li> <li>• Motor Module monitoring channel: By wiring the "EP" terminal accordingly on the individual Motor Modules, the following is possible: <ul style="list-style-type: none"> <li>– Selecting/deselecting the STO</li> <li>– Grouping the terminals for STO</li> </ul> </li> </ul> <p><b>Note:</b> The STO terminals must be grouped identically in both monitoring channels.</p>
7	p9650 = "Value"	<p><b>Set F-DI changeover tolerance time.</b></p> <p>F-DI changeover tolerance time on Control Unit</p> <ul style="list-style-type: none"> <li>• The parameter is not changed until safety commissioning mode has been exited (i.e. when p0010 ≠ 95 is set).</li> <li>• Due to the different runtimes in the two monitoring channels, an F-DI changeover (e.g. selection/deselection of STO) does not take immediate effect. After an F-DI changeover, dynamic data is not subject to a data cross-check during this tolerance time.</li> </ul>
8	p9651 = "Value"	<p><b>Debounce time for the fail-safe digital inputs</b> to control STO/SBC/SS1.</p>
9	p9658 = "Value"	<p><b>Set transition period from STOP F to STOP A.</b></p> <ul style="list-style-type: none"> <li>• STOP F is the stop response that is initiated when the data cross-check is violated as a result of fault F01611 or F30611 (SI: Defect in a monitoring channel). STOP F normally triggers "No stop response".</li> <li>• After the parameterized time has expired, STOP A (immediate safety pulse inhibit) is triggered by the fault F01600 or F30600 (SI: STOP A triggered).</li> </ul> <p>The default setting for p9658 is 0 (i.e. STOP F immediately results in STOP A).</p>
10	p9659 = "Value"	<p><b>Time for carrying out forced dormant error detection and testing the safety switch-off paths.</b></p> <ul style="list-style-type: none"> <li>• After this time has expired, the user is requested to test the switch-off paths as a result of alarm A01699 (SI CU: Necessary to test the switch-off signal paths) (i.e. select/deselect STO).</li> <li>• The commissioning engineer can change the time required for carrying out the forced checking procedure and testing the safety switch-off paths.</li> </ul>
11	p9762 = "Value" p9763 = "Value"	<p><b>Set the new Safety password.</b></p> <p>Enter a new password. Confirm the new password.</p> <ul style="list-style-type: none"> <li>• The new password is not valid until it has been entered in p9762 and confirmed in p9763.</li> <li>• As of now, you must enter the new password in p9761 so that you can change Safety parameters.</li> <li>• Changing the Safety password does not mean that you have to change the checksums.</li> </ul>

No.	Parameter	Description/comments
12	p9621 = "value" p9622[0...1] = "value"	<b>Parameterize Safe Brake Adapter.</b> <ul style="list-style-type: none"> <li>Set with p9621 the signal source for the Safe Brake Adapter.</li> <li>Set with p9622 the wait times for switching on and switching off the Safe Brake Adapter relay.</li> </ul>
13	p9700 = 57 hex p9701 = DC hex	<b>Save and copy the Safety Integrated function parameters.</b> After setting the specific parameters of the Safety Integrated Functions, they must be copied from the Control Unit into the Motor/Power Module and then activated: <ul style="list-style-type: none"> <li>p9700 SI Motion copy function</li> <li>p9701 SI Motion confirm data change</li> </ul>
14	p0010 = 0	<b>Safety Integrated: Exit commissioning mode.</b> <ul style="list-style-type: none"> <li>If at least one safety monitoring function is enabled (p9601 ≠ 0), the checksums are checked:  If the target checksum on the Control Unit has not been correctly adapted, then fault F01650 (SI CU: Acceptance test required) is output with fault code 2000 and it is not possible to exit the safety commissioning mode.  If the target checksum on Motor Modules has not been correctly adapted, then fault F01650 (SI CU: Acceptance test required) is output with fault code 2001 and it is not possible to exit the safety commissioning mode.</li> <li>If a safety monitoring function has not been enabled (p9601 ≠ 0), safety commissioning mode is exited without the checksums being checked.</li> </ul> When safety commissioning mode is exited, the following is carried out: <ul style="list-style-type: none"> <li>A POWER ON must be performed after the initial commissioning. This is indicated with the A01693 message.</li> </ul>
15	p0971 = 1 p0977 = 1	All drive parameters (entire drive group or only single axis) must be manually saved from RAM to ROM. This data is not saved automatically!
16	POWER ON	<b>Carry out POWER ON.</b> After commissioning, a reset must be carried out with POWER ON.
17	-	<b>Carry out acceptance test and create test certificate.</b> Once safety commissioning is complete, the commissioning engineer must carry out an acceptance test for the enabled safety monitoring functions. The results of the acceptance test must be documented in an acceptance certificate.

### 6.7.1.2 Commissioning with STARTER

The following is a description of how you commissioning the Safety Integrated Basic Functions in STARTER.

The screen forms shown here are examples from the offline commissioning. To complete commissioning, you must establish an online connection between STARTER/SCOUT and the drives.



## Requirements


The following requirements must be satisfied before you commission the Basic Functions.

- The first commissioning of the drive has been carried out successfully.
- The terminals of the control (onboard or TM54F) are correctly wired or the PROFIsafe slot has been configured.


## Commissioning

To commission the Basic Functions, proceed as follows:

- In the project navigator, select "<Drive unit> > Drives > <Drive> > Functions > Safety Integrated."



- Select one of the following options for the Basic Functions:
  - Basic Functions via onboard terminals
  - Basic Functions via PROFIsafe
  - Basic Functions via PROFIsafe and onboard terminals
  - Basic functions via TM54F
  - Basic functions via TM54F and onboard terminals
- For this description, we will select "Basic functions via PROFIsafe and onboard terminal" because, in this case, both control variants can be seen. If you select one of the other versions, only the required settings options are visible in the respective parameter assignment screen form.



- This dialog box provides the following setting options for the Basic Functions:
  - "Control Unit (terminal)" – for control via terminal only  
Set the signal source for the STO, SBC and SS1 functions on the Control Unit (p9620) here.
  - "Safe Stop 1 delay time"  
Here, you can set the delay time of the pulse suppression for the function SS1 on the Control Unit for braking on the OFF3 deceleration time ramp (p9652).
  - "[0] SS1 with OFF3"  
Set the drive-independent brake response for the function SS1 (p9653).
  - "Safe brake control channel 1"  
Enable the Safe Brake Control, channel 1 (CU) function here (p9602). Depending on the enable, the schematic diagram of the signal characteristic and the display of the parameters change.
  - "Output "STO active""  
Select the parameters with which the "STO active" status is to be interconnected (r9773). Several interconnections are possible.
  - "STO extended settings"  
Click this button to open the "STO extended settings" dialog box:

- "PROFIsafe configuration" - only for control via PROFIsafe

Click this button to open the "PROFIsafe Configuration" dialog box:

The screenshot shows a dialog box titled "PROFIsafe configuration". The dialog has a blue title bar with a question mark icon and a close button. The main content area has a grey background and is framed by a yellow and black diagonal striped border. It contains three input fields: "PROFIsafe address" with the value "0008H", "PROFIsafe telegram" with the value "[30] PROFIsafe standard telegram 30, PZD-1/1", and "Safety parameterization" with the value "[30] PROFIsafe standard telegram 30, PZD-1/1". Below these fields is a button labeled "Accept PROFIsafe telegram". At the bottom of the dialog are two buttons: "Close" and "Help".


Enter the "PROFIsafe address" (p9610) of the drive in hexadecimal code here.

"Telegram configuration" (p60022) shows the currently parameterized PROFIsafe telegram; "Safety parameterization" (p9611) shows the telegram currently used in the Safety parameterization.

Click "Accept PROFIsafe telegram" to accept the currently parameterized PROFIsafe telegram in the Safety parameterization.

Click "Close" to return to the "Safety Integrated" dialog box.

This dialog box provides the following setting options for STO (Basic Functions):



- "F-DI input filter"  
This is where you set the debounce time for the fail-safe digital inputs used to control STO/SBC/SS1 (p9651).
- "Monitoring for simultaneous operation"  
This is where you set the tolerance time for the switchover of the safety-related inputs on the Control Unit (p9650).
- "STOP F -> STOP A delay time"  
This is where you set the transition time from STOP F to STOP A on the Control Unit (p9658).
- "Forced dormant error detection (test stop) of the shutdown paths"  
This is where you set the time interval for performing the forced dormant error detection and test of the safety shutdown paths (p9659).

- "Remaining time until test stop"  
This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
- "Shutdown paths require testing"  
Select the parameters to be interconnected with the status "Shutdown path test required" (r9773.31). One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

---

**Note****Duplicating safety parameters**

For safety reasons, when using the STARTER commissioning tool (or SCOUT), you can only set the safety-related parameters of the first channel offline.

To set the safety-related parameters of the second channel, proceed as follows:

- Activate the "Copy parameters after download" checkbox and then establish an online connection to the drive unit. Perform the download and then adapt the checksums. Execute the "Copy RAM to ROM" command and then a POWER ON.
  - Or establish an online connection to the drive unit first and then duplicate the parameters by clicking the "Copy parameters" button on the start screen of the configuration.
-

## 6.7.2 Commissioning of the Extended Functions with STARTER

The following is a description of how you commissioning the Safety Integrated Extended Functions in STARTER. The screen forms shown here are examples from the offline commissioning. To complete commissioning, you must establish an online connection between STARTER/SCOUT and the drives.

### Requirements


The following requirements must be satisfied before you commission the Extended Functions.

- The first commissioning of the drive has been carried out successfully.
- The control (PROFIsafe, TM54F or onboard F-DI/F-DO of the CU310-2) has been parameterized.

### Commissioning

To commission the Extended Functions, proceed as follows:

- In the project navigator, select "<Drive unit> > Drives > <Drive> > Functions > Safety Integrated."



- Select one of the following options for the Extended Functions:
  - Extended Functions via TM54F
  - Extended Functions via PROFIsafe
  - Extended Functions via TM54F and Basic Functions via onboard terminals
  - Extended Functions via PROFIsafe and Basic Functions via onboard terminals
  - Extended Functions via onboard terminals (only for CU310-2)
  - Extended Functions without selection
  - Extended Functions without selection and Basic Functions via onboard terminals
- For the following descriptions, we choose "Extended Functions via PROFIsafe and Basic Functions via onboard terminals," including the following variants:
  - "[0] Safety with encoder and acceleration monitoring (SAM)/delay time" (see Chapter "Extended Functions with encoder (Page 247)")
  - "[1] Safety without encoder with ramp down (SBR)" (see Chapter "Extended Functions without encoder (Page 266)")

The most important control versions and the most important STARTER dialog boxes are visible in these two cases. If you select one of the other versions, only the required settings options are visible in the respective parameter assignment screen form.

### 6.7.2.1 Extended Functions with encoder


The following uses an example to describe how you commission the Safety Integrated Extended Functions in STARTER.

The screen forms shown here are examples from the offline commissioning. To complete commissioning, you must establish an online connection between STARTER/SCOUT and the drives.

## Commissioning

To commission the Extended Functions, proceed as follows:

- In the project navigator, select "<Drive unit> > Drives > <Drive> > Functions > Safety Integrated."




- For this example, we will select the combination of "Extended Functions via PROFIsafe and Basic Functions via onboard terminals" and "[0] Safety with encoder and acceleration monitor (SAM) / delay time" because 2 control versions are visible in this case.

The screenshot displays the 'Safety Integrated' configuration software. At the top, there are two tabs: 'Safety Integrated' and 'Safety checksums'. Below the tabs, the 'Safety function selection' section contains two dropdown menus. The first dropdown is set to 'Extended functions via PROFIsafe and basic functions via onboard terminals', and the second is set to '[0] Safety with encoder and accel\_monitoring(SAM) / delay time'. A 'Configuration' button is located above a central tree structure. The tree structure includes a 'Motion monitoring' box containing several sub-sections: 'Safety basic functions (STO, SS1, SBC)', 'Safe stop functions (SS1, SS2, SOS, SAM)', 'Safe brake test (SBT)', 'Safely limited speed (SLS)', 'Safe speed monitoring (SSM)', 'Safe Direction (SDI)', and 'Safe position monitoring (SLP, SP)'. To the left of the tree, a 'Safety functions' dropdown is set to 'Inhibit'. Below the tree is an 'Acceptance mode' button. On the right side, a 'Diagnostics of the safety functions' panel lists various safety functions with radio buttons for activation: STO active, SBC active, SS1 active, SS2 active, SOS active, SBT selected, BT active, SLS active, Active level: 1, Active SLS limit value: 0 mm/min, Velocity below SSM limit value, SDI positive active, SDI negative active, SLP active, Active position range: 1, Shutdown paths require testing, and Internal event. At the bottom left, there is a checkbox labeled 'Copy parameters after download'.



## Configuration


- Click "Configuration" in the "Safety Integrated" screen form:



- This dialog box provides the following setting options for the Extended Functions:
  - "Drive type"  
Select linear axis or rotary axis / spindle axis type (p9502).
  - "Monitoring cycle clock"  
You can set the monitoring cycle for safe motion monitoring (p9500) here.
  - "Actual value acquisition clock"  
You can set the cycle time of the actual value acquisition for safe motion monitoring (p9511) here. A slower cycle time reduces the maximum permissible velocity, but also reduces the load on the Control Unit for safe actual value acquisition. You can find details about the actual value sensing in Chapter "Notes regarding safe actual value sensing using an encoder system (Page 147)".
  - "Modulo range" – for rotary axis/spindle only  
You can set the modulo value in degrees for rotary axes for the "Safe Position" function (p9505) here. This modulo value is taken into account for safe referencing and for the transfer of the safe position via PROFIsafe when absolute position is enabled.
  - "Extended alarm acknowledgment" (≙ message acknowledgment)  
When this function is activated, a safe acknowledgment can be performed by selecting/deselecting STO or SS1 (Internal Event Acknowledge) (p9507.0).

- "Select test stop" (forced dormant error detection)  
 You can set the signal source for the test stop of the safe motion monitoring functions (p9705) here.
- "Perform test stop automatically during startup"  
 If the option is activated, the test stop is automatically performed when the converter starts up (p9507.6).
- "Pulse suppression test time"  
 You set the time after which the pulses must have been suppressed after initiating the test stop (p9557) here.
- "Timer test stop"  
 You can set the interval for carrying out the forced checking procedure and test the drive-integrated safety motion monitoring functions (p9559) here.
- "Remaining time until test stop"  
 This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
- "Test stop required"  
 Select the parameters to be interconnected with the status "Shutdown path test required" (r9723.0). One or more interconnections are possible, but not mandatory.
- "PROFIsafe configuration" - only for control via PROFIsafe

Click this button to open the "PROFIsafe Configuration" dialog box:



Enter the "PROFIsafe address" (p9610) of the drive in hexadecimal code here.

"Telegram configuration" (p60022) shows the currently parameterized PROFIsafe telegram; "Safety parameterization" (p9611) shows the telegram currently used in the Safety parameterization.

- Click "Accept PROFIsafe telegram" to accept the currently parameterized PROFIsafe telegram in the safety parameterization.

- Click "Close" to return to the "Safety Integrated" dialog box.

- "Configuration encoder"

Click this button to open the "Encoder parameterization" dialog box:

## Encoder parameterization

The STARTER screen "Encoder parameterization" shows the encoder parameters relevant to the safety functions. Parameters of the motor encoder are taken over from the standard configuration. (The fields are shown as inactive.)

Image 6-6 Encoder parameterization (example; does not show all the fields of the dialog box that are possible in all versions)

This screen form provides the following display or setting options:

- "Configuration encoder"
  - "Encoder type" shows whether a rotary or a linear encoder is used. The unit system is changed accordingly (degrees or rpm, mm or mm/min) (p9516).
  - "Encoder lines " shows the number of encoder lines of the encoder being used (p9518).
  - "Fine resolution" shows the number of bits of the encoder control word used (p9519).
  - "Sign change" enables you to invert the actual value (p9516).
  - "Leadscrew pitch" enables you to enter the transformation ratio between the encoder and load in mm (linear axis with rotary encoder) (p9520; only available for linear axis).

- "Accept encoder data"

The "Accept encoder data" button is available online and enables you to update the Safety parameters. Depending on the configuration, a one or two-encoder system, the appropriate encoder parameters are copied from the basic system into the corresponding Safety parameters.

- "Mechanics configuration"

In this section you can parameterize a gear ratio for the used encoder. The gear ratio is the ratio of encoder revolutions to revolutions of the drive shaft (load revolutions).

- "Number of load revolutions" enables you to enter the number of load revolutions (p9521).
- "Number of encoder revolutions" enables you to enter the number of encoder revolutions (p9522).


- "Actual value synchronization"

- "Actual value synchronization" enables you to put the actual values of both encoders cyclically on the average value. If the actual value synchronization is not enabled, the value parameterized in p9542 is used as tolerance value in the data cross-check (p9501).
- "Actual value tolerance" enables you to enter the tolerance for the cross-check of the actual position between the two encoders (p9542; only if the actual value synchronization is blocked).
- "Speed tolerance" enables you to specify the maximum tolerance for the cross-check of the actual speed (p9549; only if actual value synchronization has been activated).
- "Maximum actual-value difference" shows the maximum difference between the load-side actual position value on the Control Unit and the load-side actual position value on the second channel.
- "Additional actual-value tolerance" shows the additional maximum difference between the load-side actual position value on the Control Unit and the load-side actual position value on the second channel, which can occur due to the delay of the actual value acquisition in the EnDat 2.2 converter.

- Click "Close" to return to the "Safety Integrated" dialog box.


## Safe Basic Functions

- Click "Safe basic functions (STO, SS1, SBC)," to parameterize the basic functions via onboard terminals:




- This screen form provides the following setting options:
  - "STO active"
    - Select the parameters with which the "STO active" status is to be interconnected (r9773.1). One or more interconnections are possible, but not mandatory.
  - "Forced dormant error detection (test stop) of the shutdown paths"
    - This is where you set the time interval for performing the forced dormant error detection and test of the safety shutdown paths (p9659).
  - "Test stop required"
    - Select the parameters to be interconnected with the status "Shutdown path test required" (r9773.31). One or more interconnections are possible, but not mandatory.
  - "Remaining time until test stop"
    - This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
  - "Safe Brake Control"
    - Activate the Safe Brake Control (SBC/p9602).

- Click "STO, SS1, SBC," to make settings for STO, SS1, and SBC:



- "Control Unit (terminal)" – for control via terminal only  
Set the signal source for the STO, SBC and SS1 functions on the Control Unit (p9620) here.
- "Safe Stop 1 delay time"  
This is where you set the delay time of the pulse suppression for the "Safe Stop 1" (SS1) function on the Control Unit to brake along the OFF3 deceleration ramp (p9652).
- "[0] SS1 with OFF3"  
You set the drive-autonomous braking response for the "Safe Stop 1" (SS1) function here (p9653). Alternatively, you can select SS1E (SS1 with external stop).
- "Output "STO active""  
Select the parameters with which the STO active status is to be interconnected (r9773). One or more interconnections are possible, but not mandatory.
- Click "STO extended settings," to make additional settings for STO or SS1.

This dialog box provides the following setting options for STO (Basic Functions):



- "F-DI input filter"  
This is where you set the debounce time for the fail-safe digital inputs used to control STO/SBC/SS1 (p9651).
- "Monitoring for simultaneous operation"  
This is where you set the tolerance time for the switchover of the safety-related inputs on the Control Unit (p9650).
- "STOP F -> STOP A delay time"  
This is where you set the transition time from STOP F to STOP A on the Control Unit (p9658).
- "Forced dormant error detection (test stop) of the shutdown paths"  
This is where you set the time interval for performing the forced dormant error detection and test of the safety shutdown paths (p9659).


- "Remaining time until test stop"
 

This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
- "Shutdown paths require testing"
 

Select the parameters to be interconnected with the status "Shutdown path test required" (r9773.31). One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

### Safe stop functions (SS1, SS2, SOS, SAM)

- Click "Safe stop functions (SS1, SS2, SOS, SAM)" in the "Safety Integrated" dialog box to parameterize SS1, SS2, SOS, and SAM:
- Change to the "SS1" page.



- "Delay time STOP F -> STOP B"
 

Enter a value for the delay time here for the transition from STOP F to STOP B (p9555).
- "Delay time SS1/STOP B -> STO active"
 


Enter a value for the delay time here for the transition from the safe pulse suppression to STOP B (p9556).
- "Shutdown velocity/shutdown speed"
 

Enter a value for the shutdown speed SS1 (p9560).
- "SS1 monitoring"
 

You can select whether you want to use SS1 with OFF3 or with external stop (p9507) here.




- Change to the "SS2/SOS" page.



- "Delay time SS2/STOP C -> SOS active"  
You can set the transition time from SS2/STOP C to SOS (p9552) here.
- "Delay time SOS -> SOS active"  
You can set the delay time for the activation of SOS (p9551) here. Please note that this is the same timer value that is effective between the selection and activation of SLS.
- "Delay time for STOP D -> SOS active"  
You can set the transition time from STOP D to SOS (p9553) here.
- "Delay time for STOP E -> SOS active"  
You can set the transition time from STOP E to SOS (p9554) here.
- "Standstill tolerance SOS"  
You can set the tolerance for the SOS function (p9530) here.


- Change to the "SAM" page (acceleration monitoring).



- "Speed tolerance"  
You set the velocity tolerance for the "SAM" function (p9548) here.
- "Shutdown speed acceleration monitoring"  
You can set the velocity limit for the "SAM" function (p9568) here.  
SAM is deactivated once the set velocity limit has been undershot.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Safe brake test (SBT)

- In the "Safety Integrated" dialog box, click "Safe brake test (SBT)" to parameterize the Safe Brake Test:




- "SBT enable"  
Enable the Safe Brake Test (p10201.0) here.
- "Selects SBT"  
Select whether you want to select the Safe Brake Test via SCC, BICO or test stop (p10203).
- "SBT motor type"  
Here, select the motor type (linear or rotary) for which you wish to test the brake (p10204).
- "Brake 1/brake 2"  
Set the following values for each brake to be tested:
  - "Brake test"  
Specify whether you want to test a motor holding brake or an external brake (p10202). If you do not wish to test a brake, then set the particular index = 0.
  - "Holding torque"  
Set the holding torque of the brake to be tested (p10209).
  - "Build up test torque"  
You can set the time in which the test torque is ramped up against the closed brake (p10208) here. The test torque is ramped down to zero within this time.

- "Test sequence 1/test sequence 2"  
You can set the following values for each brake to be tested brake and each required test sequence:
  - "Test torque"  
Set the test torque for the safe brake test as a factor in relation to the holding torque of the brake. (p10210).
  - "Tolerance"  
You can set the permissible positional deviation during the brake test (p10212) here.
  - "Test duration"  
You can set the duration of Safe Brake Test (p10211) here. During this time, the selected test torque is active on the brake.
- LEDs "Test sequence active"  
The LEDs "Test sequence active" display an AND logic operation from r10234.2, r10234.3, and r10231.4. While r10234 indicates the status bits, r10231 represents the control bits: As a consequence, r10231.4 only indicates as to whether test sequence 1 or 2 is selected, however not which one is currently active.  
While a brake test sequence is active, switching bits 2 to 4 is ignored in r10231. However, while test sequence 1 is active, by setting bit r10234.4 from 0 to 1, test sequence 2 can essentially be preselected. However, even after setting bit r10234.4 to 1, test sequence 1 is first completed and test sequence 2 is not immediately selected. However, in STARTER, as a result of this "preselection", the LED for the currently active test sequence 1 is gray and the LED for the preselected test sequence 2 is green.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Safely Limited Speed (SLS)


- Click "Safely Limited Speed (SLS)" in the "Safety Integrated" dialog box to parameterize SLS:



- This dialog box offers the following setting options for SLS:
  - "SLS limit via PROFIsafe"
    - Enter SLS via PROFIsafe (p9501.24 = 1) here.
  - "Delay time for selection of SLS -> SLS active"
    - Enter a value for the delay time for the transition from the SLS selection to the "SLS active" state (p9551). This delay time is also effective when switching to a lower SLS level. Please note that this delay time is also used for the selection of SOS.
  - "Setpoint speed limit"
    - Enter the weighting factor to determine the setpoint limit from the selected actual speed limit (p9533). The active SLS limit value is weighted with this factor, and is provided as setpoint limit in r9733.
  - "SLS limit values (SLS1 to SLS4)"
    - Enter a value for the four SLS levels (p9531[0...3]) here.
  - "Stop responses"
    - You can select which stop response is to apply for each of the four SLS levels (p9563[0...3]) here.
  - "Positive setpoint limitation"
    - Select the parameters with which the "Speed setpoint limitation effective" status (r9733[0]) is to be interconnected. One or more interconnections are possible, but not mandatory.
  - "Negative setpoint limitation"
    - Select the parameters with which the "Speed setpoint limitation effective" status (r9733[1]) is to be interconnected. One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

### Safe Speed Monitor (SSM)


- Click "Safe Speed Monitor (SSM)" in the "Safety Integrated" dialog box to parameterize SSM:



- This dialog box offers the following setting options for SSM:
  - "SSM with hysteresis"
    - Enable "SSM ( $n < nx$ ) with hysteresis and filtering" (p9501.16 = 1) here.
  - "Filter time"
    - You can enter the filter time for the SSM feedback to detect standstill ( $n < nx$ ) (p9545) here.
  - "Hysteresis"
    - You can enter a value for the velocity hysteresis for the SSM feedback to detect standstill (p9547) here.
  - "Speed limit"
    - You can enter the velocity limit for the SSM feedback to detect standstill (p9546) here.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Safe Direction (SDI)


- Click "Safe Direction (SDI)" in the "Safety Integrated" dialog box to parameterize SDI:



- This dialog box offers the following setting options for SDI:
  - "SDI"  
Enable SDI (p9501.17 = 1) here.
  - "Delay time for selection of SDI -> SDI active"  
You can set the transition time from "SDI selection" to "SDI active" on the Control Unit (p9658) here.
  - "Tolerance"  
Enter a value for the position tolerance here: Within this tolerance, movement is tolerated in the direction that has not been enabled (p9564).
  - "Stop response"  
Select the required stop response (p9566) here.
  - "Positive setpoint limitation"  
Select the parameters with which the "Speed setpoint limitation effective" status (r9733[0]) is to be interconnected. One or more interconnections are possible, but not mandatory.
  - "Negative setpoint limitation"  
Select the parameters with which the "Speed setpoint limitation effective" status (r9733[1]) is to be interconnected. One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

**Safe position monitoring (SLP, SP)**

- Click "Safe Position Monitoring (SLP, SP)" in the "Safety Integrated" dialog box to parameterize SLP and SP:




- This dialog box offers the following setting options for SLP:
  - "SLP"
    - Enable SLP (p9501.1 = 1) here.
  - "Position range 1"
    - You can enter the minimum position (P<sub>min</sub>, P9535[0], the maximum position (P<sub>max</sub>, P9534[0]) and the required stop response (p9562[0]) for position range 1 here.
  - "Position range 2"
    - You can enter the minimum position (P<sub>min</sub>, P9535[1], the maximum position (P<sub>max</sub>, P9534[1]) and the required stop response (p9562[1]) for position range 2 here.
  - "Safe position"
    - Enter the "Safe Position" (p9501.25 = 1) here.
  - "Safe Absolute Position"
    - Enter the "Safe Absolute Position" (p9501.2 = 1) here.
  - "Scaling factor for the position value in 16-bit format"
    - You can enter the scaling factor for the transfer of the safe position via PROFIsafe in 16-bit format (p9574) here.
  - "Tolerance of the actual position values (referencing)"
    - Enter the tolerance for checking the actual values after referencing (incremental encoder) or when powering-up (absolute encoder) (p9544) here.
- Click "Close" to return to the "Safety Integrated" dialog box.



## Acceptance mode

- Click "Acceptance mode" in the "Safety Integrated" dialog box to parameterize acceptance:



- This dialog box offers the following setting options for the acceptance mode:
  - "Acceptance mode time limit"
    - You can enter the maximum time for the acceptance test mode (p9558) here.
  - "Activate acceptance mode"
    - Click this button to activate the acceptance mode.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Completion

- After parameter assignment, you must save the data and duplicate the values for the second channel.

### Note

#### Duplicating safety parameters

For safety reasons, when using the STARTER commissioning tool (or SCOUT), you can only set the safety-related parameters of the first channel offline.

To set the safety-related parameters of the second channel, proceed as follows:

- Activate the "Copy parameters after download" checkbox and then establish an online connection to the drive unit. Perform the download and then adapt the checksums. Execute the "Copy RAM to ROM" command and then a POWER ON.
- Or establish an online connection to the drive unit first and then duplicate the parameters by clicking the "Copy parameters" button on the start screen of the configuration.

### 6.7.2.2 Extended Functions without encoder


The following uses an example to describe how you commission the Safety Integrated Extended Functions in STARTER.

The screen forms shown here are examples from the offline commissioning. To complete commissioning, you must establish an online connection between STARTER/SCOUT and the drives.


## Commissioning

To commission the Extended Functions, proceed as follows:

- In the project navigator, select "<Drive unit> > Drives > <Drive> > Functions > Safety Integrated."




- For this example, we will select the combination of "Extended Functions via PROFIsafe and Basic Functions via onboard terminals" and "[1] Safety without encoder with braking ramp (SBR)" because 2 control versions are visible in this case.



## Configuration

- Click "Configuration" in the "Safety Integrated" screen form:



- This dialog box provides the following setting options for the Extended Functions without encoder:
  - "Drive type"
    - Select linear axis or rotary axis / spindle axis type (p9502).
  - "Monitoring cycle clock"
    - You can set the monitoring cycle for safe motion monitoring (p9500) here.
  - "Actual value acquisition clock"
    - You can set the cycle time of the actual value acquisition for safe motion monitoring (p9511) here. The actual value sensing clock cycle must be set the same as the controller clock cycle (p0115). You can find details about the actual value sensing in Chapter "Notes regarding setting parameters for safe actual value sensing without encoder (Page 154)".
  - "Extended alarm acknowledgment" (≙ message acknowledgment)
    - When this function is activated, a safe acknowledgment can be performed by selecting/deselecting STO or SS1 (Internal Event Acknowledge) (p9507.0).
  - "Select test stop" (forced dormant error detection)
    - You can set the signal source for the test stop of the safe motion monitoring functions (p9705) here.
  - "Pulse suppression test time"

You set the time after which the pulses must have been suppressed after initiating the test stop (p9557) here.

- "Forced dormant error detection (test stop) of the shutdown paths"

You can set the interval for carrying out the forced checking procedure and test the drive-integrated safety motion monitoring functions (p9559) here.

- "Forced dormant error detection (test stop) required"

Select the parameters to be interconnected with the status "Shutdown path test required" (r9723.0). One or more interconnections are possible, but not mandatory.

- "PROFIsafe configuration" - only for control via PROFIsafe

Click this button to open the "PROFIsafe Configuration" dialog box:

Enter the "PROFIsafe address" (p9610) of the drive in hexadecimal code here.

"Telegram configuration" (p60022) shows the currently parameterized PROFIsafe telegram; "Safety parameterization" (p9611) shows the telegram currently used in the Safety parameterization.


Click "Accept PROFIsafe telegram" to accept the currently parameterized PROFIsafe telegram in the Safety parameterization.

Click "Close" to return to the "Safety Integrated" dialog box.

- "Mechanics configuration"

Click this button to open the "Mechanical System Configuration" dialog box:

## Mechanical system configuration



- This dialog box offers the following setting options:
  - "Actual value tolerance"
 

You set the tolerance for the cross-check of the actual position between the two monitoring channels (p9542) here.  
The tolerance must be set higher (e.g. 12° rotary and 1 mm linear) for encoderless motion monitoring functions.
  - "Number of load revolutions"
 

You can set the "Number of load revolutions" (p9521) here.
  - "Number of motor revolutions × number of pole pairs"
 


You can set the "Number of motor revolutions × number of pole pairs" (p9522) here.
- Click "Close" to return to the "Configuration" dialog box.

## Actual value acquisition configuration

- Click "Actual value acquisition configuration" to open the "Actual Value Acquisition Without Encoder Configuration" dialog box. A description of this dialog can be found in Section "Notes regarding setting parameters for safe actual value sensing without encoder (Page 154)".
- Then click "Close" to return to the "Safety Integrated" dialog box.


## Safe Basic Functions

- Click "Safe basic functions (STO, SS1, SBC)," to parameterize the basic functions via onboard terminals:



- This screen form provides the following setting options:
  - "STO active"
    - Select the parameters with which the "STO active" status is to be interconnected (r9773.1). One or more interconnections are possible, but not mandatory.
  - "Forced dormant error detection (test stop) of the shutdown paths"
    - This is where you set the time interval for performing the forced dormant error detection and test of the safety shutdown paths (p9659).
  - "Test stop required"
    - Select the parameters to be interconnected with the status "Shutdown path test required" (r9773.31). One or more interconnections are possible, but not mandatory.
  - "Remaining time until test stop"
    - This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
  - "Safe Brake Control"
    - Activate the Safe Brake Control (SBC/p9602).

- Click "STO, SS1, SBC," to make settings for STO, SS1, and SBC:




- "Control Unit (terminal)" – for control via terminal only  
Set the signal source for the STO, SBC and SS1 functions on the Control Unit (p9620) here.
- "Safe Stop 1 delay time"  
This is where you set the delay time of the pulse suppression for the "Safe Stop 1" (SS1) function on the Control Unit to brake along the OFF3 deceleration ramp (p9652).
- "[0] SS1 with OFF3"  
You set the drive-autonomous braking response for the "Safe Stop 1" (SS1) function here (p9653). Alternatively, you can select SS1E (SS1 with external stop).
- "Output "STO active""  
Select the parameters with which the STO active status is to be interconnected (r9773). One or more interconnections are possible, but not mandatory.
- Click "STO extended settings," to make additional settings for STO or SS1.



## STO extended settings

This dialog box provides the following setting options for STO (Basic Functions):




- "F-DI input filter"  
This is where you set the debounce time for the fail-safe digital inputs used to control STO/SBC/SS1 (p9651).
- "Monitoring for simultaneous operation"  
This is where you set the tolerance time for the switchover of the safety-related inputs on the Control Unit (p9650).
- "STOP F -> STOP A delay time"  
This is where you set the transition time from STOP F to STOP A on the Control Unit (p9658).
- "Forced dormant error detection (test stop) of the shutdown paths"  
This is where you set the time interval for performing the forced dormant error detection and test of the safety shutdown paths (p9659).

- "Remaining time until test stop"  
This indicates the remaining time until dynamic operation and test of the safety switch-off signal paths are performed (p9660).
- "Shutdown paths require testing"  
Select the parameters to be interconnected with the status "Shutdown path test required" (r9773.31). One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.


## Safe stop functions (SS1, SBR)

- Click "Safe stop functions (SS1, SBR)" in the "Safety Integrated" dialog box to parameterize SS1 and SBR.
- Go to page "SS1"



- "Delay time STOP F -> STOP B"  
Enter a value for the delay time here for the transition from STOP F to STOP B (p9555).
- "Shutdown speed SS1"  
Enter a value for the shutdown speed SS1 (p9560).
- "SS1 monitoring"  
You can select whether you want to use SS1 with or without drive-autonomous OFF3 ramp (p9507) here.

- Go to page "SBR"



- "Delay time"

Set the delay time for the monitoring of the braking ramp (p9582) here. After the delay time, monitoring of the braking ramp will be started.

- "Monitoring time"

Set the monitoring time for determination of the braking ramp (p9583) here. The gradient of the braking ramp depends on p9581 (reference value) and p9583 (monitoring time).


- "Reference velocity"

Set the reference value for determination of the braking ramp (p9581) here. The gradient of the braking ramp depends on p9581 (reference value) and p9583 (monitoring time).

- Click "Close" to return to the "Safety Integrated" dialog box.

## Safely Limited Speed (SLS)


- Click "Safely Limited Speed (SLS)" in the "Safety Integrated" dialog box to parameterize SLS:



- This dialog box offers the following setting options for SLS:
  - "SLS limit via PROFIsafe"
    - Enter SLS via PROFIsafe (p9501.24 = 1) here.
  - "Setpoint speed limit"
    - Enter the weighting factor to determine the setpoint limit from the selected actual speed limit (p9533). The active SLS limit value is weighted with this factor, and is provided as setpoint limit in r9733.
  - "SLS limit values (SLS1 to SLS4)"
    - Enter a value for the four SLS levels (p9531[0...3]) here.
  - "Stop responses"
    - You can select which stop response is to apply for each of the four SLS levels (p9563[0...3]) here. Only STOP A and STOP B can be configured as stop responses for "Safely-Limited Speed" (SLS) without encoder.
  - "Positive setpoint limitation"
    - Select the parameters with which the "Speed setpoint limitation effective" status (r9733[0]) is to be interconnected. One or more interconnections are possible, but not mandatory.
  - "Negative setpoint limitation"
    - Select the parameters with which the "Speed setpoint limitation effective" status (r9733[1]) is to be interconnected. One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Safe Speed Monitor (SSM)


- Click "Safe Speed Monitor (SSM)" in the "Safety Integrated" dialog box to parameterize SSM:



- This dialog box offers the following setting options for SSM:
  - "SSM with hysteresis"
    - Enable "SSM ( $n < n_x$ ) with hysteresis and filtering" (p9501.16 = 1) here.
  - "Filter time"
    - You can enter the filter time for the SSM feedback to detect standstill ( $n < n_x$ ) (p9545) here.
  - "Hysteresis"
    - You can enter a value for the velocity hysteresis for the SSM feedback to detect standstill (p9547) here.
  - "Speed limit"
    - You can enter the velocity limit for the SSM feedback to detect standstill (p9546) here.
  - "SSM active feedback for pulse inhibit"
    - You can set how SSM and its feedback behave during pulse suppression in encoderless operation (p9509.0).
- Click "Close" to return to the "Safety Integrated" dialog box.

## Safe Direction (SDI)


- Click "Safe Direction (SDI)" in the "Safety Integrated" dialog box to parameterize SDI:



- This dialog box offers the following setting options for SDI:
  - "SDI"  
Enable SDI (p9501.17 = 1) here.
  - "Delay time for selection of SDI -> SDI active"  
You can set the transition time from "SDI selection" to "SDI active" on the Control Unit (p9658) here.
  - "Tolerance"  
Enter a value for the position tolerance here: Within this tolerance, movement is tolerated in the direction that has not been enabled (p9564).
  - "Stop response"  
Select the required stop response (p9566) here.
  - "SDI active feedback for pulse inhibit"  
You can set how SDI and its feedback behave during pulse suppression in encoderless operation (p9509.8).
  - "Positive setpoint limitation"  
Select the parameters with which the "Speed setpoint limitation effective" status (r9733[0]) is to be interconnected. One or more interconnections are possible, but not mandatory.
  - "Negative setpoint limitation"  
Select the parameters with which the "Speed setpoint limitation effective" status (r9733[1]) is to be interconnected. One or more interconnections are possible, but not mandatory.
- Click "Close" to return to the "Safety Integrated" dialog box.

### Safe Position (SP)

- Click "Safe Position (SP)" in the "Safety Integrated" dialog box to parameterize SP:




- This dialog box offers the following setting options for SP:
  - "Safe position"  
Enter the "Safe Position" (p9501.25 = 1) here.
  - "Scaling factor for the position value in 16-bit format"  
You can enter the scaling factor for the transfer of the safe position via PROFIsafe in 16-bit format (p9574) here.
- Click "Close" to return to the "Safety Integrated" dialog box.



## Acceptance mode

- Click "Acceptance mode" in the "Safety Integrated" dialog box to parameterize acceptance:



- This dialog box offers the following setting options for the acceptance mode:
  - "Acceptance mode time limit"
    - You can enter the maximum time for the acceptance test mode (p9558) here.
  - "Activate acceptance mode"
    - Click this button to activate the acceptance mode.
- Click "Close" to return to the "Safety Integrated" dialog box.

## Completion

- After parameter assignment, you must save the data and duplicate the values for the second channel.

---

### Note

#### Duplicating safety parameters

For safety reasons, when using the STARTER commissioning tool (or SCOUT), you can only set the safety-related parameters of the first channel offline.

To set the safety-related parameters of the second channel, proceed as follows:

- Activate the "Copy parameters after download" checkbox and then establish an online connection to the drive unit. Perform the download and then adapt the checksums. Execute the "Copy RAM to ROM" command and then a POWER ON.
  - Or establish an online connection to the drive unit first and then duplicate the parameters by clicking the "Copy parameters" button on the start screen of the configuration.
-

## 6.8 Commissioning CU310-2 using STARTER/SCOUT

This description explains commissioning using control via onboard terminals as example.

The following preconditions must be met to configure Safety Integrated on the CU310-2:

- Concluded initial commissioning of all drives
- Connect the sensors to the F-DIs and an actuator to the F-DO (if used)

### Configuration sequence

1. Configuring Safety functions of the CU310-2
2. Configuring inputs (if used)
3. Configuring outputs (if used)
4. Copy parameters to the 2nd drive object
5. Change the safety password
6. Activate the configuration by selecting "Activate settings"
7. Save the project in STARTER
8. Save the project in the drive by selecting "Copy RAM to ROM"
9. Execute POWER ON
10. Acceptance test

## 6.8.1 Configuration start screen

In order to parameterize the Safety functionality of the CU310-2, in the STARTER commissioning tool, select the item "<Drive unit> > Drive\_1 > Functions→ Safety Integrated". Using the two drop-down lists, under "Select safety function", select the required safety functionality, the control version and the encoder being used:




Image 6-7 CU310-2: Safety starting screen (example)

- You can find examples for configuring the Safety Integrated functions in the chapters:
  - "Commissioning Basic Functions (Page 240)"
  - "Commissioning Extended Functions (Page 238)"

## 6.8.2 F-DI/F-DO configuration

### F-DIs to control the Extended Functions

This setting option is only available when controlling Extended functions via the onboard terminals.




Image 6-8 F-DIs to control the Extended Functions screen from

#### NC/NO contact (p10040)

Terminal property F-DI 0-2 (p10040.0 = F-DI 0, ... p10040.2 = F-DI 2), only the property of the second (lower) digital input is set. Always connect an NC contact to digital input 1 (upper). The 2nd digital input can be configured as a NO contact.

#### LED symbol in the F-DI screen

The LED symbol after the AND element indicates the logical state (inactive: gray, active: green, discrepancy error: red).

## Transferring F-DIs via PROFIsafe

The safe state of the F-DIs selected is transferred via PROFIsafe to an F-controller. You can set the transfer for each F-DI.

This setting option is only available when controlling Extended functions via the onboard terminals.




Image 6-9 Transferring F-DIs via PROFIsafe screen form



The status of the F-DI is transferred in the safety status word 2 (S\_ZSW2)



The status of the F-DI is not transferred.

---

### Note

#### Displaying status values

It is only possible to display the status values of F-DIs for PROFIsafe telegrams 31, 901 and 902.

---

Screen of the F-DO fail-safe output




Image 6-10 Output screen

**Signal source for F-DO (p10042)**

A six-way AND logic operation is connected downstream of the output terminal pair of the F-DO; the signal sources for the inputs of the AND can be selected:

- If a signal source is not connected to an input, then the input is set to HIGH (default), exception: If a signal source is not connected at any input, then the output signal = 0
- Status signals of the drive

For additional information on status signals, see Section "Function of the F-DO" in Section "Control via TM54F/CU310-2".

**Selection of the test sensor feedback (p10046) and selection of test mode for forced dormant error detection (test stop) (p10047)**

On the F-DO, testing the readback cable can be activated with dynamic operation and the test mode for the test stop can be selected (for more information, see Chapter "Forced dormant error detection (test stop) (Page 160)").

**LED symbol in the F-DO screen**

The LED symbol after the AND element indicates the logical state (inactive: gray, active: green).

### 6.8.3 Control interface of the drive




Image 6-11 Drive screen

Functions of this screen:

- Select an F-DI for functions STO, SS1, SS2, SOS, SLS, for the velocity limits (bit-coded) of SLS (p10022 to p10028) as well as SDI (p10030 and p10031) and select SLP (p10032 and p10033).

An F-DI can be assigned several functions.

- Configuration of the "Safe State" signal (p10039)

A safety output signal "Safe State" can be generated for the drive from the following status signals: STO active (Power\_removed), SS1 active, SS2 active, SOS active, SLS active, SDI positive active, SDI negative active, SLP active

The status signals of the individual functions (STO active, SS1 active, etc.) are ORed. The "Safe State" signal can be assigned to the F-DO.

- Static selection/deselection of functions
  - With "Statically selected", a safety function can be permanently selected.
  - With "Statically inactive", a function can be permanently deselected. This setting is required or recommended for all functions that are not used.

## 6.8.4 Forced dormant error detection (test stop) of the CU310-2

### Testing fail-safe inputs and outputs

Fail-safe inputs and outputs must be tested for fail-safety at defined time intervals (forced dormant error detection or test stop). For this purpose, the CU310-2 contains a function block that runs this forced dormant error detection (test stop) for the fail-safe output when selected via a BICO source. Each time a forced dormant error detection (test stop) is performed without error, a timer is started to monitor the time until the next required test. After this time interval (p10003) has elapsed and every time the Control Unit is switched on, the user is informed by the message A01774 that forced dormant error detection (test stop) must be performed.

- 3 modes can be selected for testing the output (see following chapter).

---

#### Note

##### Testing the sensors for the CU310-2

Unlike TM54F, the sensors connected to the F-DI of the CU310-2 cannot be tested as part of forced dormant error detection (test stop). The user must cyclically test sensors connected to the F-DIs. Then it is sufficient to actuate the particular sensor and to check the corresponding function selection.

---



## Execution

When parameterizing, proceed as follows:

1. Derive the suitable mode from the circuit used in your application (see figures in the following chapters).
2. Set the mode that you wish to use in parameter p10047.
3. Use parameter p10046 to define whether the digital output F-DO 0 is to be tested.
4. Use parameter p10001 to set the time within which the digital output signals to the corresponding digital inputs or DIAG inputs must be recognized.
5. With parameter p10003, set the interval within which forced dormant error detection (test stop) will be performed. After this interval has elapsed, the user is informed by the message A01774 that forced dormant error detection (test stop) must be performed for the F-DI/F-DO.
6. Set the signal source which triggers the start using parameter p10007. This can be, for example, a control signal or switch via a BICO switchable signal.

While being executed, message A01772 (test stop fail-safe output active) is displayed. The messages A01772 and A01774 only disappear again after the execution. If an error has been detected by forced dormant error detection (test stop), fault F01773 is output. Using the test sequence specified for each mode, you can see which error has occurred from the fault value of the test step.



### WARNING

#### **Danger to life due to unwanted movement given improper use of the feedback DI of the F-DO**

With the test sequence, unwanted movements of the drive can be caused if the DI of the F-DO is not only used for feedback with test stop/forced dormant error detection but also for other purposes.

- Only use the DI of the F-DO for feedback with forced dormant error detection (test stop) and not for other purposes.

## Forced dormant error detection (test stop): Duration

You can calculate the duration using this formula:

$$T_{\text{Test stop}} = 8 \times p9500 + 6 \times p10001$$

Test of the F-DO	Evaluation of the active F-DIs
---------------------	-----------------------------------

6.8.4.1 Test mode 1: Evaluation of internal diagnostic signal (passive load)




Image 6-12 F-DO circuit "Test mode 1: Evaluation of internal diagnostic signal (passive load)"

DO+	DO-	Expected response, DIAG signal
OFF	OFF	LOW
ON	ON	LOW
OFF	ON	LOW
ON	OFF	HIGH
OFF	OFF	LOW

Test sequence for test mode 1

6.8.4.2 Test mode 2: Read back F-DO in DI (relay circuit)




Image 6-13 F-DO circuit "Test mode 2: Read back F-DO in DI (relay circuit)"

DO+	DO-	Expected response, DI signal
OFF	OFF	HIGH
ON	ON	LOW
OFF	ON	LOW
ON	OFF	LOW
OFF	OFF	HIGH

Test sequence for test mode 2

6.8.4.3 Test mode 3: Read back F-DO into the DI (actuator with feedback signal)




Image 6-14 F-DO circuit "Test mode 3: Read back F-DO into the DI (actuator with feedback signal)"

DO+	DO-	Expected response, DI signal
OFF	OFF	HIGH
ON	ON	LOW
OFF	ON	HIGH
ON	OFF	HIGH
OFF	OFF	HIGH

Test sequence for test mode 3

#### 6.8.4.4 Test stop mode parameters

##### Overview of important parameters (see SINAMICS S 120/S150 List Manual)

- p9500 SI Motion monitoring cycle (Control Unit) (only Extended Functions)
- p10001 SI Motion wait time for test stop on DO
- p10003 SI Motion forced dormant error detection timer
- p10007 BI: SI Motion forced dormant error detection F-DO signal source
- p10017 SI Motion digital inputs debounce time (CPU 1)
- p10046 SI Motion F-DO feedback signal input activation
- p10047 SI Motion F-DO test stop mode (CPU 1)

## 6.9 Commissioning TM54F by means of STARTER/SCOUT

### 6.9.1 Basic sequence of commissioning

The following conditions must be met before you can configure the TM54F:

- Initial commissioning of all drives has been completed.
- F-DIs and F-DOs of the TM54F that are to be used must be wired.

#### Configuration sequence

1. Insert the TM54F
2. Configure the TM54F and generate the drive groups
3. Configure Safety functions of the drive groups
4. Configure inputs, configure outputs
5. Copy parameters to the 2nd drive object (TM54F\_SL)
6. Changing the safety password
7. Activate the configuration by selecting "Activate settings"
8. Save the project in STARTER
9. Save the project in the drive by selecting "Copy RAM to ROM"
10. Execute POWER ON
11. Acceptance test

## 6.9.2 Configuration start screen




Image 6-15 Configuration startscreen TM54F

The following functions can be selected in the start screen:

- Configuration  
Opens the "Configuration" screen
- Inputs  
Opens the "Inputs" screen
- Outputs  
Opens the "Outputs" screen
- Drive group 1 ... 4  
Opens the corresponding screen of drive group 1 to 4
- Copy parameters (only available online)  
To copy the configuration to the second drive object (TM54F\_SL), press "Copy parameters".
- Copying parameters after download (only available offline)  
With this function, Copy parameters (parameters are copied from processor 1 to processor 2) can be selected offline. Copying of parameters is then triggered after the next download. Execution of this function does not lead to an adjustment of the Safety checksum.

6.9 Commissioning TM54F by means of STARTER/SCOUT

- Change/activate settings (only available online)
  - Change settings  
You can select this button and enter the TM54F password to activate the commissioning mode. The button function changes to "Activate settings".
  - Activate settings  
This function activates your parameter settings and initiates calculation of the actual CRC and the corresponding transfer to the target CRC.  
A message is output prompting you to save the project and then restart the system. It is also required to carry out an acceptance test.
- Change password  
In order to change the password, enter the old password (factory setting: 0) and then enter and confirm the new password.

### 6.9.3 Function diagrams and parameters

#### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2891                      SI TM54F - Parameter manager



## 6.9.4 TM54F configuration

### Configuration screen of TM54F for Safety Integrated




Image 6-16 TM54F configuration

Functions of this screen:

- Assigning drive objects (p10010)  
Select a drive object to be assigned to a drive group.
- Drive groups (p10011)  
Each configured safety drive can be assigned to a drive group using a drop-down list box. The list box displays the drives and their names.
- Safety communication clock (p10000[0..5])  
Display of the Safety communication clock with which the TM54F communicates with the relevant drive. Using the "Accept clocks from drives" button, update the display of the communication clocks.

---

**Note**

**Assignment to drive groups**

When controlling Safety Integrated functions via a TM54F, you may only assign each drive to precisely one drive group of the TM54F.

---

- F-DI discrepancy time (p10002)

The signal states at the two terminals of an F-DI are monitored in order to determine whether these have assumed the same logical state within the discrepancy time.

---

**Note**

**Discrepancy time**

The discrepancy time must be set so that it is always shorter than the smallest expected switching interval of the signal at the F-DIs.

---

- TM54F sampling time (p10000[0..5])

The Safety sampling time corresponds to the sampling time of TM54F.

---

**Note**

**Setting of the Safety cycle**

The Safety clock (p10000) of the TM54F must be set equal to the monitoring cycle clock of the assigned drive object:

- r9780 (if Basic Functions are used)
  - p9500 (if Extended Functions are used)
- 

- F-DI input filter (p10017)

Parameterizing the debounce time of the F-DIs and single-channel DIs of the TM54F. The debounce time is rounded off to whole ms and then accepted. The debounce time specifies the maximum time an interference pulse can be present at F-DIs before being interpreted as a switching operation.

- F-DI selection

- The Extended Functions enter safety messages in a special message buffer when detecting internal errors or violations of limits. These messages must only be acknowledged in a safety-relevant fashion. You can assign an F-DI terminal pair for safe acknowledgment (p10006).
- You can also select the terminals for the retraction logic (p10009) required for SLP.

- Signal source, forced checking procedure (test stop) (p10007)  
Select an input terminal to start forced dormant error detection (test stop):
  - Forced dormant error detection (test stop) is started with a 0/1 signal of the input terminal and is only possible if the drive is not in commissioning mode.
  - The TM54F must be in the "Ready" state.
  - The F-DI of the TM54F must not be used as a signal source.
- Test cycle, dynamization F-DO (p10003)  
Fail-safe inputs and outputs must be tested for fail-safety at defined time intervals (forced dormant error detection or test stop). The TM54F module contains a function block that runs this forced dormant error detection (test stop) when selected via a BICO source (e.g. switching the sensor current supply L1+ and L2). Each selection triggers a timer in order to monitor the test cycle. A message is set on expiration of the monitored time. This message is also set following each switch on/off.
- Perform test stop automatically during startup  
If you activate this option, forced dormant error detection (test stop) can be performed automatically every time the power supply is switched on (POWER ON) (p9507.6 = 1).

### 6.9.5 F-DI/F-DO configuration

#### Screen of the F-DI fail-safe inputs

This setting option is only available when controlling Extended functions via the onboard terminals.




Image 6-17 Inputs screen

- **NC/NO contact (p10040)**

Terminal property F-DI 0-9 (p10040.0 = F-DI 0, ... p10040.9 = F-DI 9). Only the property of the second (lower) digital input is set. Always connect an NC contact to digital input 1 (upper). The 2nd digital input can be configured as a NO contact.

- **Activate test mode (p10041)**

With a check mark on an F-DI, you can set whether the pair of digital inputs will be included in the test during forced dormant error detection (test stop) (for more information, see Chapter "Forced dormant error detection (test stop) (Page 160)").

- **LED symbol in the F-DI screen**

The LED symbol after the AND element indicates the logical state (inactive: gray, active: green, discrepancy error: red).

### Screen of the F-DO fail-safe outputs

This setting option is only available when controlling Extended functions via the onboard terminals.




Image 6-18 Outputs screen

- **Signal source for F-DO (p10042 - p10045)**

An AND element with six inputs is interconnected with each output terminal pair of an F-DO; the signal sources for the AND inputs can be selected:

- Status signals of the drive of drive group 1 to 4

For further information on status signals, see Section "Overview of the F-DOs (Page 193)".

- If a signal source is not connected to an input, then the input is set to HIGH (default).

Exception:

If no signal sources are connected to all inputs, then the output signal = 0.

- **Selection of the test sensor feedback (p10046 [0..3]) and selection of test mode for forced dormant error detection (test stop; p10047 [0..3])**

The test of the feedback line for the dynamization can be activated at each F-DO and the test mode can be selected for the test stop (for additional information, see Section "Forced dormant error detection (test stop) (Page 160)").

- **LED symbol in the F-DO screen**

- The LED symbol after the AND element indicates the logical state (inactive: gray, active: green).
- The LED symbol of the digital inputs DI20 to DI23 indicates the status of the digital input (inactive: gray, active: green).

- **Wait time DI (p10001)**

Here you can set the wait time for testing the digital output. Within this time, forced dormant error detection (test stop) of the digital output must have been detected via the relevant readback input (p10047).

### 6.9.6 Control interface of the drive group




Image 6-19 Screen, drive group

Functions of this screen:

- Select an F-DI for functions STO, SS1, SS2, SOS, SLS, for the velocity limits (bit-coded) of SLS (p10022 to p10028) as well as SDI (p10030 and p10031) and select SLP (p10032 and p10033).

A separate screen is available for each drive group. An F-DI can be assigned several functions in several drive groups.

- Configuration of the "Safe State" signal (p10039)

A safety output signal "Safe State" can be generated for each drive group from the following status signals:

- STO active (Power\_removed)
- SS1 active
- SS2 active
- SOS active
- SLS active
- SDI positive active
- SDI negative active
- SLP active

The status signals from the same functions for different drives of a drive group are logically AND'ed. The status signals of the individual functions (STO active, SS1 active, etc.) are ORed.

The "Safe State" signals can be assigned to an F-DO.

- Static selection/deselection of functions
  - With "Statically selected", a safety function can be permanently selected.
  - With "Statically inactive", a function can be permanently deselected. This setting is required or recommended for all functions that are not used.



## 6.9.7 Forced dormant error detection (test stop) of the TM54F

### Testing fail-safe inputs and outputs

Fail-safe inputs and outputs must be tested for fail-safety at defined time intervals (forced dormant error detection (test stop)). The TM54F contains a function block that runs this forced dormant error detection (test stop) in the following cases:

- When selected via a BICO source
- Automatically, each time the power supply voltage is switched on (POWER ON)

To monitor the time until the next required test, a timer (p10003) is started after every error-free forced dormant error detection (test stop). The message A35014 "TM54F test stop necessary" is set on expiration of the monitored time and each time the Control Unit is switched on.

The fail-safe digital inputs can be selected for forced dormant error detection (test stop) 3 modes can be selected for testing the output (see following chapter).

When the appropriate safety devices are implemented (e.g. protective doors), it can be assumed that running machinery will not pose any risk to personnel. The user is therefore only informed that forced dormant error detection (test stop) is due by an alarm, which requests the user to perform forced dormant error detection (test stop) at the next possible opportunity.

Examples of when forced dormant error detection (test stop) must be performed:

- When the drives are at a standstill after the system has been switched on
- Before opening the protective door
- At defined intervals (e.g. every 8 hours)
- In the automatic mode, time and event-dependent
- Automatically, each time the power supply voltage is switched on (POWER ON)

### Execution

When parameterizing, proceed as follows:

1. Derive the suitable mode from the circuit used in your application (see figures in the following chapters).
2. Set the mode which is to be used via parameter p10047.
3. Use parameter p10046 to define which digital outputs (F-DO 0 to F-DO 3) are to be tested. Note the following:

Digital outputs that are not tested are shut down during forced dormant error detection (test stop).

4. Use parameter p10041 to define which fail-safe digital inputs are to be checked during the test.

Inputs which do not have L1+ and L2+ power supplies may not be selected for the test.

It is only possible to test the sensors connected to the F-DIs, if these are supplied from L1+ or L2+. If F-DOs of preprocessing devices are connected, forced dormant error detection (test stop) cannot be used for this input.

5. Use parameter p10001 to set the time within which the digital output signals to the corresponding digital inputs DI 20 ... DI 23 or DIAG inputs must be recognized. Select this time depending on the maximum response time of the external F-DO circuit.
6. With parameter p10003, set the interval within which forced dormant error detection (test stop) is to be performed. After this interval has elapsed, the user is informed by the message A35014 that forced dormant error detection (test stop) must be performed for the TM54F.
7. Set the signal source which triggers the start using parameter p10007. This can be, for example, a control signal or switch via a BICO switchable signal.

Alternatively, forced dormant error detection (test stop) can be performed automatically every time the power supply is switched on (POWER ON) (p9507.6 = 1).

During execution, message A35012 (TM54F: Test stop active) is displayed. The values of the F-DIs are frozen for the duration of forced dormant error detection (test stop). The messages A35014 and A35012 only disappear again after the execution. If an error is found during the test, fault F35013 is output. Using the test sequence specified for each mode, you can see which error has occurred from the fault value of the test step.



#### CAUTION

##### **Feedback F-DO must only be used for forced dormant error detection (test stop)**

With the sequence, unwanted responses of the drive can be caused if the F-DO is not only used for feedback with forced dormant error detection (test stop) but also for other purposes.

- Note that the F-DO for feedback with forced dormant error detection (test stop) must not be used other purposes.

F-DOs that are not registered for evaluation by means of p10046 are set to "0" for the duration of the test ("fail-safe values").

### Forced dormant error detection (test stop): Duration

The maximum time period for the test is:  $T_{\text{Test stop}} = T_{\text{FDIs}} + T_{\text{FDOs}}$

- Test of the FDIs:  $T_{\text{FDIs}} = 3 \times r10015 + 3 \times X \text{ ms}$   
(X = 20 ms or r10015 or p10017 - the longest time of the 3 values determines the waiting time X)
- Test of the FDOs:  $T_{\text{FDOs}} = 8 \times r10015 + 6 \times Y \text{ ms}$   
(Y = p10001 or r10015 or p10017 - the longest time of the 3 values determines the wait time Y)

The safety functions of the TM54F are executed in the sampling time displayed in r10015. This sampling time corresponds to the lowest value of the communication sampling time entered in p10000[0..5].

6.9.7.1 Test mode 1: Evaluation of internal diagnostic signal (passive load)




Image 6-20 F-DO circuit "Test mode 1: Evaluation of internal diagnostic signal (passive load)"

L1+	L2+	Comment
OFF	ON	F-DIs 0 ... 4 Check for 0 V
OFF	OFF	F-DIs 5 ... 9 Check for 0 V

DO+	DO-	Expected response, DIAG signal
OFF	OFF	LOW
ON	ON	LOW
OFF	ON	LOW
ON	OFF	<b>HIGH</b>
OFF	OFF	LOW

Test sequence for test mode 1

6.9.7.2 Test mode 2: Read back F-DO in DI (relay circuit)




Image 6-21 F-DO circuit "Test mode 2: Read back F-DO in DI (relay circuit)"

L1+	L2+	Comment
OFF	ON	F-DIs 0 ... 4 Check for 0 V
ON	ON	F-DIs 5 ... 9 Check for 0 V

DO+	DO-	Expected response, DI signal
OFF	OFF	HIGH
ON	ON	LOW
OFF	ON	LOW
ON	OFF	LOW
OFF	OFF	HIGH

Test sequence for test mode 2

6.9.7.3 Test mode 3: Read back F-DO into the DI (actuator with feedback signal)




Image 6-22 F-DO circuit "Test mode 3: Read back F-DO into the DI (actuator with feedback signal)"

L1+	L2+	Comment
OFF	ON	F-DIs 0 ... 4 Check for 0 V
ON	ON	F-DIs 5 ... 9 Check for 0 V

DO+	DO-	Expected response, DI signal
OFF	OFF	HIGH
ON	ON	<b>LOW</b>
OFF	ON	HIGH
ON	OFF	HIGH
OFF	OFF	HIGH

Test sequence for test mode 3

#### 6.9.7.4 Parameter forced dormant error detection (test stop)

##### Function diagrams (see SINAMICS S120/S150 List Manual)

- 2892 SI TM54F - configuration, F-DI/F-DO Test

##### Overview of important parameters (see SINAMICS S120/S150 List Manual)

- r10015 SI TM54F sampling time
- p10001 SI TM54F wait time for test stop on DO 0 ... DO 3
- p10003 SI TM54F forced dormant error detection timer
- p10007 BI: SI TM54F forced dormant error detection F-DI/F-DO signal source
- p10017 SI TM54F digital inputs debounce time
- p10046 SI TM54F F-DO feedback signal input activation
- p10047[0...3] SI TM54F F-DO test stop mode

## 6.10 PROFIsafe communication

### Requirements for PROFIsafe communication

The following minimum software and hardware requirements apply for the configuration and operation of safety-oriented communication (F communication):

Software:	
	<ul style="list-style-type: none"> <li>• SIMATIC Manager STEP 7 V5.5 SP1 or higher</li> <li>• S7 F Configuration Pack V5.5 SP5<sup>1)</sup> or higher</li> <li>• S7 Distributed Safety Programming V5.4 SP5<sup>1)</sup> or higher</li> <li>• STARTER V4.3 or SIMOTION SCOUT<sup>2)</sup> V4.2</li> <li>• Drive ES Basic V5.4 SP4<sup>1)</sup> or higher<sup>3)</sup></li> <li>• Correct installation of the software</li> </ul>
Hardware:	
	<ul style="list-style-type: none"> <li>• A control with safety functions (in our example, SIMATIC F-CPU 317F-2)</li> <li>• SINAMICS S120 (in our example, a CU320-2)</li> <li>• Correct installation of the devices</li> </ul>

1) When using a SIMATIC F-CPU

2) If SIMOTION SCOUT is used however, SP6 cannot be used

3) As an alternative to Drive ES Basic, you can commission the communication using the GSD file.

#### Note

##### Required software or hardware components

If a single software or hardware component is either older than those specified in this document or is missing, PROFIsafe can no longer be configured via PROFIBUS or PROFINET.

### 6.10.1 PROFIsafe via PROFIBUS

The next sections deal with a sample configuration of PROFIsafe communication between a SINAMICS S120 drive unit and higher-level SIMATIC F-CPU operating as PROFIBUS master. Here a special safety connection ("safety slot") between the master and slave is set up automatically.

Using STARTER (alternatively: HW Config, one of the PROFIsafe telegrams 30, 31, 901 or 902 (submodule ID = 30, 31, 901 or 902) can be configured for the drive objects (Drive Object, DO).

#### 6.10.1.1 Configuring PROFIsafe via PROFIBUS

##### Topology (network view of the project)

Components participating in F communication via PROFIBUS are basically wired as follows:




Image 6-23 Example of a PROFIsafe topology

##### Configuring PROFIsafe communication, based on an example with SIMATIC F-CPU)

The next sections describe a configuration of PROFIsafe communication between a SIMATIC F-CPU and a drive unit. It is helpful to regularly save intermediate states.



### Creating a safety master

1. Create an F-CPU, e.g. CPU 317F-2, and a drive, e.g. SINAMICS S120 with CU320-2, in accordance with the hardware installed in HW Config.

To do this, start SIMATIC Manager and create a new project.




Image 6-24 Creating a new project

2. Create a SIMATIC S300 Station under "Insert".




Image 6-25 Creating a new station

3. Double-click "SIMATIC S300(1)" and then "Hardware" to open the "HW Config" tool.



Image 6-26 Calling HW Config

- 4. First create a mounting rail ((0)UR) under HW Config in the left-hand window:  
From the standard catalog under SIMATIC 300/RACK-300, drag the mounting rail to the upper left-hand field (the cursor has a "+" character).




Image 6-27 Creating a mounting rail

5. Select a safety-capable CPU under SIMATIC 300/CPU 300:  
In this case, for example, drag CPU 317F-2, V2.6 and drop into the RACK on slot 2 (highlighted).




Image 6-28 Creating an F host (master)

6. In the rack: Double-click on line X2 to open the "Properties - PROFIBUS Interface DP" window. Open the "Parameters" tab and set the address.




Image 6-29 Setting the PROFIBUS interface

7. PROFIBUS interface

Then click on "Properties..." and set the transmission rate (e.g. 12 Mbit/s), profile (DP).




Image 6-30 Setting the PROFIBUS profile

8. Click "OK" to confirm the settings.

This sets up the master.

9. Change into the "Properties" window of the F-CPU in the "Protection" tab:

- Activate access protection for the F-CPU. To do this, define a password.
- Activate the safety program ("CPU contains safety program").

**Creating a safety slave (drive)**

The drive can be selected in 2 ways:

- Selected in the catalog window under "PROFIBUS-DP > SINAMICS > SINAMICS S120 > SINAMICS S120 CU320-2
- or
- By installing a GSD file

To select the unit from the catalog, left click on the "SINAMICS S120 CU320-2" drive and drag the symbol to the PROFIBUS line in the upper left-hand window (the cursor has a + character) and then release the mouse button. In the following properties window, set the PROFIBUS address of the drive and exit the following window with "OK".




Image 6-31 Selecting a drive




Image 6-32 Drive created

## Selecting PROFIsafe details

The following value ranges can be set for the last two parameters of the list:

1. When selecting in HW Config, select either the CU320-2 with PROFIsafe mode V1 or V2. Modes V1.0 and V2.0 are possible for PROFIsafe.

### 2. PROFIsafe destination address F\_Dest\_Add: 1-65534

F\_Dest\_Add determines the PROFIsafe destination address of the drive object.

Any value within the range is allowed, although it must be manually entered again in the Safety configuration of the drive in the SINAMICS drive unit. The F\_Dest\_Add value must be set in both p9610 and p9810. This can be done easily in STARTER (see following figure):

- In the "Configuration" dialog box, click the "PROFIsafe configuration" button and then enter the desired address in the "PROFIsafe configuration" dialog box. The PROFIsafe destination address of the F parameters must be entered here in the hexadecimal format (C8H in the example).




Image 6-33 STARTER screen section from Safety Integrated: Setting the PROFIsafe address (example)

### 3. PROFIsafe monitoring time F\_WD\_Time: 10-65535

A valid current safety telegram must be received from the F-CPU within the monitoring time ("watchdog"). Otherwise, the drive goes to the safe state.

Set the monitoring time long enough to ensure not only that the communication functions tolerate telegram delays, but also that the fault response is triggered quickly enough if a fault occurs (e.g. interruption of the communication connection).

For additional information on F parameters, refer to the online help of the ("Help subjects" button).

### Configuring the telegram

Proceed as follows to configure the PROFIsafe telegram;

1. In STARTER change to the associated project.
2. In the project navigator, double-click on "<Control Unit> > Communication > Telegram configuration".




Image 6-34 Telegram configuration 1

3. First select standard telegram 1, and then change back to "Free telegram configuration with BICO".

The reason for this is the automatic pre-assignment of the PROFIdrive control words. However, adaptations are still required, which are only possible for a free telegram configuration.




Image 6-35 Telegram configuration 2



- Click on "Adapt telegram configuration > Add PROFIsafe", to create a PROFIsafe slot.




Image 6-36 Telegram configuration 3

- Select the required PROFIsafe telegram.




Image 6-37 Telegram configuration 4

Selecting telegram 902 is only practical when the safety program in the F-host supports 32-bit value processing.

- Transfer the completed telegram configuration to "HW Config".

## Acceptance test

Once configuring and commissioning have been successfully completed, you need to carry out an acceptance test of the drive safety functions (see Section "Acceptance tests (Page 420)").

---

### Note

#### Changing the collective signature of the safety program

If F parameters of the SINAMICS drive are changed in HW Config, the global signature of the safety program in the SIMATIC F-CPU changes. With this, you can see by the collective signature whether safety-related settings have changed in the F-CPU (F parameters of the SINAMICS slave). However, this collective signature does not contain changes to safety-related drive parameters set via SCOUT or STARTER.

---

## 6.10.2 PROFIsafe via PROFINET

The next sections deal with a sample configuration of PROFIsafe communication between a SINAMICS S120 drive unit and higher-level SIMATIC F-CPU operating as PROFINET master.

Using STARTER (alternatively: HW Config, one of the PROFIsafe telegrams 30, 31, 901 or 902 (submodule ID = 30, 31, 901 or 902) can be configured for the drive objects (Drive Object, DO).

### 6.10.2.1 Assigning the IP address and the name

To enable the master control to communicate with drives, e.g. a CU317F-2 PN/DP with a SINAMICS S120, via the PROFINET, unique names (self-explanatory names are convenient) and IP addresses must be assigned to the drives and set with the STARTER or with the Primary Setup Tool (PST) ("Initialization").

Instructions on "Assigning the IP address and the name" to the drive unit are to be found in the "SINAMICS S120 Commissioning Manual" in chapter "Activating online operation - STARTER via PROFINET IO."

### 6.10.2.2 Configuring PROFIsafe via PROFINET

#### Configuring PROFIsafe communication using SINAMICS S120 as an example

Configuring PROFIsafe via PROFINET is almost identical to configuring "PROFIsafe via PROFIBUS".

1. In HW Config, create a PROFINET-capable F-CPU, e.g. CPU 317F-2 PN/DP, corresponding to the hardware that has been installed. Create a PROFINET subnet and configure the F-CPU as an IO controller. Information about configuring an IO controller of the F-CPU 317F-2 can be found here:  
References: SIMATIC PROFINET IO Getting Started: Collection
2. In the standard module catalog under PROFINET IO, choose the module that you want to connect to the PROFINET IO subnet as an IO device, e.g. a CU320-2.
3. Drag the module onto the line of the PROFINET IO subnet. The IO device is inserted. The "Properties > Ethernet Interface SINAMICS-S120" window opens. An IP address is already recommended there and the subnet selected. Confirm with "OK" to accept the setting.
4. Save and compile the settings in HW Config, and then load them to the target device.  
This sets up a PROFINET connection between the F-CPU and the SINAMICS S120 drive.




Image 6-38 Configuring a PROFINET connection in HW Config

### Configuring the telegram

Proceed as follows to configure the PROFIsafe telegram;

1. Change to the associated STARTER project.
2. In the project navigator, double-click on "<Control Unit> > Communication > Telegram configuration".




Image 6-39 Telegram configuration 1

3. Select "Free telegram configuration with BICO".




Image 6-40 Telegram configuration 2

- Click on "Adapt telegram configuration > Add PROFIsafe", to create a PROFIsafe slot.




Image 6-41 Telegram configuration 3

- Select the required PROFIsafe telegram.




Image 6-42 Telegram configuration 4

Selecting telegram 902 is only practical when the safety program in the F-host supports 32-bit value processing.

- Transfer the completed telegram configuration to "HW Config".

### Selecting PROFIsafe details

In the overview for the SINAMICS drive, a PROFIsafe slot that needs to be configured is displayed under "Drive object".

Slot	Module	Order number	I address	Q address	D...	C...
0	S120xCU320x2xDP	6SL3 040-1MA00-0AA0 (CB...			818...	
X14	CBE20.PN.I/O				8182	
X14	Port 1				8183	
X14	Port 2				8186	
X14	Port 3				8185	
X14	Port 4				8184	
1	<b>Drive object</b>				<b>8181</b>	
1.1	Program flowchart				8181	
1.2	PROFIsafe		0..5	0..5		
1.3	Standard message fram		256...259	256...259		
1.4						
2						
3						

Image 6-43 Defining PROFIsafe for a drive

1. Under the drive module, select the "PROFIsafe" line and use the right-hand mouse key to call up the properties of the PROFIsafe slot.
2. To define the address range of the PROFIsafe telegram, click on the "Addresses" tab. The start address for inputs and outputs is identical. To confirm your entries, choose "OK".




Image 6-44 Setting PROFINET addresses

- On the "PROFIsafe" tab, you define the values of the parameters that are important to safety communication (so-called "F parameters"). If the "PROFIsafe..." tab is inactive, then you can activate this button for control using the "Activate..." button.




Image 6-45 Setting F parameters

**Setting F parameters:**

The following range of values is valid for the two last parameters of the list:

**PROFIsafe destination address F\_Dest\_Add: 1 to 65534**

F\_Dest\_Add determines the PROFIsafe destination address of the drive object. Any value within the range is allowed, although it must be manually entered again in the Safety configuration of the drive in the SINAMICS drive unit. The F\_Dest\_Add value must be set in both p9610 and p9810. That is easy to do in the PROFIsafe-STARTER screen (see "Image 6-46 Selecting a PROFIsafe telegram (Page 332)").

**PROFIsafe monitoring time F\_WD\_Time: 10 to 65535**

A valid current safety telegram must be received from the F-CPU within the monitoring time. The drive will otherwise switch into the safe state. The monitoring time should be of sufficient length to ensure not only that the communication functions tolerate telegram delays, but also that the fault response is triggered quickly enough if a fault occurs (e.g. interruption of the communication connection).



---

**Note****Check for uniqueness**

When you close the "PROFIsafe properties" dialog box, the fail-safe addresses (F\_Dest\_Add and F\_Source\_Add) are checked to ensure that they are unique. This function is only available, however, when the PROFINET link between SINAMICS S120 and SIMATIC F-CPU has already been established.

---

For additional information about creating a safety program and accessing PROFIsafe user data (e.g STW and ZSW) within the safety program, refer to the "SIMATIC, S7 Distributed Safety - Configuring and Programming" Programming and Operating Manual.

**Safety configuration (online) in the SINAMICS drive**

The process of configuring the SINAMICS drive via PROFINET by means of Safety Integrated screen forms is identical to that for configuration via PROFIBUS. On this topic, refer to Chapter "PROFIsafe configuration with STARTER (Page 330)".

**Acceptance test**

Once configuring and commissioning have been successfully completed, you need to carry out an acceptance test of the drive safety functions (see Section "Acceptance test (Page 341)").

---

**Note****Changing the collective signature of the safety program**

If F parameters of the SINAMICS drive are changed in HW Config, the global signature of the safety program in the SIMATIC F-CPU changes. With this, you can see by the collective signature whether safety-related settings have changed in the F-CPU (F parameters of the SINAMICS slave). However, this collective signature does not contain changes to safety-related drive parameters set via SCOUT or STARTER.

---

### 6.10.3 PROFIsafe configuration with STARTER

#### Activating PROFIsafe via the expert list

In order to activate the Safety Integrated functions via PROFIsafe you must set p9601.3 = 1 in the expert list. Bit 0 must be set to either "1" or "0", depending on whether the control via terminals is to be enabled in parallel via PROFIsafe or not. The value of p9601.2 is used to select as to whether the Safety Integrated Basic Functions (= 0) or the Extended Functions (= 1) are used.

---

#### Note

In addition to configuring the PROFIsafe control, generally additional parameter changes are required; these depend on which safety functions are used. You will find notes on this in Chapter "Description of Safety Integrated functions (Page 61)".

---

#### Saving and copying the Safety Integrated function parameters

- After setting the specific parameters for Safety Integrated functions (e.g. the PROFIsafe address) using the "Copy parameters" button, these must be copied from the Control Unit into the Motor/Power Module and activated using the "Activate settings" button.
- Alternatively, you can perform this procedure using the expert list:
  - p9700 SI Motion copy function
  - p9701 SI Motion confirm data change

#### Acceptance test

An acceptance test needs to be carried out once configuration and commissioning are complete (see Section "Acceptance tests (Page 420)").

---

#### Note

##### Changing the collective signature of the safety program

If F parameters of the SINAMICS drive are changed in HW Config, the global signature of the safety program in the SIMATIC F-CPU changes. This means that using the global signature it is possible to identify whether safety-relevant settings have changed in the F-CPU (F parameters of the SINAMICS slave). However, this global signature does not include the safety-relevant drive parameters so that their change cannot be checked in this way.

---

### 6.10.3.1 Selecting a PROFIsafe telegram

Proceed as follows to define the PROFIsafe telegram:

1. In parameter p60022 select the required telegram.
2. In parameter p9611, select the same telegram number.

---

**Note****Compatibility mode**

If you set p9611 = 998 for p60022 = 0 (for instance, if you have upgraded the safety project to firmware V4.5), then the PROFIsafe telegram 30 is also set as for p60022 = 30 and p9611 = 30.

---

The STARTER commissioning tool supports you when setting these parameters:

1. In STARTER, select "<Drive device> > Communication > Telegram configuration".
2. Click the "Adapt telegram configuration" button and select the telegram there.
3. Then select "<Drive device> > <Drive> > Functions > Safety Integrated".
4. Click the "Configuration" button.

5. In the "Configuration" dialog box, click the "PROFIsafe configuration" button.

In the "PROFIsafe configuration" dialog, the telegrams currently set in parameters p60022 and p9611 are displayed.




Image 6-46 Selecting a PROFIsafe telegram

6. To transfer the telegram from p60022 to p9611, click the "Accept PROFIsafe telegram" button.

## 6.11 Commissioning a linear/rotary axis

The next section outlines the safety commissioning procedure for a linear axis/rotary axis when a TM54F is used.

1. Connect a PG to the drive and link it to the target device via STARTER.
2. In the STARTER project tree, select the required drive object and under "Functions > Safety Integrated" open the start screen to configure Safety Integrated.
3. Click the "Change settings" button. The window for selecting Safety Integrated opens.
4. It is only possible to change Safety parameters after entering the valid Safety password (parameter p9761 for the drives or p10061 for the TM54F).




Image 6-47 Safety Integrated commissioning of a linear/rotary axis

5. Select the "Extended functions via TM54F" and "[0] Safety with the encoder and acc\_monitoring (SAM)/delay time" or "[2] Safety with encoder with ramp down (SBR)" from the two lists "Selection safety function."
6. Enable the safety functions (p9501) via the list of "Safety functions". Then click the "Configuration" button.

The safety configuration screen of the drive opens.




Image 6-48 Safety configuration: Drive

7. For the drive, set the same "Monitoring cycle" (safety cycle) as for the TM54F (see Chapter "TM54F configuration (Page 297)").
8. Set the required "Drive type" (linear axis / rotary axis) (p9502). Continue at item 15 if you have not changed the selected drive type.
9. Close the screen form. Click "Copy parameters" and then click "Activate settings" (exit commissioning mode, p0010=0).
10. Execute the "Copy RAM to ROM" function for the entire project by clicking the "Entire project" button.
11. Perform a POWER ON. The new parameterization is now active.
12. Reconnect STARTER to the target device. The messages that are displayed indicate that safety commissioning was not completed (different actual and target checksum). These messages have no immediate effect, but must be corrected to complete the commissioning.
13. Load the project to the PG. The display of parameter units (rotary/linear axis) will be updated accordingly in STARTER.
14. Click on "Change settings". Adapt the safety parameterization and then click "Activate settings" to activate the safety parameterization.  
  
The messages listed under Point 12 are no longer displayed or they can be acknowledged.
15. Complete the configuration by adapting the parameterization of the required monitoring limits, timers, encoder settings, etc.

## 6.12 Modular machine concept Safety Integrated

The modular machine concept for Safety Integrated Basic Functions and Extended Functions provides support for commissioning modular machines. A complete machine, including all its available options, is created in a topology. Only those components that are actually implemented in the finished machine are later activated. Likewise, certain components can also be deactivated to begin with and reactivated if they are required at a later stage.

With the modular machine concept, a distinction is made between the following applications:

- Once the components with safety functions have been activated for the first time after series commissioning, the hardware replacement needs to be confirmed (see "Information about replacing components" in this manual).
- Once all the drives (including Safety Integrated Extended Functions) have been commissioned, they are to be deactivated (p0105) without changing the hardware. They can only be activated again with a subsequent warm start or by means of POWER ON.

### NOTICE

#### Deactivate with p0895 not permitted

Deactivation of drive objects or power unit components using parameter p0895 is not permitted when the safety functions are enabled.

- The drive objects of the TM54F can be deactivated using parameter p0105. The TM54F itself can only be deactivated when all the drives entered in p10010 "SI drive object assignment" were deactivated separately by means of p0105 beforehand.
- When spare parts are required and the drive is deactivated (p0105) during the delivery period for the required hardware component. When it is activated again on the following restart or POWER ON and hardware replacement confirmation (see Chapter "Information pertaining to component replacements (Page 361)").
- Component exchange on a Control Unit (e.g. to localize faults). For Safety Integrated, this is the same as a hardware replacement. This must be connected after a restart or POWER ON with a hardware replacement confirmation (see Chapter "Information pertaining to component replacements (Page 361)").
- If a drive with enabled safety functions is copied offline, then fault F01656 can occur when downloading the project. This behavior occurs whenever component numbers change during copying (e.g. different drive object number or hardware). In this case, please observe the procedure when fault F01656 occurs (see SINAMICS S120/S150 List Manual).

## 6.13 Information pertaining to series commissioning

A commissioned project that has been uploaded to STARTER can be transferred to another drive unit keeping the existing safety parameterization.

1. Load the STARTER project into the drive unit.
2. Make sure that nobody is in the danger zone, and only then switch on the machine.
3. Note the following alarms depending on the control type:

Control type	Alarm
Extended Functions via TM54F or onboard terminals of the CU310-2	F01650 (fault value 2005) indicates the replacement of a Control Unit.
	A35015 indicates the replacement of a Motor Module.
	A01695 indicates the replacement of a Sensor Module. As a consequence, a defect is also signaled in a monitoring channel (C30711 with fault value 1031 and stop response STOP F).
Extended Functions via PROFIsafe	F01650 (fault value 2005) indicates the replacement of a Control Unit.
	A01695 indicates the replacement of a Sensor Module. As a consequence, a defect is also signaled in a monitoring channel (C30711 with fault value 1031 and stop response STOP F).

4. If you are using STARTER/SCOUT, then you must perform the following steps:
  - Click on **Acknowledge hardware replacement** in the start screen of the safety functions.
  - Faults F01650/F30650 are output (acceptance test required; see Section "Test scope for specific measures (Page 407)").
  - Continue with step 6.
5. If you are working with SINAMICS with a BOP or SIMOTION with HMI, then you must perform the following steps:
  - Activate "Safety Integrated commissioning" (p0010 = 95)
  - Start the copy function for Node Identifier (p9700 = 1D hex)
  - Confirm the hardware CRC on the drive object (p9701 = EC hex)
  - Exit the "Safety Integrated commissioning" mode (p0010 = 0)
  - Continue with step 6.
6. Perform steps 4 or 5 when replacing a Sensor Module at the drive object servo or vector, and when replacing a Motor Module at drive object TM54F\_MA (if installed).
7. Back up all parameters on the memory card (p0977 = 1).
8. Carry out a POWER ON (power off/on) for all components.



### WARNING

#### Danger to life due to unwanted motion when changing components without function test

After a component replacement, accidents resulting in serious injuries or death can be caused by unwanted motion if no function test has been performed.

- You can find more detailed information in the sections "Test scope for specific measures (Page 407)" and "acceptance testing (Page 341)".



**Safety message for standard commissioning with Safety Integrated Extended Functions**

If third-party motors with absolute encoders are being used, a situation may arise where a Safety message prevents commissioning.

One reason for this may be that a different serial number of the absolute encoder is saved on the memory card than that in the Control Unit which is to be commissioned. The Safety message can only be acknowledged once the serial number for the absolute encoder has been corrected manually (e.g. with STARTER). The description can be found in Section "Information pertaining to component replacements (Page 361)". You can then carry on with the commissioning.

## 6.14 Application examples

You can find SINAMICS application examples on the Internet page "SINAMICS application examples".

We can offer you efficient system strategies, especially as a result of the optimum interaction between SIMATIC control technology and SINAMICS drive systems.

The application examples provide you with:

- Reusable modules for scaling setpoints and actual values
- Explanation of the necessary configuring steps together with screenshots
- Security through already tested programs and modules for accessing parameters
- Significantly lower commissioning times
- Detailed documentation with parts lists of the hardware and software components being used

Further, you can also find technological application examples, such as winders, traversing arms and basic synchronous operation. These application examples also explain how to use free function blocks (FBLOCKS), logic processing integrated in the drive with Drive Control Chart (DCC) and Safety Integrated.

### Finding and calling application examples

1. Call the following site in your Internet browser:

SINAMICS application examples (<https://www.automation.siemens.com/mc-app/sinamics-application-examples/Home/Index?language=en>)

2. Select the required filter in the search mask.

Example:

The result list is updated every time a filter setting is specified.

Application	DriveType	DriveFunction	Control	EngineeringEnvironment	Communication	Speciality
> SINAMICS S: Safety-control of a S120 using S7-300/400 (STEP 7 V5) with PROFIBUS and Safety Integrated (via PROFIsafe)	S120	Safety-control	S7-300/400	STEP 7 V5	PROFIBUS	Safety Integrated
> SINAMICS S: Safety-control of a S120 using S7-300/400 (STEP 7 V5) with PROFIBUS and Safety Integrated (via TM54F)	S120	Safety-control	S7-300/400	STEP 7 V5	PROFIBUS	Safety Integrated
> SINAMICS S: Safety-control of a S120 using S7-300/400 (STEP 7 V5) with PROFINET (Shared Device) and Safety Integrated (via PROFIsafe)	S120	Safety-control	S7-300/400	STEP 7 V5	PROFIBUS PROFINET	Safety Integrated

Individual filters can be reset by clicking the X to the right of the filter. You can reset all filters simultaneously by clicking the "Reset filters" button.

3. The first details of the required application description can then be displayed in a tooltip. To do this, click the appropriate entry in the result list.

The required tooltip is then displayed in the Siemens Industry Online Support.

▶ Industry Online Support International
▶ Language
▶ Contact
▶ Help
▶ Support Request

> Home
> Product Support

Entry type: Application example, Entry ID: 29056318, Entry date: 10/25/2011
☆☆☆☆☆ (0)  
> Rate

### SINAMICS S: Safety-control of a S120 using S7-300/400 (STEP 7 V5) with PROFIBUS and Safety Integrated (via PROFIsafe)

Entry
Associated product(s)

**Task**

Extended safety functions which have been integrated in the SINAMICS S120 drives shall be activated via PROFIsafe with PROFIBUS. Both drives use different safety functions. The F-CPU is responsible for the safetyrelated logical processing of the input signal. The F-CPU acts as F master and as PROFIBUS master.

This functional example is based on the SINAMICS S120 training case (6ZB2480-0BA00) and the SAFETY training case.

This application gives you an example of how you can configure your communications.

**Downloads**

Content of downloads	Version	Download

Generally, you can download a detailed application description as PDF via the tooltip.



# Acceptance test

---

**Note****Responsibilities**

The machine manufacturer is responsible for carrying out and documenting the acceptance test: In Chapter "Acceptance tests (recommendations) (Page 403)" you will find examples how the acceptance test is carried out and documented for the individual safety functions.

---

## Why is acceptance required?

The EC Machinery Directive and DIN EN ISO 13849-1 stipulate:

- You must check safety-related functions and machine parts after commissioning.  
→ Acceptance test.

For SINAMICS Safety Integrated Functions (SI functions) this specifically means: The acceptance test is used to check the functionality of the Safety Integrated monitoring and stop functions used in the drive. The test objective is to verify proper implementation of the defined safety functions and of test mechanisms (measures for forced dormant error detection (test stop)) and to examine the response of specific monitoring functions to the explicit input of values outside tolerance limits. The test must cover all drive-specific Safety Integrated motion monitoring functions and global Safety Integrated functionality of Terminal Module TM54F (if used).

---

**Note****Purpose of the acceptance test**

The measured values (e.g. distance, time) and the system behavior identified (e.g. initiation of a specific stop) can be used for checking the plausibility of the configured safety functions. The objective of an acceptance test is to identify potential configuration errors and/or to document the correct function of the configuration. The measured values are typical values (not worst case values). They represent the behavior of the machine at the time of measurement. These measurements cannot be used to derive real values (e.g. maximum values for over-travel distances).

---

- You must create an "acceptance report" showing the test results.  
→ Documentation.

## Requirements

The acceptance test requirements (configuration check) for electrical drive safety functions emanate from DIN EN 61800-5-2, Section 7.1 Point f). The acceptance test "configuration check" is cited in this standard.

- Description of the application including a picture
- Description of the safety-relevant components (including software versions) that are used in the application
- List of the PDS(SR) [Power Drive System(Safety Related)] safety functions used
- Results of all tests of these safety functions, using the specified testing procedure
- List of all safety-relevant parameters and their values in the PDS(SR)
- Checksum, test date and confirmation by testing personnel

## Acceptance test

The acceptance test comprises 2 parts:

- Checking whether the safety functions in the converter are correctly set:
  - Does the speed control handle the configured application cases in the machine?
  - Do the set interface, times and monitoring functions match the configuration of the machine?
- Checking whether the safety-relevant functions in the plant or machine function correctly.

This part of the acceptance test goes beyond the converter acceptance test:

- Are all safety equipment such as protective door monitoring devices, light barriers or emergency-off switches connected and ready for operation?
- Does the higher-level control correctly respond to the safety-relevant feedback signals of the converter?
- Do the converter settings match the configured safety-relevant function in the machine?

## Documentation

The documentation consists of the following parts:

- Description of the safety-relevant components and functions of the machine or plant.
- Report of the acceptance test results.
- Report of the settings of the safety functions.
- Countersigned documentation.

## Authorized persons

Personnel from the **machine manufacturer**, who, on account of their technical qualifications and knowledge of the safety functions, are in a position to perform the acceptance test in the correct manner.



### **WARNING**

#### **Danger to life due to unwanted motion due to incorrect parameter changes**

Incorrect parameter changes for SI functions can result in unwanted motion leading to death or severe injury.

- After making a change to a parameter for the safety integrated functions, always perform an acceptance test for the function in question.
- Document the values calculated in an acceptance report.

## 7.1 General information about the acceptance test

The test of each SI function must be carried out by an authorized person and logged in the acceptance report. The report must be signed by the person who carried out the acceptance test. Access rights to SI parameters must be protected by a password. This procedure must be documented in the acceptance report - the password itself must not appear there. Authorized in this sense refers to a person who has the necessary technical training and knowledge of the safety functions and is authorized by the machine manufacturer to carry out the acceptance test.

---

### Note

#### Further information

- See the information in sections "Commissioning (Page 219)" and "Description of Safety Integrated functions (Page 61)".
- The acceptance test report in Chapter "Acceptance tests (recommendations) (Page 403)" is an example and a recommendation.
- An acceptance report template in electronic format is available at your local Siemens sales office.

---

### Note

#### PFH values

The PFH values of the individual SINAMICS S120 safety components can be found at:

<http://support.automation.siemens.com/WWW/view/de/76254308>

---

## Necessity of an acceptance test

A complete acceptance test (as described in this section) is required after initial commissioning of Safety Integrated functionality on a machine. The acceptance tests must be carried out for each individual drive. Safety-related function expansions, transfer of the commissioning settings to other series machines, hardware changes, software upgrades or similar, permit the acceptance test to be performed with a reduced scope if necessary. A summary of conditions which determine the necessary test scope or proposals in this context is provided below.

## Requirements for the acceptance test

- The machine is properly wired.
- All safety equipment such as protective door monitoring devices, light barriers or emergency limit switches are connected and ready for operation.
- Commissioning of the open-loop and closed-loop control must be completed, as e.g. the over-travel distance may otherwise change as a result of a changed dynamic response of the drive control. These include, for example:
  - Configuration of the setpoint channel
  - Position control in the higher-level controller
  - Drive control



## Note on the acceptance test mode

The acceptance test mode can be activated for a definable period (p9558) by setting the appropriate parameters (p9570). It tolerates specific limit violations during the acceptance test. For instance, the setpoint speed limits are no longer active in the acceptance test mode. To ensure that this state is not accidentally kept, the acceptance test mode is automatically exited after the time set in p9558.

It is only worth activating acceptance test mode during the acceptance test of the SS2, SOS, SDI, SLS and SLP functions. It has no effect on other functions.

Normally, SOS can be selected directly or via SS2. To be able to trigger violation of the SOS standstill limits with the acceptance test mode active (also in the "SS2 active" state) the setpoint is enabled again by the acceptance test mode after deceleration and transition to SOS to allow the motor to move. When an SOS violation is acknowledged in the active acceptance test mode, the current position is adopted as the new stop position so that an SOS violation is not immediately identified again.



### WARNING

#### **Danger to life due to axis movements during the acceptance test**

If a speed setpoint  $\neq 0$  is present, the active stop function SS2 is set, and the motor is at a standstill (active SOS), the axis starts to move as soon as the acceptance test is activated. If persons are in the danger zone, accidents causing death or severe injury can occur.

- Take suitable measures to ensure that nobody is in the danger zone during the acceptance test.

## 7.2 Safety logbook

The "Safety Logbook" function is used to detect changes to safety parameters that affect the associated CRC sums. CRCs are only generated when p9601 (SI enable, functions integrated in the drive CU/Motor Module) is > 0.

Data changes are detected when the CRCs of the SI parameters change. Each SI parameter change that is to become active requires the reference CRC to be changed so that the drive can be operated without SI fault messages. In addition to functional safety changes, safety changes as a result of hardware being replaced can be detected when the CRC has changed.

The following changes are recorded by the safety logbook:

- Functional changes are recorded in the checksum r9781[0]:
  - Functional CRCs of the motion monitoring functions (p9729[0...1]), axis specific (Extended Functions)
  - Functional cyclic redundancy checks of the basic safety functions integrated in the drive (p9799, SI setpoint checksum SI parameters CU), for each axis.
  - Functional CRCs of the TM54F (p10005[0]), global (Basic and Extended Functions)
  - Enabling of functions integrated in the drive (p9601), axis specific (Basic and Extended Functions)
- Hardware-dependent changes are recorded in the checksum r9781[1]:
  - Hardware-dependent CRC of the motion monitoring functions (p9729[2]), axis specific (Extended Functions)
  - Hardware-dependent CRC of the TM54F (p10005[1]), global (Basic and Extended Functions)

## 8.1 Latest information

Important note for maintaining the operational safety of your system:

### NOTICE

#### **Danger to operational safety due to unwanted motion**

Systems with safety-related characteristics are subject to special operational safety requirements on the part of the operating company. If information on a lack of product safety becomes known in the course of observing a product, this information is declared in various ways. For this reason, we publish a special newsletter containing information on product developments and features that are (or could be) relevant when operating safety-related systems.

- You should subscribe to and carefully read the corresponding newsletter in order to obtain the latest information and to allow you to modify your equipment accordingly.

To subscribe to the newsletter, please proceed as follows:

1. Go into the Internet under:  
Siemens automation ([http://automation.siemens.com /](http://automation.siemens.com/))
2. Select the desired language for the Web page.
3. Click on the menu item "Presales info".
4. Click on the menu item "Newsletter".

---

### Note

#### **Newsletter**


You have to register and log in if you want to subscribe to any newsletters. You will be led automatically through the registration process.

---

5. Click on "Login / registration".
6. Login with your access data. If you do not yet have a login and password, select "Yes, I would like to register now".  
You can subscribe to the individual newsletters in the following window.
7. Under the "All newsletters" heading on this page, you can see which newsletter is currently available.

8. Open the topic "Products and solutions".

You will now be shown which newsletter is available for this particular subject area or topic. You can subscribe to the appropriate newsletter by clicking on the "Subscribe" entry. If you require more detailed information on the newsletters, then please use the supplementary function on the website.



9. At the very least, register for the newsletters for the following product areas:

- Safety Integrated

## 8.2 Certification

The safety functions of the SINAMICS S drive system meet the following requirements:

- Category 3 to DIN EN ISO 13849-1
- Performance level (PL) d according to DIN EN ISO 13849-1
- Safety integrity level 2 (SIL 2) according to IEC 61508 and EN 61800-5-2

In addition, most of the safety functions of the SINAMICS S have been certified by independent institutes. An up-to-date list of certified components is available on request from your local Siemens office.

## 8.3 Probability of failure of the safety functions (PFH value)

The probability of failure of safety functions must be specified in the form of a PFH value (Probability of Failure per Hour) according to IEC 61508, IEC 62061 and DIN EN ISO 13849-1. The PFH value of a safety function depends on the safety concept of the drive unit and its hardware configuration, as well as on the PFH values of other components used for this safety function.

Corresponding PFH values are provided for the SINAMICS S120 drive system, depending on the hardware configuration (number of drives, control type, number of encoders used). The various integrated safety functions are not differentiated.

- The PFH values of the individual SINAMICS S120 safety components can be found at:  
<http://support.automation.siemens.com/WW/view/de/76254308>
- The PFH values of all safety components from Siemens are available in the "Safety Evaluation Tool"; see:  
[www.siemens.de/safety-evaluation-tool](http://www.siemens.de/safety-evaluation-tool)

## 8.4 Response times

The Basic Functions are executed in the monitoring cycle (p9780). PROFIsafe telegrams are evaluated in the PROFIsafe scan cycle, which corresponds to twice the monitoring clock cycle (PROFIsafe scan cycle = 2 × r9780).

---

### Note

#### Actual value of the monitoring cycle (r9780)

You can only see the actual value of the monitoring cycle (r9780) if you are connected ONLINE with the drive. However, you can use the following values to roughly calculate the response times:

---

p0115[0] = 31.25 µs or 62.5 µs or 125 µs	r9780 = 4 ms
p0115[0] = 250 µs	r9780 = 8 ms
p0115[0] = 400 µs or 500 µs	r9780 = 16 ms

### Note for understanding the tables

The drive system is the component that provides the safety functions. The designation "fault-free drive system" means that the component that provides the safety functions does not have a defect itself:

- Worst case for a fault-free drive system

For faults outside the drive system, such as e.g. faulty setpoint input from a control system, limit value violations as a result of the behavior of the motor, closed-loop control, load, etc., the "Worst case for a fault-free drive system" response time is guaranteed.

- Worst case when a fault exists

For a single fault within the drive system, such as a defect in a switch-off signal path of the power unit, a defect in an encoder actual value measurement, a defect in a microprocessor (Control Unit or Motor Module) etc., the "Worst case when a fault exists" response time is guaranteed.

### 8.4.1 Control of Basic Functions via terminals on the Control Unit and Motor Module (CU310-2 and CU320-2)

The following table lists the response times from the control via terminals until the response actually occurs.

Table 8- 1 Response times for control via terminals on the Control Unit and the Motor Module.

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$2 \times r_{9780} + t_{_E}^{1)}$	$3 \times r_{9780} + t_{_E}^{1)}$
SBC	$4 \times r_{9780} + t_{_E}^{1)}$	$8 \times r_{9780} + t_{_E}^{1)}$
SS1/SS1E (time-controlled) Selection until STO is initiated	$2 \times r_{9780} + p_{9652} + t_{_E}^{1)}$	$3 \times r_{9780} + p_{9652} + t_{_E}^{1)}$
SS1/SS1E (time-controlled) Selection until SBC is initiated	$4 \times r_{9780} + p_{9652} + t_{_E}^{1)}$	$8 \times r_{9780} + p_{9652} + t_{_E}^{1)}$
SS1 (time-controlled) Selection until braking is initiated	$3 \times r_{9780} + 2 \text{ ms} + t_{_E}^{1)}$	$4 \times r_{9780} + 2 \text{ ms} + t_{_E}^{1)}$

<sup>1)</sup> The following applies for  $t_{_E}$  (debounce time of the digital input being used):

$p_{9651} = 0$	$t_{_E} = 2 \times p_{0799}$ (default = 4 ms)
$p_{9651} \neq 0$	$t_{_E} = p_{9651} + p_{0799} + 1 \text{ ms}$

The minimum time for  $t_{_E}$  is  $t_{_E\_min} = 2 \text{ ms}$ .



## 8.4.2 Control of Basic Functions via PROFIsafe (CU310-2 and CU320-2)

The following table lists the response times<sup>1)</sup> from receiving the PROFIsafe telegram at the Control Unit up to initiating the particular response.

Table 8- 2 Response times when controlling via PROFIsafe

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$5 \times r9780 + t_K^{(2)}$	$5 \times r9780 + t_K^{(2)}$
SBC	$6 \times r9780 + t_K^{(2)}$	$10 \times r9780 + t_K^{(2)}$
SS1/SS1E (time-controlled) Selection until STO is initiated	$5 \times r9780 + p9652 + t_K^{(2)}$	$5 \times r9780 + p9652 + t_K^{(2)}$
SS1/SS1E (time-controlled) Selection until SBC is initiated	$6 \times r9780 + p9652 + t_K^{(2)}$	$10 \times r9780 + p9652 + t_K^{(2)}$
SS1 (time-controlled) Selection until braking is initiated	$5 \times r9780 + 2 \text{ ms} + t_K^{(2)}$	$5 \times r9780 + 2 \text{ ms} + t_K^{(2)}$

- 1) The specified response times involve internal SINAMICS response times. Program run times in the F-host and the transmission time via PROFIBUS or PROFINET are not taken into account. When calculating the response times between the F-CPU and the converter, you must take into account that faults in the communication can result in a safety function only being selected after the PROFIsafe monitoring time (F\_WD\_Time) has expired. The PROFIsafe monitoring time (F\_WD\_Time) must also be included in the calculation when an error occurs.
- 2)  $t_K$  is the time for internal communication within the SINAMICS module;  $t_K$  can be determined as follows:

For isochronous communication	$t_K = T_o$ (for $T_o$ , see parameter r2064[4])
For non-isochronous communication	$t_K = 4 \text{ ms}$ (for modules on which p2048 or p8848 <sup>3)</sup> do not exist)
	$t_K = \text{value from p2048 or p8848}^{(3)}$ (for modules, on which p2048 or p8848 <sup>3)</sup> exist)

- 3) p2048 is applicable for communication via IF1, p8848 for communication via IF2.

### 8.4.3 Control of Basic Functions via TM54F

The following table lists the response times from the control via TM54F until the response actually occurs.

Table 8- 3 Response times for control via TM54F

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$3 \times r_{9780} + p_{10017} + 2 \text{ ms}$	$3 \times r_{9780} + p_{10017} + 2 \text{ ms}$
SBC	$4 \times r_{9780} + p_{10017} + 2 \text{ ms}$	$8 \times r_{9780} + p_{10017} + 2 \text{ ms}$
SS1/SS1E (time-controlled) Selection until STO is initiated	$3 \times r_{9780} + p_{9652} + p_{10017} + 2 \text{ ms}$	$3 \times r_{9780} + p_{9652} + p_{10017} + 2 \text{ ms}$
SS1/SS1E (time-controlled) Selection until SBC is initiated	$4 \times r_{9780} + p_{9652} + p_{10017} + 2 \text{ ms}$	$8 \times r_{9780} + p_{9652} + p_{10017} + 2 \text{ ms}$
SS1 (time-controlled) Selection until braking is initiated	$3 \times r_{9780} + p_{10017} + 4 \text{ ms}$	$3 \times r_{9780} + p_{10017} + 4 \text{ ms}$

## 8.4.4 Control of Extended Functions with encoder via PROFIsafe (CU310-2 and CU320-2)

The following table lists the response times<sup>1)2)</sup> from receiving the PROFIsafe telegram at the Control Unit up to initiating the particular response.

Table 8- 4 Response times when controlling via PROFIsafe

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$5 \times p9500 + r9780 + t_K^{(6)}$	$5 \times p9500 + 2 \times r9780 + t_K^{(6)}$
SBC	$5 \times p9500 + 2 \times r9780 + t_K^{(6)}$	$5 \times p9500 + 6 \times r9780 + t_K^{(6)}$
SS1 (time controlled), SS1E, SS2E: Time from selecting up to starting the safe timer SS1 (acceleration controlled), SS2: Time from selecting up to initiating braking SOS: Time from selecting up to starting standstill monitoring	$5 \times p9500 + 2 \text{ ms} + t_K^{(6)}$	$5 \times p9500 + 2 \text{ ms} + t_K^{(6)}$
SBR or SAM (limit value violation until STO is active)	$2 \times p9500 + r9780$	$2.5 \times p9500 + r9780 + t_{ACT}^{(5)}$
SOS standstill tolerance window violated	$1.5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{ACT}^{(5)}$
SLS speed limit violated <sup>3)</sup>	$2 \times p9500 + 2 \text{ ms}$	$3.5 \times p9500 + 2 \text{ ms} + t_{ACT}^{(5)}$
SSM <sup>4)</sup>	$4 \times p9500$	$4.5 \times p9500 + t_{ACT}^{(5)}$
SDI (limit value violation until braking is initiated)	$1.5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{ACT}^{(5)}$
SLP (limit value violation until a response is initiated)	$1.5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{ACT}^{(5)}$

- 1) The specified response times are valid for Extended Functions with and without selection.
- 2) The specified response times involve internal SINAMICS response times. Program run times in the F-host and the transmission time via PROFIBUS or PROFINET are not taken into account. When calculating the response times between the F-CPU and the converter, you must take into account that faults in the communication can result in a safety function only being selected after the PROFIsafe monitoring time (F\_WD\_Time) has expired. The PROFIsafe monitoring time (F\_WD\_Time) must also be included in the calculation when an error occurs.
- 3) SLS: Specification of the response time required to initiate a braking response in the drive - or for the output of the "SOS selected" message to the motion control system.
- 4) SSM: The data corresponds to the times between the limit value being fallen below up to sending the information via PROFIsafe.
- 5)  $t_{ACT}$ :

For $p9511 \neq 0$	$t_{ACT} = p9511$
For $p9511 = 0$	If an isochronous PROFIBUS master is available: $t_{ACT} = \text{PROFIBUS cycle}$ Otherwise: $t_{ACT} = 1 \text{ ms}$

- 6)  $t_K$  is the time for internal communication within the SINAMICS module;  $t_K$  can be determined as follows:

For isochronous communication	$t_K = T_o$ (for $T_o$ , see parameter r2064[4])
For non-isochronous communication	$t_K = 4 \text{ ms}$ (for modules, on which p2048 or p8848 <sup>7)</sup> does not exist) $t_K = \text{value from p2048 or p8848}^{(7)}$ (for modules on which p2048 or p8848 <sup>7)</sup> exists)

- 7) p2048 applies to communication via IF1, p8848 to communication via IF2.

### 8.4.5 Control of Extended Functions with encoder via TM54F (CU310-2 and CU320-2)

The table below shows the response times<sup>1)</sup> from the occurrence of a signal at the terminals until the response is initiated.

Table 8- 5 Response times for control via TM54F

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$3,5 \times p9500 + r9780 + p10017^4) + 1$ ms	$4 \times p9500 + 2 \times r9780 + p10017^4) + 1$ ms
SBC	$3,5 \times p9500 + 2 \times r9780 + p10017^4) + 1$ ms	$4 \times p9500 + 6 \times r9780 + p10017^4) + 1$ ms
SS1 (time and acceleration controlled), SS1E (tme controlled), SS2 selection until braking is initiated	$3,5 \times p9500 + p10017^4) + 3$ ms	$4 \times p9500 + p10017^4) + 3$ ms
SBR or SAM (limit value violation until STO is active)	$2 \times p9500 + r9780$	$2,5 \times p9500 + r9780 + t\_IST^5)$
SOS standstill tolerance window violated	$1,5 \times p9500 + 2$ ms	$3 \times p9500 + 2$ ms + $t\_IST^5)$
SLS speed limit violated <sup>2)</sup>	$2 \times p9500 + 2$ ms	$3,5 \times p9500 + 2$ ms + $t\_IST^5)$
SSM <sup>3)</sup>	$3 \times p9500$	$3,5 \times p9500 + t\_IST^5)$
SDI (limit value violation until braking is initiated)	$1,5 \times p9500 + 2$ ms	$3 \times p9500 + 2$ ms + $t\_IST^5)$
SLP (limit value violation until a response is initiated)	$1,5 \times p9500 + 2$ ms	$3 \times p9500 + 2$ ms + $t\_IST^5)$

- 1) The specified response times are valid for Extended Functions with and without selection!
- 2) SLS: Specification of the response time required to initiate a braking response in the drive - or for the output of the "SOS selected" message to the motion control system.
- 3) SSM: The data corresponds to the times between the limit value being fallen below up to output of the information at the F-DO.
- 4) For CU310-2, use the parameter p10017 of the drive object "TM54F\_xx" to calculate the response time, not that of the control unit.
- 5) For  $t\_ACT$ , the following applies:

For p9511 ≠ 0		$t\_ACT = p9511$
For p9511 = 0	If an isochronous PROFIBUS master is available:	$t\_ACT = PROFIBUS$ cycle
	Otherwise:	$t\_ACT = 1$ ms

## 8.4.6 Control of Extended Functions with encoder via terminals (only CU310-2)

The table below shows the response times<sup>1)</sup> from the occurrence of a signal at the terminals until the response is initiated.

Table 8- 6 Response times when controlling the Extended Functions with encoder via safe onboard terminals (only CU310-2)

Function	Worst case for	
	Drive system has no fault	A fault is present
STO	$3,5 \times p9500 + r9780 + t_E^{5)}$	$4 \times p9500 + 2 \times r9780 + t_E^{5)}$
SBC	$3,5 \times p9500 + 2 \times r9780 + t_E^{5)}$	$4 \times p9500 + 9 \times r9780 + t_E^{5)}$
SS1 (time and acceleration controlled), SS1E (time controlled), SS2 selection until braking is initiated	$3,5 \times p9500 + 2 \text{ ms} + t_E^{5)}$	$4 \times p9500 + 2 \text{ ms} + t_E^{5)}$
SBR or SAM (limit value violation until STO is active)	$2 \times p9500 + r9780$	$2,5 \times p9500 + r9780 + t_{IST}^{4)}$
SOS standstill tolerance window violated	$1,5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{IST}^{4)}$
SLS speed limit violated <sup>2)</sup>	$2 \times p9500 + 2 \text{ ms}$	$3,5 \times p9500 + 2 \text{ ms} + t_{IST}^{4)}$
SSM <sup>3)</sup>	$3 \times p9500$	$3,5 \times p9500 + t_{IST}^{4)}$
SDI (limit value violation until braking is initiated)	$1,5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{IST}^{4)}$
SLP (limit value violation until a response is initiated)	$1,5 \times p9500 + 2 \text{ ms}$	$3 \times p9500 + 2 \text{ ms} + t_{IST}^{4)}$

- 1) The specified response times are valid for Extended Functions with and without selection!
- 2) SLS: Specification of the response time required to initiate a braking response in the drive - or for the output of the "SOS selected" message to the motion control system.
- 3) SSM: The data corresponds to the times between the limit value being fallen below up to output of the information via the TM54F terminals.
- 4)  $t_{ACT}$ :

For $p9511 \neq 0$		$t_{ACT} = p9511$
For $p9511 = 0$	If an isochronous PROFIBUS master is available:	$t_{ACT} = \text{PROFIBUS cycle}$
	Otherwise:	$t_{ACT} = 1 \text{ ms}$

- 5) For  $t_E$ , the following applies:

$p10017 = 0$	$t_E = 2 \times p0799$
$p10017 \neq 0$	$t_E = p10017 + p0799 + 1 \text{ ms}$

### 8.4.7 Control of Extended Functions without encoder via PROFIsafe (CU310-2 and CU320-2)

The following table lists the response times<sup>1)2)</sup> from receiving the PROFIsafe telegram at the Control Unit up to initiating the particular response.

Table 8-7 Response times when controlling via PROFIsafe

Function		Worst case for	
		Drive system has no fault	A fault is present
STO		$5 \times p9500 + r9780 + t_K^{(4)}$	$5 \times p9500 + 2 \times r9780 + t_K^{(4)}$
SBC		$5 \times p9500 + 2 \times r9780 + t_K^{(4)}$	$5 \times p9500 + 6 \times r9780 + t_K^{(4)}$
SS1 (speed controlled/time and acceleration controlled), SS1E (time controlled)		$5 \times p9500 + 2 \text{ ms} + t_K^{(4)}$	$5 \times p9500 + 2 \text{ ms} + t_K^{(4)}$
SBR or SAM (limit value violation until STO is active)		$3 \times p9500 + r9780 + p9587 + 4 \text{ ms}$	$3,5 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
SLS speed limit violated <sup>3)</sup>	Standard <sup>3)</sup>	$3 \times p9500 + p9587 + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
	Start phase <sup>3)</sup>	$3 \times p9500 + p9587 + p9586^{(3)} + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9587 + p9586^{(3)} + 32 \text{ ms}$
SSM		$6 \times p9500 + p9587 + 4 \text{ ms}$	$6,5 \times p9500 + p9587 + 32 \text{ ms}$
SDI (limit value violation until braking is initiated)	Standard <sup>3)</sup>	$2,5 \times p9500 + p9587 + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
	Start phase <sup>3)</sup>	$2,5 \times p9500 + p9587 + p9586^{(3)} + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + p9586^{(3)} + 32 \text{ ms}$

- 1) The specified response times are valid for Extended Functions with and without selection!
- 2) The specified response times involve internal SINAMICS response times. Program run times in the F-host and the transmission time via PROFIBUS or PROFINET are not taken into account. When calculating the response times between the F-CPU and the converter, you must take into account that faults in the communication can result in a safety function only being selected after the PROFIsafe monitoring time (F\_WD\_Time) has expired. The PROFIsafe monitoring time (F\_WD\_Time) must also be included in the calculation when an error occurs.
- 3) Start phase: This describes the behavior after switching on (ON command with previously deleted pulses).  
Standard: This behavior applies when the pulses have already been enabled.  
There is a different behavior, because with the aid of p9586, the encoderless actual value acquisition after pulse enable can only be activated with a delay.
- 4)  $t_K$  is the time for internal communication within the SINAMICS module;  $t_K$  can be determined as follows:

For isochronous communication	$t_K = T_o$ (for $T_o$ , see parameter r2064[4])
For non-isochronous communication	$t_K = 4 \text{ ms}$ (for modules, on which p2048 or p8848 <sup>5)</sup> does not exist)
	$t_K = \text{value from p2048 or p8848}^{(5)}$ (for modules on which p2048 or p8848 <sup>5)</sup> exists)

<sup>5)</sup> p2048 applies to communication via IF1, p8848 to communication via IF2.

## 8.4.8 Control of Extended Functions without encoder via terminals (only CU310-2)

The table below shows the response times<sup>1)</sup> from the occurrence of a signal at the terminals until the response is initiated.

Table 8- 8 Response times for control of the Extended Functions without encoder via terminals (only CU310-2)

Function		Worst case for	
		Drive system has no fault	A fault is present
STO		$3,5 \times p9500 + r9780 + t_E^{(3)}$	$4 \times p9500 + 2 \times r9780 + t_E^{(3)}$
SBC		$3,5 \times p9500 + 2 \times r9780 + t_E^{(3)}$	$4 \times p9500 + 9 \times r9780 + t_E^{(3)}$
SS1 (speed controlled/time and acceleration controlled), SS1E (time controlled)		$3,5 \times p9500 + 2 \text{ ms} + t_E^{(3)}$	$4 \times p9500 + 2 \text{ ms} + t_E^{(3)}$
SBR or SAM (limit value violation until STO is active)		$3 \times p9500 + r9780 + p9587 + 4 \text{ ms}$	$3,5 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
SLS speed limit violated <sup>3)</sup>	Standard <sup>2)</sup>	$3 \times p9500 + p9587 + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9578 + 32 \text{ ms}$
	Start phase <sup>2)</sup>	$3 \times p9500 + p9586^{(2)} + p9578 + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9586^{(2)} + p9578 + 32 \text{ ms}$
SSM		$4 \times p9500 + p9587 + 4 \text{ ms}$	$4,5 \times p9500 + p9587 + 32 \text{ ms}$
SDI (limit value violation until braking is initiated)	Standard <sup>2)</sup>	$2,5 \times p9500 + p9587 + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
	Start phase <sup>2)</sup>	$2,5 \times p9500 + p9587 + p9586^{(2)} + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + p9586^{(2)} + 32 \text{ ms}$

1) The specified response times are valid for Extended Functions with and without selection!


2) Start phase: This describes the behavior after switching on (ON command with previously deleted pulses).

Standard: This behavior applies when the pulses have already been enabled.

There is a different behavior, because with the aid of p9586, the encoderless actual value acquisition after pulse enable can only be activated with a delay.

3) For  $t_E$ , the following applies:

p10017 = 0	$t_E = 2 \times p0799$
p10017 ≠ 0	$t_E = p10017 + p0799 + 1 \text{ ms}$

 CAUTION
<p><b>Extension of the response times for SLS without encoder or SDI without encoder under certain circumstances</b></p> <p>If the safety functions SLS without encoder or SDI without encoder are already selected when the gating pulses for the Power Module are enabled, then during the starting phase, it is absolutely imperative that you take into account the response times when limit values are violated and for system errors in order to extend the time value set in parameter p9586<sup>2)</sup> with respect to the standard values (see the table above).</p> <p>After the time interval set in p9586, the standard response times apply (see table above).</p>

### 8.4.9 Control of Extended Functions without encoder via TM54F (CU310-2 and CU320-2)

The table below shows the response times<sup>1)</sup> from the occurrence of a signal at the terminals until the response is initiated.

Table 8-9 Response times for control via TM54F

Function		Worst case for	
		Drive system has no fault	A fault is present
STO		$3,5 \times p9500 + r9780 + p10017^{3)} + 1 \text{ ms}$	$4 \times p9500 + 2 \times r9780 + p10017^{3)} + 1 \text{ ms}$
SBC		$3,5 \times p9500 + 2 \times r9780 + p10017^{3)} + 1 \text{ ms}$	$4 \times p9500 + 6 \times r9780 + p10017^{3)} + 1 \text{ ms}$
SS1 (speed controlled/time and acceleration controlled), SS1E (time controlled)		$3,5 \times p9500 + p10017^{3)} + 3 \text{ ms}$	$4 \times p9500 + p10017^{3)} + 3 \text{ ms}$
SBR or SAM (limit value violation until STO is active)		$3 \times p9500 + r9780 + p9587 + 4 \text{ ms}$	$3,5 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
SLS speed limit violated <sup>3)</sup>	Standard <sup>2)</sup>	$3 \times p9500 + p9587 + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
	Start phase <sup>2)</sup>	$3 \times p9500 + p9587 + p9586^{2)} + 6 \text{ ms}$	$4,5 \times p9500 + r9780 + p9587 + p9586^{2)} + 32 \text{ ms}$
SSM		$4 \times p9500 + p9587 + 4 \text{ ms}$	$4,5 \times p9500 + p9587 + 32 \text{ ms}$
SDI (limit value violation until braking is initiated)	Standard <sup>2)</sup>	$2,5 \times p9500 + p9587 + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + 32 \text{ ms}$
	Start phase <sup>2)</sup>	$2,5 \times p9500 + p9587 + p9586^{2)} + 6 \text{ ms}$	$4 \times p9500 + r9780 + p9587 + p9586^{2)} + 32 \text{ ms}$

- 1) The specified response times are valid for Extended Functions with and without selection!
- 2) Start phase: This describes the behavior after switching on (ON command with previously deleted pulses).  
Standard: This behavior applies when the pulses have already been enabled.  
There is a different behavior, because with the aid of p9586, the encoderless actual value acquisition after pulse enable can only be activated with a delay.
- 3) For CU310-2, use the parameter p10017 of the drive object "TM54F\_xx" to calculate the response time, not that of the control unit.



#### CAUTION

##### Extension of the response times for SLS without encoder or SDI without encoder under certain circumstances

If the safety functions SLS without encoder or SDI without encoder are already selected when the gating pulses for the Power Module are enabled, then during the starting phase, it is absolutely imperative that you take into account the response times when limit values are violated and for system errors in order to extend the time value set in parameter p9586<sup>2)</sup> with respect to the standard values (see the table above).

After the time interval set in parameter p9586, the standard response times apply (see table above).



# Maintenance

## 9.1 Information pertaining to component replacements

### Replacing a component from the perspective of Safety Integrated

---

**Note****Note additional safety instructions**

Observe the instructions with regard to changing or replacing software components in Section "Safety instructions (Page 17)"!

---

The faulty component was replaced according to safety regulations. The information relevant from the perspective of Safety Integrated is provided in the following. For information about component replacements, see "Example of component replacements" in the SINAMICS S120 Function Manual Drive Functions.

- Based on the NodeID and the saved CRC of the particular hardware component, the drive identifies that a component has been replaced. You can take the responses of the drive and the actions that have to be carried out from the following table:

9.1 Information pertaining to component replacements

	Replaced component	Control type	Drive response (fault)	User action			Diagnostic parameters
				Fault acknowledgment required <sup>1)</sup>	Acknowledgment is required that the component has been replaced <sup>2)</sup>	Save <sup>3)</sup>	
<b>Basic Functions</b>	Control Unit	All	F01641.0 = 1	Yes	No	Yes	r9776.2 = 1
	Motor Module	All	F01641.1 = 1	Yes	No	Yes	r9776.2 = 1
	Power Module	All	F01641.2 = 1	Yes	No	Yes	r9776.2 = 1
<b>Extended Functions</b>	Control Unit	All	F01641.0 = 1	Yes	No	Yes	r9776.2 = 1
	Motor Module	PROFIsafe, OnBoard F-DI, without selection	F01641.1 = 1	Yes	No	Yes	r9776.2 = 1
		TM54F	F01640.1 = 1	Yes	Yes	Yes	r9776.2 = 1 r9776.3 = 1
	Power Module	All	F01641.2 = 1	Yes	No	Yes	r9776.2 = 1
	Sensor Module (CPU 1)	All	F01641.3 = 1	Yes	No	Yes	r9776.2 = 1
	Sensor Module (CPU 2)	All	F01640.4 = 1	Yes	Yes	Yes	r9776.2 = 1 r9776.3 = 1
	Encoder <sup>4)</sup>	All	F01641.5 = 1 F01641.6 = 1	Yes	No	Yes	r9776.2 = 1
	TM54F	All	F01641 (only on TM54F_MA)	Yes	No	Yes	r9776.2 = 1

- 1) The fault must be acknowledged each time a component is replaced using a standard acknowledgment (e.g. using a 0/1 signal at p2103). However, even without acknowledgment the drive can still be operated.
- 2) The replacement of the components listed in the table must be acknowledged in order to ensure the new internal device communications to be established. When replacing other components, acknowledgment is not required, as the new communications to be established are automatically ensured.  
To acknowledge a component replacement, perform the following sequence on all of the drive objects involved:
  - Check whether the following preconditions are fulfilled:
    - p0010 = 0
    - It is not permissible for a firmware update to be active on the drive object.
    - Set p9702 = 29 (= 1D hex)
- 3) The modified data must be saved after a component has been replaced:
  - It is not permissible for a firmware update to be active on the drive object.
  - Copy from RAM to ROM by setting p0977 = 1.
 If the data is not saved, the fault is output again after the next POWER ON.
- 4) Only for encoders with serial number (e.g. EnDat)

**! WARNING****Danger to life due to high speeds after replacing motors for Safety without encoder**

When using safety functions without encoder, the motor pole pair number plays a decisive role. If a motor is replaced, then the behavior depends on the pole pair number: If a motor with a higher pole pair number is used (other than that configured), the mechanical speed is less than that calculated by Safety Integrated. If a motor with a lower pole pair number is used (e.g. when a motor is replaced), the mechanical speed is higher than that calculated by Safety Integrated.

- After a replacement such as this, perform a test by comparing the safe actual speed (r9714) with the normal speed (r0063 or the output frequency), and if required, correct the configured pole pair number.

**Acceptance test and acceptance report****! WARNING****Danger to life due to unwanted motion when changing components without function test**

After a component replacement, connections or functions can be defective so that death or serious injury can result if a person enters the danger zone of the motors.

- After component replacement, always run a simplified function test.  
You can find more detailed information in the chapters "Test scope for specific measures (Page 407)" and "Acceptance test (Page 341)".

**Overview of important parameters (see SINAMICS S 120/S150 List Manual)**

- r9670 SI module identification Control Unit
- r9671[0...n] SI module identification Motor Module
- p9672 SI module identification Power Module
- p9673 SI module identification sensor channel 1
- p9674 SI module identification sensor channel 2
- p9675 SI module identification sensor channel 1
- p9676 SI module identification sensor channel 2
- p9702 Acknowledge SI component replacement
- r9776 SI diagnostics
- r9793[0...9] SI diagnostics component replacement
- r10070 SI TM54F module identification

## 9.2 Note regarding firmware update

 **WARNING**

**Danger to life on a firmware update without POWER ON and acceptance test**

If the message A01007 "POWER ON required for DRIVE-CLiQ component" appears after a firmware update, death or serious injury can be caused if a person enters the danger zone of the motors.

- Then perform a partial acceptance test.
- Do not enter the danger zone of the motor until the acceptance test has been successfully completed.

 **WARNING**

**Danger to life due to unwanted motion when changing components without function test**

After a component replacement, connections or functions can be defective so that death or serious injury can result if a person enters the danger zone of the motors.

- Perform a POWER ON before resuming operation.
- After component replacement, always run a simplified function test.  
You can find more detailed information in the chapters "Test scope for specific measures (Page 407)" and "Acceptance tests (Page 420)".

## 9.3 Safety faults

### 9.3.1 Stop responses

Faults with Safety Integrated Extended Functions and violation of limits can trigger the following stop response:

Table 9- 1 Stop response overview

Stop response	Triggered ...	Action	Effect
STOP A <sup>1)</sup> (corresponds to STO <sup>2)</sup> )	<ul style="list-style-type: none"> <li>For all acknowledgeable safety faults with pulse suppression</li> <li>Subsequent response of STOP B</li> <li>Configurable subsequent stop p9563 for SLS</li> <li>Configurable subsequent stop p9566 for SDI</li> <li>Configurable subsequent stop p9562 for SLP</li> </ul>	Immediate pulse suppression	Drive coasts down
STOP B <sup>1)</sup> (corresponds to SS <sup>3)</sup> )	<p>Examples:</p> <ul style="list-style-type: none"> <li>Standstill tolerance violated in p9530 (SOS)</li> <li>Configurable subsequent stop p9563 for SLS</li> <li>Configurable subsequent stop p9566 for SDI</li> <li>Configurable subsequent stop p9562 for SLP</li> <li>Subsequent response of STOP F</li> </ul>	Immediate input of speed set-point = 0 and start of timer $t_B$ . Once $t_B$ or $n_{act} < n_{shutdown}$ has expired, STOP A is triggered.	STOP B with subsequent STOP A. The drive decelerates along the OFF3 ramp and then switches to STOP A. <b>Note:</b> For "SS1 with external stop" (SS1E), braking is <b>not</b> along the OFF3 ramp (see Section "Safe Stop 1 with external stop (Page 90)")
STOP C <sup>1)</sup> (corresponds to SS <sup>4)</sup> )	<ul style="list-style-type: none"> <li>Configurable subsequent stop p9563 for SLS</li> <li>Configurable subsequent stop p9566 for SDI</li> <li>Configurable subsequent stop p9562 for SLP</li> </ul>	Immediate input of speed set-point = 0 and start of timer $t_C$ . Once $t_C$ has elapsed, SOS is selected.	The drive decelerates along the OFF3 ramp; SOS is then selected.
STOP D <sup>1)</sup>	<ul style="list-style-type: none"> <li>Configurable subsequent stop p9563 for SLS</li> <li>Configurable subsequent stop p9566 for SDI</li> <li>Configurable subsequent stop p9562 for SLP</li> </ul>	Timer $t_D$ starts. No drive-integrated response. SOS is activated on expiration of $t_D$ .	The drive must be decelerated by the higher-level controller (within the drive group)! Once $t_D$ has elapsed, SOS is selected. An automatic response is only triggered if the standstill tolerance window is violated in SOS.

Stop response	Triggered ...	Action	Effect
STOP E <sup>1)</sup>	<ul style="list-style-type: none"> <li>Configurable subsequent stop p9563 for SLS</li> <li>Configurable subsequent stop p9566 for SDI</li> <li>Configurable subsequent stop p9562 for SLP</li> </ul>	SOS triggered after the expiry of p9554	Controlling the drive-integrated ESR functionality
STOP F <sup>1)</sup>	If an error occurs in the data cross-check. Follow-up response STOP B or STOP A	Timer $t_{F1}$ (Basic Functions) or $t_{F2}$ (Extended Functions) No drive response	If a safety function (SOS, SLS) has been selected or if SSM with hysteresis has been enabled, transition to STOP A after $t_{F1}$ (Basic Functions) has elapsed or STOP B after $t_{F2}$ (Extended Functions) has elapsed.

- <sup>1)</sup> See also the following note "delayed pulse cancellation when the bus fails".
- <sup>2)</sup> The behavior of the drive after STOP A is triggered corresponds (apart from the safety messages) to the behavior after STO is triggered. Note that the parameterization of STO applies equally for STOP A.
- <sup>3)</sup> The behavior of the drive after STOP B is triggered corresponds (apart from the safety messages) to the behavior after SS1 is triggered. Monitoring with the aid of SAM or SBR, for example, works in exactly the same way. Note that the parameterization of SS1 applies equally for STOP B.
- <sup>4)</sup> The behavior of the drive after STOP C is triggered corresponds (apart from the safety messages) to the behavior after SS2 is triggered. Monitoring with the aid of SAM or SBR (for safety with encoder), for example, works in exactly the same way. Note that the parameterization of SS2 applies equally for STOP C.

---

### Note

#### Delayed pulse cancellation when the bus fails

For SLS and SDI, the stop responses are also available with delayed pulse cancellation when the bus fails (in order that the drive does not immediately respond with pulse cancellation when a communication error occurs):

- If  $p9580 \neq 0$  and SLS is active, in the event of communication failure, the parameterized ESR reaction is only realized if, as SLS response, a STOP with delayed pulse cancellation when the bus fails has been parameterized ( $p9563[0...3] \geq 10$ ).
- If  $p9580 \neq 0$  and SDI is active, in the event of communication failure, the parameterized ESR reaction is only realized if, as SDI response, a STOP with delayed pulse cancellation when the bus fails has been parameterized ( $p9566[0...3] \geq 10$ ).
- If  $p9580 \neq 0$  and SLP is active, in the event of communication failure, the parameterized ESR reaction is only realized if, as SLP response, a STOP with delayed pulse cancellation when the bus fails has been parameterized ( $p9566[0...3] \geq 10$ ).

The delay time ( $p9580$ ) must not exceed 800 ms.

---

---

**Note**

**Delay time between STOP F and STOP B**

A delay time between STOP F and STOP B should only be set if an additional response is initiated during this time when the "Internal Event" (r9722.7) message signal is evaluated.

Further, when using the delay time, a monitoring function should always be selected (e.g. SLS with a high limit speed) or the hysteresis of SSM should be configured.

When hysteresis is activated for SSM, then this should be considered to be an activated monitoring function.

---

**On delays at the stop response transitions**

t <sub>B</sub>	p9556
t <sub>C</sub>	p9552
t <sub>D</sub>	p9553
t <sub>F1</sub>	p9658
t <sub>F2</sub>	p9555
n <sub>shutdown</sub> :	p9560

**Description of faults and alarms**

---

**Note**

**References**

The faults and alarms for SINAMICS Safety Integrated are described in the following documentation:

References: SINAMICS S120/S150 List Manual

---

## 9.3.2 Stop response priorities

Table 9- 2 Stop response priorities

Priority classes	Stop response
Highest priority	STOP A
.....	STOP B
...	STOP C
..	STOP D
..	STOP E
Lowest priority	STOP F

### Priorities of stop responses and Extended Functions

Table 9- 3 Priorities of stop responses and Extended Functions

Stop response / Extended Function		Highest priority	...	...	...	...	Lowest priority
		STOP A	STOP B	STOP C	STOP D	STOP E	STOP F
Highest priority	<b>STO</b>	STOP A / STO	STO	STO	STO	STO	STO
.....	<b>SS1</b>	STOP A	STOP B / SS1	SS1	SS1	SS1	SS1
...	<b>SS2</b>	STOP A	STOP B	STOP C / SS2	SS2	SS2	SS2 / STOP B <sup>2)</sup>
..	<b>SOS</b>	STOP A <sup>1)</sup>	STOP B <sup>1)</sup>	SOS	SOS	STOP E/SOS	STOP B <sup>2)</sup>
Lowest priority	<b>SLS</b>	STOP A <sup>3)</sup>	STOP B <sup>3)</sup>	STOP C <sup>4)</sup>	STOP D <sup>4)</sup>	STOP E <sup>4)</sup>	STOP B <sup>2)</sup>

- 1) The SOS monitoring function remains active, although the fault response in the event of a fault can no longer be triggered because it is already present.
- 2) STOP B is the subsequent stop of STOP F, which is activated after a parameterizable time. STOP F alone does not have any effect; the active safety function is still present.
- 3) The SLS monitoring function remains active, although the fault response in the event of a fault can no longer be triggered because it is already present.
- 4) SLS remains active during the braking phase, after which the system switches to SOS.

The table above specifies which stop response / safety function is set if a STOP is triggered when a safety function is active. The STOPS are arranged here from left to right in descending order of priority (STOP A-F).

No overall priority is assigned in the individual safety functions. SOS remains active, for example, even if STO is requested. The safety functions that cause the drive to decelerate (SS1, SS2) are specified from top to bottom in descending order of priority.



If a field contains two entries, the stop responses and safety functions have the same priority. Explanation:

- STOP A corresponds to selecting STO
- STOP B corresponds to selecting SS1
- STOP C corresponds to selecting SS2
- STOP D corresponds to selecting SOS
- STOP E corresponds to selecting SOS (for additional activation of the standard "Extended stop and retract (ESR)" function)
- When the SS2 function is active, STOP F results in follow-up stop B. SS2 remains active.

**Examples for illustrating the information in the table:**

- Safety function SS1 has just been selected. STOP A remains selected.
- By selecting a STOP with a higher priority, STOPS that are present with a lower priority will be replaced. This means that when SS1 is selected ( $\neq$  STOP B), any STOPS C-F that are present will be replaced.
- The SLS safety function is selected. This selection does not modify the function of STOP A-D. A STOP F now triggers a STOP B because a safety function has been activated.
- Stop response, STOP C is selected. If the STO or SS1 safety functions are active, this does not have any effect. If SS2 is active, this brake ramp is retained. If SOS is active, SOS remains effective, which is also the end status of STOP C. When SLS is selected, the drive is decelerated with STOP C.

### 9.3.3 Acknowledging safety faults

---

#### Note

#### Acknowledgment through Power Off/On

Safety faults can also be acknowledged (as with all other faults) by switching the drive unit off and then on again (POWER ON).

If this action has not eliminated the fault cause, the fault is displayed again immediately after power-up.

---

#### Acknowledgment via TM54F/CU310-2

Parameter p10006 "SI acknowledgment internal event input terminal" allows faults to be acknowledged in the safety drives and with an F-DI of the TM54F or the CU310-2 itself.

The "**safe fault acknowledgment**" mechanism functions as follows:

The fail-safe input F-DI on the TM54F or on the CU310-2 that was parameterized with the function p10006 "Safety Integrated acknowledgment internal event input terminal", is activated. In this way, faults that have occurred on the drives or on the TM54F are acknowledged by means of a safe input signal. The falling edge at this input resets the status "Internal Event" in the drives and, if used, in the TM54F or the CU310-2.

To prevent safety faults from being acknowledged unintentionally or incorrectly, the signal at the F DI terminal, which was parameterized for acknowledgment purposes, must be at level "0" in the quiescent state. To trigger the acknowledgment (falling edge at F DI), the signal must first be set to "1" and then back to "0". If the required idle state is not reached, an alarm is output.

After "safe fault acknowledgment", when using a TM54F, an acknowledgment must be made at the Control Unit, in order to:

- Delete the TM54F faults from the fault buffer
- Reset the red Ready LED on the TM54F.

#### Acknowledgment via PROFIsafe

The higher-level controller sets the signal "Internal Event ACK" via the PROFIsafe telegram (STW bit 7) separately for each drive object. A falling edge in this signal resets the status "Internal Event" in the relevant drive, which therefore acknowledges the fault.

Faults in the drive objects (DOs) cannot be acknowledged by the higher-level controller in the line-up but must instead be acknowledged separately for each individual drive object.

#### Extended acknowledgment

If STO or SS1 is selected/deselected (and p9507.0 = 1 are set), then the safety messages are canceled automatically.

If, in addition to the "Basic Functions via terminals", the "Extended Functions" are also enabled, then acknowledgment is also possible by selecting/deselecting STO via PROFIsafe or terminals at the TM54F or at the CU310-2.

## 9.4 Message buffer

In addition to the fault buffer for F... faults and the alarm buffer for A... alarms (see the relevant section in: /IH1/ SINAMICS S120 Commissioning Manual), a special message buffer for C... safety messages is available for Safety Integrated Extended Functions.

The fault messages for the Safety Integrated Basic Functions are stored in the standard fault buffer (see Section "Buffer for faults and alarms" in /IH1/ SINAMICS S120 Commissioning Manual).

### Note

#### Messages of the Basic and the Extended Functions

Set parameter p3117 = 1 if you need to save both the Basic Functions messages and the Extended Functions messages in the standard fault buffer.

The message buffer for safety messages is similar to the fault buffer for fault messages. The message buffer comprises the message code, message value, and message time (received, resolved), the component number for identifying the affected SINAMICS component and diagnostics attributes. The following diagram shows how the message buffer is structured:




Image 9-1 Structure of the message buffer

When a safety message is present, bit r2139.5 is set to 1 ("safety message active"). The entry in the message buffer is delayed. For this reason, the message buffer should not be read until a change in the buffer (r9744) has been detected after "Safety message present" is output.

The messages must be acknowledged via a fail-safe input F-DI of the TM54F/CU310-2 or via PROFIsafe.

**Properties of the safety message buffer:**

- The entries appear in the buffer according to the time at which they occurred.
- If a new message case occurs, the message buffer is reorganized accordingly. The history is recorded in the "Acknowledged message case" 1 to 7.
- If the cause of at least one message in "Current message case" is rectified and acknowledged, the message buffer is reorganized accordingly. Messages that have not been rectified remain in "Current message case".
- If "Current message case" contains 8 messages and a new message for the current message case is output, the message in the current message case parameters is overwritten with the new message in index 7.
- r9744 is incremented each time the message buffer changes.
- A message value (r9749, r9753) can be output for a message. The message value is used to diagnose the message more accurately (refer to the message description for more details).

**Deleting the message buffer:**

The message buffer can be deleted as follows: p9752 = 0. Parameter p9752 (SI message cases, counter) is also reset to 0 at POWER ON. This also clears the fault memory.

**Overview of important parameters (see SINAMICS S 120/S150 List Manual)**

- r2139.0...15 CO/BO: Status word, faults/alarms 1
- r9744 SI message buffer changes, counter
- r9745[0...63] SI component
- r9747[0...63] SI message code
- r9748[0...63] SI message time received in milliseconds
- r9749[0...63] SI message value
- r9750[0...63] SI diagnostic attributes
- p9752 SI message cases, counter
- r9753[0...63] SI message value for float values
- r9754[0...63] SI message time received in days
- r9755[0...63] SI message time removed in milliseconds
- r9756[0...63] SI message time removed in days

## Standards and regulations

### 10.1 General information

#### 10.1.1 Aims

Manufacturers and operating companies of equipment, machines, and products are responsible for ensuring the required level of safety. This means that plants, machines, and other equipment must be designed to be as safe as possible in accordance with the current state of the art. For this purpose, companies describe in the various standards the current state of the art covering all aspects relevant to safety. If it can be justifiably assumed that all of the relevant standards are complied with, this ensures that state-of-the-art technology has been utilized and, in turn, a plant builder or a manufacturer of a machine or a piece of equipment has fulfilled his appropriate responsibility.

Safety systems are designed to minimize potential hazards for both people and the environment by means of suitable technical equipment, without restricting industrial production and the use of machines more than is necessary. The protection of man and environment must be assigned equal importance in all countries based on internationally harmonized rules and regulations. This is also intended to avoid competitive advantages or disadvantages due to different safety requirements in different countries.

There are different concepts and requirements in the various regions and countries of the world when it comes to ensuring the appropriate degree of safety. The legislation and the requirements of how and when proof is to be given and whether there is an adequate level of safety are just as different as the assignment of responsibilities.

The most important thing for manufacturers of machines and companies that set up plants and systems is that the legislation and regulations in the country where the machine or plant is being operated apply. For example, the control system for a machine that is to be used in the US must fulfill local US requirements even if the machine manufacturer (OEM) is based in the European Economic Area (EEA).

### 10.1.2 Functional safety

Safety, from the perspective of the object to be protected, cannot be split-up. The causes of hazards and, in turn, the technical measures to avoid them can vary significantly. This is why a differentiation is made between different types of safety (e.g. by specifying the cause of possible hazards). "Functional safety" is involved if safety depends on the correct function.

To ensure the functional safety of a machine or plant, the safety-related parts of the protection and control devices must function correctly. In addition, the systems must behave in such a way that either the plant remains in a safe state or it is brought into a safe state if a fault occurs. In this case, it is necessary to use specially qualified technology that fulfills the requirements described in the associated Standards. The requirements to implement functional safety are based on the following basic goals:

- Avoiding systematic faults
- Controlling random faults or failures

Benchmarks for establishing whether or not a sufficient level of functional safety has been achieved include the probability of hazardous failures, the fault tolerance, and the quality that is to be ensured by avoiding systematic faults. This is expressed in the standards using specific classification. In IEC/EN 61508, IEC/EN 62061 "Safety Integrity Level" (SIL) and EN ISO 13849-1 "Category" and "Performance Level" (PL).

## 10.2 Safety of machinery in Europe

The EU Directives that apply to the implementation of products are based on Article 95 of the EU contract, which regulates the free exchange of goods. These are based on a new global concept ("new approach", "global approach"):

- EU Directives only specify general safety goals and define basic safety requirements.
- Technical details can be defined by means of standards by Standards Associations that have the appropriate mandate from the commission of the European Parliament and Council (CEN, CENELEC). These standards are harmonized in line with a specific directive and listed in the official journal of the commission of the European Parliament and Council. Legislation does not specify that certain standards have to be observed. When the harmonized Standards are observed, it can be assumed that the safety requirements and specifications of the Directives involved have been fulfilled.
- EU Directives specify that the Member States must mutually recognize domestic regulations.

The EU Directives are equal. This means that if several Directives apply for a specific piece of equipment or device, the requirements of all of the relevant Directives apply (e.g. for a machine with electrical equipment, the Machinery Directive and the Low-Voltage Directive apply).

### 10.2.1 Machinery Directive

The basic safety and health requirements specified in Annex I of the Directive must be fulfilled for the safety of machines.

The protective goals must be implemented responsibly to ensure compliance with the Directive.

Manufacturers of a machine must verify that their machine complies with the basic requirements. This verification is facilitated by means of harmonized standards.

IEC 61800-5-2:2007 is relevant for the machinery directive: Adjustable-speed electrical power drive systems, Part 5-2: Safety requirements - Functional safety

Within the context of IEC 61508, IEC 61800-5-2 considers adjustable speed electric power drive systems (PDS), which are suitable for use in safety-related applications (PDS(SR)).

IEC 61800-5-2 places demands on PDS(SR) as subsystems of a safety-related system. This therefore permits the implementation of the electrical/electronic/programmable electronic elements of a PDS(SR) taking into account the safety-relevant performance of the safety function(s) of a PDS.

Manufacturers and suppliers of PDS(SR) can prove to users (e.g. integrators of control systems, developers of machines and plants etc.) the safety-relevant performance of their equipment by implementing the specifications stipulated in standard IEC 61800-5-2.

## 10.2.2 Harmonized European Standards

The two Standards Organizations CEN (Comité Européen de Normalisation) and CENELEC (Comité Européen de Normalisation Électrotechnique), mandated by the EU Commission, drew-up harmonized European standards in order to precisely specify the requirements of the EC directives for a specific product. These standards (EN standards) are published in the official journal of the commission of the European Parliament and Council and must be included without revision in domestic standards. They are designed to fulfill basic health and safety requirements as well as the protective goals specified in Annex I of the Machinery Directive.

When the harmonized standards are observed, it is "automatically assumed" that the Directive is fulfilled. As such, manufacturers can assume that they have observed the safety aspects of the Directive under the assumption that these are also covered in this standard. However, not every European Standard is harmonized in this sense. Key here is the listing in the official journal of the commission of the European Parliament and Council.

The European Safety of Machines standard is hierarchically structured. It is divided into:

- A standards (basic standards)
- B standards (group standards)
- C standards (product standards)

### **Type A standards/basic standards**

A standards include basic terminology and definitions relating to all types of machine. This includes EN ISO 12100 (previously EN 292-1) "Safety of Machines, Basic Terminology, General Design Principles".

A standards are aimed primarily at the bodies responsible for setting the B and C standards. The measures specified here for minimizing risk, however, may also be useful for manufacturers if no applicable C standards have been defined.

### **Type B standards/group standards**

B standards cover all safety-related standards for various different machine types. B standards are aimed primarily at the bodies responsible for setting C standards. They can also be useful for manufacturers during the machine design and construction phases, however, if no applicable C standards have been defined.

A further sub-division has been made for B standards:

- Type B1 standards for higher-level safety aspects (e.g. ergonomic principles, safety clearances from sources of danger, minimum clearances to prevent parts of the body from being crushed).
- Type B2 standards for protective safety devices are defined for different machine types (e.g. EMERGENCY STOP devices, two-hand operating circuits, interlocking elements, contactless protective devices, safety-related parts of controls).

### **Type C standards/product standards**

C standards are product-specific standards (e.g. for machine tools, woodworking machines, elevators, packaging machines, printing machines etc.). Product standards cover machine-specific requirements. The requirements can, under certain circumstances, deviate from the basic and group standards. Type C/product standards have the highest priority for machine manufacturers who can assume that it fulfills the basic requirements of Annex I of the Machinery Directive (automatic presumption of compliance). If no product standard has been



defined for a particular machine, type B standards can be applied when the machine is constructed.

A complete list of the standards specified and the mandated draft standards are available on the Internet at the following address:

<http://www.newapproach.org/>

Recommendation: Due to the rapid pace of technical development and the associated changes in machine concepts, the standards (and C standards in particular) should be checked to ensure that they are up to date. Please note that the application of a particular standard may not be mandatory provided that all the safety requirements of the applicable EU directives are fulfilled.

### 10.2.3 Standards for implementing safety-related controllers

If the functional safety of a machine depends on various control functions, the controller must be implemented in such a way that the probability of safety functions failing in a dangerous fashion is sufficiently minimized. EN ISO 13849-1 (formerly EN 954-1) and IEC61508 define principles for implementing safety-related machine controllers which, when properly applied, ensure that all the safety requirements of the EC Machinery Directive are fulfilled. These standards ensure that the relevant safety requirements of the Machinery Directive are fulfilled.




Image 10-1 Standards for implementing safety-related controllers

The application areas of EN ISO 13849-1, EN 62061, and EN 61508 are very similar. To help users make an appropriate decision, the IEC and ISO associations have specified the application areas of both standards in a joint table in the introduction to the standards. EN ISO 13849-1 or EN 62061 should be applied depending on the technology (mechanics,

10.2 Safety of machinery in Europe

hydraulics, pneumatics, electrics, electronics, programmable electronics), risk classification and architecture.

Standard IEC 61800-5-2:2007 is applicable for variable-speed electric drives with integrated safety functions. IEC 61800-5-2 defines requirements and gives recommendations for designing and developing, integrating and validating safety-related applications regarding their functional safety. IEC 61800-5-2 is applicable for adjustable speed electric power drive systems, which are handled in other parts of IEC 61800 standards.

	Systems for executing safety-related control functions	EN ISO 13849-1	EN 62061
A	Non-electrical (e.g. hydraulic, pneumatic)	X	Not covered
B	Electromechanical (e.g. relay and/or basic electronics)	Restricted to the designated architectures (see comment 1) and max. up to PL = e	All architectures and max. up to SIL 3
C	Complex electronics (e.g. programmable electronics)	Restricted to the designated architectures (see comment 1) and max. up to PL = d	All architectures and max. up to SIL 3
D	A standards combined with B standards	Restricted to the designated architectures (see comment 1) and max. up to PL = e	X See comment 3
E	C standards combined with B standards	Restricted to the designated architectures (see comment 1) and max. up to PL = d	All architectures and max. up to SIL 3
F	C standards combined with A standards or C standards combined with A standards and B standards	X  See comment 2	X  See comment 3
<p>"X" indicates that the point is covered by this standard.</p> <p>Comment 1: Designated architectures are described in Annex B of EN ISO 13849-1 and provide a simplified basis for the quantification.</p> <p>Comment 2: For complex electronics: Using designated architectures in compliance with EN ISO 13849-1 up to PL = d or every architecture in compliance with EN 62061.</p> <p>Comment 3: For non-electrical systems: Use components that comply with EN ISO 13849-1 as sub-systems.</p>			

## 10.2.4 DIN EN ISO 13849-1 (replaces EN 954-1)

A qualitative analysis according to DIN EN 13849-1 is not sufficient for modern control systems due to their technology. Among other things, DIN EN ISO 13849-1 does not take into account time behavior (e.g. test interval and/or cyclic test, lifetime). This results in the probabilistic approach in DIN EN ISO 13849-1 (probability of failure per unit time).

DIN EN ISO 13849-1 is based on the known categories of EN 954-1. It now also takes into account complete safety functions and all the devices required to execute these. With DIN EN ISO 13849-1, safety functions are investigated from a quantitative perspective going beyond the qualitative basis of EN 954-1. Performance levels (PL), which are based on the categories, are used. The following safety-related characteristic quantities are required for devices/equipment:

- Category (structural requirement)
- PL: Performance level
- $MTTF_d$ : Mean time to dangerous failure
  
- DC: Diagnostic coverage
  
- CCF:  
Common cause failure

The standard describes how the performance level (PL) is calculated for safety-related components of the controller on the basis of designated architectures. For deviations from this, DIN EN ISO 13849-1 refers to IEC 61508.

When combining several safety-related parts to form a complete system, the standard explains how to determine the resulting PL.

---

### **Note**

#### **DIN EN ISO 13849-1 and machinery directive**

Since May 2007, DIN EN ISO 13849-1 has been harmonized as part of the Machinery Directive.

---

## 10.2.5 EN 62061

EN 62061 (identical to IEC 62061) is a sector-specific standard subordinate to IEC/EN 61508. It describes the implementation of safety-related electrical machine control systems and looks at the complete life cycle, from the conceptual phase to decommissioning. The standard is based on the quantitative and qualitative analyses of safety functions,

whereby it systematically applies a top-down approach to implementing complex control systems (known as "functional decomposition"). The safety functions derived from the risk analysis are sub-divided into sub-safety functions, which are then assigned to real devices, sub-systems, and sub-system elements. Both the hardware and software are covered. EN 62061 also describes the requirements placed on implementing application programs.

A safety-related control systems comprises different sub-systems. From a safety perspective, the sub-systems are described in terms of the SIL claim limit and  $PFH_D$  characteristic quantities.

Programmable electronic devices (e.g. PLCs or variable-speed drives) must fulfill IEC 61508. They can then be integrated in the controller as sub-systems. The following safety-related characteristic quantities must be specified by the manufacturers of these devices.

Safety-related characteristic quantities for subsystems:

- SIL CL: SIL claim limit
- $PFH_D$ :  
Probability of dangerous failures per hour
- T1:  
Lifetime

Simple sub-systems (e.g. sensors and actuators) in electromechanical components can, in turn, comprise sub-system elements (devices) interconnected in different ways with the characteristic quantities required for determining the relevant  $PFH_D$  value of the sub-system.

Safety-related characteristic quantities for subsystem elements (devices):

- $\lambda$ :  
Failure rate
- B10 value: For elements that are subject to wear
- T1:  
Lifetime

For electromechanical devices, a manufacturer specifies a failure rate  $\lambda$  with reference to the number of operating cycles. The failure rate per unit time and the lifetime must be determined using the switching frequency for the particular application.

Parameters for the sub-system, which comprises sub-system elements, that must be defined during the design phase:

- T2:  
Diagnostic test interval
- $\beta$ :  
Susceptibility to common cause failure
- DC:  
Diagnostic coverage

The PFH<sub>D</sub> value of the safety-related controller is determined by adding the individual PFH<sub>D</sub> values for subsystems.

The user has the following options when setting up a safety-related controller:

- Use devices and sub-systems that already comply with EN ISO 13849-1, IEC/EN 61508, or IEC/EN 62061. The standard provides information specifying how qualified devices can be integrated when safety functions are implemented.
- Develop own subsystems:
  - Programmable, electronic systems and complex systems: Application of IEC 61508 or IEC 61800-5-2.
  - Simple devices and subsystems: Application of EN 62061.

EN 62061 does not include information about non-electric systems. The standard provides detailed information on implementing safety-related electrical, electronic, and programmable electronic control systems. DIN EN ISO 13849-1 must be applied for non-electric systems.

---

**Note**

**Function examples**

Details of simple sub-systems that have been implemented and integrated are now available as "functional examples".

---

**Note**

**EN 62061 and machinery directive**

IEC 62061 has been ratified as EN 62061 in Europe and harmonized as part of the Machinery Directive.

---

## 10.2.6 Series of standards IEC 61508 (VDE 0803)

This series of standards describes the current state of the art.

IEC 61508 is not harmonized in line with any EU directives, which means that an automatic presumption of conformity for fulfilling the protective requirements of a directive is not implied. The manufacturer of a safety-related product, however, can also use IEC 61508 to fulfill basic requirements of European directives in accordance with the latest conceptual design, for example, in the following cases:

- If no harmonized standard exists for the application in question. In this particular case, the manufacturer may use IEC 61508. although no presumption of conformity exists here.
- A harmonized European standard (e.g. EN 62061, EN ISO 13849, EN 60204-1) references IEC 61508. This ensures that the appropriate requirements of the directives are fulfilled ("standard that is also applicable"). When manufacturers apply IEC 61508 properly and responsibly in accordance with this reference, they can use the presumption of conformity of the referencing standard.

IEC 61508 covers all the aspects that must be taken into account when E/E/PES systems (e)lectrical, (e)lectronic, and (p)rogrammable (e)lectronic system) are used in order to execute

safety functions and/or to ensure the appropriate level of functional safety. Other hazards (e.g. electric shock) are not part of the standard, similar to DIN ISO 13849.

IEC 61508 has recently been declared the "International Basic Safety Publication", which makes it a framework for other sector-specific standards (e.g. EN 62061). As a result, this standard is now accepted worldwide, particularly in North America and in the automotive industry. Today, many regulatory bodies already stipulate it (e.g. as a basis for NRTL listing).

Another recent development with respect to IEC 61508 is its system approach, which extends the technical requirements to include the entire safety installation from the sensor to the actuator, the quantification of the probability of hazardous failure due to random hardware failures, and the creation of documentation covering all phases of the safety-related lifecycle of the E/E/PES.

### 10.2.7 Risk analysis/assessment

Risks are intrinsic in machines due to their design and functionality. For this reason, the Machinery Directive requires that a risk assessment be performed for each machine and, if necessary, the level of risk reduced until the residual risk is less than the tolerable risk. To assess these risks, the following standards must be applied:

- EN ISO 12100 "Safety of Machinery - General Design Principles - Risk Assessment and Minimizing Risks"
- EN ISO 13849-1 (successor to EN 954-1) "Safety-related parts of control systems"

EN ISO 12100 focuses on the risks to be analyzed and the design principles for minimizing risk.

The risk assessment is a procedure that allows hazards resulting from machines to be systematically investigated. Where necessary, the risk assessment is followed by a risk reduction procedure. When the procedure is repeated, this is known as an iterative process. This can help eliminate hazards (as far as this is possible) and can act as a basis for implementing suitable protective measures.

The risk assessment involves the following:

- Risk analysis
  - Determines the limits of the machine (EN ISO 12100)
  - Identification of hazards (EN ISO 12100)
  - Estimating the level of risk (EN 1050 Paragraph 7)
- Risk evaluation

As part of the iterative process to achieve the required level of safety, a risk assessment is carried out after the risk estimation. A decision must be made here as to whether the residual risk needs to be reduced. If the risk is to be further reduced, suitable protective measures must be selected and applied. The risk assessment must then be repeated.




Image 10-2 Iterative process for achieving safety

Risks must be reduced by designing and implementing the machine accordingly (e.g. by means of controllers or protective measures suitable for the safety-related functions).

If the protective measures involve the use of interlocking or control functions, these must be designed according to EN ISO 13849-1. For electrical and electronic control systems, EN 62061 can be applied instead of EN ISO 13849-1. Electronic controllers and bus systems must also comply with IEC 61508.

### 10.2.8 Risk reduction

Risk reduction measures for a machine can be implemented by means of safety-related control functions in addition to structural measures. To implement these control functions, special requirements must be taken into account, graded according to the magnitude of the risk. These are described in EN ISO 13849-1 or, in the case of electrical controllers (particularly programmable electronics), in EN 61508 or EN 62061. The requirements regarding safety-related controller components are graded according to the magnitude of the risk and the level to which the risk needs to be reduced.

**EN ISO 13849-1** defines a risk flow chart that instead of categories results in hierarchically graduated Performance Levels (PL).

**IEC/EN 62061** uses "Safety Integrity Level" (SIL) for classification purposes. This is a quantified measure of the safety-related performance of a controller. The required SIL is also determined in accordance with the risk assessment principle according to ISO 12100 (EN 1050). Annex A of the standard describes a method for determining the required Safety Integrity Level (SIL).

Regardless of which standard is applied, steps must be taken to ensure that all the machine controller components required for executing the safety-related functions fulfill these requirements.

### 10.2.9 Residual risk

In today's technologically advanced world, the concept of safety is relative. The ability to ensure safety to the extent that risk is ruled out in all circumstances – "zero-risk guarantee" – is practically impossible. The residual risk is the risk that remains once all the relevant protective measures have been implemented in accordance with the latest state of the art.

Residual risks must be clearly referred to in the machine/plant documentation (user information according to EN ISO 12100).

### 10.2.10 EC declaration of conformity

The EC Declaration of Conformity for the product can be found on the Internet at:

<http://support.automation.siemens.com>

Enter the number 67385845 there as the search term or contact your local Siemens office.



## 10.3 Machine safety in the USA

A key difference between the USA and Europe in the legal requirements regarding safety at work is that, in the USA, no legislation exists regarding machinery safety that is applicable in all of the states and that defines the responsibility of the manufacturer/supplier. A general requirement exists stating that employers must ensure a safe workplace.

### 10.3.1 Minimum requirements of the OSHA

The Occupational Safety and Health Act (OSHA) from 1970 regulates the requirement that employers must offer a safe place of work. The core requirements of OSHA are specified in Section 5 "Duties".

The requirements of the OSH Act are managed by the "Occupational Safety and Health Administration" (also known as OSHA). OSHA employs regional inspectors who check whether or not workplaces comply with the applicable regulations.

The OSHA regulations are described in OSHA 29 CFR 1910.xxx ("OSHA Regulations (29 CFR) PART 1910 Occupational Safety and Health"). (CFR: Code of Federal Regulations.)

<http://www.osha.gov>

The application of standards is regulated in 29 CFR 1910.5 "Applicability of standards". The concept is similar to that used in Europe. Product-specific standards have priority over general standards insofar as they cover the relevant aspects. Once the standards are fulfilled, employers can assume that they have fulfilled the core requirements of the OSH Act with respect to the aspects covered by the standards.

In conjunction with certain applications, OSHA requires that all electrical equipment and devices that are used to protect workers be authorized by an OSHA-certified, "Nationally Recognized Testing Laboratory" (NRTL) for the specific application.

In addition to the OSHA regulations, the current standards defined by organizations such as NFPA and ANSI must be carefully observed and the extensive product liability legislation that exists in the US taken into account. Due to the product liability legislation, it is in the interests of manufacturing and operating companies that they carefully maintain the applicable regulations and are "forced" to fulfill the requirement to use state-of-the-art technology.

Third-party insurance companies generally demand that their customers fulfill the applicable standards of the standards organizations. Self-insured companies are not initially subject to this requirement but, in the event of an accident, they must provide verification that they have applied generally-recognized safety principles.

### 10.3.2 NRTL listing

To protect employees, all electrical equipment used in the USA must be certified for the planned application by a "Nationally Recognized Testing Laboratory" (NRTL) certified by the OSHA. NRTLs are authorized to certify equipment and material by means of listing, labeling, or similar. Domestic standards (e.g. NFPA 79) and international standards (e.g. IEC/EN 61508 for E/E/PES systems) are the basis for testing.

### 10.3.3 NFPA 79

Standard NFPA 79 (Electrical Standard for Industrial Machinery) applies to electrical equipment on industrial machines with rated voltages of less than 600 V. A group of machines that operate together in a coordinated fashion is also considered to be one machine.

For programmable electronics and communication buses, NFPA 79 states as a basic requirement that these must be listed if they are to be used to implement and execute safety-related functions. If this requirement is fulfilled, then electronic controls and communication buses can also be used for Emergency Stop functions, Stop Categories 0 and 1 (refer to NFPA 79 9.2.5.4.1.4). Just the same as EN 60204-1, NFPA 79 no longer specifies that the electrical energy must be disconnected by electromechanical means for emergency stop functions.

The core requirements regarding programmable electronics and communication buses in accordance with NFPA 79 9.4.3:

1. Control systems that contain software-based controllers must:
  - In the event of a single fault
    - (a) Initiate that the system switches to a safe shutdown mode
    - (b) Prevent the system from restarting until the fault has been rectified
    - (c) Prevent an unexpected restart
  - Offer the same level of protection as hard-wired controllers
  - Be implemented in accordance with a recognized standard that defines the requirements for such systems.
2. IEC 61508, IEC 62061, ISO 13849-1, ISO 13849-2 and IEC 61800-5-2 are specified as suitable standards in a note.

**Underwriter Laboratories Inc. (UL)** has defined a special category for "Programmable Safety Controllers" for implementing this requirement (code NRGF). This category covers control devices that contain software and are designed for use in safety-related functions.

A precise description of the category and a list of devices that fulfill this requirement can be found on the Internet at the following address:

<http://www.ul.com> → Online Certifications Directory → UL Category code/Guide information → search for category "NRGF"

**TUV Rheinland of North America, Inc.** is also an NRTL for these applications.

### 10.3.4 ANSIB11

ANSI B11 standards are joint standards developed by associations such as the Association for Manufacturing Technology (AMT) and the Robotic Industries Association (RIA).

The hazards of a machine are evaluated by means of a risk analysis/assessment. The risk analysis is an important requirement in accordance with NFPA 79, ANSI/RIA 15.06, ANSI B11.TR-3 and SEMI S10 (semiconductors). The documented results of a risk analysis can be used to select a suitable safety system based on the safety class of the application in question.

## 10.4 Machine safety in Japan

The situation in Japan is different from that in Europe and the US. Legislation such as that prescribed in Europe does not exist. Similarly, product liability does not play such an important role as it does in the US.

Instead of legal requirements to apply standards have been defined, an administrative recommendation to apply JIS (Japanese Industrial Standard) is in place: Japan bases its approach on the European concept and uses basic standards as national standards (see table).

Table 10- 1 Japanese standards

ISO/IEC number	JIS number	Comment
ISO12100 (EN 1050)	JIS B 9700, JIS B 9702	earlier designation TR B 0008 and TR B 0009
ISO13849-1	JIS B 9705-1	
ISO13849-2	JIS B 9705-1	
IEC 60204-1	JIS B 9960-1	Without annex F or route map of the European foreword
IEC 61508-0 to -7	JIS C 0508	
IEC 62061		JIS number not yet assigned

## **10.5 Equipment regulations**

In addition to the requirements of the guidelines and standards, company-specific requirements must be taken into account. Large corporations in particular (e.g. automobile manufacturers) make stringent demands regarding automation components, which are often listed in their own equipment specifications.

Safety-related issues (e.g. operating modes, operator actions with access to hazardous areas, EMERGENCY STOP concepts, etc.) should be clarified with customers early on so that they can be integrated in the risk assessment/risk reduction process.

## 10.6 Other safety-related issues

### 10.6.1 Information sheets issued by the Employer's Liability Insurance Association

Safety-related measures to be implemented cannot always be derived from directives, standards, or regulations. In this case, supplementary information and explanations are required.

Some regulatory bodies issue publications on an extremely wide range of subjects.

---

#### Note

These publications are in German. In some instances, they are also available in English and French.

---

Information sheets covering the following areas are available, for example:

- Process monitoring in production environments
- Axes subject to gravitational force
- Roller pressing machines
- Lathes and turning centers - purchasing/selling

These information sheets issued by specialist committees can be obtained by all interested parties (e.g. to provide support in factories, or when regulations or safety-related measures for plants and machines are defined). These information sheets provide support for the fields of machinery construction, production systems, and steel construction.

You can download the information sheets from the Internet address (<http://www.bghm.de/>) (website is in German, although some of the sheets are available in English):

1. First select the area "Arbeitsschützer", followed by the menu item "Praxishilfen" and finally "DGUV-Informationen".

### 10.6.2 Additional references

- Safety Integrated, The Safety Program for Industries of the World (5th Edition and Supplement), Article No. 6ZB5 000-0AA01-0BA1
- Safety Integrated - Terms and Standards - Machine Safety Terminology (Edition 04/2007), Article No. E86060-T1813-A101-A1



# Appendix

## A.1 List of abbreviations

---

### Note

The following list of abbreviations includes all abbreviations and their meanings used in the entire SINAMICS family of drives.

---

Abbreviation	Source of abbreviation	Significance
<b>A</b>		
A...	Alarm	Warning
AC	Alternating Current	Alternating current
ADC	Analog Digital Converter	Analog-Digital converter
AI	Analog Input	Analog input
AIM	Active Interface Module	Active Interface Module
ALM	Active Line Module	Active Line Module
AO	Analog Output	Analog output
AOP	Advanced Operator Panel	Advanced Operator Panel
APC	Advanced Positioning Control	Advanced Positioning Control
AR	Automatic Restart	Automatic restart
ASC	Armature Short Circuit	Armature short-circuit
ASCII	American Standard Code for Information Interchange	American coding standard for the exchange of information
AS-i	AS-Interface (Actuator Sensor Interface)	AS-interface (open bus system in automation technology)
ASM	Asynchronmotor	Induction motor
<b>B</b>		
BB	Betriebsbedingung	Operation condition
BERO	-	Contactless proximity switch
BI	Binector Input	Binector input
BIA	Berufsgenossenschaftliches Institut für Arbeitssicherheit	BG-Institute for Occupational Safety and Health
BICO	Binector Connector Technology	Binector connector technology
BLM	Basic Line Module	Basic Line Module

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
BO	Binector Output	Binector output
BOP	Basic Operator Panel	Basic operator panel
<b>C</b>		
C	Capacitance	Capacitance
C...	-	Safety message
CAN	Controller Area Network	Serial bus system
CBC	Communication Board CAN	Communication Board CAN
CBE	Communication Board Ethernet	PROFINET communication module (Ethernet)
CD	Compact Disc	Compact disk
CDS	Command Data Set	Command data set
CF Card	CompactFlash Card	CompactFlash card
CI	Connector Input	Connector input
CLC	Clearance Control	Clearance control
CNC	Computerized Numerical Control	Computer-supported numerical control
CO	Connector Output	Connector output
CO/BO	Connector Output / Binector Output	Connector Output / Binector Output
COB ID	CAN Object-Identification	CAN Object-Identification
CoL	Certificate of License	Certificate of License
COM	Common contact of a changeover relay	Center contact of a changeover contact
COMM	Commissioning	Startup
CP	Communication Processor	Communications processor
CPU	Central Processing Unit	Central processing unit
CRC	Cyclic Redundancy Check	Cyclic redundancy check
CSM	Control Supply Module	Control Supply Module
CU	Control Unit	Control Unit
CUA	Control Unit Adapter	Control Unit Adapter
CUD	Control Unit DC	Control Unit DC
<b>D</b>		
DAC	Digital Analog Converter	Digital analog converter
DC	Direct Current	DC current
DCB	Drive Control Block	Drive Control Block
DCBRK	DC Brake	DC braking
DCC	Drive Control Chart	Drive Control Chart
DCN	Direct Current Negative	Direct current negative
DCP	Direct Current Positive	Direct current positive
DDC	Dynamic Drive Control	Dynamic Drive Control
DDS	Drive Data Set	Drive Data Set
DI	Digital Input	Digital input
DI/DO	Digital Input / Digital Output	Digital input/output, bidirectional
DMC	DRIVE-CLiQ Hub Module Cabinet	DRIVE-CLiQ Hub Module Cabinet



<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
DME	DRIVE-CLiQ Hub Module External	DRIVE-CLiQ Hub Module External
DMM	Double Motor Module	Double Motor Module
DO	Digital Output	Digital output
DO	Drive Object	Drive object
DP	Decentralized Peripherals	Distributed I/O
DPRAM	Dual-Port Random Access Memory	Dual-Port Random Access Memory
DQ	DRIVE-CLiQ	DRIVE-CLiQ
DRAM	Dynamic Random Access Memory	Dynamic Random Access Memory
DRIVE-CLiQ	Drive Component Link with IQ	Drive Component Link with IQ
DSC	Dynamic Servo Control	Dynamic Servo Control
DTC	Digital Time Clock	Timer
<b>E</b>		
EASC	External Armature Short-Circuit	External armature short-circuit
EDS	Encoder Data Set	Encoder data set
EEPROM	Electrically Erasable Programmable Read-Only Memory	Electrically Erasable Programmable Read-Only-Memory
EGB	Elektrostatisch gefährdete Baugruppen	Electrostatic sensitive devices
ELCB	Earth Leakage Circuit-Breaker	Residual current operated circuit breaker
ELP	Earth Leakage Protection	Ground-fault monitoring
EMC	Electromagnetic Compatibility	Electromagnetic compatibility
EMF	Electromotive Force	Electromotive force
EMK	Elektromotorische Kraft	Electromotive force
EMV	Elektromagnetische Verträglichkeit	Electromagnetic compatibility
EN	Europäische Norm	European Standard
EnDat	Encoder-Data-Interface	Encoder interface
EP	Enable Pulses	Pulse enable
EPOS	Einfachpositionierer	Basic positioner
ES	Engineering System	Engineering system
ESB	Ersatzschaltbild	Equivalent circuit diagram
ESD	Electrostatically Sensitive Devices	Electrostatic sensitive devices
ESM	Essential Service Mode	Essential service mode
ESR	Extended Stop and Retract	Extended stop and retract
<b>F</b>		
F...	Fault	Fault
FAQ	Frequently Asked Questions	Frequently Asked Questions
FBLOCKS	Free Blocks	Free function blocks
FCC	Function control chart	Function control chart
FCC	Flux Current Control	Flux current control
FD	Function Diagram	Function diagram
F-DI	Fail-safe Digital Input	Failsafe digital input

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
F-DO	Fail-safe Digital Output	Fail-safe digital output
FEPRM	Flash-EPRM	Non-volatile write and read memory
FG	Function Generator	Function Generator
FI	-	Fault current
FOC	Fiber-Optic Cable	Fiber-optic cable
FP	Funktionsplan	Function diagram
FPGA	Field Programmable Gate Array	Field Programmable Gate Array
FW	Firmware	Firmware
<b>G</b>		
GB	Gigabyte	Gigabyte
GC	Global Control	Global control telegram (broadcast telegram)
GND	Ground	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as M)
GSD	Gerätstammdatei	Generic Station Description: Describes the features of a PROFIBUS slave
GSV	Gate Supply Voltage	Gate supply voltage
GUID	Globally Unique Identifier	Globally Unique Identifier
<b>H</b>		
HF	High Frequency	High frequency
HFD	Hochfrequenzdrossel	Radio frequency reactor
HLA	Hydraulic Linear Actuator	Hydraulic linear actuator
HLG	Hochlaufgeber	Ramp-function Generator
HM	Hydraulic Module	Hydraulic Module
HMI	Human Machine Interface	Human Machine Interface
HTL	High-Threshold Logic	Logic with high interference threshold
HW	Hardware	Hardware
<b>I</b>		
i. V.	In Vorbereitung	Under development: This property is currently not available
I/O	Input/Output	Input/output
I2C	Inter-Integrated Circuit	Internal serial data bus
IASC	Internal Armature Short-Circuit	Internal armature short-circuit
IBN	Inbetriebnahme	Startup
ID	Identifier	Identification
IE	Industrial Ethernet	Industrial Ethernet
IEC	International Electrotechnical Commission	International Electrotechnical Commission
IF	Interface	Interface
IGBT	Insulated Gate Bipolar Transistor	Insulated gate bipolar transistor
IGCT	Integrated Gate-Controlled Thyristor	Semiconductor power switch with integrated control electrode

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
IL	Impulslöschung	Pulse suppression
IP	Internet Protocol	Internet protocol
IPO	Interpolator	Interpolator
IT	Isolé Terre	Non-grounded three-phase line supply
IVP	Internal Voltage Protection	Internal voltage protection
<b>J</b>		
JOG	Jogging	Jogging
<b>K</b>		
KDV	Kreuzweiser Datenvergleich	Data cross-check
KHP	Know-How Protection	Know-how protection
KIP	Kinetische Pufferung	Kinetic buffering
Kp	-	Proportional gain
KTY84	-	Temperature sensor
<b>L</b>		
L	-	Symbol for inductance
LED	Light Emitting Diode	Light emitting diode
LIN	Linearmotor	Linear motor
LR	Lageregler	Position controller
LSB	Least Significant Bit	Least Significant Bit
LSC	Line-side converter	Line-side converter
LSS	Line-Side Switch	Line-side switch
LU	Length Unit	Length unit
LWL	Lichtwellenleiter	Fiber-optic cable
<b>M</b>		
M	-	Symbol for torque
M	Masse	Reference potential for all signal and operating voltages, usually defined as 0 V (also referred to as GND)
MB	Megabyte	Megabyte
MCC	Motion Control Chart	Motion Control Chart
MDI	Manual Data Input	Manual data input
MDS	Motor Data Set	Motor data set
MLFB	Maschinenlesbare Fabrikatebezeichnung	Machine-readable product code
MM	Motor Module	Motor Module
MMC	Man-Machine Communication	Man-machine communication
MMC	Micro Memory Card	Micro memory card
MSB	Most Significant Bit	Most significant bit
MSC	Motor Side Converter	Motor-side converter
MSCY_C1	Master Slave Cycle Class 1	Cyclic communication between master (class 1) and slave

A.1 List of abbreviations

Abbreviation	Source of abbreviation	Significance
MSC	Motorstromrichter	Motor-side converter
MT	Messtaster	Probe
<b>N</b>		
N. C.	Not Connected	Not connected
N...	No Report	No report or internal message
NAMUR	Normenarbeitsgemeinschaft für Mess- und Regeltechnik in der chemischen Industrie	Standardization association for measurement and control in chemical industries
NC	Normally Closed (contact)	NC contacts
NC	Numerical Control	Numerical control
NEMA	National Electrical Manufacturers Association	Standardization association in USA (United States of America)
NM	Nullmarke	Zero mark
NO	Normally Open (contact)	NO contacts
NSR	Netzstromrichter	Line-side converter
NVRAM	Non-Volatile Random Access Memory	Non-volatile read/write memory
<b>O</b>		
OA	Open Architecture	Software component which provides additional functions for the SINAMICS drive system
OAIF	Open Architecture Interface	Version of the SINAMICS firmware as of which the OA-application can be used
OASP	Open Architecture Support Package	Expands the STARTER commissioning tool by the corresponding OA-application
OC	Operating Condition	Operation condition
OEM	Original Equipment Manufacturer	Original equipment manufacturer
OLP	Optical Link Plug	Bus connector for fiber-optic cable
OMI	Option Module Interface	Option Module Interface
<b>P</b>		
p...	-	Adjustable parameters
P1	Processor 1	CPU 1
P2	Processor 2	CPU 2
PB	PROFIBUS	PROFIBUS
PcCtrl	PC Control	Master control
PD	PROFIdrive	PROFIdrive
PDC	Precision Drive Control	Precision Drive Control
PDS	Power Unit Data Set	Power unit data set
PE	Protective Earth	Protective ground
PELV	Protective Extra-Low Voltage	Safety extra-low voltage
PFH	Probability of dangerous failure per hour	Probability of dangerous failure per hour
PG	Programmiergerät	Programming device
PI	Proportional integral	Proportional integral
PID	Proportional integral differential	Proportional integral differential

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
PLC	Programmable Logic Controller	Programmable logic controller
PLL	Phase-locked loop	Phase-locked loop
PM	Power Module	Power Module
PMSM	Permanent-Magnet Synchronous Motor	Permanent-magnet synchronous motor
PN	PROFINET	PROFINET
PNO	PROFIBUS Nutzerorganisation	PROFIBUS user organization
PPI	Point-to-Point Interface	Point-to-point interface
PRBS	Pseudo Random Binary Signal	White noise
PROFIBUS	Process Field Bus	Serial data bus
PS	Power Supply	Power supply
PSA	Power Stack Adapter	Power Stack Adapter
PT1000	-	Temperature sensor
PTC	Positive Temperature Coefficient	Positive temperature coefficient
PTP	Point-To-Point	Point-to-point
PWM	Pulse Width Modulation	Pulse width modulation
PZD	Prozessdaten	Process data
<b>Q</b>		
<b>R</b>		
r...	-	Display parameters (read only)
RAM	Random Access Memory	Speicher zum Lesen und Schreiben
RCCB	Residual Current Circuit Breaker	Residual current operated circuit breaker
RCD	Residual Current Device	Residual current operated circuit breaker
RCM	Residual Current Monitor	Residual current monitor
REL	Reluctance motor textile	Reluctance motor textile
RESM	Reluctance Synchronous Motor	Synchronous reluctance motor
RFG	Ramp-Function Generator	Ramp-function Generator
RJ45	Registered Jack 45	Term for an 8-pin socket system for data transmission with shielded or non-shielded multi-wire copper cables
RKA	Rückkühlanlage	Cooling unit
RLM	Renewable Line Module	Renewable Line Module
RO	Read Only	Read only
ROM	Read-Only Memory	Read-only memory
RPDO	Receive Process Data Object	Receive Process Data Object
RS232	Recommended Standard 232	Interface standard for a cable-connected serial data transmission between a sender and receiver (also known as EIA232)
RS485	Recommended Standard 485	Interface standard for a cable-connected differential, parallel, and/or serial bus system (data transmission between a number of senders and receivers, also known as EIA485)

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
RTC	Real-Time Clock	Real-time clock
RZA	Raumzeigerapproximation	Space-vector approximation
<b>S</b>		
S1	-	Continuous operation
S3	-	Intermittent duty
SAM	Safe Acceleration Monitor	Safe acceleration monitoring
SBC	Safe Brake Control	Safe brake control
SBH	Sicherer Betriebshalt	Safe operating stop
SBR	Safe Brake Ramp	Safe brake ramp monitoring
SBT	Safe Brake Test	Safe brake test
SCA	Safe Cam	Safe cam
SCC	Safety Control Channel	Safety Control Channel
SD Card	SecureDigital Card	Secure digital memory card
SDC	Standard Drive Control	Standard Drive Control
SDI	Safe Direction	Safe motion direction
SE	Sicherer Software-Endschalter	Safe software limit switch
SESM	Separately Excited Synchronous Motor	Separately excited synchronous motor
SG	Sicher reduzierte Geschwindigkeit	Safely-limited speed
SGA	Sicherheitsgerichteter Ausgang	Safety-related output
SGE	Sicherheitsgerichteter Eingang	Safety-related input
SH	Sicherer Halt	Safe stop
SI	Safety Integrated	Safety Integrated
SIC	Safety Info Channel	Safety Info Channel
SIL	Safety Integrity Level	Safety Integrity Level
SITOP	-	Siemens power supply system
SLM	Smart Line Module	Smart Line Module
SLP	Safely Limited Position	Safely Limited Position
SLS	Safely-Limited Speed	Safely-limited speed
SLVC	Sensorless Vector Control	Sensorless vector control
SM	Sensor Module	Sensor Module
SMC	Sensor Module Cabinet	Sensor Module Cabinet
SME	Sensor Module External	Sensor Module External
SMI	SINAMICS Sensor Module Integrated	SINAMICS Sensor Module Integrated
SMM	Single Motor Module	Single Motor Module
SN	Sicherer Software-Nocken	Safe software cam
SOS	Safe Operating Stop	Safe operating stop
SP	Service Pack	Service pack
SP	Safe Position	Safe position
SPC	Setpoint Channel	Setpoint channel
SPI	Serial Peripheral Interface	Serial peripheral interface

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
SPS	Speicherprogrammierbare Steuerung	Programmable logic controller
SS1	Safe Stop 1	Safe Stop 1 (monitored for time and ramp)
SS1E	Safe Stop 1 External	Safe Stop 1 with external stop
SS2	Safe Stop 2	Safe Stop 2
SS2E	Safe Stop 2 External	Safe Stop 2 with external stop
SSI	Synchronous Serial Interface	Synchronous serial interface
SSM	Safe Speed Monitor	Safe feedback from speed monitor
SSP	SINAMICS support package	SINAMICS support package
STO	Safe Torque Off	Safe torque off
STW	Steuerwort	Control word
<b>T</b>		
TB	Terminal Board	Terminal Board
TEC	Technology Extension	Software component which is installed as an additional technology package and which expands the functionality of SINAMICS (previously OA-application)
TIA	Totally Integrated Automation	Totally Integrated Automation
TM	Terminal Module	Terminal Module
TN	Terre Neutre	Grounded three-phase line supply
Tn	-	Integral time
TPDO	Transmit Process Data Object	Transmit Process Data Object
TT	Terre Terre	Grounded three-phase line supply
TTL	Transistor-Transistor Logic	Transistor-Transistor-Logik
Tv	-	Rate time
<b>U</b>		
UL	Underwriters Laboratories Inc.	Underwriters Laboratories Inc.
UPS	Uninterruptible Power Supply	Uninterruptible power supply
USV	Unterbrechungsfreie Stromversorgung	Uninterruptible power supply
UTC	Universal Time Coordinated	Universal time coordinated
<b>V</b>		
VC	Vector Control	Vector control
Vdc	-	DC-link voltage
VdcN	-	Partial DC-link voltage negative
VdcP	-	Partial DC-link voltage positive
VDE	Verband Deutscher Elektrotechniker	Verband Deutscher Elektrotechniker [Association of German Electrical Engineers]
VDI	Verein Deutscher Ingenieure	Verein Deutscher Ingenieure [Association of German Engineers]
VPM	Voltage Protection Module	Voltage Protection Module
Vpp	Volt peak to peak	Volt peak to peak
VSM	Voltage Sensing Module	Voltage Sensing Module

A.1 List of abbreviations

---

<b>Abbreviation</b>	<b>Source of abbreviation</b>	<b>Significance</b>
<b>W</b>		
WEA	Wiedereinschaltautomatik	Automatic restart
WZM	Werkzeugmaschine	Machine tool
<b>X</b>		
XML	Extensible Markup Language	Extensible markup language (standard language for Web publishing and document management)
<b>Y</b>		
<b>Z</b>		
ZK	Zwischenkreis	DC link
ZM	Zero Mark	Zero mark
ZSW	Zustandswort	Status Word



## A.2 Documentation overview

General documentation/catalogs			
SINAMICS	G110	D11.1	- Inverter built-in units 0.12 kW up to 3 kW
	G120	D31	- SINAMICS Inverters for Single-Axis Drives and SIMOTICS Motors
	G130, G150	D11.1	- Inverter built-in units - Inverter cabinet units
	S120, S150	D21.3	- SINAMICS S120 Built-in units in the Chassis format and Cabinet Modules - SINAMICS S150 Drive Converter Cabinet Units
SIMOTION, SINAMICS	S120	PM21	- SIMOTION, SINAMICS S120 and Motors for Production Machines
Manufacturer/service documentation			
SINAMICS	G110		- Getting Started - Operating instructions - List Manuals
	G120		- Getting Started - Operating instructions - Hardware Installation Manuals - Function Manual Safety Integrated - List Manuals
	G130		- Operating instructions - List Manual
	G150		- Operating instructions - List Manual
	GM150, SM120/SM150, GL150, SL150		- Operating instructions - List Manuals
	S110		- Manual - Getting Started - Function Manual - List Manual
	S120		- Getting Started with STARTER - Commissioning Manual with STARTER - Getting Started with Startdrive (available as of Startdrive V14 release) - Commissioning Manual with Startdrive (available as of Startdrive V14 release) - Commissioning Manual CANopen - Function Manual Drive Functions - Function Manual Safety Integrated - Function Manual DCC - List Manual - Manual Control Unit and supplementary system components - Manual LT Booksize - Manual LT Booksize C/D Type - Manual LT Chassis air-cooled - Manual LT Chassis liquid-cooled - Manual Combi - Manual Cabinet Modules - Manual AC Drive - SINAMICS S120M Manual Distributed Drive Technology - SINAMICS HLA System Manual Hydraulic Drive
	S150		- Operating instructions - List Manual
Motors			- Configuration Manuals, Motors
General			- Configuration Manual, EMC Guidelines

### Significant changes with respect to the Manual, Edition 04/2014

<b>New functions in Firmware V4.8</b>	<b>See Chapter</b>
Control of Basic Functions via TM54F	Control via TM54F (Page 190) and various other points
The Extended Functions SS1 and SS2 can be parameterized with SAM or SBR if the motor is operated with an encoder.	Safe Stop 1 (SS1) (Page 87), Safe Stop 2 (SS2) (Page 94) and various other points
Safe Stop 2 with external stop (SS2E)	SS2 with external stop (SS2E) (Page 96)

<b>Revised/supplementary descriptions</b>	<b>See Chapter</b>
	Note relating to safe actual value sensing using an encoder system (Page 147)
	Relevant checksums for the acceptance (Page 408)

---

#### Note

An overview of the availability of hardware components and software functions is provided in the appendix of the following literature:

- SINAMICS S120 Function Manual Drive Functions
-

## A.3 Acceptance tests (recommendations)

### A.3.1 Contents and depth of the acceptance test

#### A.3.1.1 Content of the complete acceptance test

##### A) Documentation

Documentation of the machine and of safety functions

- Machine description (with overview)
- Specification of the controller (if this exists)
- Function table:
  - Active monitoring functions depending on the operating mode and the protective door
  - Other sensors with protective functions
  - The table is part or is the result of the configuring work.
- SI functions for each drive
- Information about safety equipment

##### B) Functional testing of safety functions

Detailed function test and evaluation of SI functions used. For some functions, trace recordings of individual parameters can be used. The procedure is described in detail in Section Acceptance tests (Page 420).

- Encoder parameterization test
  - Required when using the Extended Functions with encoder
  - Only required at an encoder replacement
- Test of the SI function "Safe Torque Off" (STO)
  - Required when used in Basic and/or Extended Functions
- Test of the SI function "Safe Stop 1" (SS1)
  - Required when used in Basic and/or Extended Functions
  - If the Extended Functions are used, a trace recording of individual parameters can be used.
- Test of the SI function "Safe Brake Control" (SBC)
  - Required when using Basic and/or Extended Functions
- Test of the SI function "Safe Brake Test" (SBT)
  - If the Extended Functions are used, a trace recording of individual parameters can be used.
- Test of the SI function "Safe Stop 2" (SS2)
  - For this purpose, a trace recording of individual parameters can be used.

- Test of the SI function "Safe Operating Stop" (SOS)
  - For this purpose, a trace recording of individual parameters can be used.
- Test of the SI function "Safely-Limited Speed" (SLS)
  - For this purpose, a trace recording of individual parameters can be used.
- Test of the SI function "Safe Direction" (SDI)
  - For this purpose, a trace recording of individual parameters can be used.
- Test of the SI function "Safe Speed Monitor" (SSM)
  - For this purpose, a trace recording of individual parameters can be used.
- Test of the SI function "Safely-Limited Position" (SLP)
  - For this purpose, a trace recording of individual parameters can be used.

**C) Functional testing of forced dormant error detection (test stop)**

Test of the forced dormant error detection (test stop) of the safety functions on each drive (for the Basic and/or Extended Functions) and the TM54F (if used).

- Test of the forced dormant error detection (test stop) of the safety function on the drive
  - If you are using Basic Functions, you need to activate and then deactivate STO once again.
  - If you are using Extended Functions, you need to perform forced dormant error detection (test stop).
- Forced dormant error detection (test stop) of the TM54F (if available)
  - Perform forced dormant error detection (test stop) of the TM54F
- Forced dormant error detection (test stop) of the CU310-2 (if available)
  - Perform forced dormant error detection (test stop) of the CU310-2

**D) Conclusion of the report**

Report of the commissioning status tested and countersignatures

- Inspection of SI parameters
- Logging of checksums (for each drive)
- Issuing of the safety password and documenting this process (do not specify the safety password in the report!)
- RAM to ROM backup, upload of project data to STARTER, and backup of the project
- Countersignature

### A.3.1.2 Content of the partial acceptance test

#### A) Documentation

Documentation of the machine and of safety functions

1. Extending/changing the hardware data
2. Extending/changing the software data (specify version)
3. Extending/changing the function table:
  - Active monitoring functions depending on the operating mode and the protective door
  - Other sensors with protective functions
  - The table is part or is the result of the configuring work
4. Extending/changing the SI functions per drive
5. Extending/changing the specifications of the safety equipment

#### B) Functional testing of safety functions

Detailed function test and evaluation of SI functions used. For some functions, trace recordings of individual parameters can be used. The procedure is described in detail in Section Acceptance tests (Page 420).

1. Test of the SI function "Safe Torque Off" (STO)
  - Required when used in Basic and/or Extended Functions
  - You do not need to prepare a trace recording for this test.
2. Test of the SI function "Safe Stop 1" (SS1)
  - Required when used in Basic and/or Extended Functions
  - If the Extended Functions are used, a trace recording of individual parameters can be used.
3. Test of the SI function "Safe Brake Control" (SBC)
  - Required when using Basic and/or Extended Functions
  - You do not need to prepare a trace recording for this test.
4. Test of the SI function "Safe Brake Test" (SBT)
  - Required when using the Extended Functions
5. Test of the SI function "Safe Stop 2" (SS2)
  - For this purpose, a trace recording of individual parameters can be used.
6. Test of the SI function "Safe Operating Stop" (SOS)
  - For this purpose, a trace recording of individual parameters can be used.
7. Test of the SI function "Safely-Limited Speed" (SLS)
  - For this purpose, a trace recording of individual parameters can be used.
8. Test of the SI function "Safe Direction" (SDI)
  - For this purpose, a trace recording of individual parameters can be used.

- 9. Test of the SI function "Safe Speed Monitor" (SSM)
  - For this purpose, a trace recording of individual parameters can be used.
- 10. Test of the SI function "Safely-Limited Position" (SLP)
  - For this purpose, a trace recording of individual parameters can be used.


**C) Functional testing of forced dormant error detection (test stop)**

Test of the forced dormant error detection (test stop) of the safety functions on each drive (for the Basic and/or Extended Functions) and the TM54F (if used).

- 1. Test of the forced dormant error detection (test stop) of the safety function on the drive
  - If you are using Basic Functions, you need to activate and then deactivate STO once again.
  - If you are using Extended Functions, you need to perform forced dormant error detection (test stop).
- 2. Forced dormant error detection (test stop) of the TM54F (if available)
  - Perform forced dormant error detection (test stop) of the TM54F
- 3. Forced dormant error detection (test stop) of the CU310-2 (if available)
  - Perform forced dormant error detection (test stop) of the CU310-2

**D) Functional testing of actual value acquisition**

- 1. General testing of actual value acquisition
  - After exchanging the component, initial activation and brief operation in both directions.

 <b>WARNING</b>
<b>Risk through process</b> The operation causes the machine to move. <ul style="list-style-type: none"><li>• During this process, all personnel must keep out of the danger area.</li></ul>

- 2. Test of fail-safe actual value acquisition
  - Only necessary if Extended Functions are used
  - If the motion monitoring functions are activated (e.g. SLS or SSM with hysteresis), briefly operate the drive in both directions.
- 3. Encoder parameterization test
  - Required when using the Extended Functions with encoder
  - Only required at an encoder replacement
  - You do not need to prepare a trace recording for this test.

**E) Conclusion of the report**

Report of the commissioning status tested and countersignatures

- 1. Extension of checksums (for each drive)
- 2. Countersignature

### A.3.1.3 Test scope for specific measures

#### Scope of partial acceptance tests for specific measures

The measures and points specified in the table refer to the information given in Section Content of the partial acceptance test (Page 405).

Table A- 1 Scope of partial acceptance tests for specific measures

Measure	A) Documentation	B) Functional testing of safety functions	C) Functional testing of forced dormant error detection (test stop)	D) Functional testing of actual value acquisition	E) Conclusion of the report
Replacement of the encoder system	No	No	No	Yes	Yes
Replacement of an SMC/SME	Yes, Points 1 and 2	No	No	Yes	Yes
Replacement of a motor with DRIVE-CLiQ	Yes, Points 1 and 2	No	No	Yes	Yes
Replacement of the following hardware: Control Unit, Motor Module, Power Module, or Safe Brake Relay	Yes, Points 1 and 2	Yes, Points 1 or 2 and 3	Yes, only Point 1	Yes, only Point 1	Yes
Replacement of the TM54F	Yes, Points 1 and 2	Yes, but only testing of the selection of the safety functions	Yes	Yes, only Point 1	Yes
Firmware modification <sup>1)</sup> (CU / power unit / Sensor Modules)	Yes, only Point 2	Yes, if new safety functions are to be used	Yes	Yes, only Point 1	Yes
Change to a single parameter of a safety function (e.g. SLS limit)	Yes, Points 4 and 5.	Yes, test the appropriate function	No	Yes	Yes
Transfer of project data to other machines (series commissioning)	Yes	Yes, but only testing of the selection of the safety functions	Yes	Yes	Yes
Other firmware version <sup>1)</sup> on Simotion D	Yes, only Point 2	Yes, if new safety functions are to be used	Yes	Yes, only Point 1	Yes

<sup>1)</sup> Upgrading or downgrading

**A.3.1.4 Relevant checksums for the acceptance**

**Checksums of the safety functions**

The following checksums are available for every drive with activated safety functions.

Safety function/parameters	Checksum	Reason for changing the checksum
<b>Basic Functions</b>		
p9799	Reference checksum (channel 1)	Changing the safety parameters of basic functions
p9899	Reference checksum (channel 2)	
<b>Extended Functions</b>		
p9799	Reference checksum (channel 1)	Changing the safety parameters of extended functions
p9899	Reference checksum (channel 2)	
p9729[0]	Reference checksum SI parameters for motion monitoring (channel 1)	Changing the safety parameters of extended functions, which do not refer to encoder data
p9729[1]	Reference checksum SI parameters for actual values (channel 1)	Changing encoder parameters (e.g. encoder pulse number, fine resolution, ...) or mechanical settings (e.g. gear unit, spindle pitch, ...)
p9729[2]	Reference checksum SI parameters for hardware (channel 1)	As soon as a Sensor Module evaluated by safety integrated is replaced
p9399[0]	Reference checksum SI parameters for motion monitoring (channel 2)	Changing the safety parameters of extended functions
p9399[1]	Reference checksum SI parameters with hardware reference (channel 2)	Replacing safety-relevant hardware
<b>TM54F</b>		
p10005[0]	Reference checksum, hardware-independent TM54F parameters (available for master and slave modules)	Changing a TM54F safety parameter
p10005[1]	Reference checksum, hardware-dependent TM54F parameters	Replacing a Motor Module which is controlled via the TM54F

All safety changes (functional or referred to the hardware) are identified in the safety logbook of the Control Unit. As soon as a safety parameter is changed, then the checksum in the Control Unit also changes. As a consequence, it is sufficient to document the functional checksum of the safety logbook (r9781[0]) and the associated time stamp (r9782[0]).

**Note**

For the functional checksum, it must be guaranteed that the components to be replaced are replaced by identical components (the same MLFB).

The following diagram shows the functional reference checksums of the SINAMICS components for the safety logbook of the Control Unit.






Image A-1 Parameters for the functional reference checksums of SINAMICS components

## A.3.2 Acceptance reports

### A.3.2.1 Plant description - Documentation part 1

Table A- 2 Machine description and overview diagram

Designation	
Type	
Serial number	
Manufacturer	
End customer	
Electrical drives	
Other drives	
Overview diagram of machine	

A.3 Acceptance tests (recommendations)

Table A- 3 Values of relevant parameters

Versions of the firmware and of Safety Integrated			
Component	DO number	Firmware version	SI version
Parameters Control Unit		r0018 =	r9590[0...3] = r9770[0...3] = Note: Parameters can be found in the drive.
Parameters Motor Modules	<b>DO number</b>	<b>Firmware version</b>	<b>SI version</b>
		r0128 =	r9390[0...3] = r9870[0...3] =
		r0128 =	r9390[0...3] = r9870[0...3] =
		r0128 =	r9390[0...3] = r9870[0...3] =
		r0128 =	r9390[0...3] = r9870[0...3] =
		r0128 =	r9390[0...3] = r9870[0...3] =
Parameters Sensor Modules	<b>DO number</b>	<b>Firmware version</b>	<b>SI version<sup>1)</sup></b>
		r0148 =	r9890[0...2] =
		r0148 =	r9890[0...2] =
		r0148 =	r9890[0...2] =
		r0148 =	r9890[0...2] =
		r0148 =	r9890[0...2] =
Parameters TM54F	<b>DO number</b>	<b>Firmware version</b>	<b>SI version</b>
		r0158 =	r10090 =
Monitoring clock cycles of Safety Integrated			
Basic Functions	<b>DO number</b>	<b>SI monitoring clock cycle Control Unit</b>	<b>SI monitoring clock cycle Motor Module</b>
		r9780 =	r9880 =
		r9780 =	r9880 =
		r9780 =	r9880 =
		r9780 =	r9880 =
		r9780 =	r9880 =

Extended Functions	<b>DO number</b>	<b>SI monitoring clock cycle Motor Module</b>	<b>SI monitoring clock cycle Control Unit</b>
		p9300 =	p9500 =
		p9300 =	p9500 =
		p9300 =	p9500 =
		p9300 =	p9500 =
		p9300 =	p9500 =
		p9300 =	p9500 =
Parameters TM54F	<b>DO number</b>	<b>SI monitoring clock cycle TM54F</b>	
		p10000[0] =	
		p10000[1] =	
		p10000[2] =	
		p10000[3] =	
		p10000[4] =	
		p10000[5] =	

1) Use the Sensor Module firm ware version here for DQI encoders (r0148[0...n]).

### A.3.2.2 Description of safety functions - Documentation Part 2

#### Note

#### Example

This description of a system is for illustration purposes only. In each case, the actual settings for the system concerned will need to be modified as required.

### Function table

Table A- 4 Example table: Active safety functions depending on the operating mode and the protective door or other sensors

Operating mode	Protective door	Drive	Status of the safety functions
Production	Closed and locked	1 2	All deselected SLS 1 enabled
	Unlocked	1 2	SOS selected SS1 selected
Setup	Closed and locked	1 2	All deselected SLS 1 enabled
	Unlocked	1 2	SLS 1 deselected SOS enabled
...	...	...	...

SI functions for each drive

Table A- 5 Example: Functional overview of the safety functions

Drive	SI function	Limit value	Active if
1	SOS	100 mm	refer to the function table
	SLS 1	200000 mm/min	refer to the function table
2	SOS	100 mm	refer to the function table
	SLS 1	50 rpm	refer to the function table
...	...	...	...

Remarks:

All drives use the SI function SS1 for the EMERGENCY STOP functionality.

Drive 2 is equipped with a holding brake which is controlled by two channels via the corresponding Motor Module output.

Drive-specific safety parameters

You need to fill out this table for each axis.

SI function	Parameter Motor Modules / CU	Motor Module value $\Delta$ CU value
Enable safety functions	p9501	0000 bin
Axis type	p9502	0
SP modulo value	p9505	0
Function specification	p9506	0
Function configuration	p9507	0000 0000 bin
Behavior during pulse suppression	p9509	0
Actual value acquisition cycle	p9511	0.0 ms
Enable safety functions without selection	p9512	0
Non-safety-related measuring increments POS1	p9513	22000
Absolute encoder linear measuring increments	p9514	100
Coarse position value configuration	p9515	0000 bin
Encoder configuration, safety functions	p9516	0000 bin
Linear scale graduations	p9517	10 nm
Encoder pulses per revolution	p9518	2048
Fine resolution G1_XIST1	p9519	11
Leadscrew pitch	p9520	10 mm
Gearbox encoder (motor) / load denominator	p9521[0]	1
	p9521[1]	1
	p9521[2]	1
	p9521[3]	1
	p9521[4]	1
	p9521[5]	1
	p9521[6]	1
	p9521[7]	1

SI function	Parameter Motor Modules / CU	Motor Module value Δ CU value
Gearbox encoder (motor) / load numerator	p9522[0] p9522[1] p9522[2] p9522[3] p9522[4] p9522[5] p9522[6] p9522[7]	1 1 1 1 1 1 1 1
Redundant coarse position value valid bits	p9523	9
Redundant coarse position value fine resolution bits	p9524	-2
Redundant coarse position value relevant bits	p9525	16
Encoder assignment	p9526	1
SI Motion Sensor Module node identifier	p9328[0] p9328[1] p9328[2] p9328[3] p9328[4] p9328[5] p9328[6] p9328[7] p9328[8] p9328[9] p9328[10] p9328[11]	0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex 0000 hex
SI Motion Gx_XIST1 coarse position safety most significant bit	p9529	14
SOS standstill tolerance	p9530	1.000°
SLS limit values	p9531[0] p9531[1] p9531[2] p9531[3]	2000.00 mm/min 2000.00 mm/min 2000.00 mm/min 2000.00 mm/min
SI Motion SLS speed setpoint limiting	p9533	0.000 %
SLP upper limit values	p9534[0] p9534[1]	10000 mm 20000 mm
SLP lower limit values	p9535[0] p9535[1]	3000 mm 12000 mm
SI Motion gearbox direction of rotation reversal	p9539[0] p9539[1] p9539[2] p9539[3] p9539[4] p9539[5] p9539[6] p9539[7]	0 0 0 0 0 0 0 0
Encoder comparison algorithm	p9541	10
Actual value comparison tolerance	p9542	0.1000°
SI Motion gearbox switching position tolerance	p9543	1
Actual value comparison tolerance (referencing)	p9544	0.01 mm

A.3 Acceptance tests (recommendations)

SI function	Parameter Motor Modules / CU	Motor Module value $\pm$ CU value
SSM filter time	p9545	0.0 ms
SSM speed limit	p9546	20.00 mm/min
SSM speed hysteresis	p9547	10 mm/min
SAM actual speed tolerance	p9548	300.00 rpm
Slip speed tolerance	p9549	6.0 rpm
SLS changeover delay time	p9551	100.00 ms
STOP C -> SOS delay time	p9552	100.00 ms
STOP D -> SOS delay time	p9553	100.00 ms
STOP E -> SOS transition time	p9554	100.00 $\mu$ s
STOP F -> STOP B delay time	p9555	0.00 ms
Pulse suppression delay time	p9556	100.00 ms
Pulse suppression test time	p9557	100.00 ms
Acceptance test mode time limit	p9558	40000.00 ms
Forced checking procedure timer	p9559	8.00 h
Pulse suppression shutdown speed	p9560	0.0 rpm
SLP stop response	p9562[0] p9562[1]	2 2
PLC stop response	p9563[0] p9563[1] p9563[2] p9563[3]	2 2 2 2
SDI tolerance	p9564	0.1 mm
SDI delay time	p9565	10.00 $\mu$ s
SDI stop response	p9566	1
SI Motion switchover speed to SOS	p9567	0.00
SAM speed limit	p9568	0.0 mm/min
SI Motion transition time to SOS after standstill	p9569	0.00
SI Motion reference position	p9572	0.000
SI Motion accept reference position	p9573	0
Safe position scaling	p9574	1000
SI Motion SLP delay time	p9577	0.00
Pulse suppression delay bus failure	p9580	100.00 $\mu$ s
Brake ramp reference value	p9581	1500 rpm
Brake ramp delay time	p9582	250 ms
Brake ramp monitoring time	p9583	10.00 s
Fault tolerance actual value acquisition without encoder	p9585	-1
Evaluation delay time without encoder	p9586	100.00 ms
Actual value acquisition without encoder filter time	p9587	100.00 $\mu$ s
Minimum current actual value acquisition without encoder	p9588	10.00 %

## A.3 Acceptance tests (recommendations)

SI function	Parameter Motor Modules / CU	Motor Module value Δ CU value
Acceleration voltage tolerance	p9589	100.00 %
Signal source for STO/SBC/SS1	p9620[0] p9620[1] p9620[2] p9620[3] p9620[4] p9620[5] p9620[6] p9620[7]	0 0 0 0 0 0 0 0
SI module identification CU	p9670	0
SI module identification MM	p9671	0
SI module identification PM	p9672	0
SI module identification SM channel 1	p9673	0
SI module identification SM channel 2	p9674	0
SI module identification sensor channel 1	p9675	0
SI module identification sensor channel 2	p9676	0
SI Motion pulse suppression fail safe delay time	p9697	0.00 ms
Test stop signal source	p9705	1:722:5
Enable drive-integrated functions	p9601	0000 bin
Enable safe brake control	p9602	0
PROFIsafe address	p9610	0000 hex
PROFIsafe telegram selection	p9611	900
Signal source for SBA	p9621	0
SBA relay wait times	p9622[0] p9622[1]	100.00 ms 65.00 ms
SGE changeover tolerance time	p9650	500.00 ms
STO/SBC/SS1 debounce time	p9651	0.00 ms
Safe Stop 1 delay time	p9652	0.00 s
SS1 with OFF3	p9653	0
STOP F -> STOP A delay time	p9658	0.00 μs
Forced checking procedure timer	p9659	8.00 h
SI wait time for test stop at DO (CU310-2)	p10001	500.00
SI discrepancy monitoring time (CU310-2)	p10002	500.00
SI forced dormant error detection timer (CU310-2)	p10003	8.00
SI acknowledgment internal event F-DI (CU310-2)	p10006	1
BI: SI forced dormant error detection F-DO signal source (CU310-2)	p10007	0
SLP retraction F-DI (CU310-2)	p10009	1
SI digital inputs debounce time (CU310-2)	p10017	1.00
SI STO input terminal (CU310-2)	p10022	1
SI SS1 input terminal (CU310-2)	p10023	1
SI SS2 input terminal (CU310-2)	p10024	1

A.3 Acceptance tests (recommendations)

SI function	Parameter Motor Modules / CU	Motor Module value $\pm$ CU value
SI SOS input terminal (CU310-2)	p10025	1
SI SLS input terminal (CU310-2)	p10026	1
SI SLS limit bit 0 input terminal (CU310-2)	p10027	2
SI SLS limit bit 1 input terminal (CU310-2)	p10028	2
SI SDI positive input terminal (CU310-2)	p10030	3
SI SDI negative input terminal (CU310-2)	p10031	3
SI SLP selection input terminal (CU310-2)	p10032	2
SI SLP position range input terminal (CU310-2)	p10033	2
SI Safe State signal selection (CU310-2)	p10039	0000 0001 bin
SI F-DI input mode (CU310-2)	p10040	0000 bin
SI F-DO 0 signal sources (CU310-2)-	p10042[0] p10042[1] p10042[2] p10042[3] p10042[4] p10042[5]	0 0 0 0 0 0
SI test sensor feedback (CU310-2)	p10046	0000 bin
SI F-DO test stop mode (CU310-2)	p10047	2
SI F-DI monitoring status (CU310-2)	r10049	2
SI PROFIsafe F-DI transfer (CU310-2)	p10050	0000 bin
CO/BO: SI Motion digital inputs status	p10051	0 hex
CO/BO: SI Motion digital outputs status	p10052	0 hex
SI Motion wait time for test stop on DO	p10101	500.00
SI Motion F-DI switch over discrepancy time	p10102	500.00
SI Motion acknowledgment internal event F-DI	p10106	0
SI Motion SLP retraction F-DI	p10109	0
SI Motion digital inputs debounce time	p10117	1.00
SI Motion STO input terminal	p10122	0
SI Motion SS1 input terminal	p10123	0
SI Motion SS2 input terminal	p10124	0
SI Motion SOS input terminal	p10125	0
SI Motion SLS input terminal	p10126	0
SI Motion SLS limit bit 0 input terminal	p10127	0
SI Motion SLS limit bit 1 input terminal	p10128	0
SI Motion SDI positive input terminal	p10130	0
SI Motion SDI negative input terminal	p10131	0
SI Motion SLP input terminal	p10132	0
SI Motion SLP position range input terminal	p10133	0
SI Motion Safe State signal selection	p10139	1 hex
SI Motion F-DI input mode	p10140	0 hex



## A.3 Acceptance tests (recommendations)

SI function	Parameter Motor Modules / CU	Motor Module value Δ CU value
SI F-DO 0 signal sources (CU310-2)	p10142[0] p10142[1] p10142[2] p10142[3] p10142[4] p10142[5]	0 0 0 0 0 0
SI Motion test sensor feedback signal	p10146	0000 bin
SI Motion F-DO test stop mode	p10147	2
SI Motion F-DI monitoring status	r10149	0 hex
SI Motion transfer PROFIsafe F-DI	p10150	0 hex
CO/BO: SI Motion digital inputs status	r10151	0 hex
CO/BO: SI Motion digital outputs status	r10152	0 hex
SI Motion SBT enable safety functions	p10201	1
SI Motion SBT brake selection	p10202[0] p10202[1]	1 1
SI Motion SBT control selection	p10203	0
SI Motion SBT motor type	p10204	0
SI Motion SBT ramp time test torque	p10208[0] p10208[1]	1000 1000
SI Motion SBT brake holding torque	p10209[0] p10209[1]	10.00 10.00
SI Motion SBT test force factor sequence 1	p10210[0] p10210[1]	1.00 1.00
SI Motion SBT test duration sequence 1	p10211[0] p10211[1]	1000 1000
SI Motion SBT position tolerance sequence 1	p10212[0] p10212[1]	2.000 2.000
SI Motion SBT direction of rotation	p10218	1
SI Motion SBT test force factor sequence 2	p10220[0] p10220[1]	0.5 0.5
SI Motion SBT test duration sequence 2	p10221[0] p10221[1]	500 500
SI Motion SBT position tolerance sequence 2	p10222[0] p10222[1]	1.000 1.000
BI: SI Motion SBT control word	p10230[0] p10230[1] p10230[2] p10230[3] p10230[4] p10230[5]	0 0 0 0 0 0
CI: Safety Control Channel control word 3	p10235	0
CI: SI Safety Control Channel control word S_STW1B	p10250	0

Parameterizing the SI functions via TM54F

Table A- 6 Parameters for control via the TM54F (excerpt)

SI function	Parameter	Value
Wait time for test stop on DO	p10001	500.00 ms
Monitoring time discrepancy	p10002	12.00 ms
Forced checking procedure timer	p10003	8.00 h
Acknowledging internal event input terminal	p10006	0
Input terminal forced checking procedure	p10007	0
SLP retraction F-DI	p10009	1
Assignment of drive objects	p10010[0] p10010[1] p10010[2] p10010[3] p10010[4] p10010[5]	0 0 0 0 0 0
Assignment of drive groups	p10011[0] p10011[1] p10011[2] p10011[3] p10011[4] p10011[5]	1 1 1 1 1 1
Digital inputs debounce time	p10017	1.00 ms
STO inputterminal	p10022[0] p10022[1] p10022[2] p10022[3]	0 0 0 0
SS1 inputterminal	p10023[0] p10023[1] p10023[2] p10023[3]	0 0 0 0
SS2 inputterminal	p10024[0] p10024[1] p10024[2] p10024[3]	0 0 0 0
SOS inputterminal	p10025[0] p10025[1] p10025[2] p10025[3]	0 0 0 0
PLC inputterminal	p10026[0] p10026[1] p10026[2] p10026[3]	0 0 0 0
SLS_Limit(1) inputterminal	p10027[0] p10027[1] p10027[2] p10027[3]	0 0 0 0

## A.3 Acceptance tests (recommendations)

SI function	Parameter	Value
SLS_Limit(2) inputterminal	p10028[0] p10028[1] p10028[2] p10028[3]	0 0 0 0
SI SDI positive inputterminal	p10030[0] p10030[1] p10030[2] p10030[3]	0 0 0 0
SI SDI negative inputterminal	p10031[0] p10031[1] p10031[2] p10031[3]	0 0 0 0
SI SLP inputterminal	p10032[0] p10032[1] p10032[2] p10032[3]	0 0 0 0
SI SLP position range inputterminal	p10033	0
Safe state signal selection	p10039[0] p10039[1] p10039[2] p10039[3]	1 hex 1 hex 1 hex 1 hex
F-DI inputmode	p10040	0 hex
F-DI test enable	p10041	0 hex
F-DO 0 signal sources	p10042[0] p10042[1] p10042[2] p10042[3] p10042[4] p10042[5]	0 0 0 0 0 0
F-DO 1 signal sources	p10043[0] p10043[1] p10043[2] p10043[3] p10043[4] p10043[5]	0 0 0 0 0 0
F-DO 2 signal sources	p10044[0] p10044[1] p10044[2] p10044[3] p10044[4] p10044[5]	0 0 0 0 0 0
F-DO 3 signal sources	p10045[0] p10045[1] p10045[2] p10045[3] p10045[4] p10045[5]	0 0 0 0 0 0
Test Sensor feedback signal	p10046.0 p10046.1 p10046.2 p10046.3	0 hex 0 hex 0 hex 0 hex

A.3 Acceptance tests (recommendations)

SI function	Parameter	Value
Selection of test mode for test stop	p10047[0]	2
	p10047[1]	2
	p10047[2]	2
	p10047[3]	2
SI F-DI F-DO test stop configuration	p10048	1
SI module identification TM54F	p10070	0

Safety equipment

Protective door	The protective door is unlocked by means of single-channel request key
Protective door switch	The protective door is equipped with a safety door switch. The safety door switch returns the dual-channel signal "Door closed and locked". Changeover and selection of safety functions in accordance with the table shown above.
Mode selector switch	The "Production" and "Setup" modes are set by means of a mode selector switch. The key switch features two contact levels. Changeover and selection of safety functions in accordance with the table shown above.
Emergency Stop button	The dual-channel Emergency Stop pushbuttons are connected in series. The Emergency Stop signal activates SS1 for all drives. Then the external brakes and STO are activated.
Forced dormant error detection (test stop)	Activation by means of: <ul style="list-style-type: none"> <li>• Machine power on</li> <li>• Unlocking the protective door</li> </ul>

A.3.3 Acceptance tests

---

**Note**

**Conditions for the acceptance test**

As far as possible, the acceptance tests are to be carried out at the maximum possible machine speed and acceleration rates to determine the maximum braking distances and braking times that can be expected.

---

**Note**

**Acceptance test for Basic and Extended Functions**

If Basic Functions and Extended Functions are combined, the acceptance test for both types must be carried out for the functions used.

---

**Note**

**Trace recordings**

The trace recordings for the Extended Functions aid evaluation of the more complex functionality compared with the Basic Functions, for which trace recording is not required. However, these are only a suggestion; where necessary, you can also use other recording options (e.g. via HMI).

---

**Note****Non-critical alarms**

When evaluating the alarm buffer you can tolerate the following alarms:

- A01697 SI Motion: Motion monitoring test required
- A35014 TM54F: Test stop required

These alarms occur after every system startup and can be evaluated as non-critical.

- A01699 SI CU: Shutdown path test required

This alarm occurs after the time in p9659 has expired.

You do not need to include these alarms in the acceptance report.

---

**Note****No acceptance test with alarm A01796**

If the alarm A01796 is active, the pulses are safely canceled, and an acceptance test is not possible.

---

## Acceptance test support in STARTER

The STARTER commissioning tool offers you the option of creating the acceptance report semi-automatically:

1. In STARTER, select <Drive device> → Documentation and double-click on Acceptance documentation.
2. Select the name for the file and the template to be used.
3. To generate the acceptance report, click on **Create**.

A Word document with the following contents is generated:

- Firmware versions (actual parameter values have already been entered)
- Monitoring cycles
- Checksums
- Parameter assignment of the Safety functions

For the above points, the actual parameter values have already been entered.

- Tables to perform the acceptance test step-by-step

You must manually complete these tables while the acceptance test is being performed.

## Acceptance test support using STARTER script

You will find a STARTER script on the following Internet page to help you with acceptance tests:

<http://support.automation.siemens.com/WW/view/de/52248627>

A PDF with a detailed description of the script is provided at the same link.

**A.3.3.1 Acceptance tests – Basic Functions**

**Acceptance test for Safe Torque Off (STO)**

No.	Description	Status
<p><b>Note:</b>                      The acceptance test must be individually performed for each configured control.                      The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• STO function enabled (onboard terminals/PROFIsafe/TM54F)</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7]); see note "non-critical alarms" at the beginning of Section "Acceptance test".</li> <li>• r9772.17 = 0 (STO deselection via terminals - DI CU / EP terminal Motor Module); only relevant for STO via terminal</li> <li>• r9772.20 = 0 (STO deselection via PROFIsafe); only relevant for STO via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 0 (STO deselected and inactive - drive)</li> <li>• r9774.0 = r9774.1 = 0 (STO deselected and inactive - group); only relevant for grouping</li> </ul>	
2.	<p>Run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> <p>Select STO when you issue the traversing command and check the following:</p> <ul style="list-style-type: none"> <li>• The drive coasts to a standstill or is braked and stopped by the mechanical brake.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9772.17 = 1 (STO selection via terminal - DI CU / EP terminal Motor Module); only relevant for STO via terminal</li> <li>• r9772.20 = 1 (STO selection via PROFIsafe); only relevant for STO via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 1 (STO selected and active – drive)</li> <li>• r9774.0 = r9774.1 = 1 (STO selected and active – group); only relevant for grouping</li> </ul>	
3.	<p>Deselect STO and check the following:</p> <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9772.17 = 0 (STO deselection via terminals - DI CU / EP terminal Motor Module); only relevant for STO via terminal</li> <li>• r9772.20 = 0 (STO deselection via PROFIsafe); only relevant for STO via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 0 (STO deselected and inactive – drive)</li> <li>• r9774.0 = r9774.1 = 0 (STO deselected and inactive – group); only relevant for grouping</li> </ul>	
4.	<p>Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.</p>	

## Acceptance test for Safe Stop 1, time controlled (SS1)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• STO function enabled (onboard terminals/PROFIsafe/TM54F)</li> <li>• SS1 function enabled (p9652 &gt; 0)</li> <li>• Only for "SS1 with external stop" p9653 = 1</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7]); see note "non-critical alarms" at the beginning of Section "Acceptance test".</li> <li>• r9772.22 = 0 (SS1 deselection via terminals – DI CU / EP terminal Motor Module); only relevant for SS1 via terminal</li> <li>• r9772.23 = 0 (SS1 deselection via PROFIsafe); only relevant for SS1 via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 0 (STO deselected and inactive – drive)</li> <li>• r9773.5 = r9773.6 = 0 (SS1 deselected and inactive – drive)</li> <li>• r9774.0 = r9774.1 = 0 (STO deselected and inactive – group); only relevant for grouping</li> <li>• r9774.5 = r9774.6 = 0 (SS1 deselected and inactive – group); only relevant for grouping</li> </ul>	
2.	Run the drive <p>Check whether the correct drive is operational</p> <p>Select SS1 when you issue the traversing command and check the following:</p> <ul style="list-style-type: none"> <li>• Drive brakes along the OFF3 ramp (p1135) (not in the case of SS1 with external stop)</li> </ul> <p>Before the expiry of the SS1 delay time (p9652), the following applies:</p> <ul style="list-style-type: none"> <li>• r9772.22 = 1 (SS1 selection via terminals – DI CU / EP terminal Motor Module); only relevant for SS1 via terminal</li> <li>• r9772.23 = 1 (SS1 selection via PROFIsafe); only relevant for SS1 via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 0 (STO deselected and inactive – drive)</li> <li>• r9773.5 = r9773.6 = 1 (SS1 selected and active – drive)</li> <li>• r9774.0 = r9774.1 = 0 (STO deselected and inactive - group); only relevant for grouping</li> <li>• r9774.5 = r9774.6 = 1 (SS1 selected and active - group); only relevant for grouping</li> </ul> <p>STO is initiated after expiry of the SS1 delay time (p9652).</p> <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9773.0 = r9773.1 = 1 (STO selected and active – drive)</li> <li>• r9773.5 = r9773.6 = 1 (SS1 selected and active – drive)</li> <li>• r9774.0 = r9774.1 = 1 (STO selected and active – group); only relevant for grouping</li> </ul>	

## A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9774.5 = r9774.6 = 1 (SS1 selected and active - group); only relevant for grouping</li> </ul>	
3.	Canceling SS1 <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9772.22 = 0 (SS1 deselection via terminals – DI CU / EP terminal Motor Module); only relevant for SS1 via terminal</li> <li>• r9772.23 = 0 (SS1 deselection via PROFIsafe); only relevant for SS1 via PROFIsafe</li> <li>• r9773.0 = r9773.1 = 0 (STO deselected and inactive – drive)</li> <li>• r9773.5 = r9773.6 = 0 (SS1 deselected and inactive – drive)</li> <li>• r9774.0 = r9774.1 = 0 (STO deselected and inactive – group); only relevant for grouping</li> <li>• r9774.5 = r9774.6 = 0 (SS1 deselected and inactive – group); only relevant for grouping</li> </ul>	
4.	Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.	



## Acceptance test for "Safe Brake Control" (SBC)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• STO function enabled (onboard terminals/PROFIsafe/TM54F)</li> <li>• SBC function enabled (p9602 = 1)</li> <li>• Brake as in sequence control or brake always released (p1215 = 1 or p1215 = 2)</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7]); see note "non-critical alarms" at the beginning of Section "Acceptance test".</li> <li>• r9773.4 = 0 (SBC not requested - drive)</li> <li>• r9774.4 = 0 (SBC not requested - group); only relevant for grouping</li> <li>• r9773.1 = 0 (STO inactive – drive)</li> <li>• r9774.1 = 0 (STO inactive – group); only relevant for grouping</li> </ul>	
2.	Run drive (if applied, brake is released) <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> Select STO/SS1 when you issue the traversing command and check the following: <ul style="list-style-type: none"> <li>• The brake is applied (for SS1 the drive is previously decelerated along the OFF3 ramp)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9773.4 = 1 (SBC not requested – drive)</li> <li>• r9774.4 = 1 (SBC not requested – group); only relevant for grouping</li> <li>• r9773.1 = 1 (STO inactive – drive)</li> <li>• r9774.1 = 1 (STO inactive – group); only relevant for grouping</li> </ul>	
3.	Deselect STO and check the following: <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7])</li> <li>• r9773.4 = 0 (SBC not requested – drive)</li> <li>• r9774.4 = 0 (SBC not requested – group); only relevant for grouping</li> <li>• r9773.1 = 0 (STO inactive – drive)</li> <li>• r9774.1 = 0 (STO inactive – group); only relevant for grouping</li> </ul>	
4.	Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.	

**A.3.3.2 Acceptance tests for Extended Functions (with encoder)**

**Encoder parameterization test**

Table A- 7 Encoder parameterization test

No.	Description	Status
<p><b>Note:</b> This test of the encoder parameterization must only be performed once if you use the Safety Integrated Extended Functions with encoder.</p>		
1.	<p>The motor-side actual velocity value r0063 must, when converted to the load-side, produce the load-side actual velocity value r9714[0]:</p> <ul style="list-style-type: none"> <li>• Linear motor, linear axis:  <math>r9714[0] \text{ [mm/min]} = r0063 \text{ [m/min]} \times 1000 \text{ [mm/m]}</math></li> <li>• Rotary motor, linear axis:  <math>r9714[0] \text{ [mm/min]} = r0063 \text{ [rpm]} \times p9520 \text{ [mm/rev]} \times p9521/p9522</math></li> <li>• Rotary motor, rotary axis:  <math>r9714[0] \text{ [rpm]} = r0063 \text{ [rpm]} \times p9521/p9522</math></li> </ul>	
<p><b>Note:</b> If it is not possible to check the actual velocity value in your configuration, check the position as an alternative:</p> <ul style="list-style-type: none"> <li>• Traverse a rotary axis through a precisely defined angle (e.g. one revolution). The safety position values from r9708[0] and r9708[1] must then match at standstill.</li> <li>• Traverse a linear axis a precisely defined distance (e.g. 10 mm). The safety position values from r9708[0] and r9708[1] must then match at standstill.</li> </ul>		


## Acceptance test Safe Torque Off with encoder (Extended Functions)

No.	Description	Status
<b>Notes:</b> The acceptance test must be individually conducted for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> <li>• r9720.0 = 1 (STO deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul>	
2.	Run the drive <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> Select STO when you issue the traversing command and check the following: <ul style="list-style-type: none"> <li>• The drive coasts to a standstill or is braked and stopped by the mechanical brake.</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used).</li> <li>• r9720.0 = 0 (STO selected)</li> <li>• r9722.0 = 1 (STO active)</li> </ul>	
3.	Deselect STO and check the following: <ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9720.0 = 1 (STO deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul>	
4.	Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.	

**Acceptance test for Safe Stop 1, time and acceleration controlled**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• Only for "Safe Stop 1 with external stop (Page 90)": p9507.3 = 1</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<p>Run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul>	
3.	<p>Configure and activate trace recording.</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9720.1 = 0)</li> <li>• Record the following values: r9714[0], r9720, r9722</li> <li>• Select the time interval and pretrigger so you can recognize the selection of SS1 and the transition into the subsequent STO state</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9720.1 (deactivation SS1)</li> <li>• r9722.0 (STO active)</li> <li>• r9722.1 (SS1 active)</li> </ul> <p>Select SS1 while the drive is moving</p> <ul style="list-style-type: none"> <li>• Drive brakes along the OFF3 ramp (not in the case of SS1 with external stop)</li> <li>• Subsequent state STO is activated</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• STO is triggered after the SS1 timer (p9556) has expired, or if the speed drops below the shutdown speed (p9560) (not in the case of SS1 with external stop)</li> </ul>	
5.	<p>Save/print the trace and add it to the acceptance report (refer to the example below)</p>	
6.	<p>Deselect SS1</p> <ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> <p>Acknowledge switch-on inhibit and run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul>	

## Example trace: SS1 (with encoder)



- ① Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ② Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ③ SS1 active
- ④ STO active
- ⑤ Deselect SS1

Image A-2 Example trace: SS1 (with encoder)

Trace evaluation:

- SS1 function is selected (time axis 0 ms; see bit "deselection SS1")
  - Response bit "SS1 active" is set (time axis approx. 20 ms)
  - The drive decelerates along the configured OFF3 ramp (p1135)
  - Recording of r9714[0] (orange curve) shows whether the OFF3 ramp is active.
- 

**Note**

**Behavior for SS1 with external STOP**

When selecting "Safe Stop 1 with external stop (Page 90)" the drive is not braked along the OFF3 ramp, but after the delay time (p9556) has expired, only STO/SBC is automatically initiated.

---

- STO is activated (time axis approx. 370 ms; see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (in this case shutdown speed SS1 is fallen below, before SS1 timer p9556 has expired)
- 

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---

## Acceptance test for Safe Brake Control with encoder (Extended Functions)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SBC function enabled (p9602 = 1)</li> <li>• Brake as in sequence control or brake always released (p1215 = 1 or p1215 = 2)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> <li>• r9773.4 = 0 (SBC not requested)</li> <li>• r9720.0 = 1 (STO deselected) or r9720.1 = 1 (SS1 deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul>	
2.	Run drive (if applied, brake is released) <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> Select STO when you issue the traversing command and check the following: <ul style="list-style-type: none"> <li>• Brake is applied</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9773.4 = 1 (SBC requested)</li> <li>• r9720.0 = 0 (STO selected) or r9720.1 = 0 (SS1 selected)</li> <li>• r9722.0 = 1 (STO active)</li> </ul>	
3.	Deselect STO and check the following: <ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9720.0 = 1 (STO deselected) or r9720.1 = 1 (SS1 deselected)</li> <li>• r9722.0 = 0 (STO active)</li> </ul>	
4.	Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.	


**Acceptance test for Safe Operating Stop (SOS)**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SOS inactive (r9722.3 = 0)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to run the drive with activated SOS.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording.</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize start-up of the drive and violation of the SOS tolerance window (p9530)</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9720.3 (deselect SOS)</li> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.7 (internal event; set when the first safety message occurs)</li> </ul> <p>Select SOS</p> <p>Traverse the drive beyond the standstill limit set in p9530</p> <ul style="list-style-type: none"> <li>• Check whether the drive moves briefly and then is braked back to a standstill</li> </ul> <p>Check whether the following safety messages are pending:</p> <ul style="list-style-type: none"> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace:	



No.	Description	Status
	<ul style="list-style-type: none"> <li>As soon as r9713[0] leaves the tolerance window, a safety message becomes active (r9722.7 = 0)</li> <li>As a consequence, the drive is brought to a standstill with STOP B and STOP A</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SOS and acknowledge safety messages	
	<ul style="list-style-type: none"> <li>No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>Check whether the drive is moving</li> </ul>	

Example trace: SOS



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Internal event
- ③ SOS active
- ④ SS1 active
- ⑤ STO active
- ⑥ STOP A or B
- ⑦ Deselect SOS

Image A-3 Example trace: SOS

Trace evaluation:

- SOS function is activated (see bits "deselect SOS" and "SOS active")
- The drive starts moving (time axis approx. -100 ms)
- Exiting the SOS tolerance window is recognized (time axis approx. 0 ms)
- Safety fault is initiated (time axis approx. 0 ms; bit "internal event" is set to 0)
- Fault response STOP B is initiated (see bit "STOP A or B active" and "SS1 active")
- The drive is braked to a standstill
- Standstill is reached (time axis approx. 200 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) before the SS1 timer (p9556) has expired (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired)

---

**Note**

**Time differences through internal calculations**


Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---

## Acceptance test for Safe Stop 2 (SS2)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SS2 deselected (r9720.2 = 1)</li> <li>• SS2 inactive (r9722.2 = 0)</li> <li>• SOS inactive (r9722.3 = 0)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	Run the drive <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul>	
3.	Configure and activate trace recording. <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9720.2 = 0)</li> <li>• Record the following values: r9714[0], r9720, r9722</li> <li>• Select the time interval and pretrigger so you can recognize the selection of SS2 and the transition into the subsequent SOS state</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9720.2 (deselection SS2)</li> <li>• r9722.2 (SS2 active)</li> <li>• r9722.3 (SOS active)</li> </ul> Select SS2 while the drive is moving <ul style="list-style-type: none"> <li>• Drive brakes along the OFF3 ramp (not in the case of SS2 with external stop (SS2E))</li> <li>• Subsequent SOS state is activated</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• SOS is triggered after the SS2 timer (p9352/9552) has expired.</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SS2 <ul style="list-style-type: none"> <li>• Check whether the drive is operating with the setpoint again</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	

Example trace: SS2



- ① Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ② Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ③ SOS active
- ④ SS2 active
- ⑤ DeselectSS2

Image A-4 Example trace: SS2

Trace evaluation:

- SS2 function is selected (time axis 0 ms; see bit "deselection SS2")
- Response bit "SS2 active" is set (time axis approx. 20 ms)
- The drive decelerates along the configured OFF3 ramp (p1135)
- Recording r9714[0] (②) indicates whether the OFF3 ramp is active
- SOS is activated (time axis approx. 500 ms; see bit "SOS active"); at this point the SS2 timer (p9552) has expired

Note

Time differences through internal calculations

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

## Acceptance tests for Safely Limited Speed with encoder (Extended Functions)


### SLS with encoder with stop response "STOP A"

No.	Description	Status
<b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	<b>Initial state</b> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SLS inactive (r9722.4 = 0) Note: SLS is active for motion monitoring without selection.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<b>Configure and activate trace recording</b> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9714[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLS limit has been exceeded and the subsequent drive responses</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> <li>• r9722.7 (internal event; set when the first safety message occurs)</li> </ul> Select SLS with level x Note: SLS is already active for motion monitoring without selection. <b>Switch on the drive and specify the setpoint above the SLS limit</b> <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (p9531[x]) has been exceeded that it is coasting down or a configured holding brake is closed</li> </ul> <b>Check whether the following safety messages are pending:</b> <ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	

## A.3 Acceptance tests (recommendations)

No.	Description	Status
4.	Analyze trace:	
	<ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a safety message (r9722.7 = 0) becomes active</li> </ul>	
	<ul style="list-style-type: none"> <li>• STOP A is initiated as a consequence</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Acknowledge safety messages and, if required, deselect SLS	
	<ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	Check whether the drive is moving	

## Example trace: SLS (with encoder) with STOP A



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Active SLS level bit 1
- ③ Active SLS level bit 0
- ④ SLS active
- ⑤ Internal event
- ⑥ STO active
- ⑦ STOP A or B active
- ⑧ Select SLS bit 1
- ⑨ Select SLS bit 0
- ⑩ Deselect SLS

Image A-5 Example trace: SLS (with encoder) with STOP A

## Trace evaluation:

- SLS function with SLS level 1 is activated (see bits "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -400 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP A is initiated (time axis 0 ms; see bit "STOP A or B active" and "STO active")
- Drive coasts down (see curve of Drive\_1.r9714[0])

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.


**SLS with encoder with stop response "STOP B"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. The control can be realized without selection, via TM54F or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording.</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9714[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLS limit has been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> <li>• r9722.7 (internal event; set when the first safety message occurs)</li> </ul> <p>Select SLS with level x Note: SLS is already active for motion monitoring without selection.</p> <p>Switch on the drive and specify the setpoint above the SLS limit</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (p9531[x]) has been exceeded that it is braked along the OFF3 ramp before STOP A becomes active</li> </ul> <p>Check whether the following safety messages are pending:</p>	



No.	Description	Status
	<ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01701, C30701 (STOP B initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a safety message (r9722.7 = 0) becomes active</li> <li>• A STOP B is initiated as a consequence (with subsequent stop STOP A)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Acknowledge safety messages and, if required, deselect SLS	
	<ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used).</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	

Example trace: SLS (with encoder) with STOP B



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ③ Active SLS level bit 1
- ④ Active SLS level bit 0
- ⑤ SLS active
- ⑥ Internal event
- ⑦ SS1 active
- ⑧ STO active
- ⑨ STOP A or B active
- ⑩ Select SLS bit 1
- ⑪ Select SLS bit 0
- ⑫ Deselect SLS

Image A-6 Example trace: SLS (with encoder) with STOP B

Trace evaluation:

- SLS function with SLS level 2 is activated (see bits "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -400 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP B is initiated (time axis 0 ms; see bit "STOP A or B active" and "SS1 active")
- Drive is decelerated to a standstill (see curve of Drive\_1.r9714[0])
- Standstill reached (time axis from approx. 250 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

---

#### Note

##### Time differences through internal calculations

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---


### SLS with encoder with stop response "STOP C"

No.	Description	Status
<b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>• Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> </ul>	
	<ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F; see note "Non-critical alarms" at the beginning of Section "Acceptance tests."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	Configure and activate trace recording.	
	<ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>• Record the following values: r9714[0], r9721, r9722</li> </ul>	
	<ul style="list-style-type: none"> <li>• Select the time interval and pretrigger so you can recognize when the active SLS limit has been exceeded and the subsequent drive responses</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	Select SLS with level x Note: SLS is already active for motion monitoring without selection. Switch on the drive and specify the setpoint above the SLS limit <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (p9531[x]) has been exceeded that it is braked to a standstill along the OFF3 ramp</li> </ul> Check whether the following safety messages are pending: <ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> <li>• C01708, C30708 (STOP C initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a safety message (r9722.7 = 0) becomes active</li> <li>• STOP C is initiated as a consequence</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9721.13 (STOP C active)</li> <li>• r9722.2 (SS2 active; set for STOP C)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.4 (SLS active) and r9722.9/10 (active SLS level)</li> <li>• r9722.7 (internal event; set when the first safety message occurs)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SLS or bring the speed setpoint back to the required range <ul style="list-style-type: none"> <li>• Please note that after safe acknowledgment of the safety messages, the actual setpoint becomes effective again.</li> </ul> Acknowledging safety messages <ul style="list-style-type: none"> <li>• Check whether the drive is operating with the setpoint again</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	

## Example trace: SLS (with encoder) with STOP C



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ③ Active SLS level bit 1
- ④ Active SLS level bit 0
- ⑤ SLS active
- ⑥ Internal event
- ⑦ SOS active
- ⑧ SS2 active
- ⑨ STOP C active
- ⑩ Select SLS bit 1
- ⑪ Select SLS bit 0
- ⑫ Deselect SLS

Image A-7 Example trace: SLS (with encoder) with STOP C

A.3 Acceptance tests (recommendations)

Trace evaluation:

- SLS function with SLS level 1 is activated (see bits "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -400 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP C is initiated (see bit "STOP C active" and "SS2 active")
- Drive is decelerated to a standstill (see curve of Drive\_1.r9714[0])
- After the SS2 timer has expired, the subsequent SOS function is activated (time axis 500 ms)
- The "SOS active" bit is set and "SLS active" is reset

**Note**

**Time differences through internal calculations**


Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

**SLS with encoder with stop response "STOP D"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9714[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so that the exceeding of the active SLS limit and the subsequent drive responses can be recognized</li> </ul>	

No.	Description	Status
	For better analysis, display the following bit values:	
	<ul style="list-style-type: none"> <li>• r9721.14 (STOP D active)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.3 (SOS active)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.7 (internal event; set when the first safety message occurs)</li> </ul>	
	Select SLS with level x	
	Note: SLS is already active for motion monitoring without selection.	
	Switch on the drive and specify the setpoint above the SLS limit	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (9531[x]) has been exceeded and the SOS standstill tolerance window has been exited, that it is braked along the OFF3 ramp before STOP A becomes active as a consequence</li> </ul>	
	Check whether the following safety messages are pending:	
	<ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01709, C30709 (STOP D initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01701, C30701 (STOP B initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
	4. Analyze trace:	
	<ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a safety message (r9722.7 = 0) becomes active</li> </ul>	
	<ul style="list-style-type: none"> <li>• STOP D is initiated as a consequence.</li> </ul>	
	<ul style="list-style-type: none"> <li>• As a consequence of STOP D (selection SOS) the above-described responses will be triggered if the drive is not stopped by the higher-level controller on activation of STOP D</li> </ul>	
	5. Save/print the trace and add it to the acceptance report (refer to the example below)	
	6. Acknowledge safety messages and, if required, deselect SLS	
	<ul style="list-style-type: none"> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	

Example trace: SLS (with encoder) with STOP D



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Active SLS level bit 1
- ③ Active SLS level bit 0
- ④ SLS active
- ⑤ Internal event
- ⑥ SOS active
- ⑦ SS1 active
- ⑧ STO active
- ⑨ STOP D active
- ⑩ Select SLS bit 1
- ⑪ Select SLS bit 0
- ⑫ Deselect SLS

Image A-8 Example trace: SLS (with encoder) with STOP D



Trace evaluation:

- SLS function with SLS level 2 is activated (see bits "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -400 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP D (corresponds to selection SOS) is initiated (see bit "STOP D active")
- The standstill position is only safely monitored (time axis 100 ms; see bit "SOS active") after the transition time STOP D to SOS (p9553) has expired
- However, as the axis continues to rotate, the standstill tolerance window is violated (time axis approx. 120 ms)
- STOP B is initiated (see bit "SS1 active")
- The drive is braked to a standstill
- Standstill is reached (time axis approx. 500 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

---

#### Note

##### Time differences through internal calculations

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---


### SLS with encoder with stop response "STOP E"

No.	Description	Status
<b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	• Drive in the "Ready" state (p0010 = 0)	
	• Safety Integrated Extended Functions enabled (p9601.2 = 1)	
	• Safety functions enabled (p9501.0 = 1)	
	• Safety configured with encoder (p9506 = 0 or p9506 = 2)	
	• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."	

A.3 Acceptance tests (recommendations)

No.	Description	Status
2.	<ul style="list-style-type: none"> <li>It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit</li> <li>Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>Record the following values: r9714[0], r9721, r9722</li> <li>Select the time interval and pretrigger so that the exceeding of the active SLS limit and the subsequent drive responses can be recognized</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>r9721.15 (STOP E active)</li> <li>r9722.3 (SOS active)</li> <li>r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> <li>r9722.7 (internal event; set when the first safety message occurs)</li> </ul> <p>Select SLS with level x Note: SLS is already active for motion monitoring without selection.</p> <p>Switch on the drive and specify the setpoint above the SLS limit</p> <ul style="list-style-type: none"> <li>Check whether the drive is moving, and after the SLS limit (9531[x]) has been exceeded and the SOS standstill tolerance window has been exited, that it is braked along the OFF3 ramp before STOP A becomes active as a consequence</li> </ul> <p>Check whether the following safety messages are pending:</p> <ul style="list-style-type: none"> <li>C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> <li>C01710, C30710 (STOP E initiated)</li> <li>C01707, C30707 (tolerance for safe operating stop exceeded)</li> <li>C01701, C30701 (STOP B initiated)</li> <li>C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>If r9714[0] exceeds the active SLS limit, a safety message (r9722.7 = 0) becomes active</li> <li>STOP E is initiated as a consequence.</li> <li>As a consequence of STOP E (selection SOS) the above-described responses will be triggered if the drive is not stopped by the higher-level controller on activation of STOP E</li> </ul>	
5.	<p>Save/print the trace and add it to the acceptance report (refer to the example below)</p>	
6.	<p>Acknowledge safety messages and, if required, deselect SLS</p> <ul style="list-style-type: none"> <li>No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> <p>Acknowledge switch-on inhibit and run the drive</p> <ul style="list-style-type: none"> <li>Check whether the drive is moving</li> </ul>	

## Example trace: SLS (with encoder) with STOP E



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Active SLS level bit 1
- ③ Active SLS level bit 0
- ④ SLS active
- ⑤ Internal event
- ⑥ SOS active
- ⑦ SS1 active
- ⑧ STO active
- ⑨ STOP E active
- ⑩ Select SLS bit 1
- ⑪ Select SLS bit 0
- ⑫ Deselect SLS

Image A-9 Example trace: SLS (with encoder) with STOP E

Trace evaluation:

- SLS function with SLS level 2 is activated (see bits "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -400 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault reaction STOP E (corresponds to selection SOS) is initiated (see bit "STOP E active")
- The standstill position is only safely monitored (time axis 100 ms; see bit "SOS active") after the transition time STOP E to SOS (p9553) has expired
- However, as the axis continues to rotate, the standstill tolerance window is violated (time axis approx. 120 ms)
- STOP B is initiated (see bit "SS1 active")
- The drive is braked to a standstill
- Standstill is reached (time axis approx. 500 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

---

**Note**

**Time differences through internal calculations**


Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---

## Acceptance test for Safe Speed Monitor with encoder (Extended Functions)

No.	Description	Status
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• No Safety message (r0945, r2122, r9747) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance tests."</li> </ul>	
2.	Switch off the drive or specify speed setpoint = 0 Configure and activate trace recording <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.15 = 0)</li> <li>• Record the following values: r9714[0], r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the level exceeds the SSM limit (p9546) and subsequently falls below it again.</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9722.15 (SSM (speed below the limit value))</li> </ul> Switch on the drive and specify the setpoint so that the level briefly exceeds the SSM limit and then drops below it once more <ul style="list-style-type: none"> <li>• Check whether the drive is turning</li> </ul>	
3.	Analyze trace: <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the SSM limit p9546, r9722.15 = 0 applies</li> <li>• Once the limit has been undershot, r9722.15 = 1 is valid</li> <li>• If the hysteresis is active, r9722.15 only becomes 1 again if r9714[0] falls below the SSM limit p9546 minus hysteresis value p9547.</li> </ul>	
4.	Save/print the trace and add it to the acceptance report (refer to the example below)	

Example trace: SSM (with encoder) with hysteresis



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② SSM (speed below limit value)

Image A-10 Example trace: SSM (with encoder) with hysteresis

Trace evaluation:

- Drive is accelerated (time axis from approx. -300 ms)
- SSM limit value (p9546) is exceeded (time axis 0 ms)
- Bit "SSM (speed below limit value)" is set to 0 (time axis 0 ms)
- Drive is decelerated again (time axis approx. 750 ms)
- Hysteresis active: The above mentioned bit is only set to 1 again if the speed falls below the SSM limit value minus the hysteresis value (p9547) (time axis approx. 1080 ms)

---

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---

## Acceptance test for Safe Direction with encoder (Extended Functions)

### SDI positive/negative with encoder and stop response "STOP A"


No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	<b>Initial state</b> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• For "Motion monitoring without selection (Page 205)": - "SDI positive or negative" activated (p9512.12 = 1 or p9512.13 = 1)</li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• SDI positive deselected (r9720.12 = 1) and SDI negative deselected (r9720.13 = 1) Note: The parameterized SDI monitoring is already active for motion monitoring without selection.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<b>Configure and activate trace recording</b> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul> Select SDI positive or SDI negative Note: The parameterized SDI monitoring is already active for motion monitoring without selection.           Switch-on the drive and traverse in the negative or positive direction of rotation <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SDI tolerance (p9564) has been exceeded that it is coasting down or a configured holding brake is closed</li> </ul> Check whether the following safety messages are pending:	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• As soon as r9713[0] leaves the SDI tolerance window, a safety message becomes active (r9722.7 = 0).</li> <li>• As consequence, STOP A is initiated and the pulses are canceled (p9721.2 = 1).</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge safety messages Initiate a POWER ON or a warm restart for motion monitoring functions without selection.	
	<ul style="list-style-type: none"> <li>• No safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	



## Example trace: SDI positive (with encoder) with STOP A



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI positive
- ③ SDI positive active
- ④ Internal event
- ⑤ STO active
- ⑥ Enable pulses

Image A-11 Example trace: SDI positive (with encoder) with STOP A

## Trace evaluation:

- Function SDI positive is activated (see bit "SDI positive active")
- The drive starts moving (time axis approx. -200 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Error response STOP A is initiated (time axis 0 ms; bits "STO active" and "Pulse enable" are set to 1)
- The drive coasts to a standstill or a configured holding brake is closed

**Note**

**Time differences through internal calculations**


Small time differences (of the order of two to three safety cycles (here up to 8 ms)) are caused by internal calculations and do not present a problem.

**SDI positive/negative with encoder and stop response "STOP B"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• For "Motion monitoring without selection (Page 205)": - "SDI positive or negative" activated (p9512.12 = 1 or p9512.13 = 1)</li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• SDI positive deselected (r9720.12 = 1) and SDI negative deselected (r9720.13 = 1) Note: The parameterized SDI monitoring is already active for motion monitoring without selection.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul>	

No.	Description	Status
	Select SDI positive or SDI negative Note: The parameterized SDI monitoring is already active for motion monitoring without selection. Switch-on the drive and traverse in the negative or positive direction of rotation <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SDI tolerance (p9564) has been exceeded that it is decelerated along the OFF3 ramp before STOP A becomes active</li> </ul> Check whether the following safety messages are pending: <ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• As soon as r9713[0] leaves the SDI tolerance window, a safety message becomes active (r9722.7 = 0).</li> <li>• STOP B is initiated as a consequence (with subsequent stop STOP A)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge safety messages Initiate a POWER ON or a warm restart for motion monitoring functions without selection. <ul style="list-style-type: none"> <li>• No safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> Acknowledge switch-on inhibit and run the drive <ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	

Example trace: SDI positive (with encoder) with STOP B



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI positive
- ③ SDI positive active
- ④ Internal event
- ⑤ SS1 active
- ⑥ Enable pulses

Image A-12 Example trace: SDI positive (with encoder) with STOP B

Trace evaluation:

- Function SDI positive is activated (see bit "SDI positive active")
- The drive starts moving (time axis approx. -300 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Error response STOP B is triggered (time axis 0 ms; see bit "SS1 active")
- The drive is braked to a standstill
- Standstill reached (time axis from approx. 250 ms)
- STOP A (as follow-up response to STOP B) is activated; at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

**Note****Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 6 ms)) are caused by internal calculations and do not present a problem.


**SDI positive/negative with encoder and stop response "STOP C"**

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	<b>Initial state</b> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• For "Motion monitoring without selection (Page 205)": - "SDI positive or negative" activated (p9512.12 = 1 or p9512.13 = 1)</li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• SDI positive deselected (r9720.12 = 1) and SDI negative deselected (r9720.13 = 1) Note: The parameterized SDI monitoring is already active for motion monitoring without selection.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<b>Configure and activate trace recording</b> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9721.13 (STOP C active)</li> <li>• r9722.2 (SS2 active, set for STOP C)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul> Select SDI positive or SDI negative Note: The parameterized SDI monitoring is already active for motion monitoring without selection. Switch-on the drive and traverse in the negative or positive direction of rotation <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SDI tolerance (p9564/9364) has been exceeded that it is decelerated to a standstill along the OFF3 ramp</li> </ul> Check whether the following safety messages are pending: <ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> <li>• C01708, C30708 (STOP C initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• As soon as r9713[0] leaves the SDI tolerance window, a safety message becomes active (r9722.7 = 0).</li> <li>• STOP C is initiated as a consequence.</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge safety messages Initiate a POWER ON or a warm restart for motion monitoring functions without selection. <ul style="list-style-type: none"> <li>• Check whether the drive is running with the setpoint again</li> <li>• No safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	

## Example, SDI positive trace (with encoder) with STOP C



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI positive
- ③ SDI positive active
- ④ Internal event
- ⑤ STOP C active
- ⑥ SOS active

Image A-13 Example trace: SDI positive (with encoder) with STOP C

## Trace evaluation:

- Function SDI positive is activated (see bit "SDI positive active")
- The drive starts moving (time axis approx. -300 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Error response STOP C is triggered (time axis 0 ms; see bit "STOP C active")
- The drive is braked to a standstill
- After the SS2 timer has expired, the subsequent SOS function is activated (time axis 400 ms)
- The "SOS active" bit is set

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 6 ms)) are caused by internal calculations and do not present a problem.


**SDI positive/negative with encoder and stop response "STOP D"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• For "Motion monitoring without selection (Page 205)": - "SDI positive or negative" activated (p9512.12 = 1 or p9512.13 = 1)</li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• SDI positive deselected (r9720.12 = 1) and SDI negative deselected (r9720.13 = 1) Note: The parameterized SDI monitoring is already active for motion monitoring without selection.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F; see note "Non-critical alarms" at the beginning of Section "Acceptance tests."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9721.14 (STOP D active)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> </ul>	



No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul> Select SDI positive or SDI negative Note: The parameterized SDI monitoring is already active for motion monitoring without selection. Switch-on the drive and traverse in the negative or positive direction of rotation <ul style="list-style-type: none"> <li>• Check whether the drive moves and - after the SDI tolerance (p9564) has been exceeded as well as the standstill window for SOS exited - decelerates along the OFF3 ramp before STOP A becomes active</li> </ul> Check whether the following safety messages are pending: <ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> <li>• C01709, C30709 (STOP D initiated)</li> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• As soon as r9713[0] leaves the SDI tolerance window, a safety message becomes active (r9722.7 = 0).</li> <li>• STOP D is initiated as a consequence.</li> <li>• As a consequence of STOP D (selection SOS) the above-described responses will be triggered if the drive is not stopped by the higher-level controller on activation of STOP D</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge safety messages Initiate a POWER ON or a warm restart for motion monitoring functions without selection. <ul style="list-style-type: none"> <li>• No safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> Acknowledge switch-on inhibit and run the drive <ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	

Example trace: SDI positive (with encoder) with STOP D



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI positive
- ③ SDI positive active
- ④ Internal event
- ⑤ SOS active
- ⑥ SS1 active
- ⑦ STOP D active
- ⑧ Enable pulses

Image A-14 Example trace: SDI positive (with encoder) with STOP D

Trace evaluation:

- Function SDI positive is activated (see bit "SDI positive active")
- The drive starts moving (time axis approx. -300 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP D (corresponds to selecting SOS) is initiated (time axis 0 ms; see bit "STOP D active")
- The standstill position is only safely monitored (time axis 300 ms; see bit "SOS active") after the transition time STOP D to SOS (p9553) has expired

- However, as the axis continues to rotate, the standstill tolerance window is violated (time axis approx. 600 ms)
- STOP B is initiated (see bit "SS1 active")
- The drive is braked to a standstill
- Standstill is reached (time axis approx. 650 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

**Note****Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 6 ms)) are caused by internal calculations and do not present a problem.


**SDI positive/negative with encoder and stop response "STOP E"**

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	• Drive in the "Ready" state (p0010 = 0)	
	• Safety Integrated Extended Functions enabled (p9601.2 = 1)	
	• Safety functions enabled (p9501.0 = 1)	
	• Safety configured with encoder (p9506 = 0 or p9506 = 2)	
	• For "Motion monitoring without selection (Page 205)": - "SDI positive or negative" activated (p9512.12 = 1 or p9512.13 = 1)	
	• SDI enabled (p9501.17 = 1)	
	• SDI positive deselected (r9720.12 = 1) and SDI negative deselected (r9720.13 = 1)  Note: The parameterized SDI monitoring is already active for motion monitoring without selection.	
	• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."	
2.	• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance. • Note that the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".	
3.	Configure and activate trace recording	
	• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)	
	• Record the following values: r9713[0], r9721, r9722	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9721.15 (STOP E active)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul> <p>Select SDI positive or SDI negative                      Note: The parameterized SDI monitoring is already active for motion monitoring without selection.</p> <p>Switch-on the drive and traverse in the negative or positive direction of rotation</p> <ul style="list-style-type: none"> <li>• Check whether the drive moves and - after the SDI tolerance (p9564) has been exceeded as well as the standstill window for SOS exited - decelerates along the OFF3 ramp before STOP A becomes active</li> </ul> <p>Check whether the following safety messages are pending:</p> <ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> <li>• C01710, C30710 (STOP E initiated)</li> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• As soon as r9713[0] leaves the SDI tolerance window, a safety message becomes active (r9722.7 = 0).</li> <li>• STOP E is initiated as a consequence.</li> <li>• As a consequence of STOP E (selection SOS) the above-described responses will be triggered if the drive is not stopped by the drive-based ESR function or higher-level controller when STOP E is activated</li> </ul>	
5.	<p>Save/print the trace and add it to the acceptance report (refer to the example below)</p>	
6.	<p>Deselect SDI and safely acknowledge safety messages Initiate a POWER ON or a warm restart for motion monitoring functions without selection.</p> <ul style="list-style-type: none"> <li>• No safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> <p>Acknowledge switch-on inhibit and run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	
7.	<p>Repeat points 1 to 6 for the opposite direction.</p>	

## Example trace: SDI positive (with encoder) with STOP E



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI positive
- ③ SDI positive active
- ④ Internal event
- ⑤ SOS active
- ⑥ SS1 active
- ⑦ STOP E active
- ⑧ Enable pulses

Image A-15 Example trace: SDI positive (with encoder) with STOP E

## Trace evaluation:

- Function SDI positive is activated (see bit "SDI positive active")
- The drive starts moving (time axis approx. -300 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP E (corresponds to selecting SOS) is initiated (time axis 0 ms; see bit "STOP E active")
- The standstill position is only safely monitored (time axis 500 ms; see bit "SOS active") after the transition time STOP E to SOS (p9554) has expired

- However, as the axis continues to rotate, the standstill tolerance window is violated (time axis approx. 800 ms)
- STOP B is initiated (see bit "SS1 active")
- The drive is braked to a standstill
- Standstill is reached (time axis approx. 850 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560) (drops below the shutdown speed SS1 before SS1 timer (p9556) has expired).

---

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three safety cycles (here up to 6 ms)) are caused by internal calculations and do not present a problem.

---

## Acceptance test for Safely Limited Position

### Requirements

- To perform the SLP acceptance test, you must activate the acceptance test mode (p9570).
- Then you must select the SLP acceptance test (p9575 = 172)
- With the aid of the Safety Control Channel (SCC), a higher-level controller can now be informed of an active SLP acceptance test through bit 14 in S\_ZSWB3 so that the controller can deactivate the software limit switches.
- If EPOS is enabled, the SLP acceptance test is signaled to EPOS via an internal software interface so that EPOS can deactivate the EPOS monitoring functions.

### SLP with stop response "STOP A"

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both limits in each traversing range used. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	• Drive in the "Ready" state (p0010 = 0)	
	• Safety Integrated Extended Functions enabled (p9601.2 = 1)	
	• Safety functions enabled (p9501.0 = 1)	
	• Safety configured with encoder (p9506 = 0 or p9506 = 2)	
	• SLP enabled (p9501.1 = 1)	
	• SLP deselected (r9720.6 = 1)	
	• Drive safely referenced (r9721.7 = r9722.23 = 1)	
	• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."	
2.	• It may be necessary to take measures in the higher-level controller to be able to exceed the position limits.	
3.	Configure and activate trace recording	
	• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)	
	• Record the following values: r9708[0], r9713[0], r9721, r9722	
	• Select the time interval and pretrigger so you can recognize when the active SLP limits have been exceeded and the subsequent drive responses	
	For better analysis, display the following bit values:	
	• r9721.12 (STOP A or B active)	
	• r9722.0 (STO active; set for STOP A)	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>r9722.7 (internal event; set to 0 when the first safety message occurs)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.6 (SLP active)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.30 (SLP limit high maintained)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.31 (SLP limit low maintained)</li> </ul>	
	Select SLP traversing range	
	Traverse the drive to a safe absolute position within this traversing range	
	Select SLP	
	Switch-on the drive and traverse in the positive or negative direction of rotation	
	<ul style="list-style-type: none"> <li>Check whether the drive is moving, and after the upper or lower SLP limit (p9534 or p9535) has been exceeded, that it coasts down or a configured holding brake is closed.</li> </ul>	
	Check whether the following safety messages are pending:	
	<ul style="list-style-type: none"> <li>C01715 (10), C30715 (10); SLP1 violated, or C01715 (20), C30715 (20); SLP2 violated</li> </ul>	
	<ul style="list-style-type: none"> <li>C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>As soon as r9708[0] leaves the SLP limits, a safety message becomes active (r9722.7 = 0).</li> <li>If the upper SLP limit is violated, the safety message "SLP upper limit not maintained" becomes active (r9722.30 = 0).</li> <li>If the lower SLP limit is violated, the safety message "SLP lower limit not maintained" becomes active (r9722.31 = 0).</li> <li>As consequence, STOP A is initiated and the pulses are canceled (p9721.2 = 1).</li> </ul>	
5.	Save/print the trace and attach to the acceptance report	
6.	Repeat points 1 to 6 for the opposite SLP limit.	

SLP with stop response "STOP B"

No.	Description	Status
<b>Note:</b>		
The acceptance test must be individually performed for each configured control and for both limits. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> </ul>	
	<ul style="list-style-type: none"> <li>SLP enabled (p9501.1 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>SLP deselected (r9720.6 = 1)</li> </ul>	



No.	Description	Status
	<ul style="list-style-type: none"> <li>• Drive safely referenced (r9721.7 = r9722.23 = 1)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the position limits.</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9708[0], r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLP limits have been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.6 (SLP active)</li> <li>• r9722.30 (SLP limit high maintained)</li> <li>• r9722.31 (SLP limit low maintained)</li> </ul> <p>Select SLP traversing range</p> <p>Traverse the drive to a safe absolute position within this traversing range</p> <p>Select SLP</p> <p>Switch-on the drive and traverse in the negative or positive direction of rotation</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLP limit (p9564) has been exceeded that it is braked along the OFF3 ramp before STOP A becomes active</li> </ul> <p>Check whether the following safety messages are pending:</p> <ul style="list-style-type: none"> <li>• C01715 (10), C30715 (10); SLP1 violated, or C01715 (20), C30715 (20); SLP2 violated</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• As soon as r9708[0] leaves the SLP limits, a safety message becomes active (r9722.7 = 0).</li> <li>• If the upper SLP limit is violated, the safety message "SLP upper limit not maintained" becomes active (r9722.30 = 0).</li> <li>• If the lower SLP limit is violated, the safety message "SLP lower limit not maintained" becomes active (r9722.31 = 0).</li> <li>• STOP B is initiated as a consequence (with subsequent stop STOP A)</li> </ul>	
5.	Save/print the trace and attach to the acceptance report	
6.	Repeat points 1 to 6 for the other position limit.	

**SLP with stop response "STOP C"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control and for both limits. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SLP enabled (p9501.1 = 1)</li> <li>• SLP deselected (r9720.6 = 1)</li> <li>• Drive safely referenced (r9721.7 = r9722.23 = 1)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the position limits.</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9708[0], r9713[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLP limits have been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9722.2 (SS2 is active, is set with STOP C); r9722.3 (SOS active)</li> <li>• r9721.13 (STOP C active)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.6 (SLP active)</li> <li>• r9722.30 (SLP limit high maintained)</li> <li>• r9722.31 (SLP limit low maintained)</li> </ul> <p>Select SLP traversing range</p> <p>Traverse the drive to a safe absolute position within this traversing range</p> <p>Select SLP</p> <p>Switch-on the drive and traverse in the negative or positive direction of rotation</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the upper or lower SLP limit (p9534 or p9535) has been exceeded, that it is braked to a standstill along the OFF3 ramp</li> </ul> <p>Check whether the following safety messages are pending:</p> <ul style="list-style-type: none"> <li>• C01715 (10), C30715 (10); SLP1 violated, or C01715 (20), C30715 (20); SLP2 violated</li> </ul>	

No.	Description	Status
	<ul style="list-style-type: none"> <li>C01708, C30708 (STOP C initiated)</li> </ul>	
4.	Analyze trace:	
	<ul style="list-style-type: none"> <li>As soon as r9708[0] leaves the SLP limits, a safety message becomes active (r9722.7 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>If the upper SLP limit is violated, the safety message "SLP upper limit not maintained" becomes active (r9722.30 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>If the lower SLP limit is violated, the safety message "SLP lower limit not maintained" becomes active (r9722.31 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>STOP C is initiated as a consequence.</li> </ul>	
5.	Save/print the trace and attach to the acceptance report	
6.	Repeat points 1 to 6 for the opposite SLP limit.	

### SLP with stop response "STOP D"

No.	Description	Status
<b>Note:</b>		
The acceptance test must be individually performed for each configured control and for both limits. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> </ul>	
	<ul style="list-style-type: none"> <li>SLP enabled (p9501.1 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>SLP deselected (r9720.6 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Drive safely referenced (r9721.7 = r9722.23 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>It may be necessary to take measures in the higher-level controller to be able to exceed the position limits.</li> </ul>	
3.	Configure and activate trace recording	
	<ul style="list-style-type: none"> <li>Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Record the following values: r9708[0], r9713[0], r9720, r9721, r9722</li> </ul>	
	<ul style="list-style-type: none"> <li>Select the time interval and pretrigger so you can recognize when the active SLP limits have been exceeded and the subsequent drive responses</li> </ul>	
	For better analysis, display the following bit values:	
	<ul style="list-style-type: none"> <li>r9721.12 (STOP A or B active)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9721.14 (STOP D active)</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9722.1 (SS1 active; set for STOP B)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.3 (SOS active)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.6 (SLP active)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.30 (SLP limit high maintained)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.31 (SLP limit low maintained)</li> </ul>	
	Select SLP traversing range	
	Traverse the drive to a safe absolute position within this traversing range	
	Select SLP	
	Switch-on the drive and traverse in the negative or positive direction of rotation	
	<ul style="list-style-type: none"> <li>• Check whether the drive moves and, after the upper or lower SLP limit (p9534 or p9535) has been exceeded and the standstill window for SOS exited, decelerates along the OFF3 ramp before STOP A becomes active</li> </ul>	
	Check whether the following safety messages are pending:	
	<ul style="list-style-type: none"> <li>• C01715 (10), C30715 (10); SLP1 violated, or C01715 (20), C30715 (20); SLP2 violated</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01709, C30709 (STOP D initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01701, C30701 (STOP B initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace:	
	<ul style="list-style-type: none"> <li>• As soon as r9708[0] leaves the SLP limits, a safety message becomes active (r9722.7 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>• If the upper SLP limit is violated, the safety message "SLP upper limit not maintained" becomes active (r9722.30 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>• If the lower SLP limit is violated, the safety message "SLP lower limit not maintained" becomes active (r9722.31 = 0).</li> </ul>	
	<ul style="list-style-type: none"> <li>• STOP D is initiated as a consequence.</li> </ul>	
	<ul style="list-style-type: none"> <li>• As a consequence of STOP D (selection SOS) the above-described responses will be triggered if the drive is not stopped by the higher-level controller on activation of STOP D</li> </ul>	
5.	Save/print the trace and attach to the acceptance report	
6.	Repeat points 1 to 6 for the opposite SLP limit.	

## SLP with stop response "STOP E"

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both limits. Control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> <li>• SLP enabled (p9501.1 = 1)</li> <li>• SLP deselected (r9720.6 = 1)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the position limits.</li> </ul>	
3.	Configure and activate trace recording <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9708[0], r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLP limits have been exceeded and the subsequent drive responses</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9721.15 (STOP E active)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.3 (SOS active)</li> <li>• r9722.7 (internal event; set to 0 when the first safety message occurs)</li> <li>• r9722.6 (SLP active)</li> <li>• r9722.30 (SLP limit high maintained)</li> <li>• r9722.31 (SLP limit low maintained)</li> </ul> Select SLP traversing range Traverse the drive to a safe absolute position within this traversing range Select SLP Switch-on the drive and traverse in the negative or positive direction of rotation <ul style="list-style-type: none"> <li>• Check whether the drive moves and - after the SLP limit (p9564) has been exceeded as well as the standstill window for SOS exited - decelerates along the OFF3 ramp before STOP A becomes active</li> </ul> Check whether the following safety messages are pending:	

## A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• C01715 (10), C30715 (10); SLP1 violated, or C01715 (20), C30715 (20); SLP2 violated</li> <li>• C01710, C30710 (STOP E initiated)</li> <li>• C01707, C30707 (tolerance for safe operating stop exceeded)</li> <li>• C01701, C30701 (STOP B initiated)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• As soon as r9708[0] leaves the SLP limits, a safety message becomes active (r9722.7 = 0).</li> <li>• If the upper SLP limit is violated, the safety message "SLP upper limit not maintained" becomes active (r9722.30 = 0).</li> <li>• If the lower SLP limit is violated, the safety message "SLP lower limit not maintained" becomes active (r9722.31 = 0).</li> <li>• STOP E is initiated as a consequence.</li> <li>• As a consequence of STOP E (selection SOS) the above-described responses will be triggered if the drive is not stopped by the drive-based ESR function or higher-level controller when STOP E is activated</li> </ul>	
5.	Save/print the trace and attach to the acceptance report	
6.	Repeat points 1 to 6 for the opposite SLP limit.	

## Acceptance test for Safe Brake Test (Extended Functions)

### Note

#### Differences to other acceptance tests


SBT is itself a diagnostic function. Unlike the acceptance tests of the safety functions stated above, in which a violation of the safety function has to be triggered, with SBT it is only necessary to check the correct parameterization of this diagnostic function.

No.	Description	Status
<b>Note:</b>		
The test must be performed separately for each configured brake and all the required test scenarios.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety configured with encoder (p9506 = 0 or p9506 = 2)</li> </ul>	
	<ul style="list-style-type: none"> <li>SBT enabled (p10201.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>All brakes open</li> </ul>	
	<ul style="list-style-type: none"> <li>Enable Safe Brake Control (p9602 = 1) if an internal brake is to be tested.</li> </ul>	
	<ul style="list-style-type: none"> <li>No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	Configure and activate trace recording	
	<ul style="list-style-type: none"> <li>Trigger: Trigger on variable - bit pattern (r10231.1 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Record the following values: r9713[0], r10231, r10234, r10240, r0080, r0063</li> </ul>	
	<ul style="list-style-type: none"> <li>Select the time interval so that the entire brake test (<math>2 \times p10208 + p10211</math> or <math>2 \times p10208 + p10221</math>) of the respective brake can be recorded as of the trigger time. Set a pretrigger in accordance with the time for selection of the brake test until the start of the first test sequence (e.g. 1 s).</li> </ul>	
	For better analysis, display the following bit values:	
	<ul style="list-style-type: none"> <li>r10231.0 (brake test selection)</li> </ul>	
	<ul style="list-style-type: none"> <li>r10231.1 (brake test start of the test sequence)</li> </ul>	
	<ul style="list-style-type: none"> <li>r10231.2 (brake selection)</li> </ul>	
	<ul style="list-style-type: none"> <li>r10231.5 (external brake status) when testing an external brake</li> </ul>	
	<ul style="list-style-type: none"> <li>r10234.0 (brake test selected)</li> </ul>	
	<ul style="list-style-type: none"> <li>r10234.3 (brake test active)</li> </ul>	
	<ul style="list-style-type: none"> <li>r10234.4 (brake test result)</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>r10234.5 (brake test completed)</li> </ul>	
	Trigger brake test	
	Read out r10241 after completing the brake test	
3.	Analyze trace: <ul style="list-style-type: none"> <li>r0080 must correspond approximately to -r10241 before the start of the test sequence</li> <li>p10208 must elapse to build up the torque and to clear the torque</li> <li>The constant test torque must be present over the time from p10211 or p10221</li> <li>r10240 contains the maximum value from r0080 + r10241, i.e. the maximum torque with which the brake was tested</li> </ul>	
4.	Save/print the trace and add it to the acceptance report (refer to the example below)	
5.	Repeat points 1 to 4 for all the brakes to be tested and all test sequences	

Example trace: SBT



- |   |  |   |   |
|---|--|---|---|
| ① | r10240: SI Motion SBT test torque diagnostics      | ② | r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the CU |
| ③ | r0080: Torque actual value                         | ④ | r0063: Speed actual value, smoothed   |
| ⑤ | r10234: SI Safety Info Channel status word S_ZSW3B | ⑥ | r10242: SI Motion SBT state diagnostics   |
| ⑦ | r10231: SI Motion SBT control word diagnostics     | - | -   |

Image A-16 Example trace: SBT



### A.3.3.3 Acceptance tests for Extended Functions (without encoder)

#### Encoder parameterization test

Table A- 8 Encoder parameterization test

No.	Description	Status
<b>Note:</b> This test of the encoder parameterization must only be performed once if you use the Safety Integrated Extended Functions without encoder.		
1.	The motor-side actual velocity value r0063 must, when converted to the load-side, produce the load-side actual velocity value r9714[0]:	
	<ul style="list-style-type: none"> <li>Linear motor, linear axis:  <math>r9714[0] [\text{mm/min}] = r0313 \times r0063 [\text{m/min}] \times 1000 [\text{mm/m}]</math> </li> </ul>	
	<ul style="list-style-type: none"> <li>Rotary motor, linear axis:  <math>r9714[0] [\text{mm/min}] = r0313 \times r0063 [\text{rpm}] \times p9520 [\text{mm/rev}] \times p9521/p9522</math> </li> </ul>	
	<ul style="list-style-type: none"> <li>Rotary motor, rotary axis:  <math>r9714[0] [\text{rev/min}] = r0313 \times r0063 [\text{rev/min}] \times p9521/p9522</math> </li> </ul>	
<b>Note:</b> If it is not possible to check the actual velocity value in your configuration, check the position as an alternative:		
	<ul style="list-style-type: none"> <li>Traverse a rotary axis through a precisely defined angle (e.g. one revolution). The safety position values from r9708[0] and r9708[1] must then match at standstill.</li> </ul>	
	<ul style="list-style-type: none"> <li>Traverse a linear axis a precisely defined distance (e.g. 10 mm). The safety position values from r9708[0] and r9708[1] must then match at standstill.</li> </ul>	

#### Acceptance test Safe Torque Off without encoder (Extended Functions)

No.	Description	Status
<b>Notes:</b> The acceptance test must be individually conducted for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> </ul>	
	<ul style="list-style-type: none"> <li>No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
	<ul style="list-style-type: none"> <li>r9720.0 = 1 (STO deselected)</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9722.0 = 0 (STO inactive)</li> </ul> <p>Note: After deselecting STO, the drive must be switched on within 5 seconds.</p>	
2.	<p>Run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> <p>Select STO when you issue the traversing command and check the following:</p> <ul style="list-style-type: none"> <li>• The drive coasts to a standstill or is braked and stopped by the mechanical brake (if available and configured (p1215, p9602, p9802)).</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9720.0 = 0 (STO selected)</li> <li>• r9722.0 = 1 (STO active)</li> </ul>	
3.	<p>Deselect STO and check the following</p> <p>Note: After deselecting STO, the drive must be switched on within 5 seconds.</p> <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9720.0 = 1 (STO deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul>	
4.	<p>Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.</p>	


## Acceptance test for Safe Stop 1 without encoder (Extended Functions)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• Only for "Safe Stop 1 with external stop (Page 90)": p9507.3 = 1</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	Run the drive <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul>	
3.	Configure and activate trace recording <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9720.1 = 0)</li> <li>• Record the following values: r9714[0], r9714[1], r9720, r9722</li> <li>• Select the time interval and pretrigger so you can recognize the selection of SS1 and the transition into the subsequent STO state</li> </ul> Select SS1 while the drive is moving <ul style="list-style-type: none"> <li>• Drive brakes along the OFF3 ramp (not in the case of SS1 with external stop)</li> <li>• Subsequent state STO is activated</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9720.1 (deactivation SS1)</li> <li>• r9722.0 (STO active)</li> <li>• r9722.1 (SS1 active)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• STO is triggered if the speed drops below the shutdown speed (p9560) The configuration of SBR (r9714 [1]) should have approximately the same gradient as the OFF3 ramp. The curves r9714[0] and r9714[1] should approximately run in parallel.</li> <li>• For p9506 = 3, STO is triggered after the threshold has been fallen below or after the SS1 timer has expired.</li> <li>• For p9507.3 = 1, the drive does not brake along the OFF3 ramp. Here, STO is triggered after the SS1 timer has elapsed.</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Canceling SS1	
	<ul style="list-style-type: none"> <li>No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	Note: After deselecting STO, the drive must be switched on within 5 seconds.	
	<ul style="list-style-type: none"> <li>Check whether the correct drive is operational</li> </ul>	

Example trace: SS1 (without encoder)



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ③ SS1 active
- ④ STO active
- ⑤ Deselect SS1

Image A-17 Example trace: SS1 (without encoder)

Trace evaluation:

- SS1 function is selected (time axis 0 ms; see bit "deselection SS1")
  - Response bit "SS1 active" is set (time axis approx. 20 ms)
  - The drive decelerates along the configured OFF3 ramp (p1135)
  - Recording of r9714[0] (orange curve) shows whether the OFF3 ramp is active.
- 

#### **Note**

##### **Behavior for "SS1 with external stop"**

When selecting "Safe Stop 1 with external stop (Page 90)" the drive is not braked along the OFF3 ramp, but after the delay time (p9556) has expired, only STO/SBC is automatically initiated.

---

- STO is activated (time axis approx. 720 ms; see bit "STO active"); at this point the speed falls below the shutdown speed SS1 (p9560)
- A fault is generated if the envelope curve of the SBR function (Drive\_1.r9714[1]) is exceeded by the actual speed (Drive\_1.r9714[0])

In contrast to SAM for Safety with encoder, this curve is not tracked according to actual speed, but calculated using Safety parameters. Furthermore, this monitoring only becomes active after a configurable time has elapsed (in this case the time is 250 ms). This curve should approximately run in parallel to r9714 [0].

---

#### **Note**

##### **Time differences through internal calculations**

Small time differences (of the order of two to three Safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

---

**Acceptance test for Safe Brake Control without encoder (Extended Functions)**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control. The control can be realized via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• Enable SBC function (p9602 = 1, p9802 = 1)</li> <li>• Brake as in sequence control or brake always released (p1215 = 1 or p1215 = 2)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> <li>• r9773.4 = 0 (SBC not requested)</li> <li>• r9720.0 = 1 (STO deselected) or r9720.1 = 1 (SS1 deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul> <p>Note: After deselecting STO, the drive must be switched on within 5 seconds.</p>	
2.	<p>Run drive (if applied, brake is released)</p> <ul style="list-style-type: none"> <li>• Check whether the correct drive is operational</li> </ul> <p>Select STO/SS1 when you issue the traversing command and check the following:</p> <ul style="list-style-type: none"> <li>• Brake is applied</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> <li>• r9773.4 = 1 (SBC requested)</li> <li>• r9720.0 = 0 (STO selected) or r9720.1 = 0 (SS1 selected)</li> <li>• r9722.0 = 1 (STO active)</li> </ul>	
3.	<p>Deselect STO/SS1 and check the following</p> <p>Note: After deselecting STO, the drive must be switched on within 5 seconds.</p> <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7])</li> <li>• r9773.4 = 0 (SBC deselection)</li> <li>• r9720.0 = 1 (STO deselected) or r9720.1 = 1 (SS1 deselected)</li> <li>• r9722.0 = 0 (STO inactive)</li> </ul>	
4.	<p>Acknowledge switch-on inhibit and run the drive. Check whether the correct drive is operational.</p>	

## Acceptance tests for Safely Limited Speed without encoder (Extended Functions)

### SLS without encoder with stop response "STOP A"


No.	Description	Status
<b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	<b>Initial state</b> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• For "Motion monitoring without selection (Page 205)":               <ul style="list-style-type: none"> <li>- "Safety without selection" configured (p9601 = 24hex or 25hex)</li> <li>- "Safety without selection" activated (p9512.4 = 1)</li> </ul> </li> <li>• No safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive or TM54F (if one is being used); see note "Non-critical alarms" at the beginning of Section "Acceptance tests".</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>• After selecting SLS, the drive must be switched on within 5 seconds.</li> </ul>	
3.	<b>Configure and activate trace recording</b> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9714[0], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLS limit has been exceeded and the subsequent drive responses</li> </ul> Select SLS with level x Switch on the drive and specify the setpoint above the SLS limit <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (p9331[x]) has been exceeded that it is coasting down or a configured holding brake is closed</li> </ul> Check whether the following Safety messages are pending: <ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<b>Analyze trace:</b> <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a Safety message (r9722.7 = 0) becomes active</li> <li>• STOP A is initiated as a consequence</li> </ul> For better analysis, display the following bit values:	

## A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.0 (STO active; set for STOP A)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> </ul>	
	<ul style="list-style-type: none"> <li>• r9722.7 (internal event; set when the first Safety message occurs)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SLS (if this is possible) and acknowledge Safety messages. Note: After deselecting SLS, the drive must be switched on within 5 seconds.	
	<ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	



## Example trace: SLS (without encoder) with STOP A



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Active SLS level bit 1
- ③ Active SLS level bit 0
- ④ SLS active
- ⑤ Internal event
- ⑥ STO active
- ⑦ STOP A or B active
- ⑧ Select SLS bit 1
- ⑨ Select SLS bit 0
- ⑩ Deselect SLS

Image A-18 Example trace: SLS (without encoder) with STOP A

## Trace evaluation:

- SLS function with SLS level 1 is active (see bits "deselection SLS", "selection SLS bit 0", "selection SLS bit 1" and "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -800 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)

A.3 Acceptance tests (recommendations)

- Fault response STOP A is initiated (time axis 0 ms; see bit "STOP A or B active" and "STO active")
- Drive coasts (see red curve of r9714[0])

**Note**

**Time differences through internal calculations**


Small time differences (of the order of two to three Safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.

**SLS without encoder with stop response "STOP B"**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be carried out separately for each configured control and each SLS speed limit used. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• For "Motion monitoring without selection (Page 205)":                             <ul style="list-style-type: none"> <li>- "Safety without selection" configured (p9601 = 24 hex or 25 hex)</li> <li>- "Safety without selection" activated (p9512.4 = 1)</li> </ul> </li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the active speed limit.</li> <li>• Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>• After selecting SLS, the drive must be switched on within 5 seconds.</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9714[0], r9714[1], r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SLS limit has been exceeded and the subsequent drive responses</li> </ul> <p>Select SLS with level x</p> <p>Switch on the drive and specify the setpoint above the SLS limit</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SLS limit (p9331[x]) has been exceeded that it is braked along the OFF3 ramp before STOP A becomes active</li> </ul> <p>Check whether the following Safety messages are pending:</p>	

No.	Description	Status
	<ul style="list-style-type: none"> <li>• C01714 (x00), C30714 (x00); x = 1...4 depending on the SLS level (safely limited speed exceeded)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01701, C30701 (STOP B initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the active SLS limit, a Safety message (r9722.7 = 0) becomes active</li> <li>• A STOP B is initiated as a consequence (with subsequent stop STOP A)</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.1 (SS1 active; set for STOP B)</li> <li>• r9722.4 (SLS active) and r9722.9/.10 (active SLS level)</li> <li>• r9722.7 (internal event; set when the first Safety message occurs)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	<p>Deselect SLS (if this is possible) and acknowledge Safety messages Note: After deselecting SLS, the drive must be switched on within 5 seconds.</p> <ul style="list-style-type: none"> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul> <p>Acknowledge switch-on inhibit and run the drive</p> <ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	

Example trace: SLS (without encoder) with STOP B



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② Drive\_1.r9714[1]: SI motion diagnostics velocity, actual SBR velocity limit at the Control Unit
- ③ Active SLS level bit 1
- ④ Active SLS level bit 0
- ⑤ SLS active
- ⑥ Internal event
- ⑦ SS1 active
- ⑧ STO active
- ⑨ STOP A or B active
- ⑩ Select SLS bit 1
- ⑪ Select SLS bit 0
- ⑫ Deselect SLS

Image A-19 Example trace: SLS (without encoder) with STOP B

Trace evaluation:

- SLS function with SLS level 1 is active (see bits "deselection SLS", "selection SLS bit 0", "selection SLS bit 1" and "SLS active", "active SLS level bit 0" and "active SLS level bit 1")
- Drive is accelerated beyond the SLS limit (time axis from approx. -800 ms)
- Exceeding the limit is recognized (time axis 0 ms)
- Safety fault is initiated (time axis 0 ms; bit "internal event" is set to 0)
- Fault response STOP B is initiated (time axis 0 ms; see bit "STOP A or B active" and "SS1 active")
- Drive is decelerated to a standstill (see orange curve of r9714[0])
- Standstill reached (time axis from approx. 600 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "STO active"); at this point, the speed falls below the shutdown speed SS1 (p9560)
- SBR monitoring is activated after 250 ms

---

**Note****Time differences through internal calculations**

Small time differences (of the order of two to three Safety cycles (here up to 36 ms)) are caused by internal calculations and do not present a problem.


---

**Acceptance test for Safe Speed Monitor without encoder (Extended Functions)**

Table A- 9 "Safe Speed Monitor without encoder" function

No.	Description	Status
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• Please note: With active safety functions (e.g. SLS or for SSM with configured hysteresis) and for "SSM active" feedback signal with a pulse inhibit (p9509.0 = 1), the drive enable must be issued within 5 seconds after STO deselection using a positive edge at OFF1, otherwise STO becomes active again.</li> <li>• No Safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used); see note "Non-critical alarms" at the beginning of Section "Acceptance tests."</li> </ul>	
2.	<p>Switch off the drive or specify speed setpoint = 0</p> <p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.15 = 0)</li> <li>• Record the following values: r0899, r9714[0], r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the level exceeds the SSM limit (p9546) and subsequently falls below it again. You must also trace the behavior when the pulses are canceled (as a result of OFF1, OFF2 or OFF3).</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9722.15 (SSM speed under the limit value)</li> <li>• r9722.0 (STO active)</li> <li>• r0899.11 (pulses enabled)</li> </ul> <p>Switch on the drive and specify the setpoint so that the level briefly exceeds the SSM limit and then drops below it once more. Then shutdown the drive with OFF1, OFF2 or OFF3.</p> <ul style="list-style-type: none"> <li>• Check whether the drive is turning</li> </ul>	
3.	<p>Analyze trace:</p> <ul style="list-style-type: none"> <li>• If r9714[0] exceeds the SSM limit p9546, r9722.15 = 0 applies</li> <li>• If the hysteresis is active, then r9722.15 only becomes 1 again if r9714[0] falls below the SSM limit p9546 minus hysteresis value p9547.</li> <li>• For p9509.0 = 0, for pulse cancellation, the following applies r9722.15 = 1 and r9722.0 = 1.</li> <li>• For p9509.0 = 1, for pulse cancellation, the following applies r9722.15 = 0 and r9722.0 = 0.</li> </ul>	
4.	<p>Save/print the trace and add it to the acceptance report (refer to the example below)</p>	

### Example trace: SSM (without encoder) with hysteresis



- ① Drive\_1.r9714[0]: SI motion diagnostics velocity, load-side velocity actual value at the Control Unit
- ② SSM (speed below limit value)

Image A-20 Example trace: SSM (without encoder) with hysteresis

#### Trace evaluation:

- Drive is accelerated (time axis from approx. -150 ms)
- SSM limit value (p9546) is exceeded (time axis 0 ms)
- Bit "SSM (speed below limit value)" is set to 0 (time axis 0 ms)
- Drive is decelerated again (time axis approx. 470 ms)
- Hysteresis active: The above mentioned bit is only set to 1 again if the speed falls below the SSM limit value minus the hysteresis value (p9547) (time axis approx. 670 ms)

#### Note

##### Time differences through internal calculations

Small time differences (of the order of two to three Safety cycles (here, approx. 7 ms)) are caused by internal calculations and do not present a problem.

Acceptance test for Safe Direction without encoder (Extended Functions)


SDI positive/negative without encoder with stop response "STOP A"

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• For "Motion monitoring without selection (Page 205)":                             <ul style="list-style-type: none"> <li>- "Safety without selection" configured (p9601 = 24 hex or 25 hex)</li> <li>- "Safety without selection" activated (p9512.12 = 1 or p9512.13 = 1)</li> </ul> </li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• No safety function selected</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>• Please note: With active safety function (e.g. SLS or SSM with activated hysteresis) and for SSM active feedback signal with a pulse inhibit (p9509.0 = 1), the drive enable must be issued within 5 seconds after STO deselection using a positive edge at OFF1, otherwise STO becomes active again.</li> </ul>	
3.	<p>Configure and activate trace recording</p> <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> <p>For better analysis, display the following bit values:</p> <ul style="list-style-type: none"> <li>• r9721.12 (STOP A or B active)</li> <li>• r9722.0 (STO active; set for STOP A)</li> <li>• r9722.7 (internal event; set to 0 when the first Safety message occurs)</li> <li>• r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul> <p>Select SDI positive or SDI negative</p> <p>Switch-on the drive and traverse in the negative or positive direction of rotation</p>	



No.	Description	Status
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving, and after the SDI tolerance (p9564) has been exceeded that it is coasting down or a configured holding brake is closed</li> </ul>	
	Check whether the following Safety messages are pending:	
	<ul style="list-style-type: none"> <li>• C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or C01716 (1), C30716 (1); tolerance for SDI exceeded in negative direction</li> </ul>	
	<ul style="list-style-type: none"> <li>• C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace: <ul style="list-style-type: none"> <li>• As soon as r9713[0] (unit <math>\mu\text{m}</math> or <math>\text{m}^\circ</math>) leaves the SDI tolerance window, a Safety message (r9722.7 = 0) becomes active</li> <li>• As consequence, STOP A is initiated and the pulses are canceled (p9721.2 = 1).</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge Safety messages	
	<ul style="list-style-type: none"> <li>• No Safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used)</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>• Check whether the drive is moving</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	

Example trace: SDI negative (without encoder) with STOP A



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI negative
- ③ SDI negative active
- ④ Internal event
- ⑤ STO active
- ⑥ Enable pulses

Image A-21 Example trace: SDI negative (without encoder) with STOP A

Trace evaluation:

- Function SDI negative is activated (see bits "Deselect SDI negative " and "SDI negative active")
- The drive starts moving (time axis approx. -220 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Error response STOP A is initiated (time axis 0 ms; bits "STO active" and "Pulse enable" are set to 1)
- The drive coasts to a standstill or a configured holding brake is closed

**Note****Time differences through internal calculations**

Small time differences (of the order of two to three Safety cycles (here up to 7 ms)) are caused by internal calculations and do not present a problem.


**SDI positive/negative without encoder and stop response "STOP B"**

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1 or p9506 = 3)</li> <li>• For "Motion monitoring without selection (Page 205)":               <ul style="list-style-type: none"> <li>- "Safety without selection" configured (p9601 = 24 hex or 25 hex)</li> <li>- "Safety without selection" activated (p9512.12 = 1 or p9512.13 = 1)</li> </ul> </li> <li>• SDI enabled (p9501.17 = 1)</li> <li>• No safety function selected.</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>• Please note:                With active safety function (e.g. SLS or SSM with activated hysteresis) and for "SSM active" feedback signal with a pulse inhibit (p9509.0 = 1), the drive enable must be issued within 5 seconds after STO deselection using a positive edge at OFF1, otherwise STO becomes active again.</li> </ul>	
3.	Configure and activate trace recording <ul style="list-style-type: none"> <li>• Trigger: Trigger on variable - bit pattern (r9722.7 = 0)</li> <li>• Record the following values: r9713[0], r9720, r9721, r9722</li> <li>• Select the time interval and pretrigger so you can recognize when the active SDI tolerance has been exceeded and the subsequent drive responses</li> </ul> For better analysis, display the following bit values: <ul style="list-style-type: none"> <li>• r9720.12 (deselection SDI positive) or r9720.13 (deselection SDI negative)</li> <li>• r9722.0 (STO active)</li> </ul>	

A.3 Acceptance tests (recommendations)

No.	Description	Status
	<ul style="list-style-type: none"> <li>r9722.1 (SS1 active; set for STOP B)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.7 (internal event; set to 0 when the first Safety message occurs)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.12 (SDI positive active) or r9722.13 (SDI negative active)</li> </ul>	
	Select SDI positive or SDI negative	
	Switch-on the drive and traverse in the negative or positive direction of rotation	
	<ul style="list-style-type: none"> <li>Check whether the drive is moving, and after the SDI tolerance (p9564/9364) has been exceeded that it is braked along the OFF3 ramp before STOP A becomes active</li> </ul>	
	Check whether the following Safety messages are pending:	
	<ul style="list-style-type: none"> <li>C01716 (0), C30716 (0); tolerance for SDI exceeded in positive direction or</li> </ul>	
	<ul style="list-style-type: none"> <li>C01716 (1), C30716 (1); tolerance for SDI exceeded in the negative direction</li> </ul>	
	<ul style="list-style-type: none"> <li>C01701, C30701 (STOP B initiated)</li> </ul>	
	<ul style="list-style-type: none"> <li>C01700, C30700 (STOP A initiated)</li> </ul>	
4.	Analyze trace:	
	<ul style="list-style-type: none"> <li>As soon as r9713[0] (unit <math>\mu\text{m}</math> or <math>\text{m}^\circ</math>) leaves the SDI tolerance window, a Safety message (r9722.7 = 0) becomes active</li> </ul>	
	<ul style="list-style-type: none"> <li>STOP B is initiated as a consequence (with subsequent stop STOP A)</li> </ul>	
5.	Save/print the trace and add it to the acceptance report (refer to the example below)	
6.	Deselect SDI and safely acknowledge Safety messages	
	<ul style="list-style-type: none"> <li>No Safety faults, alarms and messages (r0945[0...7], r2122[0...7], r9747[0...7])</li> </ul>	
	Acknowledge switch-on inhibit and run the drive	
	<ul style="list-style-type: none"> <li>Check whether the drive is moving</li> </ul>	
7.	Repeat points 1 to 6 for the opposite direction.	

## Example trace: SDI negative (without encoder) with STOP B



- ① Drive\_1.r9713[0]: SI motion diagnostics position actual value load side, load-side actual value on the Control Unit
- ② Deselect SDI negative
- ③ SDI negative active
- ④ Internal event
- ⑤ SS1 active
- ⑥ Enable pulses

Image A-22 Example trace: SDI negative (without encoder) with STOP B

## Trace evaluation:

- Function "SDI negative" is activated (see bits "Deselect SDI negative " and "SDI negative active")
- The drive starts moving (time axis approx. -220 ms)
- Exiting the SDI tolerance window is detected (time axis 0 ms)
- Safety messages are initiated (time axis 0 ms; bit "internal event" is set to 0)
- Error response STOP B is triggered (time axis 0 ms; see bit "SS1 active")
- The drive is braked to a standstill

A.3 Acceptance tests (recommendations)

- Shutdown speed is detected (time axis from approx. 25 ms)
- STOP A (as follow-up response to STOP B) is activated (see bit "pulse enable" = 1); at this point, the speed falls below the shutdown speed SS1 (p9560) (speed drops below the shutdown speed SS1 before SS1 timer p9556 has expired)

**Note**

**Time differences through internal calculations**

Small time differences (of the order of two to three Safety cycles (here up to 7 ms)) are caused by internal calculations and do not present a problem.

**Acceptance test for Safe Direction without encoder with monitoring when the pulses are canceled (Extended Functions)**

No.	Description	Status
<p><b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.</p>		
1.	<p>Initial state</p> <ul style="list-style-type: none"> <li>• Drive in the "Ready" state (p0010 = 0)</li> <li>• Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> <li>• Safety functions enabled (p9501.0 = 1)</li> <li>• Safety configured without encoder (p9506 = 1)</li> <li>• SDI during pulse cancellation (p9509.8 = 0)</li> <li>• No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>• It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>• Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>• Please note: With active safety function (e.g. SLS or SSM with activated hysteresis) and for "SSM active" feedback signal with a pulse inhibit (p9509.0 = 1), the drive enable must be issued within 5 seconds after STO deselection using a positive edge at OFF1, otherwise STO becomes active again.</li> </ul>	
3.	<p>Switch-on the drive and select SDI positive or negative</p> <p>Enter a positive setpoint.</p> <p>Cancel the drive pulses using OFF1, OFF2 or OFF3.</p> <p>During pulse suppression, monitoring is switched off and the status signal indicates inactive.</p>	
4.	<p>Check the following values:</p> <ul style="list-style-type: none"> <li>• r0899.11 = 1 (pulses enabled)</li> <li>• r9722.0 = 1 (STO active)</li> </ul>	

No.	Description	Status
	<ul style="list-style-type: none"> <li>r9722.12 = 1 (SDI positive active) or r9722.13 = 1 (SDI negative active)</li> </ul>	
5.	After the pulse cancellation, no Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used).	

### Acceptance test for Safe Direction without encoder without monitoring when the pulses are canceled (Extended Functions)

No.	Description	Status
<b>Note:</b> The acceptance test must be individually performed for each configured control and for both directions of rotation. Control can be realized without selection via TM54F, onboard terminals (CU310-2) or via PROFIsafe.		
1.	Initial state	
	<ul style="list-style-type: none"> <li>Drive in the "Ready" state (p0010 = 0)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety Integrated Extended Functions enabled (p9601.2 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety functions enabled (p9501.0 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>Safety configured without encoder (p9506 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>SDI during pulse cancellation (p9509.8 = 1)</li> </ul>	
	<ul style="list-style-type: none"> <li>No Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if used); see note "Non-critical alarms" at the beginning of Section "Acceptance test."</li> </ul>	
2.	<ul style="list-style-type: none"> <li>It may be necessary to take measures in the higher-level controller to be able to exceed the SDI tolerance.</li> <li>Note that regarding SDI, the internal limits (r9733[0], r9733[1] and r9733[2]) are removed by selecting "Start acceptance test".</li> <li>Please note: With active safety function (e.g. SLS or SSM with activated hysteresis) and for "SSM active" feedback signal with a pulse inhibit (p9509.0 = 1), the drive enable must be issued within 5 seconds after STO deselection using a positive edge at OFF1, otherwise STO becomes active again.</li> </ul>	
3.	Switch-on the drive and select SDI positive or negative	
	Enter a setpoint.	
	Cancel the drive pulses using OFF1, OFF2 or OFF3.	
	Monitoring continues during pulse suppression. The status signal indicates active and the system goes into the STO state.	
4.	Check the following values:	
	<ul style="list-style-type: none"> <li>r0899.11 = 1 (pulses enabled)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.0 = 1 (STO active)</li> </ul>	
	<ul style="list-style-type: none"> <li>r9722.12 = 1 (SDI positive active) or r9722.13 = 1 (SDI negative active)</li> </ul>	
5.	After the pulse cancellation, no Safety faults and alarms (r0945[0...7], r2122[0...7], r9747[0...7]) at the drive and TM54F (if one is being used).	

## A.3.3.4 Acceptance test for the transfer of F-DIs via PROFIsafe

No.	Description	Status
1.	Initial state	
	<ul style="list-style-type: none"> <li data-bbox="199 412 1209 449">• Drive in the "Ready" state (p0010 = 0)</li> <li data-bbox="199 455 1209 527">• No Safety faults and alarms (r0945[0...7], r2122[0...7]) at the drive; see note "non-critical alarms" at the beginning of Chapter "Acceptance tests."</li> </ul>	
2.	Check the "Low" status of the fail-safe input	
	<ul style="list-style-type: none"> <li data-bbox="199 583 1209 619">• Switch the signal of the fail-safe digital input to be tested to "low".</li> <li data-bbox="199 625 1209 697">• In S_ZSW2 of the PROFIsafe telegram, check whether the corresponding bit has a value of 0 (r10051.x = 0); x = F-DI</li> </ul>	
3.	Check the "High" status of the fail-safe input	
	<ul style="list-style-type: none"> <li data-bbox="199 753 1209 789">• Switch the signal of the fail-safe digital input to be tested to "high".</li> <li data-bbox="199 795 1209 866">• In S_ZSW2 of the PROFIsafe telegram, check whether the corresponding bit has a value of "1" (r10051.x = 1); x = F-DI</li> </ul>	



### A.3.4 Completion of certificate

#### SI parameters

	Specified values checked?	
	Yes	No
Control Unit		
Motor Module		

#### Checksums

Basic Functions + Extended Functions			
Drive name	Drive number	SI reference checksum SI parameters (Control Unit)	SI reference checksum SI parameters (Motor Module)
		p9799 =	p9899 =
		p9799 =	p9899 =
		p9799 =	p9899 =
		p9799 =	p9899 =
		p9799 =	p9899 =
		p9799 =	p9899 =

Only Extended Functions			
Drive name	Drive number	SI reference checksum SI parameters (Control Unit)	SI reference checksum SI parameters (Motor Module)
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
		p9399[0] = p9399[1] =	p9729[0] = p9729[1] = p9729[2] =
TM54F (master)		p10005[0] =	p10005[1] =
TM54F (slave)		p10005[0] =	p10005[1] =

**Safety logbook**

	<b>Functional<sup>1)</sup></b>
Checksum for functional tracking of changes	r9781[0] =
Checksum for hardware dependent tracking of changes	r9781[1] =
Time stamp for functional tracking of changes	r9782[0] =
Time stamp for hardware dependent tracking of changes	r9782[1] =

<sup>1)</sup> These parameters can be found in the expert list of the Control Unit.

**Data backup**

	Storage medium			Storage location
	Type	Designation	Date	
Parameter				
Program of the F-CPU				
Circuit diagrams				

**Countersignatures**

**Commissioning engineer**

This confirms that the tests and checks have been carried out properly.

Date	Name	Company/dept.	Signature

**Machine manufacturer**

This confirms that the parameters recorded above are correct.

Date	Name	Company/dept.	Signature

## A.4 Stop variants

Safe Stops are used to stop drive motion and bring it to a standstill. The type of stop response that occurs in the event of faults can either be permanently defined in the system or configured by the machine manufacturer.

In this way, the shutdown of the machine can be optimally adapted to the respective situation.

In the following list, STOP B can be compared to an SS1 and STOP C to an SS2.




Image A-23 Overview of the stop variants

### STOP A

With STOP A (corresponds to Stop Category 0 according to EN 60204-1, without electrical isolation), the drive is switched directly to zero torque via the STO function. A drive that is still running coasts to a standstill. A drive at standstill cannot be started again accidentally.

Application:

- E.g. for safety faults

## STOP B

The drive is braked at the current limit under speed control and brought to a safe standstill (SOS) (corresponds to Stop Category 1 according to EN 60204-1, without electrical isolation).

Application

- E.g. when SOS responds

## STOP C

The drive is braked at the current limit under speed control and brought to a safe operating stop (corresponds to Stop Category 2 according to EN 60204-1).

A STOP C followed by a STOP A is normally selected in the case of an emergency stop because this is the quickest way of stopping a drive.

Application:

- Operator protection

## STOP D

The drives are braked together in a path-related (interpolatory) way on the contour and brought to a safe operating stop (SOS).

Application:

- Protection for tool and workpiece (machine protection)

## STOP E

The drives are braked together, including a jerk motion during which the tool and workpiece are separated from one another, path-related and brought to a safe operating stop.

Application:

- Machine protection

## STOP F

The STOP F is permanently assigned to the result and data cross-check and cannot be changed by the user.

If a discrepancy is found in the monitoring channels of Safety Integrated, a STOP F is triggered.

Depending on the parameter assignment, a STOP A or STOP B response is triggered.

Applications:

- Detection of errors during the crosswise data and result comparison
- Detection of communication errors between SINUMERIK and the drive
- Detection of encoder errors

# Index

## 2

2-encoder system, 147

## A

Acceptance test, 341

Authorized person, 343

Record, 341

Requirements, 341, 342

SBC (Basic Functions), 425

SBC with encoder, 431

SBC without encoder, 486

SBT, 479

SDI with encoder, 455

SDI without encoder, 496

SLP, 471

SLS with encoder, 437

SLS without encoder, 487

SOS, 432

SS1 (Basic Functions), 423

SS1 with encoder, 428

SS1 without encoder, 483

SS2 with encoder, 435

SSM with encoder, 453

SSM without encoder, 494

STO (Basic Functions), 422

STO with encoder, 427

STO without encoder, 481

Support in STARTER, 421

Support using STARTER script, 421

Transferring F-DI via PROFIsafe, 504

Acknowledgment

Extended, 370

Actual value acquisition, 147

Actual value acquisition cycle clock

S120M, 153

SINAMICS S120, 237

Actual value synchronization

Encoder, 152

Alarm buffer, 371

Alarm history, 371

Alarm value, 371

Alarms

Alarm buffer, 371

Alarm history, 371

## B

Basic Functions

PROFIsafe and terminals, 175

SBC, 36, 71

SS1, 35, 40, 68

STO, 34, 62

STO for HLA, 66

TM54F, 33, 62

Bit pattern test, 173

## C

C01770, 171

Calculating the speed, 129, 129

Change password

TM54F, 296

Changing

Password, 222

Commissioning

CU310-2, 282

Linear axis, 333

Rotary axis, 333

Safety Integrated, 230

TM54F, 294

Communication failure, 197

ESR, 197

Component replacement, 335

Effects, 361

POWER ON and acceptance test, 363, 364

Required measures, 361

Copy, 335

Offline, 335

CPU time, 236

Deactivated drive, 236

CU310-2

Commissioning, 282

## D

Data set switchover, 20

DDS

Switchover, 20

Deactivated drive

CPU time, 236

- Delay time
  - SBR, 42
  - SS1, 88
- Drive object
  - Activation/deactivation, 335
- DRIVE-CLiQ rules, 224
  
- E**
- EDS
  - Switchover, 20
- Emergency Stop button, 35
- EN 61800-5-2, 34
- Enabling PROFIsafe, 175
- Encoder
  - Actual value synchronization, 152
  - HTL/TTL, 151
  - Systems, 147
  - Types, 147
  - Types for HLA, 152
  - With sin/cos-1 Vpp signals, 151
- ESR
  - Communication failure, 197
- Extended acknowledgment, 370
- Extended Functions, 80
  - Deactivating/activating a drive object, 335
  - License, 80
  - Parking, 82
  - Requirements, 80
  
- F**
- F parameters, 328
- F\_Dest\_Add, 328
- F01611
  - Fault value 1000, 171, 174
- Fault acknowledgment on TM54F
  - Safe, 365
- Fault response, 365
- F-DI, 167
- F-DO, 167
- Filter
  - On/off test, 173
- Firmware update
  - POWER ON and acceptance test, 364
- Forced dormant error detection (test stop), 160, 226
  - Automatically when powering up, 78, 161, 165
  - Basic Functions, 78
  - CU310-2, 288
  - Extended Functions, 160
  - HLA, 66
  - Initiated by the application, 78, 161, 165
  - Interval, 305
  - TM54F, 305
- Function test, 160
  
- G**
- Group drives, 224
- Group drives connected in parallel, 224
  
- H**
- HLA, 27
- HTL/TTL encoders, 151
- HW Config, 313
- Hydraulic Drive, 27
  
- I**
- Increased position tolerance, 157
- Internal armature short-circuit, 65
  
- L**
- License
  - Basic Functions, 175
  - Extended Functions, 80, 175
- Limit value violation, 365
- Linear axis
  - Commissioning, 333
  
- M**
- Machine manufacturer, 343
- Message buffer, 371
- Modular machine concept, 335
  
- O**
- On/off test, 173
- Overview of Safety Integrated functions, 32
  
- P**
- Parking, 82
- Password
  - Changing, 222
- PFH value, 350

- Position tolerance, 157
  - Increased, 157
- Probability of failure, 350
- Process data
  - S\_CYCLE\_COUNT, 188
  - S\_SLS\_LIMIT\_A, 188
  - S\_SLS\_LIMIT\_A\_ACTIVE, 188
  - S\_XIST16, 188
  - S\_XIST32, 189
- Process data, control words
  - S\_STW1 (Basic Functions), 179
  - S\_STW1 (Extended Functions), 183
  - S\_STW2 (Basic Functions), 181
  - S\_STW2 (Extended Functions), 185
- Process data, status words
  - S\_ZSW1 (Basic Functions), 180
  - S\_ZSW1 (Extended Functions), 184
  - S\_ZSW2 (Basic Functions), 182
  - S\_ZSW2 (Extended Functions), 186
- PROFIsafe, 167
  - Activate, 330
  - Address of the drive, 319
  - Destination address, 319
  - F\_Dest\_Add, 319
  - Mode, 319
  - Monitoring time, 319
  - SLS limit value, 100
  - topology, 312
- R**
- Requirements
  - Extended Functions, 80
- Residual risk, 21
- Response times, 351
  - Basic Functions via PROFIsafe (CU310-2 and CU320-2), 353
  - Basic Functions via terminals on the Control Unit and the Motor Module, 352
  - Basic Functions via TM54F, 354
  - Extended Functions with encoder via PROFIsafe (CU310-2 and CU320-2), 355
  - Extended Functions with encoder via terminals (only CU310-2), 357
  - Extended Functions with encoder via TM54F (CU310-2 and CU320-2), 356
  - Extended Functions without encoder via PROFIsafe (CU310-2 and CU320-2), 358
  - Extended Functions without encoder via terminals (only CU310-2), 359
  - Extended Functions without encoder via TM54F (CU310-2 and CU320-2), 360
- Rotary axis
  - Commissioning, 333
- S**
- S\_CYCLE\_COUNT, 188
- S\_SLS\_LIMIT\_A, 188
- S\_SLS\_LIMIT\_A\_ACTIVE, 188
- S\_STW1
  - Basic Functions, 179
  - Extended Functions, 183
- S\_STW1B, 216
- S\_STW2
  - Basic Functions, 181
  - Extended Functions, 185
- S\_STW3B, 216
- S\_V\_LIMIT\_B, 215
- S\_XIST16, 188
- S\_XIST32, 189
- S\_ZSW1
  - Basic Functions, 180
  - Extended Functions, 184
- S\_ZSW1B, 213
- S\_ZSW2
  - Basic Functions, 182
  - Extended Functions, 186
- S\_ZSW2B, 214
- S\_ZSW3B, 215
- S120M
  - Actual value acquisition cycle clock, 153
- Safe Acceleration Monitor, 142
  - SAM, 81
- Safe actual value acquisition, 147
- Safe Brake Adapter
  - Chassis format, 73
- Safe Brake Control
  - Chassis format, 73
  - Extended Functions, 91
  - SBC, 71, 91
- Safe Brake Ramp
  - SBR, 81, 81, 87, 94, 144
- Safe Direction, 55, 115
  - With encoder, 115
  - Without selection, 119
- Safe gearbox stage switchover, 157
- Safe motion direction, 115
- Safe motion monitoring, 153
- Safe Operating Stop, 43
  - SOS, 92
- Safe position
  - Transfer, 129
- Safe referencing, 58, 127

- Safe Speed Monitor
  - General, 108
  - Restart, 113
  - SSM, 108
  - With encoder, 109
  - Without encoder, 111
- Safe Stop 1
  - Basic Functions, 68
  - Extended Functions, 87
  - Speed controlled, 89
  - SS1, 68, 81, 81, 87, 87, 94
  - Time and acceleration controlled, 87
  - Time-controlled, 68
  - With encoder, 87
  - With external stop (Extended Functions), 90
  - With OFF3 (Basic Functions), 68
  - With OFF3 (Extended Functions), 87, 88
  - Without encoder, 89
- Safe Stop 2, 45, 94
  - SS2, 94
  - with external stop, 96
- Safe Torque Off, 34
  - Basic Functions, 62
  - Extended Functions, 40, 86
  - For HLA (Basic Functions), 66
  - STO, 40, 62, 86
- Safely Limited Position, 57, 57
- Safely Limited Speed, 47, 99
  - With encoder, 100
  - Without selection, 105
- Safety Control Channel, 207
- Safety Evaluation Tool, 350
- Safety Info Channel, 207
- Safety Integrated, 220
  - Commissioning, 230
  - Password, 222
  - With encoder, 81
  - Without encoder, 81
- Safety Integrated Basic Functions
  - Stop responses, 76
- Safety Integrated password, 222
- Safety logbook, 346
- Safety Master
  - Creating a safety slot, 313
- Safety slave, 317
- Safety slot, 229
- SAM
  - For SS1, 42
  - For SS2, 46
- SAM (Safe Acceleration Monitor), 142
- SBA, 73
- SBC
  - Acceptance test, 425
  - Basic Functions, 36, 71
  - Safe Brake Control, 36, 71
  - Safe Brake Control (Extended Functions), 91
  - Select, 36
  - With encoder (acceptance test), 431
  - Without encoder (acceptance test), 486
- SBR
  - Delay time, 42
  - For SLS, 51
  - For SS1, 42
  - For SS2, 46
- SBT
  - Acceptance test, 479
  - Brake wear, 31
- SCC
  - See Safety Control Channel, 207
- SDI, 115
  - Crane trolley, 30, 55
  - General, 55
  - Pressure cylinder, 30, 55
  - Protection against jamming, 30, 55
  - Rolling shutter gate, 30, 55
  - Safe Direction, 55
  - Time response, 55
  - With encoder, 115
  - With encoder (acceptance test), 455
  - Without encoder, 117, 117
  - Without encoder (acceptance test), 496
  - Without selection, 119
- Series commissioning with third-party motor, 337
- SIC
  - see Safety Info Channel, 207
- SINAMICS S120M
  - Actual value acquisition cycle clock, 237
- Single-encoder system, 147
- SLP, 57, 57
  - General, 57
  - Safely Limited Position, 57
  - With encoder (acceptance test), 471
- SLS
  - Deselect, 49
  - Horizontal conveyors, 30, 47
  - Level, 50
  - Limit value via PROFIsafe, 100, 102
  - Monitoring threshold, 51
  - Safely Limited Speed, 47
  - Select, 49
  - Speed limit values, 101
  - Spindle drive, 30, 47
  - Switching over the monitoring threshold, 50



- Time response, 48, 49
  - With encoder, 100
  - With encoder (acceptance test), 437
  - Without encoder, 103
  - Without encoder (acceptance test), 487
  - Without selection, 105
- SOS, 43
  - Acceptance test, 432
  - Protective door, 43
  - Safe Operating Stop, 92
- SP, 129
  - Calculation of the safe velocity, 31
  - Different reaction to sensors, 31
  - Multi-dimensional protection areas, 31
  - Safe cam sequencer, 31
  - Safe response depending on the position of the axes, 31
  - Safety concepts across axes, 31
  - Zone concepts, 31
- SS1
  - Acceptance test (Basic Functions), 423
  - Basic Functions, 35, 40, 68
  - Brake ramp monitoring, 89
  - Braking behavior, 42
  - Delay, 51
  - Delay time, 42, 88
  - Delay time SBR, 42
  - Enable, 42
  - Example, 30
  - Monitoring mode, 41
  - Principle of operation, 35, 41
  - Protective door, 34, 40
  - Safe Stop 1, 35, 40, 68, 87
  - Safe Stop 1 (Basic Functions), 68
  - Safe Stop 1 (Extended Functions), 87
  - SBR, 89
  - Shutdown speed, 42
  - Speed controlled, 89
  - Time and acceleration controlled, 89
  - Time response, 35, 41, 42
  - Tolerance, 42
  - With encoder, 87
  - With encoder (acceptance test), 428
  - With external stop (Basic Functions), 69
  - With external stop (Extended Functions), 90
  - With OFF3 (Basic Functions), 68
  - With OFF3 (Extended Functions), 87
  - Without encoder, 89
  - Without encoder (acceptance test), 483
- SS1E, 69
  - SS1 with external stop (Basic Functions), 69
- SS2, 45
  - Braking behavior, 46
  - Diagnostics, 46
  - Enable, 46
  - Principle of operation, 45
  - Protective door, 45
  - Safe Stop 2, 45, 45, 94
  - Select, 46
  - Speed, 45
  - Time response, 45, 46
  - With encoder (acceptance test), 435
  - with external stop, 96
- SS2E, 96
- SSM
  - Centrifuge, 30, 53
  - Restart, 113
  - Safe Speed Monitor, 108
  - Time response, 54
  - With encoder, 109
  - With encoder (acceptance test), 453
  - Without encoder, 111
  - Without encoder (acceptance test), 494
- Standstill monitoring, 42
- STARTER
  - Acceptance test support, 421
  - Acceptance test support using script, 421
- STO
  - Basic Functions, 34, 62
  - Emergency Stop button, 30
  - For HLA (Basic Functions), 66
  - Internal armature short-circuit, 65
  - Safe Torque Off, 34
  - Safe Torque Off (Basic Functions), 40, 62, 86
  - Select, 34
  - With encoder (acceptance test), 427
  - Without encoder (acceptance test), 481
- STOP A, 76, 365
- STOP B, 365
- STOP C, 365
- STOP D, 365
- STOP E, 365
- STOP F, 76, 365
- Stop response, 365
  - Priorities compared to Extended Functions, 368
  - Priority classes, 368
  - STOP A, 76
  - STOP F, 76
- Switching operation
  - Basic Functions, 171
  - Timing, 171, 174
- Switching over
  - SLS level, 50

Switching over the gear ratio  
Safe, 157

## T

Telegram

30, 177

31, 178

700, 207

701, 208

901, 178

902, 178

Test of switch-off signal paths, 78

Test stop

Automatically when powering up, 161

Extended Functions, 160

General, 226

Initiated by the application, 161

Third-party motor with absolute encoder, 337

Time and acceleration controlled, 89

TM54F, 167

Basic Functions, 33, 62

Change password, 296

Commissioning, 294

Transferring F-DI via PROFIsafe (acceptance test), 504

Transferring safe position, 129

Two-channel brake control, 72



Siemens AG  
Digital Factory  
Motion Control  
Postfach 3180  
91050 ERLANGEN  
GERMANY

Subject to change

[www.siemens.com/motioncontrol](http://www.siemens.com/motioncontrol)