

Instruction Manual PSx3xxSE



halstrup-walcher GmbH

Stegener Straße 10
D-79199 Kirchzarten

Phone: +49 (0) 76 61/39 63-0
Fax: +49 (0) 76 61/39 63-99

E-Mail: info@halstrup-walcher.com
Internet: www.halstrup-walcher.com

Table of Contents

1	Safety precautions.....	4
1.1	Appropriate use.....	4
1.2	Shipping, assembly, electrical connections and start-up.....	4
1.3	Troubleshooting, maintenance, repairs, disposal.....	4
1.4	Symbols	5
2	Instrument description	5
2.1	Functions	5
2.2	Assembly Hollow shaft:	5
2.3	Pin assignment	6
2.3.1	Supply voltage connector	6
2.3.2	Sockets for the bus	6
2.3.3	Electrical grounding.....	6
2.4	Setting the device address	6
2.5	LEDs and address switches	7
2.6	sercosIII cycle data	7
2.6.1	Master to PSx3xxSE (MDT)	7
2.6.2	PSx3xxSE to Master (AT)	8
2.7	Parameters	9
2.7.1	Read only parameters.....	9
2.7.2	Writable parameters.....	10
2.7.3	Table of type-dependent values	13
2.7.4	Commands.....	14
2.8	Error messages.....	14
2.8.1	Error (C1D)	14
2.8.2	Warnings (C2D)	15
3	Special features.....	15
3.1	Positioning	15
3.1.1	Positioning sequence with loop	16
3.1.2	Positioning sequence without loop	16
3.2	Speed, acceleration and delay	16
3.3	Response if the drive encounters an obstacle or is turned manually	16
3.4	Drag error.....	17
3.4.1	Monitoring	17
3.4.2	Correction	17
3.5	Readjustment.....	17
3.6	Absolute measuring system	17
3.6.1	Positioning range (S-0-0278).....	17
3.6.2	Scale for the positional data (S-0-0079 and P-0-0079).....	18
3.6.3	Direction of rotation (S-0-0055)	19
3.6.4	Referencing (S-0-0175) and/or (S-0-0052).....	19
3.6.5	Setting parameters without automatic adjustment	19
4	Technical data.....	20
4.1	Ambient conditions.....	20
4.2	Electrical data	20
4.3	Physical data.....	21

Purpose of instruction manual

This instruction manual describes the features of the PSx3xxSE positioning system and provides guidelines for its use.

Improper use of these instruments or failure to follow these instructions may cause injury or equipment damage. All individuals responsible for operating these instruments must therefore be properly trained and aware of the hazards. The instruction manual, and in particular the safety precautions contained therein, must be followed carefully. Contact the manufacturer if you do not understand any part of this instruction manual.

Handle this manual with care:

It must be readily available throughout the lifecycle of the instruments.

It must be provided to any individuals who assume responsibility for operating the instrument at a later date.

It must include any supplementary materials provided by the manufacturer.

The manufacturer reserves the right to continue developing this instrument model without documenting such development in each individual case. The manufacturer will be happy to determine whether this manual is up-to-date.

Conformity

This device is state of the art. It complies with the legal requirements of EC directives. This is shown by the CE mark.



© 2011, 2015, 2016, 2017

The manufacturer owns the copyright to this instruction manual. It contains technical data, instructions and drawings detailing the devices' features and how to use them. It must not be copied either wholly or in part or made available to third parties.

1 Safety precautions

1.1 Appropriate use

Positioning systems are especially suitable for automatically setting tools, stops or spindles for wood-processing equipment, packing lines, printing equipment, filling units and other types of special machines.

PSx3xxSE positioning systems are not stand-alone instruments and may only be used if coupled to another machine.

Always observe the operating requirements—particularly the permissible supply voltage—indicated on the rating plate and in the “Technical data” section of this manual.

The instrument may only be handled as indicated in this manual. Modifications to the instrument are prohibited. The manufacturer is not liable for damages caused by improper use or failure to follow these instructions. Violations of this type render all warranty claims null and void.

1.2 Shipping, assembly, electrical connections and start-up

Assembly and the electrical connections should only be handled by professionals. They should be given proper training and be authorised by the operator of the facility.

The instrument may only be operated by appropriately trained individuals who have been authorized by the operator of the facility.

Specific safety precautions are given in individual sections of this manual.

1.3 Troubleshooting, maintenance, repairs, disposal

The individual responsible for the electrical connections must be notified immediately if the instrument is damaged or if errors occur.

This individual must take the instrument out of service until the error has been corrected and ensure that it cannot be used unintentionally.

This instrument requires no maintenance.

Only the manufacturer may perform repairs that require the housing to be opened.

The electronic components of the instrument contain environmentally hazardous materials and materials that can be reused. The instrument must therefore be sent to a recycling plant when you no longer wish to use it. The environment codes of your particular country must be complied with.

1.4 Symbols

The symbols given below are used throughout this manual to indicate instances when improper operation could result in the following hazards:



WARNING!

This warns you of a potential hazard that could lead to bodily injury up to and including death if the corresponding instructions are not followed.



CAUTION!

This warns you of a potential hazard that could lead to significant property damage if corresponding instructions are not followed.



INFORMATION!

This indicates that the corresponding information is important for operating the instrument properly.

2 Instrument description

2.1 Functions

The PSx3xxSE positioning system, an intelligent, compact, complete solution for positioning auxiliary and positioning axes, consists of an EC motor, gear power amplifier, control electronics, absolute measuring system and sercos 3 interface. The integrated absolute measuring system eliminates the need for a time-consuming reference run. Connecting to a bus system simplifies the wiring. A hollow shaft with adjustable collar makes assembly quite simple. The positioning system is especially suitable for automatically setting tools, stops or spindles for wood-processing equipment, packing lines, printing equipment, filling units and other types of special machines.

PSx3xxSE positioning systems convert a digital positioning signal into an angle of rotation.

2.2 Assembly

Hollow shaft:

The PSx3xxSE is mounted onto the machine by sliding the hollow shaft of the positioning gear onto the axis to be driven and then securing it with the adjustable collar (recommended diameter of the axis is either 8h9 or 14h9; wrench torque for screw: 1.5Nm). The adjustable collar should be tightened only just to the point where it can no longer rotate freely. Securing the pin under the hollow shaft into an appropriate bore will prevent further rotation.

Solid shaft:

The PSx3xxSE is mounted on the machine by fixing the solid shaft with coupling and intermediate flange to the axis of the machine.



Never apply force to the housing cover, e.g., for supporting weight.





Never run the PSx3xxSE in reverse (i.e. do not apply external force to the output shaft in order to turn it).

2.3 Pin assignment

For the supply voltage either a Binder series 713/763 (A-coded) round, 5-pin plug for PSE and PSS devices or a 5-pin Harting plug with protective sleeve (HAN4A) for the PSE34xx devices is located in the housing cover of the PSx3xxSE.

Two round 4-pin sockets, Binder series 825 (D-coded) are provided for connection to the bus.

2.3.1 Supply voltage connector




1. +24V motor
2. ground (motor)
3. +24V control unit
4. ground (control unit)
5. housing/pressure balance



To prevent the ingress of fluids into the PSW-housing during cooldown, use a special cable with an airtube for pressure balancing of your PSW.

2.3.2 Sockets for the bus



1. TD+ (WH/GN, white/green)
2. RD+ (WH/OG, white/orange)
3. TD- (GN, green)
4. RD- (OG, orange)



Due to the use of 4-pin sockets, only four-wire cables should be used.

2.3.3 Electrical grounding

Next to the connecting plugs there is a M4 stud bolt. It is recommended to connect the positioning system with a cable as short as possible to the machine base. The minimum wire cross section therefor is 1.5mm².

2.4 Setting the device address

In its delivery state, the PSx3xxSE has the address 1. A different address can be assigned using the parameter S-0-1040 or via the optional address switches. If the switches are resting in the position 00 or not available, the address is set using S-0-1040. The change in address is saved automatically and therefore continues to be available after the device is restarted. If you set the address using the switches (i.e. switches set to > 00) you cannot change this value using the bus.

2.5 LEDs and address switches

The following LEDs are located under the transparent sealing plug:

P1/P2: Green link LEDs for ports 1 and 2


S: sercos LED (see sercosIII specifications)

V-Motor: The LED is illuminated yellow when power is available to the motor.

OFF → Motor power supply is too high or low

ON → Motor power supply ok

flashing → Motor power supply ok, PSx in delivery state



Address switch:

The rotary switches indicate the tens and ones places of the address selected. If the switches are resting in the position 00 or are not available, the address is set using S-0-1040.

The delivery setting is 00, the PSE reports to the bus with the address 1.

If you set the address using the switches (i.e. switches set to > 00) you cannot change this value using the bus.

2.6 sercosIII cycle data

The IO-profile is used with a fixed configuration (SCP_FixCFG). When configuring the connections, you must be aware of the following:

S-0-1050.0.x are the settings for the AT (producer)

S-0-1050.1.x are the settings for the MDT (consumer)

The command and/or status bytes 'Connection Control', 'Positioning Control' and 'Producer RTB word container' are initialised with 0 during the change from CP3 to CP4.

2.6.1 Master to PSx3xxSE (MDT)

Bit	Byte	Meaning	Corresponding IDN
0-15	0-1	Connection control	S-0-1050.1.08
16-31	2-3	I/O Control	S-0-1500.00.01
32-47	4-5	Positioning control	S-0-0346
48-79	6-9	Positioning command value	S-0-0282

Connection Control

Bit 15-12: Counter

Bit 1: New Data

Bit 0: Producer ready

A run command will only accepted if this bit is set.

I/O Control

Bit15: Output operation state

A run command will only accepted if this bit is set.

Positioning control (control word)

Bit 2-1: Positioning modes

00: Positioning → Drive moves to the transferred target value

01: Jogging + → Drive moves to the upper limit switch

10: Jogging - → Drive moves to the lower limit switch

11: Positioning Halt → Drive brakes with the specified deceleration ramp
(can also be used in jogging mode)

Bit 0: Toggle

Must be toggled if a run command is to be accepted.

2.6.2 PSx3xxSE to Master (AT)

Bit	Byte	Meaning	Corresponding IDN
0-15	0-1	Connection control	S-0-1050.0.08
16-31	2-3	I/O status	S-0-1500.00.02
32-47	4-5	Producer RTB word container	S-0-0144
48-63	6-7	Torque feedback value	S-0-0084
64-95	8-11	Velocity feedback value 1	S-0-0040
96-127	12-15	Position feedback value 1	S-0-0051

Connection Control

Bit 15-12: Counter

Bit 1: New data

Bit 0: Producer ready

I/O status

Bit 15: Outputs ready to operate

is set as soon as bit 15 is set in the I/O control

Bit 14: Inputs valid

always 1

Bit 13: Error of resource I/O (C1D)

Error code is in S-0-0390 and diagnosis text in S-0-0095

Bit 12: Warning of resource I/O (C2D)

Error code is in S-0-0390 and diagnosis text in S-0-0095

Producer RTB word container (status word)

Bit 3: Positioning halt

Drive was stopped (by 'positioning halt' command in the control word)

Bit 2: In position (S-0-0336, bit 0)

Drive is within the positioning window

Bit 1: Status command value processing (S-0-0135, bit 3)

Drive is running

Bit 0: Takeover positioning command value (S-0-0419, bit 0)

Accept target value (is toggled)

2.7 Parameters

2.7.1 Read only parameters

Name, designation	IDN	Function	Unit	Byte count/ data type
Actual rpm	S-0-0040	Current rpm	rpm	4 / signed decimal
Actual position	S-0-0051	Current position	*	4 / signed decimal
Actual torque	S-0-0084	Current torque value	cNm	2 / signed decimal
In position	S-0-0336	Drive is in the positioning window	-	2 / binary
Motor supply voltage	S-0-0380	Current supply voltage for the motor	V	2 / unsigned decimal
Temperature	S-0-383	Internal temperature of the device	°C	2 / unsigned decimal
Error text	S-0-0095	Error in text form	-	Full text
Diagnosis code	S-0-0390	Code for errors and/or warnings (see Section 0)	-	4 / hexadecimal
Vendor code	S-0-1300.0.3	sercosIII Vendor code (10)	-	2 / unsigned decimal
Device type	S-0-1300.0.5	PSE3xx-xx bzw. PSE3xxVG-xx	-	Full text
Software version	S-0-1300.0.9	x.xx	-	Full text
Serial number	S-0-1300.0.12	Device serial number	-	Full text
Production date	S-0-1300.0.13	YYYY-MM-DDTHH:MM:SSZ	-	Full text
Maximum torque	P-0-0084	Maximum torque value during the last run, not valid in the acceleration and deceleration phase	cNm	2 / signed decimal
Control unit voltage	P-0-0380	Current supply voltage for control unit	V	2 / unsigned decimal

* The units are dependent on the scale (S-0-0079 and P-0-0079).

2.7.2 Writable parameters

Name, designation	IDN	Function	Byte / Type
Upper limit	S-0-0049	Maximum permitted target position Unit: * Min.: lower limit Max.: positioning range – 3 rotations Default setting: 101200 Changes only possible when at a standstill	4 / sd
Lower limit	S-0-0050	Minimum permissible target position Unit: * Min.: positioning range – 253 rotations Max.: upper limit Default setting: 1200 Changes only possible when at a standstill	4 / sd
Referencing of the position	S-0-0052	Writing causes the current position to be "referenced" onto the transferred value The limit switch and the positioning range are also shifted. The difference is found in S-0-0175. Unit: * Min./Max.: Any desired value Default setting: 0 Changes only possible when at a standstill	4 / sd
Direction of rotation	S-0-0055	When looking at the output shaft: 16: clockwise 23: counter clockwise Default setting: 16 Changes only possible when at a standstill	2 / bin
Positioning window	S-0-0057	Permissible difference between target and actual values for the "in position" bit (S-0-0336) Unit: * Min.: 1* Max.: 100* Default setting: 2 Changes only possible when at a standstill	4 / ud
Loop length	S-0-0058	Number of increments, which the drive runs to a target in a specified direction. Run without loop with value 0 Unit: * Min.: -400* Max.: 400* Default setting: -250 Changes only possible when at a standstill	4 / sd
Scale for positional data	S-0-0079	Increments per revolution, e.g. spindle pitch 1.5 mm with resolution 1/100 mm → 150 Min.: 1 Max.: 10000 Default setting: 400 Changes only possible when at a standstill	4 / ud
Maximum torque	S-0-0092	Max. permissible torque during the run Unit: cNm Default setting: **	2 / ud

Name, designation	IDN	Function	Byte / Type
Drag error	S-0-0159	Max. drag error before a C2D warning is generated Monitoring deactivated with 0. Unit: * Min.: 0 Max.: 1000* Default setting: 0	4 / ud
Reference value	S-0-0175	Correction factor for the target, actual and limit switch values Unit: * Min./Max.: Any desired value Default setting: 0 Changes only possible when at a standstill	4 / sd
Target rpm	S-0-0259	Rpm to be used for positioning runs Unit: rpm Min./Max.: ** Default setting: **	4 / sd
Acceleration	S-0-0260	Acceleration ramp Unit: rotations/(min * sec) Min./Max.: ** Default setting: **	4 / sd
Positioning range	S-0-0278	Definition of the positioning range relative to the absolute value encoder Unit: * Min.: actual position + 3 rotations Max.: actual position + 253 rotations Default setting: 102400 Changes only possible when at a standstill	4 / sd
Target value	S-0-0282	Specified target position (can be written using SVC in CP2- 4), stop by writing the same target value once again Unit: *	4 / sd
Deceleration	S-0-0359	Deceleration ramp Unit: rotations/(min * sec) Min./Max.: ** Default setting: **	4 / sd
Holding torque	S-0-0533	Holding torque at standstill Unit: cNm Min.: 0 Max.: ** Default setting: **	4 / sd
Maximum start- up torque	S-0-0822	Max. permissible torque in the start-up phase Unit: cNm Min./Max.: ** Default setting: **	2 / ud
Time for start- up torque	S-0-0823	Time in which the start-up torque applies Unit: msec Min.: 10 Max.: 1000 Default setting: 200	2 / ud

Name, designation	IDN	Function	Byte / Type
Address	S-0-1040	sercosIII address Min.: 1 Max.: 511 Default setting: 1	2 / ud
Extended scale for positional data	P-0-0079	Used in combination with S-0-0079 to set "unlevel" resolutions Min.: 1 Max.: 10000 Default setting: 400 Changes only possible when at a standstill	4 / ud
Drag error correction factor	P-0-0159	Drag error correction is deactivated with the value 0. Min.: 0 Max.: 10 Default setting: 0 Changes only possible when at a standstill	2 / ud
Holding torque at completion of run	P-0-0822	Holding torque at completion of run Unit: cNm Min.: 0 Max.: ** Default setting: **	2 / ud
Time for holding torque at completion of run	P-0-0823	Time for holding torque at completion of run Unit: cNm Min.: 0 Max.: ** Default setting: **	2 / ud
Adjustment release	P-0-0900	Adjustment with value = 1 (only for PSE without brake) Min.: 0 Max.: 1 Default setting: 0	2 / ud

- * * The units and/or values are dependent on the scale (S-0-0079 and P-0-0079).
- ** * The value depends on the type of device (see following table).

2.7.3 Table of type-dependent values

Device type PSE and PSS	301-x 311-x	302-x 312-x	305-x 315-8	322-14 332-14	325-14 335-14
Name, designation IDN	Range of values Delivery state				
Max. torque S-0-0092	2..125 100	10..250 200	50..600 500	10..250 200	20..500 400
Target rpm S-0-0259	15..230 230	10..150 150	3..70 70	20..200 170	10..100 85
Acceleration S-0-0260	97..600 600	50..400 400	23..130 130	97..525 525	50..260 260
Delay S-0-0359	97..600 600	50..400 400	23..130 130	97..525 525	50..260 260
Holding torque S-0-0533	0..90 30	0..150 50	0..300 100	0..100 35	0..200 70
Start-up torque S-0-0822	2..125 125	10..250 250	50..600 600	10..250 250	20..500 500
Holding torque at completion of run P-0-0822	0..180 60	0..300 100	0..600 200	0..200 70	0..400 140

Device type PSW	301-x 311-x	302-x 312-x	305-x 315-8	322-14 332-14	325-14 335-14
Name, designation IDN	Range of values Delivery state				
Max. torque S-0-0092	2..125 100	10..250 200	50..600 500	10..250 200	20..500 400
Target rpm S-0-0259	15..180 180	10..125 125	3..60 60	20..150 125	10..80 60
Acceleration S-0-0260	97..600 600	50..400 400	23..130 130	97..525 525	50..260 260
Delay S-0-0359	97..600 600	50..400 400	23..130 130	97..525 525	50..260 260
Holding torque S-0-0533	0..90 30	0..150 50	0..300 100	0..100 35	0..200 70
Start-up torque S-0-0822	2..125 125	10..250 250	50..600 600	10..250 250	20..500 500
Holding torque at completion of run P-0-0822	0..180 60	0..300 100	0..600 200	0..200 70	0..400 140

Device type PSE	3110-14	3125-14	3410-14	3418-14
Name, designation IDN	Range of values Delivery state			
Max. torque S-0-0092	100..1200 1000	250..3000 2500	200..1200 1000	500..2000 1800
Target rpm S-0-0259	1..30 30	1..12 12	10..100 100	10..90 90
Acceleration S-0-0260	9..50 50	4..20 20	20..350 350	10..315 315
Delay S-0-0359	9..50 50	4..20 20	20..350 350	10..315 315
Holding torque S-0-0533	0..600 200	0..1250 450	0..300 200	0..450 300
Start-up torque S-0-0822	100..1200 1200	250..3000 3000	200..1200 1200	500..2000 2000
Holding torque at completion of run P-0-0822	0..1200 400	0..2500 900	0..600 400	0..900 600

2.7.4 Commands

Name, designation	IDN	Function
Delete error	S-0-0099	Deletes the C1D error
Load default settings	S-0-0262	The default settings are loaded. In order to save these permanently, you must subsequently execute S-0-0264
Save settings	S-0-0264	Saves the parameter in EEPROM

2.8 Error messages

Errors (C1D) and warnings (C2D) are reported using bits 13 and 12 in the I/O status. The diagnosis code is stored in S-0-0390 and the diagnosis text in S-0-0095.

2.8.1 Error (C1D)

The sercos LED is illuminated red when an error occurs.

When an error occurs during the run, the run is aborted. No further run commands will be accepted until the error is deleted. Errors are deleted using IDN S-0-0099. If the error continues, the error message will be displayed again.

The type of error can be found in the diagnosis code (S-0-0390).

0xC00F2019: Internal device temperature exceeds specified limit.

0xC00F2026: Motor voltage too low (voltage < 17.5V).

0xC00F2055: Obstruction (extreme difficulty running, insufficient torque).

0xC00F8022: Error in calculating/determining the absolute position.

This error cannot be deleted. If necessary, restart drive.

0xC00F8025: Motor voltage too high (voltage > 30V).

0xC00F8028: Motor current too high.

0xC10F6320: Incorrect parameters (error in loading or saving).

This error cannot be deleted. Restart the drive and, if the error continues, load the default settings with S-0-0262.

2.8.2 Warnings (C2D)

A warning does not result in a run being aborted. Run commands continue to be accepted when warnings are active. The drive issues the following warnings (S-0-0390):

0xC00E2028: Drag error (see Section 3.4)

A new run command deletes this warning.

0xC00E2053: Invalid target value, target value lies outside the permissible positioning range.

A new run command deletes this warning.

0xC00E6043: Upper limit exceeded.

Warning is deleted as soon as the drive is within the permissible positioning range.

0xC00E6044: Lower limit exceeded.

Warning is deleted as soon as the drive is within the permissible positioning range.

3 Special features

3.1 Positioning

To perform a positioning run, the control word (positioning control) must be written as follows in the MDT: bit 2-1 = 00 and bit 0 must be toggled. When the run command has been successfully accepted, the bit 0 in the status word (Producer RTB word container) is toggled in the AT.

Here are the responses in various situations:

New target value during a run

The new target position is accepted immediately. If a change of direction is required, the drive brakes using the set deceleration ramp and then approaches the new target value.

Stop command

To perform a stop command, the control word (positioning control) is written as follows in the MDT: bit 2-1 = 11 and bit 0 must be toggled.

Stop command during a run:

- The drive brakes using the maximum possible deceleration ramp.
- There will be no readjustment of the position (see also readjustment P-0-0900).
- Bit 3 (positioning halt) in the status word (Producer RTB word container) will be set.

Stop command during standstill:

- Bit 2 (in position) in the status word (Producer RTB word container) will be set to 0.
- There will be no readjustment of the position (see also readjustment P-0-0900).



Toggling bit 0 of the control word (positioning control) in the MDT leads to the generation of a run command in the drive even if the drive is already at the target value because the internal resolution is higher. Constant toggling of bit 0 must therefore be avoided.




Runs, which involve a run to an obstruction (e.g. reference runs to a block), may only be started with reduced torque (max. run torque < 10% of nominal torque).



Underwater usage of the PSW is not allowed.

3.1.1 Positioning sequence with loop

The loop length (S-0-0058) has the effect of ensuring that a target value is always approached from the same direction. This allows you, for example, to eliminate the lash in a driven spindle. The diagram below illustrates the function of the loop length:



If the target value is above the current position (actual value 1) and the loop length is > 0 , the drive runs past the target value by the specified loop length (run 1a) and then runs to the target value (run 1b).

If the target value is below the current position and the actual value (actual value 2) is outside the loop length, the drive approaches the target value directly (run 2).

If you wish to approach the position from the left, the loop length must be < 0 .



It is not possible to perform a positioning run to the upper limit (S-0-0049) with a loop length > 0 because the drive would have to run past the upper limit in order to do so. The same applies to the lower limit (S-0-0050) with a loop length < 0 .

3.1.2 Positioning sequence without loop

Positioning runs from both directions are possible without a loop if the loop length (S-0-0058) is set to 0. This does NOT eliminate any lash present in the spindle. The PSx3xxSE internal gear backlash does not play a role in this case, as position data are acquired directly at the output shaft.

3.2 Speed, acceleration and delay

The target speed from S-0-0259, acceleration from S-0-0260 and delay from S-0-0359 apply for all runs. As the drive approaches the target at the end of the run, the delay is successively reduced in order to ensure a harmonious transient response.

If a stop command is executed, the drive brakes with the maximum possible deceleration ramp.

3.3 Response if the drive encounters an obstacle or is turned manually

If during a run the achievable rate of speed falls below the threshold parameter (30% of the target speed) for longer than 200 ms, the instrument registers an obstacle, aborts the run and a C1D error message is generated (diagnosis code: 0xC00F2055). The drive then stands still with the set holding torque (S-0-0533). A new run command will only be accepted when the error has been deleted (see Section 0).

If, when the drive is at a standstill, it is pushed out of the positioning window, the bit 'In Position' (see Section 2.6.2) will be deleted. If readjustment is active (S-0-0900), the drive will return to the target value.

3.4 Drag error

3.4.1 Monitoring

During a positioning run, the instrument compares the computed target position with the current actual value. If the difference is greater than the value "drag error" (S-0-0159), a warning (C2D) is generated (diagnosis code: 0xC00E2028). This applies in particular if the target speed cannot be achieved due to external influences (required torque, motor voltage too low). Monitoring of the drag error can be deactivated by setting S-0-0159 to 0.

3.4.2 Correction

The drag error correction can be activated with P-0-0159. The target rpm is increased or reduced by the specified factor proportionally to the drag error. It is recommended that you set the parameter to 4.

3.5 Readjustment

When P-0-0900 is set to the value 1, the drive performs a readjustment if it is pushed out of the positioning window after a run has been completed. If the loop length (S-0-0058) is not equal to 0, the drive will only readjust if it is pushed out of position in the direction of the loop. If the loop length = 0, the drive will readjust in both directions.

If a stop command is sent, the drive will only readjust when a new run command is sent. This function is only available for drives without brake.

3.6 Absolute measuring system

The PSx3xxSE actuator includes an absolute measuring system capable of covering a range of 256 rotations. In order to prevent an overrun if the drive is rotated by an external force when it is switched off, the drive can be positioned in a range of 250 rotations. The three lower and upper rotations of the measurement range are therefore blocked.



Removal of the supply voltage to the motor has no effect on the internal measurement system.

3.6.1 Positioning range (S-0-0278)

S-0-0278 is used to map the desired positioning range onto the physical range of the machine. In the delivery state, the drive is at position 51200, the upper limit switch is set to 101200 and the lower limit switch is set to 1200, yielding a positioning range of ± 125 rotations (± 50000 increments). If the desired positioning range does not exceed ± 125 rotations, none of the steps described below are required to set the range.

The following two options are available to allow you to realise any desired positioning run distances independently of the run distance set by the mounting orientation of the measurement system (physical positioning range):

1. Bring the axle to be moved (e.g. a spindle) into the desired position, run the drive to the appropriate position with the adjustable collar open and then close the adjustable collar.

Examples:

Bring the axle to be positioned into the mid-position, run the drive to the mid-position (position 51200) with the adjustable collar open, then close the adjustable collar. The drive can now run 125 rotations in both directions (default ± 50000 increments).

Bring the axle to be positioned all the way to the left (or bottom), run the drive without a loop to the smallest position (position 1200) and with the adjustable collar open, and then close the adjustable collar. The drive can now run 250 rotations to the right (or top) (default ±100000 increments).

Bring the axle to be positioned all the way to the right (or top), run the drive to the largest position (position 101200) with the adjustable collar open, then close the adjustable collar. The drive can now run 250 rotations to the left (or bottom) (default ±100000 increments).

2. Mount the drive in the required position on the axle, close the adjustable collar, then adjust the positioning range using S-0-0278. The parameter sets the upper end of the positioning range. Default setting: upper end at +256 rotations (position 102400). If, after mounting the drive, the positioning range does not match the currently displayed position, you can select the positioning range between +3 ...+253 rotations from the current position as required.

Examples:

After mounting the drive, the position 51200 is displayed (this corresponds to the delivery state). The positioning range should point exclusively to the right (or top) → +253 rotations:

$$\begin{aligned} \text{Positioning range} &= \text{actual position} + \text{scale} * \text{number of rotations} \\ \text{S-0-0278} &= \text{S-0-0051} + (400 * \text{S-0-0079} / \text{P-0-0079}) * \text{number of rotations} \\ 152400 &= 51200 + (400 * 400 / 400) * 253 \end{aligned}$$

After mounting the drive, position 100000 is displayed. However, the positioning range should point exclusively to the right (or top) → +253 rotations:

$$\begin{aligned} \text{Positioning range} &= \text{actual position} + \text{scale} * \text{number of rotations} \\ \text{S-0-0278} &= \text{S-0-0051} + (400 * \text{S-0-0079} / \text{P-0-0079}) * \text{number of rotations} \\ 201200 &= 100000 + (400 * 400 / 400) * 253 \end{aligned}$$

After mounting the drive, position 2000 is displayed. However, the positioning range should point exclusively to the left (or bottom) → +3 rotations:

$$\begin{aligned} \text{Positioning range} &= \text{actual position} + \text{scale} * \text{number of rotations} \\ \text{S-0-0278} &= \text{S-0-0051} + (400 * \text{S-0-0079} / \text{P-0-0079}) * \text{number of rotations} \\ 3200 &= 2000 + (400 * 400 / 400) * 3 \end{aligned}$$

The numbers of increments or position values indicated relate to the following settings, which correspond to the delivery state:

Referencing value (S-0-0175) = 0

Scale for the positional data (S-0-0079 and P-0-0079) = 400

When the positioning range (S-0-0278) is changed, the upper limit is set to the value (positioning range – 3 rotations * scale) and the lower limit to the value (positioning range – 253 rotations * scale). This gives a total positioning range of 250 rotations.

3.6.2 Scale for the positional data (S-0-0079 and P-0-0079)

These parameters influence the number of increments generated per rotation.

The scale can be calculated using the following formula:

$$\frac{\text{increments}}{\text{rotation}} = \frac{400 * S - 0 - 0079}{P - 0 - 0079}$$

The most advisable approach is to leave P-0-0079 at 400 and then set the increments/rotation using S-0-0079.

Examples:

The positional data should be scaled in degrees relating to the output shaft:
1 rotation = 360° → S-0-0079 = 360; P-0-0079 = 400

The drive is to be operated on a 4mm spindle with a resolution of 1/100 mm:
1 rotation = 4 mm= 400 increments → S-0-0079 = 400; P-0-0079 = 400

The drive is to be operated on a 4mm spindle with a resolution of 1/10 mm:
1 rotation = 4 mm= 40 increments → S-0-0079 = 400; P-0-0079 = 40

The drive is to be operated on a 2mm spindle with a resolution of 1/100 mm:
1 rotation = 2 mm= 200 increments → S-0-0079 = 200; P-0-0079 = 200

The drive is to count 138.23 increments per rotation:
1 rotation = 138.23 increments → S-0-0079 = 320; P-0-0079 = 926

When you change the scale for the positional data, the actual value, the referencing value, the positioning range, the upper and lower limits, the positioning window and the loop length are recalculated.

3.6.3 Direction of rotation (S-0-0055)

The direction of rotation allows you to specify in which direction the drive should rotate during runs to larger target values.

When looking at the output shaft, the following values are possible:

16: clockwise

23: counter clockwise

When you change the direction of rotation (S-0-0055), the referencing value (S-0-0175), the positioning range (S-0-0278) and the upper and lower limits (S-0-0049 and S-0-0050) are set to the delivery state.

3.6.4 Referencing (S-0-0175) and/or (S-0-0052)

Using the referencing value (S-0-0175) you can shift the whole range of values. There are two ways of setting the referencing value:

Directly – by writing the referencing value in S-0-0175.

Indirectly – by writing a position value in S-0-0052. This allows any actual value to be assigned to the current actual value. The resulting difference is then the referencing value (in S-0-0175). A change to the referencing value automatically shifts the actual value, positioning range and the upper and lower limits by the same value.

3.6.5 Setting parameters without automatic adjustment

If the user wants to avoid any automatic adjustment of values when setting the parameters for the drive, the optimum order for sending the parameters is as follows:

Direction of rotation (S-0-0055)

Scale for the positional data (S-0-0079)

Extended scale for the positional data (P-0-0079)

Referencing value (S-0-0175) and/or referencing of the position (S-0-0052)

Positioning range (S-0-0278)

Upper limit (S-0-0049)

Lower limit (S-0-0050)

Positioning window (S-0-0057)

Loop length (S-0-0058)

In order to save the settings permanently in the EEPROM, you must then use S-0-0264 (see Section 2.7.4).

4 Technical data

4.1 Ambient conditions

ambient temperature	0 °C to +45 °C		
storage temperature	-10 °C to +70 °C		
shock resistance according to DIN IEC 68-2-27	50 g 11 msec		
resistance to vibration according to DIN IEC 68-2-6	10 Hz to 55 Hz 1.5 mm 55 Hz to 1000 Hz 10 g 10 Hz to 2000 Hz 5 g		
EMC standards	CE		
conformity	CE declaration of conformity available upon request		
protection class	PSE		IP 54
	PSS		IP 65
	PSW		IP 66 (in operation) IP 68 (at standstill)
duty cycle	Device model	Duty cycle in %	Base time in sec.
	PSE34xx	20	300
	PSE30xx to 33xx	30	300
	PSS	20	600
	PSW	20	600

4.2 Electrical data

Nominal power output	PSx30xSE, PSx31xSE, PSE31xxSE	25 W with 30 % OT
	PSx32xSE, PSx33xSE	35 W with 30 % OT
	PSE34xxSE	100 W with 20 % OT
Supply voltage	24 VDC ±10 % (supply voltages for motor and control unit are galvanically separated) Recommendation: Use a regulated power adapter	
Nominal current, control unit	0.15 A	
Nominal current, motor	PSx30xSE, PSx31xSE, PSE31xxSE	2.2 A
	PSx32xSE, PSx33xSE	3.0 A
	PSE34xxSE	7.8 A
Positioning resolution	0,9°	
Positioning accuracy	0.9°	
Absolute value acquisition	Optical - magnetic	

4.3 Physical data

Positioning range	250 usable rotations, no mechanical limits measuring system has a span of 256 turns, minus 3 turns security stock at upper and lower range limit	
torsional rigidity (angle of rotation when switching from operation without backlash to maximum torque)	max. 0.2°	
gear backlash (without spindle compensation run)	max. 0.5°	
Spindle lash compensation	Automatic reference loop after every positioning run (may be activated or deactivated)	
Output shaft	PSE30xSE-8, PSE31xSE-8	8H9 hollow shaft with adjustable collar
	PSE30xSE-14, PSE31xSE-14, PSE32xSE, PSE33xSE	14H7 hollow shaft with adjustable collar
	PSE31xxSE, PSE34xxSE	14H7 hollow shaft with clamp and feather key
	PSS3xxSE-8 PSW3xxSE-8	8H9 hollow shaft with adj. collar or 8h8 solid shaft
	PSS3xxSE-14 PSW3xxSE-14	14H7 hollow shaft with adj. collar or 14h8 solid shaft
recommended diameter of the spindle head	according to the hollow shaft diameter with an interference fit of h9	
Maximum radial force	40 N	
Maximum axial force	20 N	
Dimensions (l x w x h)	see catalog data on our website	
Weight (approx.)	PSx30xSE-8	650 g
	PSx30xSE-14, PSx32xSE	1200 g
	PSx31xSE-8	700 g
	PSx31xSE-14, PSx33xSE	700 g
	PSE31xxSE	1200 g
	PSE34xxSE	1900 g

For additional specifications and dimension drawings, please visit our website at

<http://www.halstrup-walcher.de/en/produkte/positioniertechnik/positioniersysteme/index.php>



Die Lösung liegt im Detail

EG-Konformitätserklärung im Sinne der
EG- Richtlinie 2014/30/EU, EMV

Certificate of Conformity based on the
European Standard 2014/30/EU

Der Hersteller
The manufacturer

**halstrup-walcher GmbH
Stegener Straße 10
79199 Kirchzarten
Deutschland**

erklärt, dass die Bauart des Produktes
declares, that the construction of instrument type

Gerätebezeichnung PSE3xx, PSS3xx, PSW3xx
Device designation PSE3xx, PSS3xx, PSW3xx

entwickelt, konstruiert und gefertigt ist in Übereinstimmung mit den EG – Richtlinien
is developed, designed and manufactured in accordance with the EC Directives.

EN 61000-6-2 : 2005
EN 61000-6-4 : 2011

abgegeben durch / stated by:

Sura, Christian
(Nachname, Vorname / Surname, first name)

Geschäftsführer, Managing Director
(Stellung im Betrieb des Herstellers / Position)

Kirchzarten, 10. 10. 2016
(Ort, Datum / City, Date)


(Rechtsgültige Unterschrift/ Signature)

